



**EBERLINE**  
SERVICES

**EBERLINE ANALYTICAL CORPORATION**  
2030 Wright Avenue  
Richmond, California 94804-3849  
Phone (510) 235-2633 Fax (510) 235-0438  
Toll Free (800) 841-5487  
www.eberlineservices.com

May 2, 2008

Mr. Steve Trent  
Fluor Hanford Inc.  
1200 Jadwin Avenue  
Richland, WA 99352

Reference: **P.O. #33677**  
**Eberline Services R8-03-100-7063, SDG H3667**



Dear Mr. Trent:

Enclosed is the data report for three solid (soil) samples designated under SAF No. F08-043 received at Eberline Services on March 20, 2008. The samples were analyzed according to the accompanying chain-of-custody documents.

Please call if you have any questions concerning this report.

Sincerely,

*For* Melissa C. Mannion  
Senior Program Manager

NJV

Enclosure: Data Package

00000001

**1.0 GENERAL**

Fluor Hanford Inc. (FH) Sample Delivery Group H3667 was composed of three solid (soil) samples designated under SAF No. F08-043 with a Project Designation of: 216-A-30 Crib Sampling.

The samples were received as stated on the Chain-of-Custody documents. Any discrepancies are noted on the Eberline Services Sample Receipt Checklist.

**2.0 ANALYSIS NOTES**

**2.1 Tritium Analysis**

No problems were encountered during the course of the analyses.

**2.2 Nickel-63 Analysis**

No problems were encountered during the course of the analyses.

**2.3 Technetium-99 Analysis**


No problems were encountered during the course of the analyses.

**2.4 Isotopic Thorium Analysis**

No problems were encountered during the course of the analyses.

**3.0 Case Narrative Certification Statement**

**"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."**

*For*   
\_\_\_\_\_  
**Melissa C. Mannion**  
**Senior Program Manager**

*05/02/08*  
\_\_\_\_\_  
**Date**

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 33677  
Case no SDG\_H3666

S U M M A R Y   D A T A   S E C T I O N

| T A B L E   O F   C O N T E N T S |   |   |   |    |
|-----------------------------------|---|---|---|----|
| About this section                | . | . | . | 1  |
| Sample Summaries                  | . | . | . | 3  |
| Prep Batch Summary                | . | . | . | 5  |
| Work Summary                      | . | . | . | 6  |
| Method Blanks                     | . | . | . | 8  |
| Lab Control Samples               | . | . | . | 9  |
| Duplicates                        | . | . | . | 10 |
| Data Sheets                       | . | . | . | 11 |
| Method Summaries                  | . | . | . | 14 |
| Report Guides                     | . | . | . | 18 |
| End of Section                    | . | . | . | 32 |

  
Prepared by

  
Reviewed by

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-TOC  
Version 3.06  
Report date 05/02/08

00000003

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG H3666

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000004

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford  
Contract No. 33677  
Case no SDG H3666

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 2

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000005

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063

Contact Melissa C. Mannion

Client Hanford

Contract No. 33677

Case no SDG H3666

LAB SAMPLE SUMMARY

| LAB        |                        |                |        |       |         |             | CHAIN OF       |  |
|------------|------------------------|----------------|--------|-------|---------|-------------|----------------|--|
| SAMPLE ID  | CLIENT SAMPLE ID       | LOCATION       | MATRIX | LEVEL | SAF NO  | CUSTODY     | COLLECTED      |  |
| R803100-01 | B1TH01                 | C5941, I-001   | SOLID  |       | F08-043 | F08-043-146 | 03/04/08 13:50 |  |
| R803100-02 | B1TH02                 | C5941, I-002   | SOLID  |       | F08-043 | F08-043-147 | 03/05/08 10:20 |  |
| R803100-03 | B1TH29                 | C5941, I-002-D | SOLID  |       | F08-043 | F08-043-148 | 03/05/08 10:20 |  |
| R803100-04 | Lab Control Sample     |                | SOLID  |       | F08-043 |             |                |  |
| R803100-05 | Method Blank           |                | SOLID  |       | F08-043 |             |                |  |
| R803100-06 | Duplicate (R803100-02) | C5941, I-002   | SOLID  |       | F08-043 |             | 03/05/08 10:20 |  |

LAB SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LS  
 Version 3.06  
 Report date 05/02/08

00000006

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

**QC SUMMARY**

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

| QC BATCH | CHAIN OF CUSTODY | CLIENT SAMPLE ID       | MATRIX | % SOLIDS | SAMPLE AMOUNT | BASIS AMOUNT | DAYS SINCE RECEIVED | COLL | LAB SAMPLE ID | DEPARTMENT SAMPLE ID |
|----------|------------------|------------------------|--------|----------|---------------|--------------|---------------------|------|---------------|----------------------|
| 7063     | F08-043-146      | B1TH01                 | SOLID  | 94.8     | 147 g         |              | 03/20/08            | 16   | R803100-01    | 7063-001             |
|          | F08-043-147      | B1TH02                 | SOLID  | 91.5     | 151 g         |              | 03/20/08            | 15   | R803100-02    | 7063-002             |
|          | F08-043-148      | B1TH29                 | SOLID  | 91.6     | 160 g         |              | 03/20/08            | 15   | R803100-03    | 7063-003             |
|          |                  | Method Blank           | SOLID  |          |               |              |                     |      | R803100-05    | 7063-005             |
|          |                  | Lab Control Sample     | SOLID  |          |               |              |                     |      | R803100-04    | 7063-004             |
|          |                  | Duplicate (R803100-02) | SOLID  | 91.5     | 151 g         |              | 03/20/08            | 15   | R803100-06    | 7063-006             |

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-QS  
 Version 3.06  
 Report date 05/02/08

00000007

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

**PREP BATCH SUMMARY**

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

| TEST                                 | MATRIX | METHOD                      | PREPARATION ERROR |      | PLANCHETS ANALYZED |      |    |       | QUALI- |     |
|--------------------------------------|--------|-----------------------------|-------------------|------|--------------------|------|----|-------|--------|-----|
|                                      |        |                             | BATCH             | 2σ % | CLIENT             | MORE | RE | BLANK |        | LCS |
| <b>Alpha Spectroscopy</b>            |        |                             |                   |      |                    |      |    |       |        |     |
| TH                                   | SOLID  | Thorium, Isotopic in Solids | 6145-169          | 8.0  | 3                  |      |    | 1     | 1      | 1/1 |
| <b>Beta Counting</b>                 |        |                             |                   |      |                    |      |    |       |        |     |
| TC                                   | SOLID  | Technetium 99 in Solids     | 6145-169          | 13.2 | 3                  |      |    | 1     | 1      | 1/1 |
| <b>Liquid Scintillation Counting</b> |        |                             |                   |      |                    |      |    |       |        |     |
| H                                    | SOLID  | Tritium in Solids           | 6145-169          | 10.0 | 3                  |      |    | 1     | 1      | 1/1 |
| NI_L                                 | SOLID  | Nickel 63 in Solids         | 6145-169          | 11.2 | 3                  |      |    | 1     | 1      | 1/1 |

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.  
 Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-PBS  
 Version 3.06  
 Report date 05/02/08

00000008

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

**LAB WORK SUMMARY**

| LAB SAMPLE | CLIENT SAMPLE ID       |         |          |      | SUF- |          |          |    |                             |  |
|------------|------------------------|---------|----------|------|------|----------|----------|----|-----------------------------|--|
| COLLECTED  | LOCATION               | MATRIX  |          |      | FIX  | ANALYZED | REVIEWED | BY | METHOD                      |  |
| RECEIVED   | CUSTODY                | SAF No  | PLANCHET | TEST |      |          |          |    |                             |  |
| R803100-01 | B1TH01                 |         | 7063-001 | H    |      | 04/09/08 | 04/14/08 | BW | Tritium in Solids           |  |
| 03/04/08   | C5941, I-001           | SOLID   | 7063-001 | NI_L |      | 04/11/08 | 04/15/08 | BW | Nickel 63 in Solids         |  |
| 03/20/08   | F08-043-146            | F08-043 | 7063-001 | TC   |      | 04/14/08 | 04/16/08 | BW | Technetium 99 in Solids     |  |
|            |                        |         | 7063-001 | TH   |      | 04/18/08 | 04/21/08 | BW | Thorium, Isotopic in Solids |  |
| R803100-02 | B1TH02                 |         | 7063-002 | H    |      | 04/09/08 | 04/14/08 | BW | Tritium in Solids           |  |
| 03/05/08   | C5941, I-002           | SOLID   | 7063-002 | NI_L |      | 04/11/08 | 04/15/08 | BW | Nickel 63 in Solids         |  |
| 03/20/08   | F08-043-147            | F08-043 | 7063-002 | TC   |      | 04/14/08 | 04/16/08 | BW | Technetium 99 in Solids     |  |
|            |                        |         | 7063-002 | TH   |      | 04/18/08 | 04/21/08 | BW | Thorium, Isotopic in Solids |  |
| R803100-03 | B1TH29                 |         | 7063-003 | H    |      | 04/09/08 | 04/14/08 | BW | Tritium in Solids           |  |
| 03/05/08   | C5941, I-002-D         | SOLID   | 7063-003 | NI_L |      | 04/11/08 | 04/15/08 | BW | Nickel 63 in Solids         |  |
| 03/20/08   | F08-043-148            | F08-043 | 7063-003 | TC   |      | 04/14/08 | 04/16/08 | BW | Technetium 99 in Solids     |  |
|            |                        |         | 7063-003 | TH   |      | 04/18/08 | 04/21/08 | BW | Thorium, Isotopic in Solids |  |
| R803100-04 | Lab Control Sample     |         | 7063-004 | H    |      | 04/09/08 | 04/14/08 | BW | Tritium in Solids           |  |
|            |                        | SOLID   | 7063-004 | NI_L |      | 04/11/08 | 04/15/08 | BW | Nickel 63 in Solids         |  |
|            |                        | F08-043 | 7063-004 | TC   |      | 04/14/08 | 04/16/08 | BW | Technetium 99 in Solids     |  |
|            |                        |         | 7063-004 | TH   |      | 04/18/08 | 04/21/08 | BW | Thorium, Isotopic in Solids |  |
| R803100-05 | Method Blank           |         | 7063-005 | H    |      | 04/09/08 | 04/14/08 | BW | Tritium in Solids           |  |
|            |                        | SOLID   | 7063-005 | NI_L |      | 04/11/08 | 04/15/08 | BW | Nickel 63 in Solids         |  |
|            |                        | F08-043 | 7063-005 | TC   |      | 04/15/08 | 04/16/08 | BW | Technetium 99 in Solids     |  |
|            |                        |         | 7063-005 | TH   |      | 04/18/08 | 04/21/08 | BW | Thorium, Isotopic in Solids |  |
| R803100-06 | Duplicate (R803100-02) |         | 7063-006 | H    |      | 04/09/08 | 04/14/08 | BW | Tritium in Solids           |  |
| 03/05/08   | C5941, I-002           | SOLID   | 7063-006 | NI_L |      | 04/11/08 | 04/15/08 | BW | Nickel 63 in Solids         |  |
| 03/20/08   |                        | F08-043 | 7063-006 | TC   |      | 04/14/08 | 04/16/08 | BW | Technetium 99 in Solids     |  |
|            |                        |         | 7063-006 | TH   |      | 04/18/08 | 04/21/08 | BW | Thorium, Isotopic in Solids |  |

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LWS  
 Version 3.06  
 Report date 05/02/08

00000009

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

**WORK SUMMARY, cont.**

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

**COUNTS OF TESTS BY SAMPLE TYPE**

| TEST          | SAF No  | METHOD                      | REFERENCE          | CLIENT | MORE | RE | BLANK | LCS | DUP SPIKE | TOTAL |
|---------------|---------|-----------------------------|--------------------|--------|------|----|-------|-----|-----------|-------|
| H             | F08-043 | Tritium in Solids           | TRITIUM_COX_LSC    | 3      |      |    | 1     | 1   | 1         | 6     |
| NI_L          | F08-043 | Nickel 63 in Solids         | NI63_LSC           | 3      |      |    | 1     | 1   | 1         | 6     |
| TC            | F08-043 | Technetium 99 in Solids     | TC99_TR_SEP_GPC    | 3      |      |    | 1     | 1   | 1         | 6     |
| TH            | F08-043 | Thorium, Isotopic in Solids | THISO_IE_PLATE_AEA | 3      |      |    | 1     | 1   | 1         | 6     |
| <b>TOTALS</b> |         |                             |                    | 12     |      |    | 4     | 4   | 4         | 24    |

WORK SUMMARY

Page 2

SUMMARY DATA SECTION

Page 7

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LWS  
 Version 3.06  
 Report date 05/02/08

00000010

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H3667**

7063-005

Method Blank

**METHOD BLANK**

|                                   |                                      |                  |
|-----------------------------------|--------------------------------------|------------------|
| SDG <u>7063</u>                   | Client/Case no <u>Hanford</u>        | <u>SDG_H3666</u> |
| Contact <u>Melissa C. Mannion</u> | Contract No. <u>33677</u>            |                  |
| Lab sample id <u>R803100-05</u>   | Client sample id <u>Method Blank</u> |                  |
| Dept sample id <u>7063-005</u>    | Material/Matrix <u>SOLID</u>         |                  |
|                                   | SAF No <u>F08-043</u>                |                  |

| ANALYTE       | CAS NO     | RESULT<br>pCi/g | 2σ ERR<br>(COUNT) | MDA<br>pCi/g | RDL<br>pCi/g | QUALI-<br>FIERS | TEST |
|---------------|------------|-----------------|-------------------|--------------|--------------|-----------------|------|
| Tritium       | 10028-17-8 | 2.60            | 3.4               | 5.56         | 400          | U               | H    |
| Nickel 63     | 13981-37-8 | 0.661           | 1.5               | 2.48         | 30.0         | U               | NI_L |
| Technetium 99 | 14133-76-7 | -0.170          | 0.18              | 0.664        | 12.0         | U               | TC   |
| Thorium 228   | 14274-82-9 | 0.021           | 0.071             | 0.131        | 1.00         | U               | TH   |
| Thorium 230   | 14269-63-7 | 0.156           | 0.13              | 0.227        | 1.00         | U               | TH   |
| Thorium 232   | TH-232     | -0.028          | 0.028             | 0.078        | 1.00         | U               | TH   |

216-A-30 Crib Sampling

|                 |
|-----------------|
| QC-BLANK #65173 |
|-----------------|

|                             |
|-----------------------------|
| Lab id <u>EBRLNE</u>        |
| Protocol <u>Fluor</u>       |
| Version <u>Ver 1.0</u>      |
| Form <u>DVD-DS</u>          |
| Version <u>3.06</u>         |
| Report date <u>05/02/08</u> |

00000011



**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

7063-006

B1TH02

**DUPLICATE**

|                                   |                                 |   |          |                  |  |
|-----------------------------------|---------------------------------|---|----------|------------------|--|
| SDG <u>7063</u>                   |                                 | Client/Case no <u>Hanford</u>                       |          | SDG <u>H3666</u> |  |
| Contact <u>Melissa C. Mannion</u> |                                 | Contract No. <u>33677</u>                           |          |                  |  |
| DUPLICATE                         |                                 |   | ORIGINAL |                  |  |
| Lab sample id <u>R803100-06</u>   | Lab sample id <u>R803100-02</u> | Client sample id <u>B1TH02</u>                      |          |                  |  |
| Dept sample id <u>7063-006</u>    | Dept sample id <u>7063-002</u>  | Location/Matrix <u>C5941, I-002</u> SOLID           |          |                  |  |
|                                   | Received <u>03/20/08</u>        | Collected/Weight <u>03/05/08 10:20</u> <u>151 g</u> |          |                  |  |
| % solids <u>91.5</u>              | % solids <u>91.5</u>            | Custody/SAF No <u>F08-043-147</u> <u>F08-043</u>    |          |                  |  |

| ANALYTE       | DUPLICATE<br>pCi/g | 2σ ERR<br>(COUNT) | MDA<br>pCi/g | RDL<br>pCi/g | QUALI-<br>FIERS | TEST | ORIGINAL<br>pCi/g | 2σ ERR<br>(COUNT) | MDA<br>pCi/g | QUALI-<br>FIERS | RPD<br>% | 3σ<br>TOT | DER<br>σ |
|---------------|--------------------|-------------------|--------------|--------------|-----------------|------|-------------------|-------------------|--------------|-----------------|----------|-----------|----------|
| Tritium       | 0.874              | 2.7               | 4.59         | 400          | U               | H    | -0.615            | 2.7               | 4.66         | U               | -        |           | 0.8      |
| Nickel 63     | -0.461             | 1.8               | 3.12         | 30.0         | U               | NI_L | -0.987            | 1.8               | 3.18         | U               | -        |           | 0.4      |
| Technetium 99 | 0.071              | 0.30              | 0.885        | 12.0         | U               | TC   | 0.030             | 0.19              | 0.606        | U               | -        |           | 0.2      |
| Thorium 228   | 0.880              | 0.17              | 0.126        | 1.00         |                 | TH   | 0.806             | 0.16              | 0.152        |                 | 9        | 45        | 0.6      |
| Thorium 230   | 1.04               | 0.19              | 0.209        | 1.00         |                 | TH   | 1.05              | 0.20              | 0.201        |                 | 1        | 43        | 0.1      |
| Thorium 232   | 1.08               | 0.17              | 0.071        | 1.00         |                 | TH   | 0.818             | 0.15              | 0.059        |                 | 28       | 40        | 2.1      |

216-A-30 Crib Sampling

QC-DUP#2 65174

|                             |
|-----------------------------|
| Lab id <u>EBRLNE</u>        |
| Protocol <u>Fluor</u>       |
| Version <u>Ver 1.0</u>      |
| Form <u>DVD-DUP</u>         |
| Version <u>3.06</u>         |
| Report date <u>05/02/08</u> |

00000013

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H3667**

7063-001

B1TH01

**D A T A   S H E E T**

|                                   |  |                  |
|-----------------------------------|--|------------------|
| SDG <u>7063</u>                   | Client/Case no <u>Hanford</u>          | SDG <u>H3666</u> |
| Contact <u>Melissa C. Mannion</u> | Contract No. <u>33677</u>              |                  |
| Lab sample id <u>R803100-01</u>   | Client sample id <u>B1TH01</u>         |                  |
| Dept sample id <u>7063-001</u>    | Location/Matrix <u>C5941, I-001</u>    | <u>SOLID</u>     |
| Received <u>03/20/08</u>          | Collected/Weight <u>03/04/08 13:50</u> | <u>147 g</u>     |
| % solids <u>94.8</u>              | Custody/SAF No <u>F08-043-146</u>      | <u>F08-043</u>   |

| ANALYTE       | CAS NO     | RESULT<br>pCi/g | 2σ ERR<br>(COUNT) | MDA<br>pCi/g | RDL<br>pCi/g | QUALI-<br>FIERS | TEST |
|---------------|------------|-----------------|-------------------|--------------|--------------|-----------------|------|
| Tritium       | 10028-17-8 | -0.211          | 2.8               | 4.79         | 400          | U               | H    |
| Nickel 63     | 13981-37-8 | 1.05            | 1.6               | 2.63         | 30.0         | U               | NI_L |
| Technetium 99 | 14133-76-7 | -0.037          | 0.19              | 0.642        | 12.0         | U               | TC   |
| Thorium 228   | 14274-82-9 | 0.852           | 0.16              | 0.154        | 1.00         |                 | TH   |
| Thorium 230   | 14269-63-7 | 0.952           | 0.18              | 0.200        | 1.00         |                 | TH   |
| Thorium 232   | TH-232     | 0.907           | 0.15              | 0.076        | 1.00         |                 | TH   |

216-A-30 Crib Sampling

**DATA SHEETS**

Page 1

**SUMMARY DATA SECTION**

Page 11

|                             |
|-----------------------------|
| Lab id <u>EBRLNE</u>        |
| Protocol <u>Fluor</u>       |
| Version <u>Ver 1.0</u>      |
| Form <u>DVD-DS</u>          |
| Version <u>3.06</u>         |
| Report date <u>05/02/08</u> |

00000014

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H3667

7063-002

B1TH02

DATA SHEET

|                                   |  |                  |
|-----------------------------------|--|------------------|
| SDG <u>7063</u>                   | Client/Case no <u>Hanford</u>          | SDG <u>H3666</u> |
| Contact <u>Melissa C. Mannion</u> | Contract <u>No. 33677</u>              |                  |
| Lab sample id <u>R803100-02</u>   | Client sample id <u>B1TH02</u>         |                  |
| Dept sample id <u>7063-002</u>    | Location/Matrix <u>C5941, I-002</u>    | <u>SOLID</u>     |
| Received <u>03/20/08</u>          | Collected/Weight <u>03/05/08 10:20</u> | <u>151 g</u>     |
| % solids <u>91.5</u>              | Custody/SAF No <u>F08-043-147</u>      | <u>F08-043</u>   |

| ANALYTE       | CAS NO     | RESULT<br>pCi/g | 2σ ERR<br>(COUNT) | MDA<br>pCi/g | RDL<br>pCi/g | QUALI-<br>FIERS | TEST |
|---------------|------------|-----------------|-------------------|--------------|--------------|-----------------|------|
| Tritium       | 10028-17-8 | -0.615          | 2.7               | 4.66         | 400          | U               | H    |
| Nickel 63     | 13981-37-8 | -0.987          | 1.8               | 3.18         | 30.0         | U               | NI_L |
| Technetium 99 | 14133-76-7 | 0.030           | 0.19              | 0.606        | 12.0         | U               | TC   |
| Thorium 228   | 14274-82-9 | 0.806           | 0.16              | 0.152        | 1.00         |                 | TH   |
| Thorium 230   | 14269-63-7 | 1.05            | 0.20              | 0.201        | 1.00         |                 | TH   |
| Thorium 232   | TH-232     | 0.818           | 0.15              | 0.059        | 1.00         |                 | TH   |

216-A-30 Crib Sampling

|                             |
|-----------------------------|
| Lab id <u>EBRLNE</u>        |
| Protocol <u>Fluor</u>       |
| Version <u>Ver 1.0</u>      |
| Form <u>DVD-DS</u>          |
| Version <u>3.06</u>         |
| Report date <u>05/02/08</u> |

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H3667

7063-003

B1TH29

DATA SHEET

|                                   |  |                  |
|-----------------------------------|--|------------------|
| SDG <u>7063</u>                   | Client/Case no <u>Hanford</u>          | SDG <u>H3666</u> |
| Contact <u>Melissa C. Mannion</u> | Contract No. <u>33677</u>              |                  |
| Lab sample id <u>R803100-03</u>   | Client sample id <u>B1TH29</u>         |                  |
| Dept sample id <u>7063-003</u>    | Location/Matrix <u>C5941, I-002-D</u>  | <u>SOLID</u>     |
| Received <u>03/20/08</u>          | Collected/Weight <u>03/05/08 10:20</u> | <u>160 g</u>     |
| % solids <u>91.6</u>              | Custody/SAF No <u>F08-043-148</u>      | <u>F08-043</u>   |

| ANALYTE       | CAS NO     | RESULT<br>pCi/g | 2σ ERR<br>(COUNT) | MDA<br>pCi/g | RDL<br>pCi/g | QUALI-<br>FIERS | TEST |
|---------------|------------|-----------------|-------------------|--------------|--------------|-----------------|------|
| Tritium       | 10028-17-8 | -1.86           | 2.5               | 4.55         | 400          | U               | H    |
| Nickel 63     | 13981-37-8 | -0.308          | 1.7               | 2.97         | 30.0         | U               | NI_L |
| Technetium 99 | 14133-76-7 | -0.040          | 0.17              | 0.578        | 12.0         | U               | TC   |
| Thorium 228   | 14274-82-9 | 1.02            | 0.17              | 0.079        | 1.00         |                 | TH   |
| Thorium 230   | 14269-63-7 | 1.02            | 0.19              | 0.212        | 1.00         |                 | TH   |
| Thorium 232   | TH-232     | 1.10            | 0.17              | 0.079        | 1.00         |                 | TH   |

216-A-30 Crib Sampling

DATA SHEETS

Page 3

SUMMARY DATA SECTION

Page 13

|                             |
|-----------------------------|
| Lab id <u>EBRLNE</u>        |
| Protocol <u>Fluor</u>       |
| Version <u>Ver 1.0</u>      |
| Form <u>DVD-DS</u>          |
| Version <u>3.06</u>         |
| Report date <u>05/02/08</u> |

00000016

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

Test TH Matrix SOLID  
SDG 7063  
Contact Melissa C. Mannion

**LAB METHOD SUMMARY**

THORIUM, ISOTOPIC IN SOLIDS  
ALPHA SPECTROSCOPY

Client Hanford  
Contract No. 33677  
Contract SDG H3666

**RESULTS**

LAB RAW SUP-  
SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Thorium 230

Preparation batch 6145-169

|            |          |                        |       |
|------------|----------|------------------------|-------|
| R803100-01 | 7063-001 | B1TH01                 | 0.952 |
| R803100-02 | 7063-002 | B1TH02                 | 1.05  |
| R803100-03 | 7063-003 | B1TH29                 | 1.02  |
| R803100-04 | 7063-004 | Lab Control Sample     | ok    |
| R803100-05 | 7063-005 | Method Blank           | U     |
| R803100-06 | 7063-006 | Duplicate (R803100-02) | ok    |

Nominal values and limits from method RDLs (pCi/g) 1.00  
216-A-30 Crib Sampling

**METHOD PERFORMANCE**

LAB RAW SUP- MAX MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-  
SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/g g FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6145-169 2σ prep error 8.0 % Reference Lab Notebook #6145, pg. 169

|            |                        |       |       |    |     |    |          |       |        |
|------------|------------------------|-------|-------|----|-----|----|----------|-------|--------|
| R803100-01 | B1TH01                 | 0.200 | 0.250 | 93 | 871 | 45 | 04/18/08 | 04/18 | SS-055 |
| R803100-02 | B1TH02                 | 0.201 | 0.250 | 90 | 871 | 44 | 04/18/08 | 04/18 | SS-061 |
| R803100-03 | B1TH29                 | 0.212 | 0.250 | 93 | 872 | 44 | 04/18/08 | 04/18 | SS-064 |
| R803100-04 | Lab Control Sample     | 0.220 | 0.250 | 93 | 873 |    | 04/18/08 | 04/18 | SS-065 |
| R803100-05 | Method Blank           | 0.227 | 0.250 | 91 | 874 |    | 04/18/08 | 04/18 | SS-031 |
| R803100-06 | Duplicate (R803100-02) | 0.209 | 0.250 | 93 | 874 | 44 | 04/18/08 | 04/18 | SS-033 |

Nominal values and limits from method 1.00 0.250 20-105 150 180

|            |           |  |
|------------|-----------|--|
| PROCEDURES | REFERENCE | THISO_IE_PLATE_AEA   |
|            | SPP-071   | Soil Dissolution, > 1.0g Aliquot, rev 5  |
|            | CP-900    | Thorium in Water and Dissolved Solid Samples by Extraction Chromatography, rev 1 |
|            | CP-008    | Heavy Element Electroplating, rev 9  |

|                 |       |               |
|-----------------|-------|---------------|
| AVERAGES ± 2 SD | MDA   | 0.212 ± 0.021 |
| FOR 6 SAMPLES   | YIELD | 92 ± 3        |

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 14

Lab id EBRINE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-LMS  
Version 3.06  
Report date 05/02/08

00000017

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

Test TC Matrix SOLID  
 SDG 7063  
 Contact Melissa C. Mannion

**LAB METHOD SUMMARY**

TECHNETIUM 99 IN SOLIDS

BETA COUNTING

Client Hanford  
 Contract No. 33677  
 Contract SDG H3666

**RESULTS**

| LAB                        | RAW      | SUF-     |                        |           | Technetium |
|----------------------------|----------|----------|------------------------|-----------|------------|
| SAMPLE ID                  | TEST FIX | PLANCHET | CLIENT                 | SAMPLE ID | 99         |
| Preparation batch 6145-169 |          |          |                        |           |            |
| R803100-01                 |          | 7063-001 | B1TH01                 |           | U          |
| R803100-02                 |          | 7063-002 | B1TH02                 |           | U          |
| R803100-03                 |          | 7063-003 | B1TH29                 |           | U          |
| R803100-04                 |          | 7063-004 | Lab Control Sample     |           | ok         |
| R803100-05                 |          | 7063-005 | Method Blank           |           | U          |
| R803100-06                 |          | 7063-006 | Duplicate (R803100-02) |           | - U        |

Nominal values and limits from method RDLs (pCi/g) 12.0  
 216-A-30 Crib Sampling

**METHOD PERFORMANCE**

| LAB   | RAW      | SUF-                   | MDA   | ALIQ | PREP | DILU- | YIELD | EFF | COUNT | FWHM | DRIFT | DAYS | ANAL-    |       |          |
|---|----------|------------------------|-------|------|------|-------|-------|-----|-------|------|-------|------|----------|-------|----------|
| SAMPLE ID   | TEST FIX | CLIENT                 | pCi/g | g    | FAC  | TION  | %     | %   | min   | keV  | KeV   | HELD | PREPARED | YZED  | DETECTOR |
| Preparation batch 6145-169 2σ prep error 13.2 % Reference Lab Notebook #6145, pg. 169 |          |                        |       |      |      |       |       |     |       |      |       |      |          |       |          |
| R803100-01  |          | B1TH01                 | 0.642 | 1.00 |      |       | 84    |     | 50    |      |       | 41   | 04/10/08 | 04/14 | GRB-221  |
| R803100-02  |          | B1TH02                 | 0.606 | 1.00 |      |       | 86    |     | 50    |      |       | 40   | 04/10/08 | 04/14 | GRB-222  |
| R803100-03  |          | B1TH29                 | 0.578 | 1.00 |      |       | 91    |     | 50    |      |       | 40   | 04/10/08 | 04/14 | GRB-223  |
| R803100-04  |          | Lab Control Sample     | 0.522 | 1.00 |      |       | 99    |     | 50    |      |       |      | 04/10/08 | 04/14 | GRB-224  |
| R803100-05  |          | Method Blank           | 0.664 | 1.00 |      |       | 81    |     | 50    |      |       |      | 04/10/08 | 04/15 | GRB-232  |
| R803100-06  |          | Duplicate (R803100-02) | 0.885 | 1.00 |      |       | 75    |     | 50    |      |       | 40   | 04/10/08 | 04/14 | GRB-226  |

Nominal values and limits from method 12.0 1.00 20-105 50 180

PROCEDURES REFERENCE TC99\_TR\_SEP\_GPC  
 SPP-062 Sample Aliquoting, rev 0  
 CP-431 Technetium-99 Purification of Soil or Resin by  
 Extraction Chromatography, rev 2  
 CP-008 Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD MDA 0.650 ± 0.251  
 FOR 6 SAMPLES YIELD 86 ± 17

METHOD SUMMARIES

Page 2

SUMMARY DATA SECTION

Page 15

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LMS  
 Version 3.06  
 Report date 05/02/08

00000018

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

Test H Matrix SOLID  
 SDG 7063  
 Contact Melissa C. Mannion

**LAB METHOD SUMMARY**

TRITIUM IN SOLIDS

LIQUID SCINTILLATION COUNTING

Client Hanford  
 Contract No. 33677  
 Contract SDG H3666

**RESULTS**

| LAB                        | RAW      | SUF-     |                        |         |
|----------------------------|----------|----------|------------------------|---------|
| SAMPLE ID                  | TEST FIX | PLANCHET | CLIENT SAMPLE ID       | Tritium |
| Preparation batch 6145-169 |          |          |                        |         |
| R803100-01                 |          | 7063-001 | B1TH01                 | U       |
| R803100-02                 |          | 7063-002 | B1TH02                 | U       |
| R803100-03                 |          | 7063-003 | B1TH29                 | U       |
| R803100-04                 |          | 7063-004 | Lab Control Sample     | ok      |
| R803100-05                 |          | 7063-005 | Method Blank           | U       |
| R803100-06                 |          | 7063-006 | Duplicate (R803100-02) | - U     |

Nominal values and limits from method RDLs (pCi/g) 400  
 216-A-30 Crib Sampling

**METHOD PERFORMANCE**

| LAB   | RAW      | SUF-                   | MDA   | ALIQ  | PREP | DILU- | YIELD | EFF | COUNT     | FWHM | DRIFT | DAYS           | ANAL-         |
|---|----------|------------------------|-------|-------|------|-------|-------|-----|-----------|------|-------|----------------|---------------|
| SAMPLE ID   | TEST FIX | CLIENT SAMPLE ID       | pCi/g | g     | FAC  | TION  | %     | %   | min       | keV  | KeV   | HELD PREPARED  | YZED DETECTOR |
| Preparation batch 6145-169 2σ prep error 10.0 % Reference Lab Notebook #6145, pg. 169 |          |                        |       |       |      |       |       |     |           |      |       |                |               |
| R803100-01  |          | B1TH01                 | 4.79  | 0.353 |      |       | 100   |     | 50        |      | 36    | 04/08/08 04/09 | LSC-007       |
| R803100-02  |          | B1TH02                 | 4.66  | 0.364 |      |       | 100   |     | 50        |      | 35    | 04/08/08 04/09 | LSC-007       |
| R803100-03  |          | B1TH29                 | 4.55  | 0.366 |      |       | 100   |     | 50        |      | 35    | 04/08/08 04/09 | LSC-007       |
| R803100-04  |          | Lab Control Sample     | 9.62  | 0.300 |      |       | 100   |     | <u>18</u> |      |       | 04/08/08 04/09 | LSC-007       |
| R803100-05  |          | Method Blank           | 5.56  | 0.300 |      |       | 100   |     | 50        |      |       | 04/08/08 04/09 | LSC-007       |
| R803100-06  |          | Duplicate (R803100-02) | 4.59  | 0.364 |      |       | 100   |     | 50        |      | 35    | 04/08/08 04/09 | LSC-007       |

Nominal values and limits from method 400 0.300 25 180

PROCEDURES REFERENCE TRITIUM\_COX\_LSC  
 CP-251 Tritium/Carbon-14 Oxidation, rev 8

AVERAGES ± 2 SD MDA 5.63 ± 3.98  
 FOR 6 SAMPLES YIELD 100 ± 0

METHOD SUMMARIES

Page 3

SUMMARY DATA SECTION

Page 16

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LMS  
 Version 3.06  
 Report date 05/02/08

00000019

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3667

Test NI L Matrix SOLID  
 SDG 7063  
 Contact Melissa C. Mannion

**LAB METHOD SUMMARY**

NICKEL 63 IN SOLIDS

LIQUID SCINTILLATION COUNTING

Client Hanford  
 Contract No. 33677  
 Contract SDG H3666

**RESULTS**

LAB RAW SUF-  
 SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Nickel 63

Preparation batch 6145-169

|            |  |          |                        |     |
|------------|--|----------|------------------------|-----|
| R803100-01 |  | 7063-001 | B1TH01                 | U   |
| R803100-02 |  | 7063-002 | B1TH02                 | U   |
| R803100-03 |  | 7063-003 | B1TH29                 | U   |
| R803100-04 |  | 7063-004 | Lab Control Sample     | ok  |
| R803100-05 |  | 7063-005 | Method Blank           | U   |
| R803100-06 |  | 7063-006 | Duplicate (R803100-02) | - U |

Nominal values and limits from method RDLs (pCi/g) 30.0  
 216-A-30 Crib Sampling

**METHOD PERFORMANCE**

LAB RAW SUF- MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-  
 SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/g g FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6145-169 2σ prep error 11.2 % Reference Lab Notebook #6145, pg. 169

|            |  |                        |      |       |  |  |  |    |    |  |    |          |       |         |
|------------|--|------------------------|------|-------|--|--|--|----|----|--|----|----------|-------|---------|
| R803100-01 |  | B1TH01                 | 2.63 | 0.500 |  |  |  | 90 | 50 |  | 38 | 04/11/08 | 04/11 | LSC-005 |
| R803100-02 |  | B1TH02                 | 3.18 | 0.500 |  |  |  | 74 | 50 |  | 37 | 04/11/08 | 04/11 | LSC-005 |
| R803100-03 |  | B1TH29                 | 2.97 | 0.500 |  |  |  | 81 | 50 |  | 37 | 04/11/08 | 04/11 | LSC-005 |
| R803100-04 |  | Lab Control Sample     | 2.48 | 0.500 |  |  |  | 96 | 50 |  |    | 04/11/08 | 04/11 | LSC-005 |
| R803100-05 |  | Method Blank           | 2.48 | 0.500 |  |  |  | 96 | 50 |  |    | 04/11/08 | 04/11 | LSC-005 |
| R803100-06 |  | Duplicate (R803100-02) | 3.12 | 0.500 |  |  |  | 76 | 50 |  | 37 | 04/11/08 | 04/11 | LSC-005 |

Nominal values and limits from method 30.0 0.500 30-105 25 180

PROCEDURES REFERENCE NI63\_LSC  
 SPP-070 Soil Dissolution, < 1.0g Aliquot, rev 7  
 CP-280 Nickel-63 Purification, rev 3

AVERAGES ± 2 SD MDA 2.81 ± 0.638  
 FOR 6 SAMPLES YIELD 86 ± 20

METHOD SUMMARIES

Page 4

SUMMARY DATA SECTION

Page 17

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LMS  
 Version 3.06  
 Report date 05/02/08

00000020

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG H3666

SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- \* LAB SAMPLE ID is the lab's primary identification for a sample.
- \* DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- \* CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- \* QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- \* All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 18

Lab id EBRINE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000021

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 33677

Case no SDG\_H3666

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- \* The preparation batches are shown in the same order as the Method Summary Reports are printed.
- \* Only analyses of planchets relevant to the SDG are included.
- \* Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- \* The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 19

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000022

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG H3666

WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- \* TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- \* SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- \* The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- \* PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- \* For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- \* The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

**EBERLINE SERVICES / RICHMOND**

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

**REPORT GUIDE**

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

**DATA SHEET**

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- \* TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- \* The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- \* ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- \* A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- \* When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

- U The RESULT is less than the MDA (Minimum Detectable Activity).

**REPORT GUIDES**

Page 4

**SUMMARY DATA SECTION**

Page 21

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 05/02/08

00000024

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

GUIDE, cont.

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
  - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
  - H Similar to 'L' except the recovery was high.
  - P The RESULT is 'preliminary'.
  - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
  - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- \* An MDA is underlined if it is bigger than its RDL.

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 05/02/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063

Contact Melissa C. Mannion

Client Hanford

Contract No. 33677

Case no SDG H3666

GUIDE, cont.

DATA SHEET

- \* An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- \* A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- \* When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

REPORT GUIDES

Page 6

SUMMARY DATA SECTION

Page 23

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 05/02/08

00000026

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG\_H3666

LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- \* An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- \* The first, computed limits for the recovery reflect:
  1. The error of RESULT, including that introduced by rounding the result prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.
  3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- \* The second limits are protocol defined upper and lower QC limits for the recovery.
  - \* The recovery is underlined if it is outside either of these ranges.

REPORT GUIDES

Page 7

SUMMARY DATA SECTION

Page 24

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 05/02/08

00000027

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG H3666

DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- \* The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- \* The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

REPORT GUIDES

Page 8

SUMMARY DATA SECTION

Page 25

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000028

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 33677  
Case no SDG H3666

DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- \* The RPD is underlined if it is greater than either limit.
- \* If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- \* The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

REPORT GUIDES

Page 9

SUMMARY DATA SECTION

Page 26

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000029

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 33677  
Case no SDG H3666

REPORT GUIDE

MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- \* The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- \* The second limits are protocol defined upper and lower QC limits

REPORT GUIDES

Page 10

SUMMARY DATA SECTION

Page 27

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000030

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford  
Contract No. 33677  
Case no SDG H3666

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- \* The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 28

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000031

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG\_H3666

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- \* Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- \* The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- \* If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- \* Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- \* Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

REPORT GUIDES

Page 12

SUMMARY DATA SECTION

Page 29

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 05/02/08

00000032

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
 Contract No. 33677  
 Case no SDG\_H3666

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- \* Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- \* If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- \* Aliquots are underlined if less than the nominal value specified for the method.
- \* Preparation factors are underlined if greater than the nominal value specified for the method.
- \* Dilution factors are underlined if greater than the nominal value specified for the method.
- \* Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- \* Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- \* Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

REPORT GUIDES

Page 13

SUMMARY DATA SECTION

Page 30

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 05/02/08

00000033

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063  
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
 Contract No. 33677  
 Case no SDG H3666

METHOD SUMMARY

- \* Count times are underlined if less than the nominal value specified for the method.
- \* Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- \* Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- \* Days Held are underlined if greater than the holding time specified in the protocol.
- \* Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

REPORT GUIDES

Page 14

SUMMARY DATA SECTION

Page 31

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 05/02/08

00000034

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3667

SDG 7063

Contact Melissa C. Mannion

Client Hanford

Contract No. 33677

Case no SDG H3666

GUIDE, cont.

METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

REPORT GUIDES

Page 15

SUMMARY DATA SECTION

Page 32

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 05/02/08

00000035





COLLECTOR

NCO Sampler

*POPE*

COMPANY CONTACT

TRENT, SJ

TELEPHONE NO.

373-5869

PROJECT COORDINATOR

WIDRIG, DL

PRICE CODE

8N

DATA TURNAROUND

45 Days / 45 Days

SAMPLING LOCATION

C5941, I-002-D

PROJECT DESIGNATION

216-A-30 Crib Sampling

*H3667 (7063)*

SAF NO.

F08-043

AIR QUALITY

ICE CHEST NO.

*SOIL 442*

FIELD LOGBOOK NO.

ACTUAL SAMPLE DEPTH

*4.8' - 7.3'*

COA

123215ES20

METHOD OF SHIPMENT

FEDERAL EXPRESS

SHIPPED TO

Eberline Services

OFFSITE PROPERTY NO.

SEE PTR

BILL OF LADING/AIR BILL NO.

SEE PTR

*7907 6974 5614*

MATRIX\*

A=Air  
DL=Drum  
Liquids  
DS=Drum  
Solids  
L=Liquid  
O=Oil  
S=Soil  
SE=Sediment  
T=Tissue  
V=Vegetation  
W=Water  
WI=Wipe  
X=Other

POSSIBLE SAMPLE HAZARDS/ REMARKS

Contains Radioactive Material at concentrations that are not regulated for transportation per 49 CFR but are not releasable per DOE Order 5400.5 (1990/1993)

SPECIAL HANDLING AND/OR STORAGE

Radioactive tie to B1TDDBS

PRESERVATION

None

TYPE OF CONTAINER

G/P

NO. OF CONTAINER(S)

1

VOLUME

120mL

SAMPLE ANALYSIS

SEE ITEM (1) IN SPECIAL INSTRUCTIONS

SAMPLE NO.

MATRIX\*

SAMPLE DATE

SAMPLE TIME

~~B1TH09~~ *B1TH29*

SOIL

*3-5-08 1020*

*X*

*Lot # 024825*

CHAIN OF POSSESSION

SIGN/ PRINT NAMES

SPECIAL INSTRUCTIONS

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

*J Pope 3-5-08 1152*

*Site Room Fluor 3-5-08 1152*

\*\* The 200 Area S&GRP Characterization and Monitoring Sampling and Analysis GKI applies to this SAF.  
(1) Tritium - H3; Technetium-99 {Technetium-99} Nickel-63; Isotopic Thorium {Thorium-232}

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

*MOSOR F12145 3/17/08 1230*

*Kevin Patterson Fluor Hanford 3/17/08 1230*

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

*Kevin Patterson Fluor Hanford 3/17/08 1500*

*MOSOR-REF#1 3/17/08 1500*

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

*MOSOR R2A#1 3-19-08 1000*

*Fluor Hanford 3-19-08*

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

*Fluor Hanford 3-19-08*

*Feel Ex*

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

LABORATORY SECTION

RECEIVED BY

TITLE

DATE/TIME

FINAL SAMPLE DISPOSITION

DISPOSAL METHOD

DISPOSED BY

DATE/TIME

|   |  |   |   |  |                                       |   |             |
|---|--|---|---|--|---------------------------------------|---|-------------|
| Fluor Hanford Inc.  |  | CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST        |   |  |                                       | F08-043-155                             | PAGE 1 OF 1 |
| COLLECTOR<br>NCO Sampler <i>Pope</i>  | COMPANY CONTACT<br>TRENT, SJ   | TELEPHONE NO.<br>373-5869                       | PROJECT COORDINATOR<br>WIDRIG, DL                                 |  | PRICE CODE<br>BN                      | DATA<br>TURNAROUND<br>45 Days / 45 Days |             |
| SAMPLING LOCATION<br>C5941, I-002-D   | PROJECT DESIGNATION<br>216-A-30 Crib Sampling  |   | SAF NO.<br>F08-043  |  | AIR QUALITY <input type="checkbox"/>  |   |             |
| ICE CHEST NO.<br><i>GRP-07-008</i>  | FIELD LOGBOOK NO.  | ACTUAL SAMPLE DEPTH<br><i>4.8' - 7.3'</i>       | COA<br>123215ES20   |  | METHOD OF SHIPMENT<br>FEDERAL EXPRESS |   |             |
| SHIPPED TO<br>Lionville Laboratory incorporated   | OFFSITE PROPERTY NO.<br>SEE PTR  |   | BILL OF LADING/AIR BILL NO.<br>SEE PTR <i>7909 6474 0407</i>      |  |                                       |   |             |
| MATRIX*<br>A=Air<br>DL=Drum<br>L=Liquid<br>DS=Drum<br>S=Solids<br>L=Liquid<br>O=Oil<br>S=Soil<br>SE=Sediment<br>T=Tissue<br>V=Vegetation<br>W=Water<br>WI=Wipe<br>X=Other | POSSIBLE SAMPLE HAZARDS/ REMARKS<br>Contains Radioactive Material at concentrations that are not regulated for transportation per 49 CFR but are not releasable per DOE Order 5400.5 (1990/1993) |   | PRESERVATION<br>Cool~4C   |  |                                       |   |             |
|   |  |   | TYPE OF CONTAINER<br>G  |  |                                       |   |             |
|   |  |   | NO. OF CONTAINER(S)<br>1  |  |                                       |   |             |
|   |  |   | VOLUME<br>120mL   |  |                                       |   |             |
|   | SPECIAL HANDLING AND/OR STORAGE<br>Radioactive tie to B1TDB5   |   | SAMPLE ANALYSIS<br>Chromium Hex - 7196; Sulfides - 9030 (Sulfide) |  |                                       |   |             |
| SAMPLE NO.  | MATRIX*  | SAMPLE DATE                                     | SAMPLE TIME   |  |                                       |   |             |
| B1TH29  | SOIL   | <i>3-5-08</i>                                   | <i>1020</i>   | <i>X</i>   |                                       |   |             |
|   |  |   |   | <i>Lot # 624825</i>  |                                       |   |             |
| CHAIN OF POSSESSION   |  | SIGN/ PRINT NAMES                               |   | SPECIAL INSTRUCTIONS   |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>J.S. Pope</i>  | DATE/TIME<br><i>3-5-08 1152</i>  | RECEIVED BY/STORED IN<br><i>Site RMA Frida</i>  | DATE/TIME<br><i>3-5-08 1152</i>                                   | ** The 200 Area S&GRP Characterization and Monitoring Sampling and Analysis GKI applies to this SAF. |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>MOS06</i>  | DATE/TIME<br><i>3/17/08 1230</i>   | RECEIVED BY/STORED IN<br><i>Kevin Patterson</i> | DATE/TIME<br><i>3/17/08 1230</i>                                  |  |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>Kevin Patterson</i>  | DATE/TIME<br><i>3/17/08 1500</i>   | RECEIVED BY/STORED IN<br><i>MOT45-REF #1</i>    | DATE/TIME<br><i>3/17/08 1500</i>                                  |  |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>MOT 745 Ref #1</i>   | DATE/TIME<br><i>3-19-08</i>  | RECEIVED BY/STORED IN<br><i>Fluor Hanford</i>   | DATE/TIME<br><i>3-19-08</i>                                       |  |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>Fluor Hanford</i>  | DATE/TIME<br><i>3-19-08</i>  | RECEIVED BY/STORED IN<br><i>D.E. PARCHEN</i>    | DATE/TIME<br><i>3-19-08</i>                                       |  |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>D.E. PARCHEN</i>   | DATE/TIME<br><i>3-19-08</i>  | RECEIVED BY/STORED IN<br><i>Fed Ex</i>          | DATE/TIME<br><i>3-20-08 0940</i>                                  |  |                                       |   |             |
| RELINQUISHED BY/REMOVED FROM<br><i>Ex</i>   | DATE/TIME<br><i>3-20-08 0940</i>   | RECEIVED BY/STORED IN<br><i>NOV/merh</i>        | DATE/TIME<br><i>3-20-08 0940</i>                                  |  |                                       |   |             |
| LABORATORY SECTION  | RECEIVED BY  | TITLE   |   | DATE/TIME  |                                       |   |             |
| FINAL SAMPLE DISPOSITION  | DISPOSAL METHOD  | DISPOSED BY                                     |   | DATE/TIME  |                                       |   |             |

00000039



**RICHMOND, CA LABORATORY**  
**SAMPLE RECEIPT CHECKLIST**

*JK 3/20/08*

Client: F. HANFORD City RICHLAND State WA  
 Date/Time received 03/20/08 9:30 CoC No. F08-043-146, 147  
 Container I.D. No. SUL 442 Requested TAT (Days) 45 P.O. Received Yes [ ] No [ ]

**INSPECTION**

1. Custody seals on shipping container intact? Yes  No [ ] N/A [ ]
2. Custody seals on shipping container dated & signed? Yes  No [ ] N/A [ ]
3. Custody seals on sample containers intact? Yes  No [ ] N/A [ ]
4. Custody seals on sample containers dated & signed? Yes  No [ ] N/A [ ]
5. Packing material is: Wet [ ] Dry
6. Number of samples in shipping container: 3 Sample Matrix 2
7. Number of containers per sample: 1 (Or see CoC SEE ANOMALIES)
8. Samples are in correct container Yes  No [ ]
9. Paperwork agrees with samples? Yes [ ] No [ ]
10. Samples have: Tape [ ] Hazard labels [ ] Rad labels [ ] Appropriate sample labels
11. Samples are: In good condition  Leaking [ ] Broken Container [ ] Missing
12. Samples are: Preserved [ ] Not preserved [ ] pH \_\_\_\_\_ Preservative \_\_\_\_\_
13. Describe any anomalies:  
SAMPLE BITH03 CoC F08-043-148 IS MISSING  
SAMPLE BITH29 CoC F08-043-155 (LABEL) IS AN EXTRA SAMPLE  
Sample BITH29 sent to Honville. Switch sample CoCs.
14. Was P.M. notified of any anomalies? Yes  No [ ] Date 03/20/08
15. Inspected by MFW Date: 03/20/08 Time: 11:50

| Customer Sample No. | Beta/Gamma cpm | Ion Chamber mR/hr                | Wipe | Customer Sample No. | Beta/Gamma cpm | Ion Chamber mR/hr | wipe |
|---------------------|----------------|----------------------------------|------|---------------------|----------------|-------------------|------|
| <u>All samples</u>  | <u>&lt;60</u>  |                                  |      |                     |                |                   |      |
| <u>same sample</u>  |                | <u>See email from Dana Widby</u> |      |                     |                |                   |      |
|                     |                |                                  |      |                     |                |                   |      |
|                     |                |                                  |      |                     |                |                   |      |
|                     |                |                                  |      |                     |                |                   |      |
|                     |                |                                  |      |                     |                |                   |      |
|                     |                |                                  |      |                     |                |                   |      |
|                     |                |                                  |      |                     |                |                   |      |

Ion Chamber Ser. No. \_\_\_\_\_ Calibration date \_\_\_\_\_  
 Alpha Meter Ser. No. \_\_\_\_\_ Calibration date \_\_\_\_\_  
 Beta/Gamma Meter Ser. No. 100482 Calibration date 07 MAY 07

00000040