

0012370

SINGLE-SHELL TANK WASTE CHARACTERIZATION FOR TANK 241-U-110 CORE 8

DATA PACKAGE

SECTION

1 OF 7



Westinghouse
Hanford Company

P.O. Box 1970 Richland, WA 99352

1067

222-S/RCRA Analytical Laboratories

Project: Single - Shell Tank Waste
Characterization

Tank: 241-U-110

Core: 8

Customer Id. Number: Core 8 Composite

Report Revision: 1

Date Printed: October 10, 1990




Table of Contents

Signature Form.....	4
Introduction.....	5
Sampling Data.....	8
Sample Data Summary.....	12
Physical Test Analysis.....	17
Thermo Gravimetric Analysis.....	23
Differential Scanning Calorimeter.....	23
Undigested Sample Analysis.....	26
Untreated Sample Results Summary in Wet Weight.....	27
pH Analysis.....	28
Percent Water.....	29
Mercury.....	30
Cyanide.....	36
KOH Fusion Analysis.....	38
Fusion Analysis Summary in Wet Weight.....	39
ICP Data Summary.....	40
Fusion Analysis Summary for Lab Digestion.....	41
Fusion Dissolution.....	42
Total Alpha and Total Beta Analysis.....	43
GEA Analysis.....	48
Uranium Analysis.....	90
Inductively Coupled Plasma Spectrographic Analysis.....	91
Plutonium.....	150
Americium 241.....	172
Neptunium 237.....	193
Technetium 99.....	194
Iodine 129.....	201
Strontium 89/90.....	224
Water Digestion Test Analysis.....	227
Water Digestion Summary in Wet Weight 1st Leaching.....	228
Water Digestion Summary in Wet Weight 2nd Leaching.....	229
Water Digestion Summary for Lab Digestion 1st Leaching..	230
Water Digestion Summary for Lab Digestion 2nd Leaching..	231
Water Digestion 1st Leaching.....	232
Water Digestion 2nd Leaching.....	233
pH Analysis.....	234
Ion Chromatographic Analysis.....	235
Total Organic Carbon Analysis (not acidified).....	255
Total Organic Carbon Analysis (acidified).....	262
Ammonia.....	269
Carbonate.....	270

Nitrite.....	277
Total Alpha and Total Beta Analysis I.....	279
Total Alpha and Total Beta Analysis II.....	280
GEA Analysis.....	285
Plutonium.....	325
Americium 241.....	347
Carbon 14.....	368
Iodine 129.....	374
Neptunium 237.....	389
Strontium 89/90.....	390
Technetium 99.....	394
Tritium.....	401
Arsenic.....	408
Mercury.....	410
Selenium.....	412
 Acid Digestion Test Analysis.....	414
Acid Digestion Summary in Wet Weight.....	415
ICP Data Summary.....	416
Acid Digestion Summary for Laboratory Digestion.....	417
Acid Digestion.....	418
Inductively Coupled Plasma Spectrographic Analysis.....	419
ICP Raw Data Summary.....	421
Arsenic.....	468
Mercury.....	470
Selenium.....	472
 Appendix A Analytical Analysis Cards.....	475
 Appendix B Analytical Detection Limits.....	476

This report consists of pages 1 through 476, plus page 11.1.
 Appendix A consists of pages A-1 through A-120.
 Appendix B consists of pages B-1 through B-3.

I have reviewed this report and certify that the package is in compliance with "Quality Assurance Project Plan for the Chemical Analysis of Highly Radioactive Samples in Support of Environmental Activities on the Hanford Site", WHC-SD-CP-QAPP-002. I found it to be a true and accurate accounting both technically and for completeness of the laboratory analyses performed on this sample.

Shirley A. Cervantes
Shirley A. Cervantes
Data Coordinator

Date October 25, 1990

Cary M. Seidel
Cary M. Seidel
Unit Manager

Date October 25, 1990

Larry H. Taylor
Larry H. Taylor
Laboratory Q.A. Officer

Date November 1, 1990

INTRODUCTION

INTRODUCTION

Westinghouse Hanford Company Analytical Laboratories are supporting the characterization efforts of the single shell tanks. The characterization of tank 241-U-110 was performed under Phase 1A and 1B of the "Waste Characterization Plan for the Hanford Site Single-Shelled Tanks" (WHC-EP-0210).

Tank 241-U-110 has a 500,000 gallon capacity. Construction was completed in 1944. The tank received first cycle waste, REDOX high-level waste, coating waste, and laboratory waste until 1975. Between July 7, 1975, and February 2, 1976, P-10 pumps were installed, and 41,700 gallons of liquid waste were pumped from the tank. Tank 241-U-110 still contains an estimated 195,000 gallons of waste.

Analytical Laboratories performs all analytical analysis to the specifications of the "Quality Assurance Project Plan for the Chemical Analysis of Highly Radioactive Samples in Support of Environmental Activities on the Hanford Site,"

WHC-SD-CP-QAPP-002. In accordance with WHC-SD-CP-QAPP-002, the following laboratory policies are being followed. Spikes are performed on either the undissolved sample, or the sample after dissolution, as directed by the scientist. If the spike addition is found to be less than 20% of an analyte concentration, the spike recovery is not reported due to errors introduced by the precision of the sample analysis. The concentration of spike additions will be re-evaluated before the start of phase 1C. Two spiking routines are being used during phase 1A and 1B. For the following analyses, Ion Chromatography (IC), Inductively Coupled Plasma (ICP), Mercury Hydride, Total Organic Carbon (TOC), and Carbonate analyses, the solid sample is spiked independently from the sample digestion. Any non-homogeneity of the sample could adversely affect the spike recoveries. For the radioisotopic analysis and other analyses not specified above, the spikes were performed by spiking an aliquot of sample after digestion.

The laboratory does not report sample results from batch analyses that are questionable. The results from questionable batches are discarded, and the analysis is repeated. Sample cards (laboratory travelers) for the repeated analysis are reissued for analysis after they have been stamped "rerun." Laboratory travelers are issued using a computerized routine according to a "sample point." This sample point label (segment-n) on the laboratory travelers and on the GEA analysis reports has no relationship to the sampling activities or the sample identification. All results in this data package relate only to Sample 89-050 (Segment 1 from Core 8) taken from Riser 7 of Tank 241-U-110. Segments 2 (89-051), 3 (89-052), and 4 (89-053) from this riser were not recovered from the tank by the sampling efforts.

The organic analysis of this sample will be performed by Pacific Northwest Laboratories (PNL). Due to instrument and procedure problems, PNL has been unable to separate organics from the normal paraffin hydrocarbon present in the samples. The results from the organic analysis will be provided when available.

Carbon-14 analysis on the undigested sample was not performed as the 222-S laboratory does not have analytical procedures that will analyze low levels of Carbon 14 in solids. The Chrome-VI and the ICP analysis on the water digestion was not performed because sufficient sample to complete this analysis was not available. Sample for additional digestions was not available as this sample was completely consumed performing other analyses.

All sample results reported here by weight are reported as the "wet weight" of the sample. Some samples noticeably lost moisture during the process of aliquoting and weighing for digestion. In order to minimize errors due to loss of moisture, the percent moisture was determined at the earliest opportunity. Attempts to dry the sample before analysis resulted in approximately a tenfold increase in radiation levels. In order to reduce and control radiation exposure to laboratory personnel, the samples were not dried before aliquoting and digestion. This may result in some laboratory results being biased high.

This report is formatted into sections corresponding to the type of dissolutions performed prior to analysis. A brief summary of analytical results is reported, followed by calibration data and an analysis batch report. Any notable observations regarding an analysis are noted on the batch report for that analysis. Copies of laboratory travelers can be found in Appendix A.

SAMPLING DATA

CHAIN-OF-CUSTODY RECORD FOR CORE SAMPLING

(1) Shipment Number S-028-89 (2) Sample Number 89-050 (3) Supervisor D C Hartley
 (4) Tank 1104 (5) Riser 7 (6) Segment H (7) Cask Serial Number C1026

Radiation Survey Data:	(8) FIELD	(20) LABORATORY	(9) Shipment Description:
Over Top Dose Rate	<u>1.5 mR/hr</u>	<u>0.5 mR/hr</u>	<u>2W/89/00953/W</u>
Side Dose Rate	<u>1.5 mR/hr</u>	<u>0.5 mR/hr</u>	For Future Use
Bottom Dose Rate	<u>1.5 mR/hr</u>	<u>0.5 mR/hr</u>	<u>28</u>
Smearable Contamination	<u>LDET</u> (alpha)	<u>LDET</u> (alpha)	<u>11-17-89, 1057</u>
	<u>LDET</u> (beta-gamma)	<u>LDET</u> (beta-gamma)	<u>20%</u>
	RPT <u>W. Egan</u> (Signature)	RPT <u>W. Egan</u> (Signature)	<u>20%</u>
			<u>5mR/hr</u>
			<u>19"</u>

(10) INFORMATION (Include statement of laboratory tests to be performed.*)

Core #8
WTE-EP-0210 Waste Characterization of the
Hanford Site Single Shell Tanks

*Reference laboratory work request, if available.

Comments:

(11) POINT OF ORIGIN <u>241-U</u> <u>110</u>	(12) SENDER NAME <u>D C Hartley</u> SENDER SIGNATURE <u>D C Hartley</u>	(13) DATE AND TIME RELEASED <u>11-20-89</u> <u>2202</u>	(14) DESTINATION <u>2225</u> <u>CAB S.</u> <u>200 West</u>	(16) RECIPIENT NAME <u>MSL ARRAS</u> RECIPIENT SIGNATURE <u>M. L. Arras</u>	(17) DATE AND TIME RECEIVED <u>11-20-89</u> <u>2225</u>
(15) Seal Intact Upon Release? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	(18) Seal Intact Upon Receipt? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	(19) Seal Data Consistent with this Record? Shipment No. <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No Sample No. <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No			

Single Shell Tank Waste Characterization Summary of Core Sample

TANK ID:	241-U-110
RISER ID:	#7
CORE ID:	#8

DATE SAMPLING INITIATED:	11-17-89
DATE SAMPLING COMPLETED:	11-17-89
Segments 2, 3, & 4	received empty

SEGMENT	
1	Lab Serial No. F0289
	Customer ID No. 89-050
	Last Segment? NO
2	Lab Serial No. F0321
	Customer ID No. 89-051
	Last Segment? NO
3	Lab Serial No. F0345
	Customer ID No. 89-052
	Last Segment? NO
4	Lab Serial No. F0369
	Customer ID No. 89-053
	Last Segment? YES
5	Lab Serial No.
	Customer ID No.
	Last Segment?
6	Lab Serial No.
	Customer ID No.
	Last Segment?
7	Lab Serial No.
	Customer ID No.
	Last Segment?

SEGMENT	
8	Lab Serial No.
	Customer ID No.
	Last Segment?
9	Lab Serial No.
	Customer ID No.
	Last Segment?
10	Lab Serial No.
	Customer ID No.
	Last Segment?
11	Lab Serial No.
	Customer ID No.
	Last Segment?
12	Lab Serial No.
	Customer ID No.
	Last Segment?
13	Lab Serial No.
	Customer ID No.
	Last Segment?
14	Lab Serial No.
	Customer ID No.
	Last Segment?

Single Shell Tank Core Composite

LAB SEGMENT SERIAL #:

Core 8 Composite

CUSTOMER ID: F0941

SIMI-VOLATILE ORGANIC ANALYSIS

SIMI-VOA SAMPLE

LAB SERIAL #: N/A

DATE SAMPLED:

PARTICLE SIZE DISTRIBUTION ANALYSIS

PARTICLE SIZE SAMPLE

LAB SERIAL #: F0289

DATE SAMPLED:

Homogenized Solids

UNDIGESTED SOLIDS ANALYSIS

LABORATORY SERIAL NUMBER FOR SAMPLE:

F0941

DATE SAMPLED: 11-28-89

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0942

FUSION ANALYSIS OF SOLIDS

LABORATORY SERIAL NUMBER FOR SAMPLE:

F0947

DATE SAMPLED: 11-28-89

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0948

LABORATORY SERIAL NUMBER OF SPIKED SAMPLE: F0949

ACID DIGESTION ANALYSIS OF SOLIDS

LABORATORY SERIAL NUMBER FOR SAMPLE:

F0959

DATE SAMPLED: 11-28-89

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0960

LABORATORY SERIAL NUMBER OF SPIKED SAMPLE: F0961

WATER DIGESTION ANALYSIS OF SOLIDS

LABORATORY SERIAL NUMBER FOR SAMPLE:

F0953

DATE SAMPLED: 11-28-89

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0954

LABORATORY SERIAL NUMBER OF SPIKED SAMPLE: F0955

Laboratory Notebook Reference


WHC-N-313-4

12

Notebook No.

Page No.

111



TANK 241-U-110. CORE 8. SEGMENT 1

SAMPLE DATA SUMMARY

Analytical Laboratory Data Summary

SINGLE SHELL TANK PROJECT

The next four pages of this report (including this page) summarizes the results for the analysis of the

**Core 8 Composite Sample
Tank 241-U-110**

UNTREATED SAMPLE RESULTS

	Sample	Duplicate
pH	10.28	10.78
% Water	8.73%	8.04%
Mercury	3.96E-01 ug/g	4.60E-01 ug/g
Cyanide	<1200 ug/g	<1100 ug/g

Carbon 14 was not completed

DATA SUMMARY

Sample units are Wet Weight

Core 8 Composite Fusion Dissolution

Tank: 241-U-110
Customer ID: Core Composite 8

ICP Results

		Sample	Sample	Duplicate
		Sample	Duplicate	
Radiological Analysis				
Fusion	2.71 g/L	2.12 g/L	Aluminum	307798 ug/g
Total Alpha	7.14E-03 uci/g	1.01E-02 uci/g	Antimony	LT
Total Beta	2.03 uci/g	4.00 uci/g	Barium	LT
GEA Cs-137	3.80E-01 uci/g	4.09E-01 uci/g	Beryllium	LT
Uranium	9.26E+02 ug/g	1.18E+03 ug/g	Bismuth	LT
Plutonium	5.35E-03 uci/g	<3.63E-03 uci/g	Boron	164 ug/g
Americium 241	<6.90E-03 uci/g	1.71E-02 uci/g	Cadmium	LT
Neptunium 237	<3.98E-01 uci/g	<5.09E-01 uci/g	Calcium	2519 ug/g
Technetium 99	<8.30E-03 uci/g	<1.00E-02 uci/g	Cerium	LT
Iodine 129	<3.97E-02 uci/g	<5.07E-02 uci/g	Cobalt	LT
Strontium 90	5.61E-01 uci/g	1.14 uci/g	Copper	LT
			Europium	LT
			Iron	354 ug/g
			Lanthanum	LT
			Lead	LT
			Lithium	LT
			Magnesium	647 ug/g
			Manganese	46 ug/g
			Mercury	74 ug/g
			Molybdenum	LT
			Nickel	LT
			Samarium	2104 ug/g
			Selenium	3034 ug/g
			Silver	LT
			Sodium	LT
			Strontium	2940 ug/g
			Sulfur	7153 ug/g
			Tantalum	LT
			Thallium	LT
			Thorium	LT
			Tin	LT
			Titanium	LT
			Uranium	LT
			Vanadium	LT
			Zinc	LT
			Zirconium	143 ug/g

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

DATA SUMMARY
Units For Samples Are Wet Weight

**Core 8 Composite
Water Digestion**

Tank: 241-U-110
Customer Id.: Core 8 Composite

ICP Results
Sample was not analyzed

	Sample	Duplicate
Water Digestion	10.10 g/L	9.80 g/L
pH	8.21	7.48

Anion Analysis

Fluoride	2.37E+01 ug/g	3.64E+01 ug/g
Chloride	3.01E+01 ug/g	3.28E+01 ug/g
Nitrate	2.51E+02 ug/g	3.06E+02 ug/g
Phosphate	1.12E+02 ug/g	2.13E+02 ug/g
Sulfate	<1.98E+02 ug/g	<2.04E+02 ug/g
Total Organic Carbon**	1.70E+03 ug/g	1.40E+03 ug/g
Total Organic Carbon*	8.78E+02 ug/g	8.28E+02 ug/g
Ammonia	<5.24E+03 ug/g	<5.40E+03 ug/g
Carbonate	2.97E+02 ug/g	3.57E+02 ug/g
Nitrite	1.72E+04 ug/g	7.98E+03 ug/g

Radiological Analysis

Total Alpha	<2.54E-03 uci/g	<1.35E-03 uci/g
Total Beta	2.34E-01 uci/g	3.03E-01 uci/g
GEA Cs-137	1.83E-01 uci/g	3.32E-01 uci/L
Americium 241	<1.27E-03 uci/g	<2.43E-03 uci/g
Carbon 14	1.13E-04 uci/g	1.13E-04 uci/g
Iodine 129	<5.19E-02 uci/g	<6.78E-03 uci/g
Neptunium 237	<1.07E-04 uci/g	<1.10E-01 uci/g
Plutonium	<6.30E-04 uci/g	<1.23E-03 uci/g
Strontium 90	6.50E-02 uci/g	6.41E-02 uci/g
Technetium 99	<1.40E-03 uci/g	<2.35E-03 uci/g
Tritium	<1.13E-03 uci/g	<1.13E-03 uci/g

Atomic Absorption Spectroscopy

Arsenic	<4.99E-01 ug/g	<4.99E-01 ug/g
Mercury	1.09E-01 ug/g	9.18E-02 ug/g
Selenium	<4.99E-01 ug/g	<5.02E-01 ug/g

*** Analysis Was Not Run.

** Samples were not acidified before analysis. Results include carbonate in sample.

* Samples were acidified correctly before analysis.

DATA SUMMARY
Units For Samples Are Wet Weight

**Core 8 Composite
Acid Digestion**

Tank: 241-U-110
Customer Id.8 Composite

ICP Results

Atomic Absorption Spectroscopy

Hydride Analysis

	Sample	Duplicate	Sample	Duplicate
Acid Digestion	10.24 g/L	11.95 g/L	Aluminum	132295 ug/g
			Antimony	524 ug/g
			Barium	LT
			Beryllium	LT
			Bismuth	LT
			Boron	LT
			Cadmium	LT
			Calcium	98 ug/g
			Cerium	LT
			Chromium	LT
			Copper	LT
			Europium	LT
			Iron	218 ug/g
			Lanthanum	LT
			Lead	553 ug/g
			Lithium	LT
			Magnesium	20 ug/g
			Manganese	58 ug/g
			Mercury	LT
			Molybdenum	39 ug/g
			Nickel	LT
			Potassium	LT
			Samarium	LT
			Selenium	526 ug/g
			Silver	LT
			Sodium	1111 ug/g
			Strontium	LT
			Sulfur	79 ug/g
			Tantalum	LT
			Thallium	LT
			Thorium	86 ug/g
			Tin	76 ug/g
			Titanium	12 ug/g
			Uranium	LT
			Vanadium	LT
			Zinc	56 ug/g
			Zirconium	LT

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

PHYSICAL TEST ANALYSIS

Single Shell Tank

Extrusion of Segment -- Physical Tests

LAB SEGMENT SERIAL #:	F0941	CUSTOMER ID:	Core 8 Composite
ANALYST:	K. J. Patterson	DATE EXTRUDED:	November 27, 1989
DRAINABLE LIQUID	Liquid Submitted for Segment Analysis? --		<u>NO</u>
GROSS	TARE	NET	
SERIAL	DATE/TIME	ESTIMATED	
SPECIFIC	CALCULATED		

APPEARANCE OF LIQUID:

DIMENSIONS OF SEGMENT

Completed Segment Obtained?	<u>NO</u>	LENGTH: 5 in	CALC. VOL. 3.92 cu in
REMARKS			

APPEARANCE OF SOLIDS:

Hard, white crumbly solids. Material is more sticky than previous cores.

PENETROMETER	6.0	lbs/sq in	REMARKS:
--------------	-----	-----------	----------

HOMOGENIZATION

PROCEDURE: T038A-00712	REVISION: F	QUANTITY OF MATERIAL: 103.31	GRAMS
DATE HOMOGENIZED:	12-28-89	TIME HOMOGENIZED:	5.0 MINUTES
OPERATOR: K. J. Patterson			

LABORATORY NOTEBOOK REFERENCE

WHC-N-313-4

12

Notebook No.

Page No.

Brinkmann	Particle Size	Analyzer
	Particle Size	Analyzer

**PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010**

SAMPLE NAME : SST,B000087,F0289,ETOH,SBK

FILE NAME : F0289.002

DATE	:	04/12/1989	ACQ. RANGE	:	0.5-60	COUNTS	:	131988
TIME	:	13:58	ACQ. MODE	:	SAMPLE	S.N.F.	:	0.98
CONFIG.	:	1 (0.7 S1)	ACQ. TIME	:	1169 SEC	S.D.U.	:	1648
CELL TYPE	:	MAGNETIC (S)	SAMPLE SIZE	:	4	CONCENTR.	:	1.2E+06 #/ml
SAMPLE TYPE	:	REGULAR	REQ. CONF.	:	95.00%(V)	SOLIDS	:	1.5E-03 %


PROBABILITY NUMBER DENSITY GRAPH

Name: SST,B000087,F0289,ETOH,SBK

1.2E+06 #/ml(99.7%)

Mode at 0.70 μ m<< SCALE RANGE (μ m): 0 - 10 >>Local Median : 0.91 μ mLocal Mean(nl): 1.35 μ mLocal S.D.(nl): 1.18 μ m

Local Conf(nl): 100.00 %




SAMPLE NAME : SST,B000087,F0289,ETOH,SBK
FILE NAME : F0289.002

DATE	: 04/12/1989	ACQ. RANGE	: 0.5-60	COUNTS	: 131098
TIME	: 13:58	ACQ. MODE	: SAMPLE	S.N.F.	: 0.98
CONFIG.	: 1 (0.7 S1)	ACQ. TIME	: 1169 SEC	S.D.U.	: 1648
CELL TYPE	: MAGNETIC (3)	SAMPLE SIZE	: 4	CONCENTR.	: 1.2E+06 #/ml
SAMPLE TYPE	: REGULAR	REQ. CONF.	: 95.00%(V)	SOLIDS	: 1.5E-03 %

PROBABILITY NUMBER DENSITY GRAPH

Name: SST,B000087,F0289,ETOH,SBK
1.2E+06 #/ml(99.7%)
Mode at 0.70 μm
<< SCALE RANGE (μm): 0 - 10 >>

Local Median : 0.91 μm
Local Mean(nl): 1.35 μm
Local S.D.(nl): 1.18 μm
Local Conf(nl): 100.00 %



Brinkmann

Particle Size Analyzer

PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010

SAMPLE NAME : SST,B000087,F0289,ETOH,SBK


FILE NAME : F0289.001

DATE	:	04/12/1989	: ACQ. RANGE	:	0.5-150	: COUNTS	:	275893
TIME	:	13:13	: ACQ. MODE	:	SAMPLE	: S.N.F.	:	1.00
CONFIG.	:	1 (0.7 S1)	: ACQ. TIME	:	1586 SEC	: S.D.U.	:	662
CELL TYPE	:	MAGNETIC (3)	: SAMPLE SIZE	:	4	: CONCENTR.	:	6.9E+05 #/ml
SAMPLE TYPE	:	REGULAR	: REQ. CONF.	:	95.00% (V)	: SOLIDS	:	1.9E-03 %

PROBABILITY VOLUME DENSITY GRAPH

Name: SST,B000087,F0289,ETOH,SBK
 1.3E-05 cc/ml(100.0%)
 Mode at 5.00 μm
 << SCALE RANGE (μm): ADJUSTED >>

Median : 12.52 μm	Mean(nv): 3.27 μm	Mean(vm): 15.19 μm
S.D.(nv): 2.31 μm	S.D.(vm): 11.89 μm	Conf(vm): 99.43 %



B r i n k e m a n n

Particle Size Analyzer

PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKEMANN 2010

SAMPLE NAME : SST,B000087,F0289,ETOH,SBK


FILE NAME : F0289.001

DATE	: 04/12/1989	ACQ. RANGE	: 0.5-150	COUNTS	: 275893
TIME	: 13:13	ACQ. MODE	: SAMPLE	S.N.F.	: 1.00
CONFIG.	: 1 (0.7 S1)	ACQ. TIME	: 1586 SEC	S.D.U.	: 662
CELL TYPE	: MAGNETIC (3)	SAMPLE SIZE	: 4	CONCENTR.	: 6.9E+05 #/ml
SAMPLE TYPE	: REGULAR	REQ. CONF.	: 95.00%(v)	SOLIDS	: 1.3E-03 %

PROBABILITY VOLUME DISTRIBUTION GRAPH

Name: SST,B000087,F0289,ETOH,SBK

1.3E-05 cc/ml(100.0%)

Mean(nv): 3.27 μ mMedian : 12.52 μ mS.D.(nv): 2.31 μ mMean(v_m): 15.19 μ m<< SCALE RANGE (μ m): ADJUSTED >>S.D.(v_m): 11.89 μ mConf(v_m): 99.43 %

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	WA63090/WA58053
PROCEDURE/REV	L1-000-200
TECHNOLOGIST	D. B. Bechtold
DATE	March 13, 1990
TEMPERATURE	N/A
STARTING TIME	0837
ENDING TIME	1503
CHEMIST	D. B. Bechtold


Thermographic/Differential
Scanning Calorometer Analysis

*Reagent Grade Dry Fine;
Reference Scan

	DESCRIPTION	LAB ID
1	Therographic Analysis	F0941
2	Diff. Scanning Calorimeter	F0941
3		
4		
5		
6		
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
N/A				



12.00
25
SST, B000298, F0941, AIR, SAZ, 4522

WT: 2.35 mg

SCAN RATE: 20.00 deg/min

ENDO >

PEAK FROM: 238.85

TO: 360.55

ONSET: 293.37

CAL/GRAM: 286.5

PEAK FROM: 280.55

TO: 360.55

ONSET: 294.72

CAL/GRAM: 245.08

T/G FROM: 230

TO: 280.54

ONSET: 240.83

CAL/GDEG: .583717

MIDPOINT: 241.53

5.00

0.00



DBB, SBK

FILE: F0941.D4

TEMPERATURE (C)

DSC

DATE: 90/03/07

TIME: 15:03

UNDIGESTED SAMPLE ANALYSIS

Single Shell Tank Project

Undigested Sample
Analysis Results

Tank: 241-U-110
 Customer ID: Core 8 Composite

	Check Standard	Blank	Sample	Duplicate Sample	Spike of Sample	Check Standard
Laboratory ID: pH	F0100 101.00%	F0121 6.83	F0289 10.28	F0290 10.78	N/A N/A	F0292 100.90%
Laboratory ID: % Water	F0100 96.63%	F0309 6.50E-03 g	F0289 8.73%	F0290 8.04%	N/A N/A	F0292 96.80%
Laboratory ID: Mercury	F0939 108.80%	F0940 <10.00 ng	F0941 3.96E-01 ug/g	F0942 4.60E-01 ug/g	F0943 82.90%	F0944 116.00%
Laboratory ID: Cyanide	F0939 104.40%	F0940 <3.00E+02 ug	F0941 <1.20E+03 ug/g	F0942 <1.10E+03 ug/g	F0943 104.70%	F0944 103.50%

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	AL10653
PROCEDURE/REV	LA-212-103/A-0
TECHNOLOGIST	M. Franz
DATE	January 02, 1990
TEMPERATURE	23.6 C
STARTING TIME	1330
ENDING TIME	2000
CHEMIST	R. E. Brandt

pH Analysis of Solid Sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0100
2	Reagent Blank	F0121
3	Sample 89-045	F0101
4	Duplicate Sample 89-045	F0102
5	Sample 89-047	F0125
6	Duplicate Sample 89-047	F0126
7	Sample 89-048	F0149
8	Duplicate Sample 89-048	F0150
9	Sample Composite 8	F0289
10	Duplicate Sample Composite 8	F0290
11	Final LMCS Check Std.	F0292

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	72C11A/5.0 mL			5.0 mL

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	N/A
PROCEDURE/REV	LA-564-101/D-0
TECHNOLOGIST	R. D. Hale
DATE	January 03, 1990
TEMPERATURE	120 C
STARTING TIME	1100 01-02-90
ENDING TIME	1100 01-03-90
CHEMIST	R. E. Brandt

Percent Water in Sample

Undigested Sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0100
2	Reagent Blank	F0309
3	Sample 89-047	F0125
4	Duplicate Sample 89-047	F0126
5	Sample 89-048	F0149
6	Duplicate Sample 89-048	F0150
7	Sample Composite 8	F0289
8	Duplicate Sample Composite 8	F0290
9	LMCS Check Std.	F0292
10	Sample 89-045	F0101
11	Duplicate Sample 89-045	F0102

	DESCRIPTION	LAB ID
12	Final LMCS Check Std.	F0292
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	11C11AG/1.0 g			1.0 g

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	Perkin-Elmer
PROCEDURE/REV	LA-325-102/A-2
TECHNOLOGIST	M. Myers
DATE	July 16, 1990
TEMPERATURE	20 C
STARTING TIME	1330
ENDING TIME	1500
CHEMIST	R. K. Fuller

Mercury Analysis by Atomic Absorption

Manual Cold Vapor Technique

Undigested Sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0939
2	Reagent Blank	F0940
3	Sample Composite 8	F0941
4	Duplicate Sample Composite 8	F0942
5	Spike Composite 8	F0943
6	Final LMCS Check Std.	F0944
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	58C11-CD/25 uL			25 mL
Spike	58C11-CD/25 uL	F0941/0.0384 g		25 mL

.0388g Sample F94

25μm
Sample Blank F940

Hg

7-16-90
10nm/10mV
6CB23

Sample S90 25μm 50011-CD
63μm P939

20

40

60

80

50μl 102C3-AE

89 nm

40μl 102C3-AE

73nm

$$r^2 = .9976$$

$$a = 6.3256$$

$$b = 1.66698$$

20μl 102C3-AE

41 nm

10μl 102C3-AE
25nm

Hg

7-16-90
0nm/10mV
6CB23

4nm
BLANK

50nm

.033g Sample FA48m
FA19

6nm

F1017 Sample Blank
FA18

Hg

7-16-90

10nm/10nm
helium lamps

02

04nm

07

09

00

25nm SEC II-CD Sample Std FA1017

0304g Sample 6 + 25m SEC II-CD FA14

75nm

75nm
FA13

32nm
0.0334g Sample Duplicate FA42

32nm

32nm
.033g Sample FA41

Hg

7-16-90

2.5nm
Sample Blank FA40

60023

7- Sample Blank F1010

61.5m 10mm 10ml
Sample SPC

61.5m 10mm 10ml
Sample SPC
7-16.00
60823

7-16.00
0.042g Sample 2ml 10ml 10ml F1024

7-16.00
0.042g Sample 2ml 10ml 10ml F1024

7-16.00
0.042g Sample 2ml 10ml 10ml F1024

7-16.00
0.033g Sample 2ml 10ml 10ml F1019

7-16.00
10ml 10ml
blank tubes
F1018

25ml 58C11-CD F1070

.0388g Sample 2ml-10ml + 15ml 58C11-CD
F1069

.0344g Sample Duplicate F1068
by S.R.K.

Hg
7-16-90
(0ml/10ml
6C823

.0300g Sample F1067 69μm

7ml Sample Blank F1066

25ml 58C11-CD Sample STD 61μm F1065

25ml 58C11-CD Sample STD 61.5μm F1062

Hg
7-16-90
10μm/10μm
6C823

38μm

34 .0143g Sample 1.2ml-10ml + 15ml 58C11-CD E12-2

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	WA66684
PROCEDURE/REV	LA-695-101/A-2
TECHNOLOGIST	E. Colvin
DATE	February 21, 1990
TEMPERATURE	N/A
STARTING TIME	0800 02-20-90
ENDING TIME	2200 02-21-90
CHEMIST	R. E. Brandt

Cyanide Analysis

Undigested Sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0939
2	Reagent Blank	F0940
3	Sample Composite 8	F0941
4	Duplicate Sample Composite 8	F0942
5	Spike Composite 8	F0943
6	Final LMCS Check Std.	F0944
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY Book # & ALIQUOT VOL.	SECOND Book # & ALIQUOT VOL.	THIRD Book # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	74C11B/10 uL			50 mL
Spike	75C11B/10 uL	F0941/0.3306 g		50 mL

Single Shell Tank Calibration Record

ANALYTE: CN-

PROCEDURE: LA-695-101

REVISION: A-1

INSTRUMENT: Baush & Lomb Spectronic 21

PROPERTY NUMBER: WA66684

TECHNOLOGIST: R.Brandt

PAYROLL NUMBER: 69090

DATE: July 20, 1989

CALIBRATION STANDARD ID: 88C15C

ANALYTE CONCENTRATION: 817 ug CN/mL

TYPE OF CALIBRATION: Least Square Linear Regression

Dilution	Concentration	Instrument Reading Units=
Blank	0	0.016
100 uL	0.82	0.091
200 uL	1.63	0.150
500 uL	4.08	0.354
1000 uL	8.17	0.663
2000 uL	16.34	1.275
3000 uL	24.51	1.720

COMMENTS: Y - intercept - 0.01682

Slope - 0.076317

Correlation Coefficient - 0.999874

KOH FUSION ANALYSIS

Single Shell Tank Project

Fusion Analysis
Laboratory Results Of Solids
Units Are Sample Wet Weight

Tank: 241-U-110
Customer ID: Core 8 Composite

	Check Standard	Blank	Sample	Duplicate Sample	Spike of Sample	Check Standard
Laboratory ID: Fusion			F0294 2.71 g/L	F0295 2.12 g/L		
Laboratory ID: Total Alpha	F0105 111.90%	F0308 <1.00E-04 uci/L	F0294 7.14E-03 uci/g	F0295 1.01E-02 uci/g	F0296 97.10%	F0297 100.30%
Total Beta	98.80%	<2.58E-04 uci/L	2.03 uci/g	4.00 uci/g	*	96.50%
Laboratory ID: GEA Cs-137	F0129 98.10%	F0308 2.49E-01 uci/L	F0294 3.80E-01 uci/g	F0295 4.09E-01 uci/g	F0296 99.10%	F0297 99.10%
Laboratory ID: Uranium	F0293 103.90%	F0308 <6.72E-04 g/L	F0294 9.26E+02 ug/g	F0295 1.18E+03 ug/g	F0296 152.80%	F0297 98.50%
Laboratory ID: Plutonium	F0903 109.50%	F0946 <7.29E-03 uci/L	F0947 5.35E-03 uci/g	F0948 <3.63E-03 uci/g	F0949 *	F0950 105.90%
Laboratory ID: Americium 241	F0897 101.30%	F0946 <1.50E-02 uci/L	F0947 <6.90E-03 uci/g	F0948 1.71E-02 uci/L	F0949 *	F0950 105.80%
Laboratory ID: Neptunium 237	F0897 80.50%	F0898 <1.08 uci/L	F0947 <3.98E-01 uci/g	F0948 <5.09E-01 uci/g	F0979 71.20%	F0980 63.30%
Laboratory ID: Technetium 99	F0945 110.90%	F0946 <2.28E-02 uci/L	F0947 <8.30E-03 uci/g	F0948 <1.00E-02 uci/g	F0949 107.50%	F0950 111.00%
Laboratory ID: Iodine 129	F0945 74.20%	F0946 <1.08E-01 uci/L	F0947 <3.97E-02 uci/g	F0948 <5.07E-02 uci/g	F0949 80.50%	F0950 97.40%
Laboratory ID: Strontium 90	F0945 99.70%	F0946 <8.58E-03 uci/L	F0947 5.61E-01 uci/g	F0948 1.14 uci/g	F0949 103.00%	F0950 88.80%

*Ratio Of Standard To Sample Inefficient To Calculate Spike recovery

ICP Results

DATA SUMMARY

Date Analyzed:	April 30, 1990	Acid Digested LMCS Standard	F0575
Procedure:	LA-505-151/A-0	Reagent Blank	F0583
Analyst:	J. A. White	Core 8 Composite	F0947
Digestion	Acid Digestion	Duplicate of Core 8 Composite	F0948
Procedure:	LA-505-159/A-0	Spike of 89-076	F0578
		Acid Digested LMCS Standard	F0579

	Instrument Starting LMCS Standard %	Acid Digest. LMCS Standard %	Reagent BLANK	Wet Weight Sample	Wet Weight Sample	Spike Recovery	LMCS ACID Digestion %	Closing LMCS Standard %
Aluminum	100.70%	92.02%	0.33	307798	310987	NOT CALC.	96.56%	99.27%
Antimony	103.07%	87.00%	0.02 LT	-2019 LT	-702 LT	-243.70%	67.00%	99.07%
Barium	99.30%	93.10%	0.01	-112 LT	-30 LT	103.93%	92.70%	97.17%
Beryllium	95.99%	87.90%	0.00 LT	-19 LT	-11 LT	101.02%	90.60%	94.22%
Bismuth	106.23%	94.31%	0.03 LT	-2451 LT	-1562 LT	-117.00%	101.54%	107.22%
Boron	100.71%	93.20%	0.06	164	439	76.57%	92.60%	98.05%
Cadmium	98.69%	93.70%	0.00 LT	-77 LT	-41 LT	98.39%	91.10%	96.89%
Calcium	102.21%	143.70%	0.78	2519	4046	170.51%	144.90%	99.95%
Cerium	92.37%	50.50%	-0.08 LT	-4512 LT	-1516 LT	-1338.00%	0.80%	90.43%
Cobalt	94.24%	95.40%	0.00 LT	-242 LT	69 LT	7.30%	86.60%	99.92%
Copper	100.63%	92.60%	0.01 LT	-280 LT	-76 LT	114.10%	90.60%	98.31%
Europium	98.16%	92.70%	0.00 LT	-81 LT	-25 LT	101.78%	94.90%	96.39%
Iron	103.46%	128.30%	0.58	354	632	NOT CALC.	126.30%	100.84%
Lanthanum	94.17%	89.66%	-0.01 LT	-368 LT	-103 LT	98.06%	91.90%	93.39%
Lead	105.09%	96.71%	0.03 LT	-1272 LT	-86 LT	112.52%	103.09%	108.06%
Lithium	98.13%	88.00%	-0.01 LT	-216 LT	-75 LT	99.66%	86.20%	95.95%
Magnesium	102.45%	108.40%	0.17	647	496	421.22%	107.20%	99.84%
Manganese	100.16%	97.50%	0.03	46	74	211.90%	97.00%	98.30%
Mercury	105.34%	89.88%	0.01	-73 LT	-22 LT	226.51%	94.80%	104.63%
Molybdenum	96.36%	87.60%	0.00 LT	-166 LT	-88 LT	94.24%	91.18%	94.24%
Nickel	97.87%	94.20%	0.00 LT	2104	3034	101.41%	90.70%	96.04%
Potassium	98.37%	74.68%	-0.09 LT	0	0	-733.60%	44.60%	98.37%
Samarium	95.61%	3.00%	-0.12 LT	-4951 LT	-1643 LT	-1619.00%	43.80%	99.90%
Selenium	105.26%	88.26%	-0.02 LT	-1245 LT	-135 LT	128.63%	95.04%	103.89%
Silver	102.71%	91.20%	-0.01 LT	-381 LT	-162 LT	-87.60%	96.10%	102.54%
Sodium	98.55%	97.68%	0.35	2940	7153	NOT CALC.	85.92%	96.79%
Strontium	100.99%	96.30%	0.00	29	-5 LT	146.91%	96.00%	98.64%
Sulfur	106.15%	95.42%	0.14	-200 LT	231 LT	150.68%	101.22%	105.85%
Tantalum	96.79%	76.60%	-0.01 LT	-808 LT	-358 LT	-36.62%	80.42%	95.64%
Thallium	101.95%	83.48%	-0.11 LT	-5676 LT	-2830 LT	-210.80%	91.10%	101.34%
Thorium	102.75%	87.41%	-0.08 LT	-3404 LT	-1345 LT	-112.51%	94.77%	102.26%
Tin	100.68%	98.20%	0.02 LT	-218 LT	-75 LT	100.18%	94.72%	98.67%
Titanium	99.79%	91.90%	0.09	-188 LT	-80 LT	103.53%	94.68%	96.79%
Uranium	102.10%	-13.59%	-0.89 LT	-32297 LT	-11835 LT	-1080.64%	35.91%	107.36%
Vanadium	95.92%	86.90%	-0.01 LT	-213 LT	-184 LT	31.20%	90.90%	94.94%
Zinc	100.16%	95.20%	0.08	65	143	134.21%	93.90%	98.31%
Zirconium	98.91%	88.94%	-0.01 LT	-500 LT	-179 LT	117.87%	92.02%	96.18%

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

Single Shell Tank Project

Fusion Analysis
Results Of The Laboratory Digestions

Tank: 241-U-110
Customer ID: Core 8 Composite

	Check Standard	Blank	Sample	Duplicate Sample	Spike of Sample	Check Standard
Laboratory ID: Fusion	N/A N/A	F0168 N/A	F0294 2.71 g/L	F0295 2.12 g/L	N/A N/A	N/A N/A
Laboratory ID: Total Alpha	F0105 111.90%	F0308 <1.00E-04 uci/L	F0294 1.94E-02 uci/L	F0295 2.15E-02 uci/L	F0296 97.10%	F0297 100.30%
Total Beta	98.80%	<2.58E-04 uci/L	5.49 uci/L	8.47 uci/L	*	96.50%
Laboratory ID: GEA Cs-137	F0129 98.10%	F0308 2.49E-01 uci/L	F0294 1.03 uci/L	F0295 8.67E-01 uci/L	F0296 99.10%	F0297 99.10%
Laboratory ID: Uranium	F0293 103.90%	F0308 <6.72E-04 g/L	F0294 2.51E-03 g/L	F0295 2.51E-03 g/L	F0296 152.80%	F0297 98.50%
Laboratory ID: Plutonium	F0903 109.50%	F0946 <7.29E-03 uci/L	F0947 1.45E-02 uci/L	F0948 <7.70E-03 uci/L	F0949 *	F0950 105.90%
Laboratory ID: Americium 241	F0897 101.30%	F0946 <1.50E-02 uci/L	F0947 <1.87E-02 uci/L	F0948 3.63E-02 uci/L	F0949 *	F0950 105.80%
Laboratory ID: Neptunium 237	F0897 80.50%	F0898 <1.08 uci/L	F0947 <1.08 uci/L	F0948 <1.08 uci/L	F0979 71.20%	F0980 63.30%
Laboratory ID: Technetium 99	F0945 110.90%	F0946 <2.28E-02 uci/L	F0947 <2.25E-02 uci/L	F0948 <2.12E-02 uci/L	F0949 107.50%	F0950 111.00%
Laboratory ID: Iodine 129	F0945 74.20%	F0946 <1.08E-01 uci/L	F0947 <1.08E-01 uci/L	F0948 <1.08E-01 uci/L	F0949 80.50%	F0950 97.40%
Laboratory ID: Strontium	F0945 99.70%	F0946 <8.58E-03 uci/L	F0947 1.52 uci/L	F0948 2.41 uci/L	F0949 103.00%	F0950 88.80%

*Ratio Of Standard To Sample Inefficient To Calculate Spike Recovery.

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	N/A
PROCEDURE / Rev	LA-549-141/A-1
TECHNOLOGIST	R. D. Hale
DATE	January 03, 1990
TEMPERATURE	23 C
STARTING TIME	1000
ENDING TIME	1200
CHEMIST	S. A. Catlow

Fusion Dissolution

	DESCRIPTION	LAB ID
1	Reagent Blank	F0168
2	Sample 89-045	F0106
3	Duplicate Sample 89-045	F0107
4	Sample 89-047	F0130
5	Duplicate Sample 89-047	F0131
6	Sample 89-048	F0154
7	Duplicate Sample 89-048	F0155
8	Sample Composite 8	F0294
9	Duplicate Sample Composite 8	F0295
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY Book # & ALIQUOT VOL.	SECOND Book # & ALIQUOT VOL.	THIRD Book # & ALIQUOT VOL.	FINAL VOL. OF STD.
N/A				

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	HW45676
PROCEDURE/REV	LA-508-101/C-1
TECHNOLOGIST	J. A. Hopkins
DATE	January 05, 1990
TEMPERATURE	70 F
STARTING TIME	0930
ENDING TIME	1400
CHEMIST	S. A. Catlow

Total Alpha and Total Beta
Fusion Dissolution
Detector 18

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0105
2	Reagent Blank	F0308
3	Sample 89-078	F0106
4	Duplicate Sample 89-078	F0107
5	Sample 89-047	F0130
6	Duplicate Sample 89-047	F0131
7	Sample 89-048	F0154
8	Duplicate Sample 89-048	F0155
9	Sample Composite 8	F0294
10	Duplicate Sample Composite 8	F0295
11	Spike Composite 8	F0296

	DESCRIPTION	LAB ID
12	Final LMCS Check Std.	F0297
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	83B44/10 mL			N/A
Spike	83B44/10 mL	F0294/100 uL		N/A

Single Shell Tank

Calibration Record

ANALYTE:	Am ²⁴¹		
PROCEDURE:	LQ-508-002	REVISION:	A-0
INSTRUMENT:	Detector #18	PROPERTY NUMBER:	WA93415
TECHNOLOGIST:	R.A. Jones	PAYROLL NUMBER:	65801
DATE:	June 28, 1989		
CALIBRATION STANDARD ID: 36B40A3; 36B40B3; 36B40C3; 36B40A6; 36B40B6; 36B40C5; 36B40A8; 36B40B7; 36B40C7			
ANALYTE CONCENTRATION:	N/A		
TYPE OF CALIBRATION:	Efficiency		

SST-103 Rev. (Draft) 9/15/90 Short Interim

CALIBRATION SHEET FOR ALPHA/BETA SYSTEMS: USING PROCEDURE LQ-508-002

DETECTOR No. 18

TIME ZERO DATE (HD): 15897

RADIOMUCLIDE: Am-241

HALF LIFE: 154497

DATE COUNTED (HD): 16347

COUNT TIME: 5

CPM BKG: 0.2

CALIBRATED BY: RA JONES HD 0 = 09/25/44

STANDARD ID	SIZE	DATE	TIME	COUNTS @ 0 DEG.	COUNTS @ 90 DEG.	COUNTS @ 180 DEG.	COUNTS @ 270 DEG.
-------------	------	------	------	-----------------	------------------	-------------------	-------------------

36B40A3	2	06/28/80	1542	67207	66768	67025	66645
36B40B3	2	06/28/80	1547	115573	116337	116289	116143
36B40C3	2	06/28/80	1552	162269	162819	162370	161593
36B40A6	5	06/28/80	1558	61627	62404	61970	61272
36B40B6	5	06/28/80	1603	118582	119217	118566	119430
36B40C5	5	06/28/80	1608	164322	165699	166216	166176

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
-------------	------	-----------	---------	------------	----------------	------------

36B40A8	1"	60570	0	1.00	0	0.0000
36B40B7	1"	109900	0	1.00	0	0.0000
36B40C7	1"	159700	0	1.00	0	0.0000

AVERAGE, 1" =	0.0000 +/- @95%	0.0000	-97.62 %	ON	06/28/89
---------------	-----------------	--------	----------	----	----------

STANDARD ID		STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
-------------	--	-----------	---------	------------	----------------	------------

36B40A3	2"	61800	13382	1.00	13409	0.2170
36B40B3	2"	110700	23217	1.00	23264	0.2102
36B40C3	2"	161400	32452	1.00	32518	0.2015

AVERAGE, 2" =	0.2095 +/- @95%	0.0152	7.27 %	ON	06/28/89
---------------	-----------------	--------	--------	----	----------

STANDARD ID		STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
-------------	--	-----------	---------	------------	----------------	------------

36B40A6	5"	59470	12363	1.00	12388	0.2083
36B40B6	5"	109800	23790	1.00	23838	0.2171
36B40C5	5"	160100	33120	1.00	33187	0.2073

AVERAGE, 5" =	0.2109 +/- @95%	0.0106	5.01 %	ON	06/28/89
---------------	-----------------	--------	--------	----	----------

NEW EFFS FOR DET	18 Am-241	1" =	0.0000	2" =	0.2095
------------------	-----------	------	--------	------	--------

5" =	0.2109
------	--------

Single Shell Tank

Calibration Record

ANALYTE:	Co ⁶⁰		
PROCEDURE:	LQ-508-002	REVISION:	A-0
INSTRUMENT:	Detector #18	PROPERTY NUMBER:	WA93415
TECHNOLOGIST:	R.A. Jones	PAYROLL NUMBER:	65801
DATE:	June 28, 1989		
CALIBRATION STANDARD ID: 100B40A2; 100B40B1; 100B40C1; 32B40A4; 32B40B3; 32B40C4; 32B40A5; 32B40B6; 32B40C5			
ANALYTE CONCENTRATION:	N/A		
TYPE OF CALIBRATION:	Efficiency		

SST-103 Rev. (Draft) 9/15/90 Short Interim

CALIBRATION SHEET FOR ALPHA/BETA SYSTEMS: USING PROCEDURE LQ-508-002

DETECTOR No.	18	2", 5" STD TIME ZERO DATE (HD):	15883
RADIOMUCLIDE:	Co-60	1" STD TIME ZERO DATE (HD):	16573
HALF LIFE:	1925	DATE COUNTED (HD):	16347
COUNT TIME:	5	DATE COUNTED 1" (HD)	
CPM BKG:	5		
CPM 1" BKG:			

CALIBRATED BY: RA JONES HD 0 = 09/25/44

STANDARD ID	SIZE	DATE	TIME	COUNTS @ 0 DEG.	COUNTS @ 90 DEG.	COUNTS @ 180 DEG.	COUNTS @ 270 DEG.
-------------	------	------	------	-----------------	------------------	-------------------	-------------------

32B40A4	2	06/28/89	1510	95552	95030	96367	94943
32B40B3	2	06/28/89	1515	179993	179923	180564	179845
32B40C4	2	06/28/89	1521	266251	266109	266791	262848
32B40A5	5	06/28/89	1526	80056	79664	81559	79720
32B40B6	5	06/28/89	1531	159760	162820	161429	163674
32B40C5	5	06/28/89	1536	234482	235955	237348	236432

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
-------------	------	-----------	---------	------------	----------------	------------

100B40A2	1"	67290	0	0.00	0	0.0000
100B40B1	1"	137800	0	0.00	0	0.0000
100B40C1	1"	199700	0	0.00	0	0.0000

AVERAGE, 1" =	0.0000 +/- 095%	0.0000	ERR %	ON	06/28/89
---------------	-----------------	--------	-------	----	----------

STANDARD ID	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
-------------	-----------	---------	------------	----------------	------------

32B40A4	2"	70480	19090	1.18	22561	0.3201
32B40B3	2"	135100	36011	1.18	42560	0.3150
32B40C4	2"	202400	53095	1.18	62750	0.3100

AVERAGE, 2" =	0.3151 +/- 095%	0.0099	3.13 %	ON	06/28/89
---------------	-----------------	--------	--------	----	----------

STANDARD ID	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
-------------	-----------	---------	------------	----------------	------------

32B40A5	5"	70160	16045	1.18	18963	0.2703
32B40B6	5"	135700	32379	1.18	38267	0.2820
32B40C5	5"	201900	47206	1.18	55790	0.2763

AVERAGE, 5" =	0.2762 +/- 095%	0.0115	4.16 %	ON	06/28/89
---------------	-----------------	--------	--------	----	----------

NEW EFFS FOR DET	18 Co-60	1" =	0.0000	2" =	0.3151
		5" =	0.2762		

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	N/A
PROCEDURE/REV	LA-548-121/C-2
TECHNOLOGIST	D. M. Souuthwick
DATE	January 09, 1990
TEMPERATURE	72 F
STARTING TIME	1230
ENDING TIME	1400
CHEMIST	S. A. Catlow

GEA Analysis

Fusion Dissolution

Detectors 1, 2, 3, & 4

Samples are prepared in batch
but counted randomly.

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0129
2	Reagent Blank	F0308
3	Sample 89-047	F0130
4	Duplicate Sample 89-047	F0131
5	Sample 89-048	F0154
6	Duplicate Sample 89-048	F0155
7	Sample Composite 8	F0294
8	Duplicate Sample Composite 8	F0295
9	Spike Composite 8	F0296
10	Final LMCS Check Std.	F0297
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	89B44/0.5 mL			22 mL
Spike	89B44/0.1 mL	F0294/1.0 mL		22 mL

*
*
* G A M M A S P E C T R U M A N A L Y S I S *
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

27-AUG-90 10:12:00

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 1.0
DETECTOR NUMBER: 4 / GEOMETRY NUMBER: 41
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD4885
ANALYZED BY: VR

SAMPLE DESCRIPTION: F129 SEGMENT F
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 07:02:02

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3032. SECONDS
DEAD TIME: 1.06 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 26-DEC-89
EFFICIENCY CALIBRATION PERFORMED 1-SEP-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	53.64	27.00	1.09	2713.	1439.	11.3	
1B		27.06			123.	34.3	
2	951.26	475.55	1.69	4680.	813.	25.0	CS-134
3C	1126.89	563.35	1.52	3130.	3613.	5.7	CS-134, EU-152
4C	1139.08	569.44	1.52	3058.	6581.	4.5	CS-134, BI-207
5	1209.84	604.81	1.58	3039.	41942.	1.0	CS-134
6	1323.69	661.73	1.64	1970.	65129.	0.8	CS-137
6B		661.35			379.	12.7	
7?	1591.95	795.86	1.72	1709.	30466.	1.5	CS-134
8?	1604.14	801.95	1.72	1656.	2943.	9.1	CS-134
9?	2335.95	1167.96	2.04	1036.	578.	28.6	CS-134
10?	2346.41	1173.19	2.04	916.	27276.	1.5	CO-60
11	2664.98	1332.57	2.28	257.	24755.	1.3	CO-60
12	2730.39	1365.30	2.46	111.	796.	8.2	CS-134
13	2801.12	1400.69	2.37	109.	399.	13.1	BI-214
14	2921.56	1460.96	2.47	90.	813.	7.9	K-40
14B		1460.80			854.	7.1	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY
 ? - MULTIPLET ANALYSIS CONVERGED BUT GFIT > 4
 B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0014
 BACKGROUND DESCRIPTION: BKG
 BACKGROUND COLLECT STARTED ON 8-SEP-89 AT 12:00:00
 BACKGROUND LIVE TIME: 3000. SECONDS

SAMPLE: F129 SEGMENT F

DATA COLLECTED ON 10-JAN-90 AT 07:02:02

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<3.89E-01		LLD<3.89E-01		911.07	
AG-108M	LLD<8.41E-02		LLD<8.41E-02		433.94	
AG-110M	LLD<4.06E-01		LLD<4.06E-01		657.76	
AM-241	LLD<3.93E-01		LLD<3.93E-01		59.54	
AM-243	LLD<9.32E-02		LLD<9.32E-02		74.67	
AR-41	LLD<6.76E-02		LLD<6.76E-02		1293.64	
AU-198	LLD<8.50E-02		LLD<8.50E-02		411.80	
BA-133	LLD<1.05E-01		LLD<1.05E-01		356.02	
BA-139	LLD<2.09E-01		LLD<2.09E-01		165.85	
BA-140	LLD<3.11E-01		LLD<3.11E-01		537.27	
BA-141	LLD<2.03E-01		LLD<2.03E-01		190.23	
BE-7	LLD<8.10E-01		LLD<8.10E-01		477.59	
BI-207	LLD<8.03E-02		LLD<8.03E-02		569.70	
BI-212	LLD<1.09E+00		LLD<1.09E+00		727.27	
BI-214	LLD<6.01E-01		LLD<6.01E-01		609.32	
CD-109	LLD<1.30E+00		LLD<1.30E+00		88.03	
CE-139	LLD<4.73E-02		LLD<4.73E-02		165.85	
CE-141	LLD<7.07E-02		LLD<7.07E-02		145.44	
CEPR144	LLD<6.03E-01		LLD<6.03E-01		133.51	
CO-56	LLD<8.80E-02		LLD<8.80E-02		846.76	
CO-57	LLD<3.83E-02		LLD<3.83E-02		122.06	
CO-58	LLD<8.01E-02		LLD<8.01E-02		810.75	
CO-60	2.28E+01	+ -3.30E-01	2.28E+01	+ -3.30E-01	1332.50	0.07
					1173.24	-0.04
CR-51	LLD<5.78E-01		LLD<5.78E-01		320.09	
CS-134	2.08E+01	+ -3.56E-01	2.08E+01	+ -3.56E-01	795.84	0.02
					604.70	0.12
CS-136	LLD<7.79E-02		LLD<7.79E-02		818.51	
CS-137	3.74E+01	+ -4.12E-01	3.74E+01	+ -4.12E-01	661.65	0.08
CS-138	LLD<8.08E-02		LLD<8.08E-02		1435.86	
EU-152	LLD<2.08E-01		LLD<2.08E-01		1408.01	
EU-154	LLD<1.58E-01		LLD<1.58E-01		1274.45	
EU-155	LLD<1.65E-01		LLD<1.65E-01		105.31	
FE-59	LLD<1.99E-01		LLD<1.99E-01		1099.25	
HF-181	LLD<9.82E-02		LLD<9.82E-02		482.20	
HG-203	LLD<6.67E-02		LLD<6.67E-02		279.20	
I-131	LLD<8.12E-02		LLD<8.12E-02		364.48	
I-132	LLD<9.54E-02		LLD<9.54E-02		667.69	
I-133	LLD<8.96E-02		LLD<8.96E-02		529.69	
I-134	LLD<1.18E-01		LLD<1.18E-01		847.03	
I-135	LLD<2.16E-01		LLD<2.16E-01		1260.41	
K-40	LLD<9.13E-01		LLD<9.13E-01		1460.75	
KR-85	LLD<1.67E+01		LLD<1.67E+01		513.99	
KR-85M	LLD<4.95E-02		LLD<4.95E-02		151.17	
KR-87	LLD<1.81E-01		LLD<1.81E-01		402.58	
KR-89	LLD<2.57E+00		LLD<2.57E+00		220.90	
LA-140	LLD<3.10E-02		LLD<3.10E-02		1596.20	

LA-142	LLD<1.84E-01	LLD<1.84E-01	641.83
MN-54	LLD<8.70E-02	LLD<8.70E-02	834.83
MN-56	LLD<9.93E-02	LLD<9.93E-02	846.76
NA-22	LLD<5.24E-02	LLD<5.24E-02	1274.55
NA-24	LLD<7.27E-02	LLD<7.27E-02	1368.60
NB-94	LLD<6.95E-02	LLD<6.95E-02	702.63
NB-95	LLD<8.08E-02	LLD<8.08E-02	765.78
NB-97	LLD<5.79E-01	LLD<5.79E-01	657.92
NP-238	LLD<3.64E-01	LLD<3.64E-01	984.45
NP-239	LLD<3.80E-01	LLD<3.80E-01	277.60
PA-233	LLD<1.61E-01	LLD<1.61E-01	311.98
PA-234M	LLD<1.85E+01	LLD<1.85E+01	1001.03
PB-210	LLD<1.97E+00	LLD<1.97E+00	465.03
PB-212	LLD<1.30E-01	LLD<1.30E-01	239.00
PB-214	LLD<1.76E-01	LLD<1.76E-01	351.92
PO-210	LLD<7.29E+03	LLD<7.29E+03	804.00
PO-214	LLD<3.77E+03	LLD<3.77E+03	799.70
PO-216	LLD<6.39E+03	LLD<6.39E+03	804.90
PU-239	LLD<5.16E+02	LLD<5.16E+02	129.30
PU-241	LLD<1.85E+04	LLD<1.85E+04	148.57
RA-224	LLD<1.31E+00	LLD<1.31E+00	240.99
RA-226	LLD<1.31E+00	LLD<1.31E+00	186.10
RB-88	LLD<4.01E-01	LLD<4.01E-01	1836.00
RB-89	LLD<4.47E-01	LLD<4.47E-01	1031.88
RN-220	LLD<6.99E+01	LLD<6.99E+01	549.73
RU-103	LLD<8.31E-02	LLD<8.31E-02	497.08
RURH106	LLD<1.46E+00	LLD<1.46E+00	621.80
SB-124	LLD<2.01E-01	LLD<2.01E-01	602.72
SB-125	LLD<5.67E-01	LLD<5.67E-01	176.33
SC-46	LLD<1.10E-01	LLD<1.10E-01	1120.45
SE-75	LLD<9.00E-02	LLD<9.00E-02	264.66
SN-113	LLD<1.10E-01	LLD<1.10E-01	391.67
SR-85	LLD<7.34E-02	LLD<7.34E-02	513.99
SR-91	LLD<1.43E-01	LLD<1.43E-01	555.60
SR-92	LLD<4.88E-02	LLD<4.88E-02	1383.94
TA-182	LLD<2.99E-01	LLD<2.99E-01	1121.30
TC-99M	LLD<3.95E-02	LLD<3.95E-02	140.51
TE-123M	LLD<4.32E-02	LLD<4.32E-02	159.00
TE-125M	LLD<1.25E+01	LLD<1.25E+01	109.27
TE-132	LLD<5.77E-02	LLD<5.77E-02	228.16
TH-228	LLD<4.03E+00	LLD<4.03E+00	84.37
TL-208	LLD<9.94E-02	LLD<9.94E-02	583.14
U-235	LLD<7.27E-02	LLD<7.27E-02	185.71
U-237	LLD<2.34E-01	LLD<2.34E-01	208.00
W-187	LLD<2.38E-01	LLD<2.38E-01	685.74
XE-131M	LLD<1.97E+00	LLD<1.97E+00	163.98
XE-133	LLD<1.46E-01	LLD<1.46E-01	81.00
XE-133M	LLD<4.71E-01	LLD<4.71E-01	233.21
XE-135	LLD<5.38E-02	LLD<5.38E-02	249.79
XE-138	LLD<4.52E-01	LLD<4.52E-01	258.41
Y-88	LLD<3.78E-02	LLD<3.78E-02	1836.06
Y-91	LLD<2.46E+01	LLD<2.46E+01	1204.90
Y-91M	LLD<1.08E-01	LLD<1.08E-01	555.60
ZN-65	LLD<2.35E-01	LLD<2.35E-01	1115.55
ZR-95	LLD<1.36E-01	LLD<1.36E-01	756.73
ZR-97	LLD<7.81E-02	LLD<7.81E-02	743.33

TOTAL 8.10E+01 +-6.36E-01 8.10E+01 +-6.36E-01

STANDARD DEVIATION = 0.06

E BAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.45E-09 UC/LI
TOTAL MEASURED ACTIVITY = 8.10E+01 (+-6.36E-01) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
53.64	27.00	1316.	12.8	1.37E+03
951.26	475.55	813.	25.0	5.46E+00
1126.89	563.35	3613.	5.7	2.83E+01
1139.08	569.44	6581.	4.5	5.21E+01
1604.14	801.95	2943.	9.1	3.19E+01
2335.95	1167.96	578.	28.6	8.80E+00
2730.39	1365.30	796.	8.2	1.39E+01
2801.12	1400.69	399.	13.1	7.10E+00

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
2921.56	1460.96	813.	7.9	1.50E+01

*
* * GAMMA SPECTRUM ANALYSIS *
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

27-AUG-90 09:55:27

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 95.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3888

ANALYZED BY: DM

SAMPLE DESCRIPTION: F-308 SEGMENT-U

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 09:24:49

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3003. SECONDS

DEAD TIME: 0.10 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-OCT-89

EFFICIENCY CALIBRATION PERFORMED 31-JUL-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	2921.30	1460.75	1.81	32.	603.	8.6	K-40
1B		1450.58			611.	5.5	

ERROR QUOTATION AT 1.96 SIGMA
PEAK CONFIDENCE LEVEL AT 95.0%

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0013
BACKGROUND DESCRIPTION: BKG
BACKGROUND COLLECT STARTED ON 15-JAN-90 AT 11:00:00
BACKGROUND LIVE TIME: 7000. SECONDS

SAMPLE: F-308 SEGMENT-U

DATA COLLECTED ON 10-JAN-90 AT 09:24:49

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)	
	MEASURED	DECAY ERROR	CORRECTED	ERROR	EXPECT
AC-228	LLD<1.18E+00		LLD<1.18E+00		911.07
AG-108M	LLD<1.95E-01		LLD<1.95E-01		433.94
AG-110M	LLD<2.98E-01		LLD<2.98E-01		657.76
AM-241	LLD<2.89E-01		LLD<2.89E-01		59.54
AM-243	LLD<2.27E-01		LLD<2.27E-01		74.67
AR-41	LLD<3.19E-01		LLD<3.19E-01		1293.64
AU-198	LLD<1.82E-01		LLD<1.82E-01		411.80
BA-133	LLD<3.07E-01		LLD<3.07E-01		356.02
BA-139	LLD<7.16E-01		LLD<7.16E-01		165.85
BA-140	LLD<8.17E-01		LLD<8.17E-01		537.27
BA-141	LLD<7.54E-01		LLD<7.54E-01		190.23
BE-7	LLD<1.74E+00		LLD<1.74E+00		477.59
BI-207	LLD<1.90E-01		LLD<1.90E-01		569.70
BI-212	LLD<3.10E+00		LLD<3.10E+00		727.27
BI-214	LLD<6.11E-01		LLD<6.11E-01		609.32
CD-109	LLD<3.62E+00		LLD<3.62E+00		88.03
CE-139	LLD<1.62E-01		LLD<1.62E-01		165.85
CE-141	LLD<2.83E-01		LLD<2.83E-01		145.44
CEPR144	LLD<2.49E+00		LLD<2.49E+00		133.51
CO-56	LLD<2.15E-01		LLD<2.15E-01		846.76
CO-57	LLD<1.57E-01		LLD<1.57E-01		122.06
CO-58	LLD<2.19E-01		LLD<2.19E-01		810.75
CO-60	LLD<2.64E-01		LLD<2.64E-01		1332.50
CR-51	LLD<1.62E+00		LLD<1.62E+00		320.09
CS-134	LLD<2.57E-01		LLD<2.57E-01		795.84
CS-136	LLD<2.05E-01		LLD<2.05E-01		818.51
CS-137	LLD<3.20E-01		LLD<3.20E-01		661.65
CS-138	LLD<4.38E-01		LLD<4.38E-01		1435.86
EU-152	LLD<1.35E+00		LLD<1.35E+00		1408.01
EU-154	LLD<7.68E-01		LLD<7.68E-01		1274.45
EU-155	LLD<6.08E-01		LLD<6.08E-01		105.31
FE-59	LLD<5.21E-01		LLD<5.21E-01		1099.25
HF-181	LLD<2.30E-01		LLD<2.30E-01		482.20
HG-203	LLD<1.85E-01		LLD<1.85E-01		279.20
I-131	LLD<2.15E-01		LLD<2.15E-01		364.48
I-132	LLD<2.06E-01		LLD<2.06E-01		667.69
I-133	LLD<2.14E-01		LLD<2.14E-01		529.69
I-134	LLD<3.02E-01		LLD<3.02E-01		847.03
I-135	LLD<9.96E-01		LLD<9.96E-01		1260.41
K-40	LLD<7.39E+00		LLD<7.39E+00		1460.75
KR-85	LLD<5.58E+01		LLD<5.58E+01		513.99
KR-85M	LLD<2.13E-01		LLD<2.13E-01		151.17
KR-87	LLD<4.19E-01		LLD<4.19E-01		402.58
KR-89	LLD<7.87E+00		LLD<7.87E+00		220.90
LA-140	LLD<2.91E-01		LLD<2.91E-01		1596.20
LA-142	LLD<4.85E-01		LLD<4.85E-01		641.83
MN-54	LLD<2.31E-01		LLD<2.31E-01		834.83

MN-56	LLD<2.43E-01	LLD<2.43E-01	846.76
NA-22	LLD<3.03E-01	LLD<3.03E-01	1274.55
NA-24	LLD<2.20E-01	LLD<2.20E-01	1368.60
NB-94	LLD<2.23E-01	LLD<2.23E-01	702.63
NB-95	LLD<2.03E-01	LLD<2.03E-01	765.78
NB-97	LLD<3.61E-01	LLD<3.61E-01	657.92
NP-238	LLD<9.29E-01	LLD<9.29E-01	984.45
NP-239	LLD<1.13E+00	LLD<1.13E+00	277.60
PA-233	LLD<4.34E-01	LLD<4.34E-01	311.98
PA-234M	LLD<4.11E+01	LLD<4.11E+01	1001.03
PB-210	LLD<4.80E+00	LLD<4.80E+00	465.03
PB-212	LLD<3.88E-01	LLD<3.88E-01	239.00
PB-214	LLD<6.20E-01	LLD<6.20E-01	351.92
PO-210	LLD<1.58E+04	LLD<1.58E+04	804.00
PO-214	LLD<2.01E+03	LLD<2.01E+03	799.70
PO-216	LLD<1.05E+04	LLD<1.05E+04	804.90
PU-239	LLD<2.07E+03	LLD<2.07E+03	129.30
PU-241	LLD<7.12E+04	LLD<7.12E+04	148.57
RA-224	LLD<4.28E+00	LLD<4.28E+00	240.99
RA-226	LLD<4.43E+00	LLD<4.43E+00	186.10
RB-88	LLD<2.61E+00	LLD<2.61E+00	1836.00
RB-89	LLD<1.19E+00	LLD<1.19E+00	1031.88
RN-220	LLD<1.84E+02	LLD<1.84E+02	549.73
RU-103	LLD<2.00E-01	LLD<2.00E-01	497.08
RURH106	LLD<3.92E+00	LLD<3.92E+00	621.80
SB-124	LLD<1.84E-01	LLD<1.84E-01	602.72
SB-125	LLD<1.98E+00	LLD<1.98E+00	176.33
SC-46	LLD<3.85E-01	LLD<3.85E-01	1120.45
SE-75	LLD<2.71E-01	LLD<2.71E-01	264.66
SN-113	LLD<2.69E-01	LLD<2.69E-01	391.67
SR-85	LLD<2.45E-01	LLD<2.45E-01	513.99
SR-91	LLD<3.54E-01	LLD<3.54E-01	555.60
SR-92	LLD<4.47E-01	LLD<4.47E-01	1383.94
TA-182	LLD<8.15E-01	LLD<8.15E-01	1121.30
TC-99M	LLD<1.58E-01	LLD<1.58E-01	140.51
TE-123M	LLD<1.57E-01	LLD<1.57E-01	159.00
TE-125M	LLD<4.71E+01	LLD<4.71E+01	109.27
TE-132	LLD<1.81E-01	LLD<1.81E-01	228.16
TH-228	LLD<9.83E+00	LLD<9.83E+00	84.37
TL-208	LLD<3.02E-01	LLD<3.02E-01	583.14
U-235	LLD<2.71E-01	LLD<2.71E-01	185.71
U-237	LLD<7.54E-01	LLD<7.54E-01	208.00
W-187	LLD<7.58E-01	LLD<7.58E-01	685.74
XE-131M	LLD<6.93E+00	LLD<6.93E+00	163.98
XE-133	LLD<3.12E-01	LLD<3.12E-01	81.00
XE-133M	LLD<1.60E+00	LLD<1.60E+00	233.21
XE-135	LLD<1.71E-01	LLD<1.71E-01	249.79
XE-138	LLD<1.38E+00	LLD<1.38E+00	258.41
Y-88	LLD<2.48E-01	LLD<2.48E-01	1836.06
Y-91	LLD<9.78E+01	LLD<9.78E+01	1204.90
Y-91M	LLD<2.67E-01	LLD<2.67E-01	555.60
ZN-65	LLD<6.72E-01	LLD<6.72E-01	1115.55
ZR-95	LLD<3.79E-01	LLD<3.79E-01	756.73
ZR-97	LLD<2.26E-01	LLD<2.26E-01	743.33
<hr/>			
TOTAL	0.00E-01 +-0.00E-01	0.00E-01 +-0.00E-01	

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 95.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
2921.30	1460.75	603.	8.6	1.64E+02

*
*
* G A M M A S P E C T R U M A N A L Y S I S *
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:22:07

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3887
ANALYZED BY: DM

SAMPLE DESCRIPTION: F-294 SEGMENT-G
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E+00
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 08:20:54

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3004. SECONDS
DEAD TIME: 0.13 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-OCT-89
EFFICIENCY CALIBRATION PERFORMED 31-JUL-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	1021.40	510.79	1.91	118.	137.	28.2	RN-222, I-133,
1B		510.92			134.	19.6	TL-208, NA-22,
							ZN-65, RH-106
2	1218.84	609.45	1.12	109.	139.	28.0	BI-214,
2B		609.19			122.	21.0	RU-103
3	1323.00	661.50	1.32	85.	252.	16.6	CS-137
3B		661.41			81.	28.8	
4	2921.39	1460.79	1.97	34.	584.	8.8	K-40
4B		1460.58			611.	5.5	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0013
 BACKGROUND DESCRIPTION: BKG
 BACKGROUND COLLECT STARTED ON 15-JAN-90 AT 11:00:00
 BACKGROUND LIVE TIME: 7000. SECONDS

SAMPLE: F-294 SEGMENT-G

DATA COLLECTED ON 10-JAN-90 AT 08:20:54

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)	
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT
AC-228	LLD<7.52E-01		LLD<7.52E-01		911.07
AG-108M	LLD<1.25E-01		LLD<1.25E-01		433.94
AG-110M	LLD<2.60E-01		LLD<2.60E-01		657.76
AM-241	LLD<1.88E-01		LLD<1.88E-01		59.54
AM-243	LLD<1.49E-01		LLD<1.49E-01		74.67
AR-41	LLD<2.06E-01		LLD<2.06E-01		1293.64
AU-198	LLD<1.19E-01		LLD<1.19E-01		411.80
BA-133	LLD<1.76E-01		LLD<1.76E-01		356.02
BA-139	LLD<4.59E-01		LLD<4.59E-01		165.85
BA-140	LLD<4.97E-01		LLD<4.97E-01		537.27
BA-141	LLD<4.73E-01		LLD<4.73E-01		190.23
BE-7	LLD<1.22E+00		LLD<1.22E+00		477.59
BI-207	LLD<1.23E-01		LLD<1.23E-01		569.70
BI-212	LLD<2.16E+00		LLD<2.16E+00		727.27
BI-214	LLD<4.13E-01		LLD<4.13E-01		609.32
CD-109	LLD<2.27E+00		LLD<2.27E+00		88.03
CE-139	LLD<1.04E-01		LLD<1.04E-01		165.85
CE-141	LLD<1.83E-01		LLD<1.83E-01		145.44
CEPR144	LLD<1.49E+00		LLD<1.49E+00		133.51
CO-56	LLD<1.37E-01		LLD<1.37E-01		846.76
CO-57	LLD<1.00E-01		LLD<1.00E-01		122.06
CO-58	LLD<1.28E-01		LLD<1.28E-01		810.75
CO-60	LLD<1.32E-01		LLD<1.32E-01		1332.50
CR-51	LLD<9.62E-01		LLD<9.62E-01		320.09
CS-134	LLD<1.77E-01		LLD<1.77E-01		795.84
CS-136	LLD<1.28E-01		LLD<1.28E-01		818.51
CS-137	7.80E-01	+2.19E-01	7.80E-01	+2.19E-01	661.65 -0.15
CS-138	LLD<3.48E-01		LLD<3.48E-01		1435.86
EU-152	LLD<9.42E-01		LLD<9.42E-01		1408.01
EU-154	LLD<4.53E-01		LLD<4.53E-01		1274.45
EU-155	LLD<3.89E-01		LLD<3.89E-01		105.31
FE-59	LLD<3.00E-01		LLD<3.00E-01		1099.25
HF-181	LLD<1.39E-01		LLD<1.39E-01		482.20
HG-203	LLD<1.28E-01		LLD<1.28E-01		279.20
I-131	LLD<1.34E-01		LLD<1.34E-01		364.48
I-132	LLD<1.52E-01		LLD<1.52E-01		667.69
I-133	LLD<1.31E-01		LLD<1.31E-01		529.69
I-134	LLD<2.00E-01		LLD<2.00E-01		847.03
I-135	LLD<5.62E-01		LLD<5.62E-01		1260.41
K-40	LLD<4.75E+00		LLD<4.75E+00		1460.75
KR-85	LLD<3.76E+01		LLD<3.76E+01		513.99
KR-85M	LLD<1.35E-01		LLD<1.35E-01		151.17
KR-87	LLD<2.72E-01		LLD<2.72E-01		402.58
KR-89	LLD<5.17E+00		LLD<5.17E+00		220.90
LA-140	LLD<1.51E-01		LLD<1.51E-01		1596.20
LA-142	LLD<3.36E-01		LLD<3.36E-01		641.83
MN-54	LLD<1.51E-01		LLD<1.51E-01		834.83

MN-56	LLD<1.55E-01	LLD<1.55E-01	846.76
NA-22	LLD<1.65E-01	LLD<1.65E-01	1274.55
NA-24	LLD<1.18E-01	LLD<1.18E-01	1368.60
NB-94	LLD<1.17E-01	LLD<1.17E-01	702.63
NB-95	LLD<1.50E-01	LLD<1.50E-01	765.78
NB-97	LLD<3.16E-01	LLD<3.16E-01	657.92
NP-237	LLD<6.16E-01	LLD<6.16E-01	86.50
NP-238	LLD<6.35E-01	LLD<6.35E-01	984.45
NP-239	LLD<7.17E-01	LLD<7.17E-01	277.60
PA-233	LLD<2.82E-01	LLD<2.82E-01	311.98
PA-234M	LLD<2.44E+01	LLD<2.44E+01	1001.03
PB-210	LLD<2.84E+00	LLD<2.84E+00	465.03
PB-212	LLD<2.51E-01	LLD<2.51E-01	239.00
PB-214	LLD<3.89E-01	LLD<3.89E-01	351.92
PO-210	LLD<1.07E+04	LLD<1.07E+04	804.00
PO-214	LLD<1.32E+03	LLD<1.32E+03	799.70
PO-216	LLD<7.61E+03	LLD<7.61E+03	804.90
PU-239	LLD<1.34E+03	LLD<1.34E+03	129.30
PU-241	LLD<4.44E+04	LLD<4.44E+04	148.57
RA-224	LLD<2.86E+00	LLD<2.86E+00	240.99
RA-226	LLD<2.86E+00	LLD<2.86E+00	186.10
RB-88	LLD<1.35E+00	LLD<1.35E+00	1836.00
RB-89	LLD<6.50E-01	LLD<6.50E-01	1031.88
RN-220	LLD<1.14E+02	LLD<1.14E+02	549.73
RU-103	LLD<1.34E-01	LLD<1.34E-01	497.08
RURH106	LLD<2.70E+00	LLD<2.70E+00	621.80
SB-124	LLD<1.28E-01	LLD<1.28E-01	602.72
SB-125	LLD<1.32E+00	LLD<1.32E+00	176.33
SC-46	LLD<2.32E-01	LLD<2.32E-01	1120.45
SE-75	LLD<1.70E-01	LLD<1.70E-01	264.66
SN-113	LLD<1.76E-01	LLD<1.76E-01	391.67
SR-85	LLD<1.65E-01	LLD<1.65E-01	513.99
SR-91	LLD<2.14E-01	LLD<2.14E-01	555.60
SR-92	LLD<1.88E-01	LLD<1.88E-01	1383.94
TA-182	LLD<5.08E-01	LLD<5.08E-01	1121.30
TC-99M	LLD<1.01E-01	LLD<1.01E-01	140.51
TE-123M	LLD<9.96E-02	LLD<9.96E-02	159.00
TE-125M	LLD<2.94E+01	LLD<2.94E+01	109.27
TE-132	LLD<1.17E-01	LLD<1.17E-01	228.16
TH-228	LLD<6.22E+00	LLD<6.22E+00	84.37
TL-208	LLD<1.91E-01	LLD<1.91E-01	583.14
U-235	LLD<1.71E-01	LLD<1.71E-01	185.71
U-237	LLD<4.90E-01	LLD<4.90E-01	208.00
W-187	LLD<5.09E-01	LLD<5.09E-01	685.74
XE-131M	LLD<4.39E+00	LLD<4.39E+00	163.98
XE-133	LLD<2.04E-01	LLD<2.04E-01	81.00
XE-133M	LLD<1.02E+00	LLD<1.02E+00	233.21
XE-135	LLD<1.19E-01	LLD<1.19E-01	249.79
XE-138	LLD<8.55E-01	LLD<8.55E-01	258.41
Y-88	LLD<1.28E-01	LLD<1.28E-01	1836.06
Y-91	LLD<6.70E+01	LLD<6.70E+01	1204.90
Y-91M	LLD<1.62E-01	LLD<1.62E-01	555.60
ZN-65	LLD<4.37E-01	LLD<4.37E-01	1115.55
ZR-95	LLD<2.55E-01	LLD<2.55E-01	756.73
ZR-97	LLD<1.22E-01	LLD<1.22E-01	743.33
<hr/>			
TOTAL	7.80E-01 +-2.19E-01	7.80E-01 +-2.19E-01	

EBAR = ***** MEV/DISINTEGRATION
 MAXIMUM PERMISSABLE ACTIVITY = 1.16E-08 UC/LI

TOTAL MEASURED ACTIVITY = 7.80E-01 (+-2.19E-01) UC/LI
% TECH. SPEC. = ***** (+****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1021.40	510.79	137.	28.2	1.60E+01
1218.84	609.45	139.	28.0	1.87E+01
2921.39	1460.79	584.	8.8	1.59E+02

*
*
* G A M M A S P E C T R U M A N A L Y S I S *
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:26:38

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 1.0
DETECTOR NUMBER: 4 / GEOMETRY NUMBER: 41
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD4886

ANALYZED BY: DM

SAMPLE DESCRIPTION: F-295 SEGMENT-H

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 08:24:03

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3003. SECONDS

DEAD TIME: 0.10 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 26-DEC-89

EFFICIENCY CALIBRATION PERFORMED 1-SEP-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	53.01	26.69	1.09	233.	133.	35.1	
1B		27.06			123.	34.3	
2C	1022.13	510.98	2.34	414.	359.	22.2	RN-222, I-133,
2B		510.74			335.	16.9	TL-208, NA-22, ZN-65, RH-106
3	1166.85	583.32	1.81	178.	146.	31.4	EU-154,
3B		583.17			120.	39.2	TL-208
4	1218.72	609.25	1.74	169.	161.	28.3	BI-214,
4B		609.25			197.	22.8	RU-103
5	1323.65	661.71	1.67	165.	3382.	3.6	CS-137
5B		661.35			379.	12.7	
6	1822.63	911.21	2.20	120.	91.	42.6	
6B		910.95			144.	27.4	
7	2921.45	1460.90	2.13	36.	802.	7.4	K-40
7B		1460.80			854.	7.1	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0014

BACKGROUND DESCRIPTION: BKG

BACKGROUND COLLECT STARTED ON 8-SEP-89 AT 12:00:00

BACKGROUND LIVE TIME: 3000. SECONDS

SAMPLE: F-295 SEGMENT-H
 DATA COLLECTED ON 10-JAN-90 AT 08:24:03
 DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN $\mu\text{Ci/LI}$			ENERGY COMPARISON (KEV)		
	MEASURED	DECAY ERROR	CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<7.66E-02		LLD<7.66E-02		911.07	
AG-108M	LLD<1.06E-02		LLD<1.06E-02		433.94	
AG-110M	LLD<4.74E-02		LLD<4.74E-02		657.76	
AM-241	LLD<6.55E-02		LLD<6.55E-02		59.54	
AM-243	LLD<1.69E-02		LLD<1.69E-02		74.67	
AR-41	LLD<1.77E-02		LLD<1.77E-02		1293.64	
AU-198	LLD<1.11E-02		LLD<1.11E-02		411.80	
BA-133	LLD<1.62E-02		LLD<1.62E-02		356.02	
BA-139	LLD<3.71E-02		LLD<3.71E-02		165.85	
BA-140	LLD<4.06E-02		LLD<4.06E-02		537.27	
BA-141	LLD<3.39E-02		LLD<3.39E-02		190.23	
BE-7	LLD<9.78E-02		LLD<9.78E-02		477.59	
BI-207	LLD<1.02E-02		LLD<1.02E-02		569.70	
BI-212	LLD<1.55E-01		LLD<1.55E-01		727.27	
BI-214	LLD<3.65E-02		LLD<3.65E-02		609.32	
CD-109	LLD<2.44E-01		LLD<2.44E-01		88.03	
CE-139	LLD<8.39E-03		LLD<8.39E-03		165.85	
CE-141	LLD<1.22E-02		LLD<1.22E-02		145.44	
CEPR144	LLD<1.03E-01		LLD<1.03E-01		133.51	
CO-56	LLD<1.10E-02		LLD<1.10E-02		846.76	
CO-57	LLD<6.83E-03		LLD<6.83E-03		122.06	
CO-58	LLD<1.01E-02		LLD<1.01E-02		810.75	
CO-60	LLD<1.28E-02		LLD<1.28E-02		1332.50	
CR-51	LLD<8.22E-02		LLD<8.22E-02		320.09	
CS-134	LLD<1.21E-02		LLD<1.21E-02		795.84	
CS-136	LLD<9.40E-03		LLD<9.40E-03		818.51	
CS-137	8.67E-01	+3.79E-02	8.67E-01	+3.79E-02	661.65	0.06
CS-138	LLD<3.01E-02		LLD<3.01E-02		1435.86	
EU-152	LLD<6.52E-02		LLD<6.52E-02		1408.01	
EU-154	LLD<4.04E-02		LLD<4.04E-02		1274.45	
EU-155	LLD<2.85E-02		LLD<2.85E-02		105.31	
FE-59	LLD<2.47E-02		LLD<2.47E-02		1099.25	
HF-181	LLD<1.33E-02		LLD<1.33E-02		482.20	
HG-203	LLD<1.01E-02		LLD<1.01E-02		279.20	
I-131	LLD<1.05E-02		LLD<1.05E-02		364.48	
I-132	LLD<1.22E-02		LLD<1.22E-02		667.69	
I-133	LLD<1.14E-02		LLD<1.14E-02		529.69	
I-134	LLD<1.47E-02		LLD<1.47E-02		847.03	
I-135	LLD<5.14E-02		LLD<5.14E-02		1260.41	
K-40	LLD<4.38E-01		LLD<4.38E-01		1460.75	
KR-85	LLD<3.04E+00		LLD<3.04E+00		513.99	
KR-85M	LLD<8.46E-03		LLD<8.46E-03		151.17	
KR-87	LLD<2.38E-02		LLD<2.38E-02		402.58	
KR-89	LLD<3.97E-01		LLD<3.97E-01		220.90	
LA-140	LLD<1.30E-02		LLD<1.30E-02		1596.20	
LA-142	LLD<2.54E-02		LLD<2.54E-02		641.83	
MN-54	LLD<1.03E-02		LLD<1.03E-02		834.83	

MN-56	LLD<1.25E-02	LLD<1.25E-02	846.76
NA-22	LLD<1.33E-02	LLD<1.33E-02	1274.55
NA-24	LLD<1.46E-02	LLD<1.46E-02	1368.60
NB-94	LLD<1.00E-02	LLD<1.00E-02	702.63
NB-95	LLD<1.18E-02	LLD<1.18E-02	765.78
NB-97	LLD<6.69E-02	LLD<6.69E-02	657.92
NP-237	LLD<6.88E-02	LLD<6.88E-02	86.50
NP-238	LLD<4.16E-02	LLD<4.16E-02	984.45
NP-239	LLD<5.79E-02	LLD<5.79E-02	277.60
PA-233	LLD<2.32E-02	LLD<2.32E-02	311.98
PA-234M	LLD<2.10E+00	LLD<2.10E+00	1001.03
PB-210	LLD<2.63E-01	LLD<2.63E-01	465.03
PB-212	LLD<2.74E-02	LLD<2.74E-02	239.00
PB-214	LLD<2.29E-02	LLD<2.29E-02	351.92
PO-210	LLD<8.60E+02	LLD<8.60E+02	804.00
PO-214	LLD<1.12E+02	LLD<1.12E+02	799.70
PO-216	LLD<5.36E+02	LLD<5.36E+02	804.90
PU-239	LLD<9.01E+01	LLD<9.01E+01	129.30
PU-241	LLD<3.29E+03	LLD<3.29E+03	148.57
RA-224	LLD<2.12E-01	LLD<2.12E-01	240.99
RA-226	LLD<2.15E-01	LLD<2.15E-01	186.10
RB-88	LLD<1.16E-01	LLD<1.16E-01	1836.00
RB-89	LLD<5.39E-02	LLD<5.39E-02	1031.88
RN-220	LLD<8.42E+00	LLD<8.42E+00	549.73
RU-103	LLD<1.05E-02	LLD<1.05E-02	497.08
RURH106	LLD<1.91E-01	LLD<1.91E-01	621.80
SB-124	LLD<1.00E-02	LLD<1.00E-02	602.72
SB-125	LLD<9.46E-02	LLD<9.46E-02	176.33
SC-46	LLD<1.17E-02	LLD<1.17E-02	1120.45
SE-75	LLD<1.35E-02	LLD<1.35E-02	264.66
SN-113	LLD<1.45E-02	LLD<1.45E-02	391.67
SR-85	LLD<1.33E-02	LLD<1.33E-02	513.99
SR-91	LLD<1.76E-02	LLD<1.76E-02	555.60
SR-92	LLD<1.57E-02	LLD<1.57E-02	1383.94
TA-182	LLD<3.21E-02	LLD<3.21E-02	1121.30
TC-99M	LLD<6.95E-03	LLD<6.95E-03	140.51
TE-123M	LLD<7.50E-03	LLD<7.50E-03	159.00
TE-125M	LLD<2.17E+00	LLD<2.17E+00	109.27
TE-132	LLD<8.96E-03	LLD<8.96E-03	228.16
TH-228	LLD<6.79E-01	LLD<6.79E-01	84.37
TL-208	LLD<1.86E-02	LLD<1.86E-02	583.14
U-235	LLD<1.20E-02	LLD<1.20E-02	185.71
U-237	LLD<3.72E-02	LLD<3.72E-02	208.00
W-187	LLD<3.57E-02	LLD<3.57E-02	685.74
XE-131M	LLD<3.34E-01	LLD<3.34E-01	163.98
XE-133	LLD<2.73E-02	LLD<2.73E-02	81.00
XE-133M	LLD<7.60E-02	LLD<7.60E-02	233.21
XE-135	LLD<8.54E-03	LLD<8.54E-03	249.79
XE-138	LLD<6.66E-02	LLD<6.66E-02	258.41
Y-88	LLD<1.10E-02	LLD<1.10E-02	1836.06
Y-91	LLD<5.12E+00	LLD<5.12E+00	1204.90
Y-91M	LLD<1.33E-02	LLD<1.33E-02	555.60
ZN-65	LLD<3.83E-02	LLD<3.83E-02	1115.55
ZR-95	LLD<2.02E-02	LLD<2.02E-02	756.73
ZR-97	LLD<1.10E-02	LLD<1.10E-02	743.33
<hr/>			
TOTAL	8.67E-01 +3.79E-02	8.67E-01 +3.79E-02	

E BAR = ***** MEV/DISINTEGRATION
 MAXIMUM PERMISSABLE ACTIVITY = 1.16E-08 UC/LI

TOTAL MEASURED ACTIVITY = 8.67E-01 (+-3.79E-02) UC/LI
% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
53.01	26.69	133.	35.1	1.51E+02
1022.13	510.98	359.	22.2	2.57E+00
1166.85	583.32	146.	31.4	1.18E+00
1218.72	609.25	161.	28.3	1.36E+00
1822.63	911.21	91.	42.6	1.11E+00
2921.45	1460.90	802.	7.4	1.48E+01

* * * * * GAMMA SPECTRUM ANALYSIS *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

27-AUG-90 09:32:44

ANALYSIS PARAMETERS

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 1.0
DETECTOR NUMBER: 1 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD1009

ANALYZED BY: DM

SAMPLE DESCRIPTION: F-296 SEGMENT-1

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LT / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 FA

ANALYSIS LIBRARY FILE: ANI000

COLLECT STARTED ON 10-JAN-90 AT 09:18:56

COLLECT LIVE TIME: 3000 SECONDS

REAL TIME: 3002 SECONDS

DEAD TIME: 0.07 %

DECAYED TO 0. DAYS. 0.0000 HOURS BEFORE THE START OF COLLECT.

ENERGY CALIBRATION PERFORMED 23-NOV-89
EFFICIENCY CALIBRATION PERFORMED 2-MAR-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1126.55	562.75	1.40	158.	198.	21.1	CS-134, EU-152
2C	1138.99	568.97	1.40	143.	321.	18.3	CS-134, BI-207
3C	1209.70	604.31	1.41	135.	1733.	5.8	CS-134
4C	1218.83	608.87	1.41	126.	36.	33.0	BI-214, RU-103
5	1323.55	661.22	1.57	105.	3132.	3.6	CS-137
5B		661.82			35.	46.4	
6C	1591.90	795.38	1.54	68.	1260.	6.4	CS-134
7C	1604.08	801.47	1.54	70.	118.	13.7	CS-134
8	2346.30	1172.70	1.78	66.	1128.	6.2	CO-60
9	2664.77	1332.06	1.93	7.	1107.	5.9	CO-60
10	2730.32	1364.87	2.34	11.	31.	49.8	CS-134
11	2921.09	1460.35	1.56	5.	166.	15.8	K-40
11B		1461.77			182.	11.2	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0011

BACKGROUND DESCRIPTION: BK0011

BACKGROUND COLLECT STARTED ON 10-JAN-85 AT 12:00:00

BACKGROUND LIVE TIME: 6000. SECONDS

222-S COUNTING ROOM

27-AUG-90 09:32:44

SAMPLE: F-296 SEGMENT-I

DATA COLLECTED ON 10-JAN-90 AT 09:18:56

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	(KEV) EXPECT	DIFF
AC-228	LLD<2.18E-01		LLD<2.18E-01		911.07	
AG-108M	LLD<6.07E-02		LLD<6.07E-02		433.94	
AG-110M	LLD<2.70E-01		LLD<2.70E-01		657.76	
AM-241	LLD<2.65E-01		LLD<2.65E-01		59.54	
AM-243	LLD<6.45E-02		LLD<6.45E-02		74.67	
AR-41	LLD<3.67E-02		LLD<3.67E-02		1293.64	
AU-198	LLD<5.20E-02		LLD<5.20E-02		411.80	
BA-133	LLD<8.08E-02		LLD<8.08E-02		356.02	
BA-139	LLD<1.65E-01		LLD<1.65E-01		165.85	
BA-140	LLD<2.00E-01		LLD<2.00E-01		537.27	
BA-141	LLD<1.61E-01		LLD<1.61E-01		190.23	
BE-7	LLD<5.10E-01		LLD<5.10E-01		477.59	
BI-207	LLD<5.12E-02		LLD<5.12E-02		569.70	
BI-212	LLD<6.79E-01		LLD<6.79E-01		727.27	
BI-214	LLD<2.38E-01		LLD<2.38E-01		609.32	
CD-109	LLD<1.03E+00		LLD<1.03E+00		88.03	
CE-139	LLD<3.73E-02		LLD<3.73E-02		165.85	
CE-141	LLD<5.54E-02		LLD<5.54E-02		145.44	
CEPR144	LLD<4.71E-01		LLD<4.71E-01		133.51	
CO-56	LLD<5.17E-02		LLD<5.17E-02		846.76	
CO-57	LLD<3.12E-02		LLD<3.12E-02		122.06	
CO-58	LLD<5.26E-02		LLD<5.26E-02		810.75	
CO-60	2.63E+00	+1.59E-01	2.63E+00	+1.59E-01	1332.50	-0.44
					1173.24	-0.54
CR-51	LLD<4.26E-01		LLD<4.26E-01		320.09	
CS-134	2.27E+00	+1.49E-01	2.27E+00	+1.49E-01	795.84	-0.47
					604.70	-0.39
CS-136	LLD<4.99E-02		LLD<4.99E-02		818.51	
CS-137	4.81E+00	+1.88E-01	4.81E+00	+1.88E-01	661.65	-0.43
CS-138	LLD<6.42E-02		LLD<6.42E-02		1435.86	
EU-152	LLD<1.30E-01		LLD<1.30E-01		1408.01	
EU-154	LLD<9.67E-02		LLD<9.67E-02		1274.45	
EU-155	LLD<1.22E-01		LLD<1.22E-01		105.31	
FE-59	LLD<1.11E-01		LLD<1.11E-01		1099.25	
HF-181	LLD<5.98E-02		LLD<5.98E-02		482.20	
HG-203	LLD<4.99E-02		LLD<4.99E-02		279.20	
I-131	LLD<6.21E-02		LLD<6.21E-02		364.48	
I-132	LLD<5.81E-02		LLD<5.81E-02		667.69	
I-133	LLD<5.73E-02		LLD<5.73E-02		529.69	
I-134	LLD<7.22E-02		LLD<7.22E-02		847.03	
I-135	LLD<1.49E-01		LLD<1.49E-01		1260.41	
K-40	LLD<9.06E-01		LLD<9.06E-01		1460.75	
KR-85	LLD<1.31E+01		LLD<1.31E+01		513.99	
KR-85M	LLD<3.55E-02		LLD<3.55E-02		151.17	
KR-87	LLD<1.31E-01		LLD<1.31E-01		402.58	
KR-89	LLD<2.02E+00		LLD<2.02E+00		220.90	
LA-140	LLD<3.91E-02		LLD<3.91E-02		1596.20	

LA-142	LLD<1.28E-01	LLD<1.28E-01	641.83
MN-54	LLD<5.15E-02	LLD<5.15E-02	834.83
MN-56	LLD<5.83E-02	LLD<5.83E-02	846.76
NA-22	LLD<3.24E-02	LLD<3.24E-02	1274.55
NA-24	LLD<5.26E-02	LLD<5.26E-02	1368.60
NB-94	LLD<4.51E-02	LLD<4.51E-02	702.63
NB-95	LLD<4.59E-02	LLD<4.59E-02	765.78
NB-97	LLD<3.27E-01	LLD<3.27E-01	657.92
NP-238	LLD<1.94E-01	LLD<1.94E-01	984.45
NP-239	LLD<2.84E-01	LLD<2.84E-01	277.60
PA-233	LLD<1.19E-01	LLD<1.19E-01	311.98
PA-234M	LLD<1.01E+01	LLD<1.01E+01	1001.03
PB-210	LLD<1.41E+00	LLD<1.41E+00	465.03
PB-212	LLD<9.29E-02	LLD<9.29E-02	239.00
PB-214	LLD<1.31E-01	LLD<1.31E-01	351.92
PO-210	LLD<5.05E+03	LLD<5.05E+03	804.00
PO-214	LLD<1.93E+03	LLD<1.93E+03	799.70
PO-216	LLD<4.01E+03	LLD<4.01E+03	804.90
PU-239	LLD<4.03E+02	LLD<4.03E+02	129.30
PU-241	LLD<1.49E+04	LLD<1.49E+04	148.57
RA-224	LLD<9.95E-01	LLD<9.95E-01	240.99
RA-226	LLD<8.94E-01	LLD<8.94E-01	186.10
RB-88	LLD<3.69E-02	LLD<3.69E-02	1836.00
RB-89	LLD<2.54E-01	LLD<2.54E-01	1031.88
RN-220	LLD<4.40E+01	LLD<4.40E+01	549.73
RU-103	LLD<5.29E-02	LLD<5.29E-02	497.08
RURH106	LLD<8.84E-01	LLD<8.84E-01	621.80
SB-124	LLD<6.69E-02	LLD<6.69E-02	602.72
SB-125	LLD<4.61E-01	LLD<4.61E-01	176.33
SC-46	LLD<5.84E-02	LLD<5.84E-02	1120.45
SE-75	LLD<6.48E-02	LLD<6.48E-02	264.66
SN-113	LLD<7.31E-02	LLD<7.31E-02	391.67
SR-85	LLD<5.75E-02	LLD<5.75E-02	513.99
SR-91	LLD<9.13E-02	LLD<9.13E-02	555.60
SR-92	LLD<2.99E-02	LLD<2.99E-02	1383.94
TA-182	LLD<1.52E-01	LLD<1.52E-01	1121.30
TC-99M	LLD<3.11E-02	LLD<3.11E-02	140.51
TE-123M	LLD<3.60E-02	LLD<3.60E-02	159.00
TE-125M	LLD<8.79E+00	LLD<8.79E+00	109.27
TE-132	LLD<4.28E-02	LLD<4.28E-02	228.16
TH-228	LLD<3.13E+00	LLD<3.13E+00	84.37
TL-208	LLD<6.31E-02	LLD<6.31E-02	583.14
U-235	LLD<5.90E-02	LLD<5.90E-02	185.71
U-237	LLD<1.67E-01	LLD<1.67E-01	208.00
W-187	LLD<1.59E-01	LLD<1.59E-01	685.74
XE-131M	LLD<1.58E+00	LLD<1.58E+00	163.98
XE-133	LLD<1.11E-01	LLD<1.11E-01	81.00
XE-133M	LLD<3.83E-01	LLD<3.83E-01	233.21
XE-135	LLD<4.23E-02	LLD<4.23E-02	249.79
XE-138	LLD<3.23E-01	LLD<3.23E-01	258.41
Y-88	LLD<3.50E-03	LLD<3.50E-03	1836.06
Y-91	LLD<1.32E+01	LLD<1.32E+01	1204.90
Y-91M	LLD<6.90E-02	LLD<6.90E-02	555.60
ZN-65	LLD<1.33E-01	LLD<1.33E-01	1115.55
ZR-95	LLD<9.94E-02	LLD<9.94E-02	756.73
ZR-97	LLD<4.96E-02	LLD<4.96E-02	743.33

TOTAL 9.71E+00 +-2.87E-01 9.71E+00 +-2.87E-01

STANDARD DEVIATION = 0.05

E BAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.53E-09 UC/LI
TOTAL MEASURED ACTIVITY = 9.71E+00 (+-2.87E-01) UC/LI
% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1126.55	562.75	198.	21.1	8.47E+00
1138.99	568.97	321.	18.3	1.39E+01
1604.08	801.47	118.	13.7	6.74E+00
2730.32	1364.87	31.	49.8	2.75E+00

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1218.83	608.87	36.	33.0	1.63E+00
2921.09	1460.35	166.	15.8	1.58E+01

* G A M M A S P E C T R U M A N A L Y S I S *
* *****

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

27-AUG-90 09:45:56

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 2.0
DETECTOR NUMBER: 2 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD2749
ANALYZED BY: DM

SAMPLE DESCRIPTION: F-297 SEGMENT-J
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 09:21:40

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3005. SECONDS
DEAD TIME: 0.17 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-MAR-89
EFFICIENCY CALIBRATION PERFORMED 21-OCT-88

222-S COUNTING ROOM

27-AUG-90 09:45:56

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1127.84	563.55	1.49	552.	502.	14.2	CS-134, EU-152
2C	1139.68	569.47	1.49	485.	956.	11.6	CS-134, BI-207
3	1210.48	604.86	1.70	502.	5996.	2.8	CS-134
4	1324.35	661.79	1.70	366.	8782.	2.2	CS-137
4B		661.85			36.	13.9	
5C	1592.56	795.87	1.70	266.	4293.	3.7	CS-134
6C	1604.64	801.91	1.70	270.	387.	12.5	CS-134
7	2347.01	1173.06	1.94	221.	3775.	3.4	CO-60
8	2665.46	1332.27	2.16	36.	3437.	3.4	CO-60
8B		1332.24			9.	37.4	
9	2731.09	1365.09	2.99	19.	113.	22.4	CS-134
10	2921.55	1460.32	2.32	22.	128.	21.3	K-40
10B		1460.85			156.	3.8	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0012

BACKGROUND DESCRIPTION: BKG

BACKGROUND COLLECT STARTED ON 30-AUG-88 AT 16:46:00

BACKGROUND LIVE TIME: 60000. SECONDS

222-S COUNTING ROOM

27-AUG-90 09:45:56

SAMPLE: F-297 SEGMENT-J

DATA COLLECTED ON 10-JAN-90 AT 09:21:40

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON	
	MEASURED	ERROR	DECAY CORRECTED	ERROR	(KEV) EXPECT
AC-228	LLD<1.12E+00		LLD<1.12E+00		911.07
AG-108M	LLD<2.84E-01		LLD<2.84E-01		433.94
AG-110M	LLD<1.35E+00		LLD<1.35E+00		657.76
AM-241	LLD<1.32E+00		LLD<1.32E+00		59.54
AM-243	LLD<3.41E-01		LLD<3.41E-01		74.67
AR-41	LLD<2.19E-01		LLD<2.19E-01		1293.64
AU-198	LLD<2.56E-01		LLD<2.56E-01		411.80
BA-133	LLD<3.36E-01		LLD<3.36E-01		356.02
BA-139	LLD<7.17E-01		LLD<7.17E-01		165.85
BA-140	LLD<1.03E+00		LLD<1.03E+00		537.27
BA-141	LLD<6.88E-01		LLD<6.88E-01		190.23
BE-7	LLD<2.47E+00		LLD<2.47E+00		477.59
BI-207	LLD<2.57E-01		LLD<2.57E-01		569.70
BI-212	LLD<3.76E+00		LLD<3.76E+00		727.27
BI-214	LLD<2.05E+00		LLD<2.05E+00		609.32
CD-109	LLD<4.30E+00		LLD<4.30E+00		88.03
CE-139	LLD<1.62E-01		LLD<1.62E-01		165.85
CE-141	LLD<2.59E-01		LLD<2.59E-01		145.44
CEPR144	LLD<2.06E+00		LLD<2.06E+00		133.51
CO-56	LLD<2.46E-01		LLD<2.46E-01		846.76
CO-57	LLD<1.33E-01		LLD<1.33E-01		122.06
CO-58	LLD<2.38E-01		LLD<2.38E-01		810.75
CO-60	2.25E+01	+8.14E-01	2.25E+01	+8.14E-01	1332.50 -0.23 1173.24 -0.18
CR-51	LLD<1.94E+00		LLD<1.94E+00		320.09
CS-134	2.16E+01	+8.27E-01	2.16E+01	+8.27E-01	795.84 0.03 604.70 0.16
CS-136	LLD<2.71E-01		LLD<2.71E-01		818.51
CS-137	3.78E+01	+9.55E-01	3.78E+01	+9.55E-01	661.65 0.14
CS-138	LLD<2.37E-01		LLD<2.37E-01		1435.86
EU-152	LLD<4.57E-01		LLD<4.57E-01		1408.01
EU-154	LLD<4.77E-01		LLD<4.77E-01		1274.45
EU-155	LLD<6.04E-01		LLD<6.04E-01		105.31
FE-59	LLD<5.62E-01		LLD<5.62E-01		1099.25
HF-181	LLD<2.98E-01		LLD<2.98E-01		482.20
HG-203	LLD<2.09E-01		LLD<2.09E-01		279.20
I-131	LLD<2.65E-01		LLD<2.65E-01		364.48
I-132	LLD<7.54E-01		LLD<7.54E-01		667.69
I-133	LLD<2.71E-01		LLD<2.71E-01		529.69
I-134	LLD<3.69E-01		LLD<3.69E-01		847.03
I-135	LLD<5.49E-01		LLD<5.49E-01		1260.41
K-40	LLD<2.21E+00		LLD<2.21E+00		1460.75
KR-85	LLD<5.81E+01		LLD<5.81E+01		513.99
KR-85M	LLD<1.64E-01		LLD<1.64E-01		151.17
KR-87	LLD<5.89E-01		LLD<5.89E-01		402.58
KR-89	LLD<8.53E+00		LLD<8.53E+00		220.90
LA-140	LLD<1.40E-01		LLD<1.40E-01		1596.20

LA-142	LLD<5.70E-01	LLD<5.70E-01	641.83
MN-54	LLD<2.34E-01	LLD<2.34E-01	834.83
MN-56	LLD<2.78E-01	LLD<2.78E-01	846.76
NA-22	LLD<1.69E-01	LLD<1.69E-01	1274.55
NA-24	LLD<2.34E-01	LLD<2.34E-01	1368.60
NB-94	LLD<2.25E-01	LLD<2.25E-01	702.63
NB-95	LLD<2.39E-01	LLD<2.39E-01	765.78
NB-97	LLD<1.53E+00	LLD<1.53E+00	657.92
NP-238	LLD<1.05E+00	LLD<1.05E+00	984.45
NP-239	LLD<1.26E+00	LLD<1.26E+00	277.60
PA-233	LLD<5.16E-01	LLD<5.16E-01	311.98
PA-234M	LLD<5.09E+01	LLD<5.09E+01	1001.03
PB-210	LLD<6.30E+00	LLD<6.30E+00	465.03
PB-212	LLD<3.92E-01	LLD<3.92E-01	239.00
PB-214	LLD<5.51E-01	LLD<5.51E-01	351.92
PO-210	LLD<2.06E+04	LLD<2.06E+04	804.00
PO-214	LLD<9.92E+03	LLD<9.92E+03	799.70
PO-216	LLD<1.55E+04	LLD<1.55E+04	804.90
PU-239	LLD<1.98E+03	LLD<1.98E+03	129.30
PU-241	LLD<6.31E+04	LLD<6.31E+04	148.57
RA-224	LLD<4.15E+00	LLD<4.15E+00	240.99
RA-226	LLD<3.73E+00	LLD<3.73E+00	186.10
RB-88	LLD<1.02E+00	LLD<1.02E+00	1836.00
RB-89	LLD<1.28E+00	LLD<1.28E+00	1031.88
RN-220	LLD<2.12E+02	LLD<2.12E+02	549.73
RU-103	LLD<2.59E-01	LLD<2.59E-01	497.08
RURH106	LLD<4.54E+00	LLD<4.54E+00	621.80
SB-124	LLD<5.40E-01	LLD<5.40E-01	602.72
SB-125	LLD<2.03E+00	LLD<2.03E+00	176.33
SC-46	LLD<2.87E-01	LLD<2.87E-01	1120.45
SE-75	LLD<3.02E-01	LLD<3.02E-01	264.66
SN-113	LLD<3.62E-01	LLD<3.62E-01	391.67
SR-85	LLD<2.55E-01	LLD<2.55E-01	513.99
SR-91	LLD<4.78E-01	LLD<4.78E-01	555.60
SR-92	LLD<1.72E-01	LLD<1.72E-01	1383.94
TA-182	LLD<8.32E-01	LLD<8.32E-01	1121.30
TC-99M	LLD<1.37E-01	LLD<1.37E-01	140.51
TE-123M	LLD<1.53E-01	LLD<1.53E-01	159.00
TE-125M	LLD<4.21E+01	LLD<4.21E+01	109.27
TE-132	LLD<1.84E-01	LLD<1.84E-01	228.16
TH-228	LLD<1.44E+01	LLD<1.44E+01	84.37
TL-208	LLD<3.02E-01	LLD<3.02E-01	583.14
U-235	LLD<2.48E-01	LLD<2.48E-01	185.71
U-237	LLD<7.17E-01	LLD<7.17E-01	208.00
W-187	LLD<8.09E-01	LLD<8.09E-01	685.74
XE-131M	LLD<6.84E+00	LLD<6.84E+00	163.98
XE-133	LLD<4.89E-01	LLD<4.89E-01	81.00
XE-133M	LLD<1.64E+00	LLD<1.64E+00	233.21
XE-135	LLD<1.85E-01	LLD<1.85E-01	249.79
XE-138	LLD<1.42E+00	LLD<1.42E+00	258.41
Y-88	LLD<9.63E-02	LLD<9.63E-02	1836.06
Y-91	LLD<6.86E+01	LLD<6.86E+01	1204.90
Y-91M	LLD<3.62E-01	LLD<3.62E-01	555.60
ZN-65	LLD<6.91E-01	LLD<6.91E-01	1115.55
ZR-95	LLD<4.14E-01	LLD<4.14E-01	756.73
ZR-97	LLD<2.41E-01	LLD<2.41E-01	743.33

TOTAL 8.19E+01 + -1.50E+00 8.19E+01 + -1.50E+00

EBAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.44E-09 UC/LI
TOTAL MEASURED ACTIVITY = 8.19E+01 (+-1.50E+00) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1127.84	563.55	502.	14.2	2.96E+01
1139.68	569.47	956.	11.6	5.69E+01
1604.64	801.91	387.	12.5	3.10E+01
2731.09	1365.09	113.	22.4	1.40E+01

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
2921.55	1460.32	128.	21.3	1.68E+01

Single Shell Tank Calibration Record

ANALYTE: Isotope Mixed Gamma

PROCEDURE: LQ-508-003

REVISION: B-1

INSTRUMENT: GEA Detector #1

PROPERTY NUMBER: 401934

TECHNOLOGIST: J. L. Anderson

PAYROLL NUMBER: 61413

DATE: See Attached Sheets

CALIBRATION STANDARD ID: 56B40 D1

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: Gamma Energy Analysis (Efficiency)

DETECTOR: 1
 GEOMETRY CODE: 42
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 14-Feb-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56840 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	5.721347E-03
88.032	1.512568E-02
122.0614	2.041958E-02
165.853	1.856472E-02
279.1967	
391.668	1.042777E-02
513.99	7.856059E-03
661.65	6.034966E-03
898.021	5.300244E-03
1173.237	4.218416E-03
1332.501	3.785537E-03
1836.129	2.931033E-03

EQUATION 0-165 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -5.343694\text{E+01} \\
 & + 2.034704\text{E+01} * \text{LOG(ENERGY)} \\
 & - 2.088264\text{E+00} * \text{LOG(ENERGY)}^2
 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & 8.372735\text{E+00} \\
 & + -7.762489\text{E+00} * \text{LOG(ENERGY)} \\
 & + 2.017698\text{E+00} * \text{LOG(ENERGY)}^2 \\
 & + -2.447360\text{E-01} * \text{LOG(ENERGY)}^3 \\
 & + 1.067720\text{E-02} * \text{LOG(ENERGY)}^4
 \end{aligned}$$

CEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 1
 GEOMETRY CODE: 43
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 16-Feb-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56840 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	1.397695E-03
88.032	3.641448E-03
122.0614	5.035820E-03
165.853	4.620516E-03
279.1967	
391.668	2.619018E-03
513.99	1.890740E-03
661.65	1.782478E-02
898.021	1.392563E-03
1173.237	1.117189E-03
1332.501	1.007670E-03
1836.129	7.762502E-04

EQUATION 0-165 KEV

$$\text{LOG(EFF)} = -5.354869\text{E+01}$$

+ 1.975356E+01 *LOG(ENERGY)
+ -2.020850E+00 *LOG(ENERGY)^2

EQUATION 165-1836 KEV

LOG(EFF) = 4.001880E+01
+ -2.857555E+01 *LOG(ENERGY)
+ 6.748440E+00 *LOG(ENERGY)^2
+ 7.173093E-01 *LOG(ENERGY)^3
+ 2.821780E-02 *LOG(ENERGY)^4

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

Single Shell Tank Calibration Record

ANALYTE: Mixed Isotope Standards

PROCEDURE: LQ-508-003

REVISION: B-1

INSTRUMENT: GEA Detector #2

PROPERTY NUMBER: 401934

TECHNOLOGIST: J. L. Anderson

PAYROLL NUMBER: 61413

DATE: See Attached Sheets

CALIBRATION STANDARD ID: 56B40 D1

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: Gamma Energy Analysis (Efficiency)

DETECTOR: 2
 GEOMETRY CODE: 42
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 21-Oct-88
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	3.417000E-03
88.032	1.090000E-02
122.0614	1.408000E-02
165.853	1.516000E-02
279.1967	9.929000E-03
391.668	7.578000E-03
513.99	5.075000E-03
661.65	4.927000E-03
890.021	3.727000E-03
1173.237	3.005000E-03
1332.501	2.683000E-03
1836.129	2.102000E-03

EQUATION 0-122 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -6.654070E+01 \\
 & + 2.583780E+01 * \text{LOG(ENERGY)} \\
 & + -2.677550E+00 * \text{LOG(ENERGY)}^2
 \end{aligned}$$

EQUATION 122-1836 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -1.050740E+02 \\
 & + 6.428950E+01 * \text{LOG(ENERGY)} \\
 & + -1.503170E+01 * \text{LOG(ENERGY)}^2 \\
 & + 1.533670E+00 * \text{LOG(ENERGY)}^3 \\
 & + -5.838530E-02 * \text{LOG(ENERGY)}^4
 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 2
 GEOMETRY CODE: 43
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 3
 CALITRATION DATE: 28-Sep-88
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	1.476000E-03
88.032	4.721000E-03
122.0614	6.589000E-03
165.853	6.613000E-03
279.1967	4.692000E-03
391.668	3.542000E-03
513.99	2.810000E-03
661.65	2.327000E-03
890.021	1.790000E-03
1173.237	1.437000E-03
1332.501	1.277000E-03
1836.129	9.824000E-04

EQUATION 0-165 KEV

$$\begin{aligned}\text{LOG(EFF)} = & -5.826830\text{E+01} \\ & + 2.165450\text{E+01} * \text{LOG(ENERGY)} \\ & + -2.198930\text{E+00} * \text{LOG(ENERGY)}^2\end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned}\text{LOG(EFF)} = & -2.233890\text{E+01} \\ & + 1.174520\text{E+01} * \text{LOG(ENERGY)} \\ & + -2.739550\text{E+00} * \text{LOG(ENERGY)}^2 \\ & + 2.655450\text{E-01} * \text{LOG(ENERGY)}^3 \\ & + -9.668420\text{E-03} * \text{LOG(ENERGY)}^4\end{aligned}$$

Single Shell Tank Calibration Record

ANALYTE: Mixed Isotope Standards

PROCEDURE: LQ-508-003

REVISION: B-1

INSTRUMENT: GEA Detector #3

PROPERTY NUMBER: 401934

TECHNOLOGIST: J. L. Anderson

PAYROLL NUMBER: 61413

DATE: July 2, 1989

CALIBRATION STANDARD ID: 56B40 D1

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: Gamma Energy Analysis (Efficiency)

DETECTOR: 3
 GEOMETRY CODE: 41
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 1
 CALIBRATION DATE: 2-JUL-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	2.833765E-02
88.032	2.881764E-02
122.0614	2.756557E-02
165.853	2.270614E-02
279.1967	
391.668	1.285730E-02
513.99	
661.65	7.841011E-03
898.021	5.779292E-03
1173.237	4.773005E-03
1332.501	4.270530E-03
1836.129	3.371238E-03

EQUATION 0-165 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -1.113845E+01 \\
 & + 3.484260E+00 * \text{LOG(ENERGY)} \\
 & + -3.990659E-01 * \text{LOG(ENERGY)}^2
 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -2.052334E+01 \\
 & + 9.121738E+00 * \text{LOG(ENERGY)} \\
 & + 1.553578E+00 * \text{LOG(ENERGY)}^2 \\
 & + 8.018036E-02 * \text{LOG(ENERGY)}^3
 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 3
 GEOMETRY CODE: 42
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 2-JUL-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	7.455306E-03
88.032	7.462748E-03
122.0614	7.570302E-03
165.853	6.965814E-03
279.1967	
391.668	3.596591E-03
513.99	
661.65	2.318396E-03
898.021	1.824191E-03
1173.237	1.461179E-03
1332.501	1.321243E-03
1836.129	1.011332E-03

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -6.838496\text{E}+00 \\ & + 8.819509\text{E}-01 * \text{LOG(ENERGY)} \\ & + -9.970520\text{E}-02 * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & 3.082260\text{E}-01 \\ & + -1.410839\text{E}+00 * \text{LOG(ENERGY)} \\ & + 1.042898\text{E}-01 * \text{LOG(ENERGY)}^2 \\ & + -5.874725\text{E}-03 * \text{LOG(ENERGY)}^3 \end{aligned}$$

:

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 3
 GEOMETRY CODE: 43
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 2-JUL-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	2.020462E-03
88.032	1.924344E-03
122.0614	2.027231E-03
165.053	1.712371E-03
279.1967	
391.668	1.056509E-03
513.99	
661.65	7.115743E-04
894.021	5.243920E-04
1173.237	4.551585E-04
1332.501	4.223636E-04
1836.129	3.139091E-04

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -5.300788\text{E}+00 \\ & + -3.550643\text{E}-01 * \text{LOG(ENERGY)} \\ & + 3.272635\text{E}-02 * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -9.815549\text{E}+00 \\ & + 2.402920\text{E}+00 * \text{LOG(ENERGY)} \\ & + -4.428877\text{E}-01 * \text{LOG(ENERGY)}^2 \\ & + 2.059131\text{E}-02 * \text{LOG(ENERGY)}^3 \end{aligned}$$

Single Shell Tank Calibration Record

ANALYTE: Mixed Isotope Standards

PROCEDURE: LQ-508-003

REVISION: B-1

INSTRUMENT: GEA Detector #4

PROPERTY NUMBER: 401934

TECHNOLOGIST: J. L. Anderson

PAYROLL NUMBER: 61413

DATE: September 1, 1989

CALIBRATION STANDARD ID: 56B40 D1

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: Gamma Energy Analysis (Efficiency)

CEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 4
 GEOMETRY CODE: 41
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 1
 CALIBRATION DATE: 1-Sep-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV) EFFICIENCY (COUNTS/GAMMA)

59.536	2.682446E-02
88.032	8.210956E-02
122.0614	1.118411E-01
165.853	1.066653E-01
279.1967	
391.668	5.704220E-02
513.99	
661.65	3.685958E-02
898.021	2.541629E-02
1173.237	2.161710E-02
1332.501	1.973393E-02
1836.129	1.484468E-02

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -5.844056\text{E+01} \\ & + 2.310700\text{E+01} * \text{LOG(ENERGY)} \\ & + 2.371355\text{E+00} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -1.718967\text{E+01} \\ & + 8.164155\text{E+00} * \text{LOG(ENERGY)} \\ & + -1.384196\text{E+00} * \text{LOG(ENERGY)}^2 \\ & + 7.025905\text{E-02} * \text{LOG(ENERGY)}^3 \end{aligned}$$

CEA CALIBRATION RECORD

PROCEDURE LQ-508-003

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	WA77344
PROCEDURE/REV	LA-925-106/A-1
TECHNOLOGIST	M. Franz
DATE	January 09, 1990
TEMPERATURE	N/A
STARTING TIME	1000
ENDING TIME	1330
CHEMIST	S. A. Catlow

Uranium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0293
2	Reagent Blank	F0308
3	Sample Composite 8	F0294
4	Duplicate Sample Composite 8	F0295
5	Spike Composite 8	F0296
6	Final LMCS Check Std.	F0297
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	58B38/1 uL			5.7 mL
Spike	58B38/1 uL	F0294/0.5 uL		5.8 mL

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	N/A
PROCEDURE/Rev	LA-505-151/A-0
TECHNOLOGIST	J. A. White
DATE	April 30, 1990
TEMPERATURE	N/A
STARTING TIME	0800
ENDING TIME	1530
CHEMIST	S. A. Jones

ICP

Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std	N/A
2	LMCS Digested Std	F0575
3	Reagent Blank	F0583
4	Sample 89-076	F0576
5	Duplicate Sample 89-076	F0577
6	Spike Sample 89-076	F0578
7	LMCS Digested Std	F0579
8	LMCS Check Std	N/A
9	Sample Comp 14	F1001
10	Duplicate Sample Comp 14	F1002
11	Sample Comp 06	F0923

	DESCRIPTION	LAB ID
12	Duplicate Sample Comp 06	F0924
13	Sample Comp 08	F0947
14	Duplicate Sample Comp 08	F0948
15	Final LMCS Check Std	N/A
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std	78C11K/1.0 mL	83B83A/1.0 mL	77C11J/1.0 mL	1.0 mL
Digested Std	78C11K/5.0 mL	83B83A/5.0 mL	77C11J/5.0 mL	50.0 mL
Spike	78C11K/5.0 mL	82B38G/5.0 mL	77C11J/5.0 mL	
Spike conc	F0578/0.4986 g			50.0 mL

ICP Results

RAW DATA SUMMARY

Date Analyzed:	April 30, 1990	Acid Digested LMCS Standard	F0575
Procedure:	LA-505-151/A-0	Reagent Blank	F0583
Analyst:	J. A. White	Core 8 Composite	F0947
Digestion	Acid Digestion	Duplicate of Core 8 Composite	F0948
Procedure:	LA-505-159/A-0	Spike of 89-076	F0578
		Acid Digested LMCS Standard	F0579

Instrument	Starting LMCS Standard	Acid Digest. LMCS Standard	Reagent BLANK	Wet Weight Sample	Wet Weight Sample	Spike Recovery	LMCS		Closing LMCS Standard
							ACID Digestion	%	
Aluminum	100.70%	92.02%	0.33	307798	310987	NOT CALC.	96.56%	99.27%	
Antimony	103.07%	87.00%	0.02 LT	-2019 LT	-702 LT	-243.70%	67.00%	99.07%	
Arsenic	114.94% #	99.86%	-0.02 LT	-429 LT	-123 LT	114.58%	104.44%	113.03% #	
Barium	99.30%	93.10%	0.01	-112 LT	-30 LT	103.93%	92.70%	97.17%	
Beryllium	95.99%	87.90%	0.00 LT	-19 LT	-11 LT	101.02%	90.60%	94.22%	
Bismuth	106.23%	94.31%	0.03 LT	-2451 LT	-1562 LT	-117.00%	101.54%	107.22%	
Boron	100.71%	93.20%	0.06	164	439	76.57%	92.60%	98.05%	
Cadmium	98.69%	93.70%	0.00 LT	-77 LT	-41 LT	98.39%	91.10%	96.89%	
Calcium	102.21%	143.70%	0.78	2519	4046	170.51%	144.90%	99.95%	
Cerium	92.37%	50.50%	-0.08 LT	-4512 LT	-1516 LT	-1338.00%	0.80%	90.43%	
Chromium	90.41%	87.60%	0.01	-170 LT	-50 LT	232.52%	85.80%	88.92% #	
Cobalt	94.24%	95.40%	0.00 LT	-242 LT	69 LT	7.30%	86.60%	99.92%	
Copper	100.63%	92.60%	0.01 LT	-280 LT	-76 LT	114.10%	90.60%	98.31%	
Europium	98.16%	92.70%	0.00 LT	-81 LT	-25 LT	101.78%	94.90%	96.39%	
Iron	103.46%	128.30%	0.58	354	632	NOT CALC.	126.30%	100.84%	
Lanthanum	94.17%	89.66%	-0.01 LT	-368 LT	-103 LT	98.06%	91.90%	93.39%	
Lead	105.09%	96.71%	0.03 LT	-1272 LT	-86 LT	112.52%	103.09%	108.06%	
Lithium	98.13%	88.00%	-0.01 LT	-216 LT	-75 LT	99.66%	86.20%	95.95%	
Magnesium	102.45%	108.40%	0.17	647	496	421.22%	107.20%	99.84%	
Manganese	100.16%	97.50%	0.03	46	74	211.90%	97.00%	98.30%	
Mercury	105.34%	89.88%	0.01	-73 LT	-22 LT	226.51%	94.80%	104.63%	
Molybdenum	96.36%	87.60%	0.00 LT	-166 LT	-88 LT	94.24%	91.18%	94.24%	
Neodymium	85.78% #	50.50%	-0.06 LT	-3368 LT	-1538 LT	-977.80%	18.90%	87.30% #	
Nickel	97.87%	94.20%	0.00 LT	2104	3034	101.41%	90.70%	96.04%	
Phosphorous	112.63% #	96.46%	0.10	-385 LT	149 LT	13.07%	105.20%	114.97% #	
Potassium	98.37%	74.68%	-0.09 LT	0	0	-733.60%	44.60%	98.37%	
Samarium	95.61%	3.00%	-0.12 LT	-4951 LT	-1643 LT	-1619.00%	43.80%	99.90%	
Selenium	105.26%	88.26%	-0.02 LT	-1245 LT	-135 LT	128.63%	95.04%	103.89%	
Silicon	90.12%	30.04%	0.82	4064	21979	102.49%	30.36%	87.78% #	
Silver	102.71%	91.20%	-0.01 LT	-381 LT	-162 LT	-87.60%	96.10%	102.54%	
Sodium	98.55%	97.68%	0.35	2940	7153	NOT CALC.	85.92%	96.79%	
Strontium	100.99%	96.30%	0.00	29	-5 LT	146.91%	96.00%	98.64%	
Sulfur	106.15%	95.42%	0.14	-200 LT	231 LT	150.68%	101.22%	105.85%	
Tantalum	96.79%	76.60%	-0.01 LT	-808 LT	-358 LT	-36.62%	80.42%	95.64%	
Thallium	101.95%	83.48%	-0.11 LT	-5676 LT	-2830 LT	-210.80%	91.10%	101.34%	
Thorium	102.75%	87.41%	-0.08 LT	-3404 LT	-1345 LT	-112.51%	94.77%	102.26%	
Tin	100.68%	98.20%	0.02 LT	-218 LT	-75 LT	100.18%	94.72%	98.67%	
Titanium	99.79%	91.90%	0.09	-188 LT	-80 LT	103.53%	94.68%	96.79%	
Tungsten	83.80% #	69.72%	0.01 LT	-387 LT	-147 LT	13.28%	73.20%	81.87% #	
Uranium	102.10%	-13.59%	-0.89 LT	-32297 LT	-11835 LT	-1080.64%	35.91%	107.36%	
Vanadium	95.92%	86.90%	-0.01 LT	-213 LT	-184 LT	31.20%	90.90%	94.94%	
Zinc	100.16%	95.20%	0.08	65	143	134.21%	93.90%	98.31%	
Zirconium	98.91%	88.94%	-0.01 LT	-500 LT	-179 LT	117.87%	92.02%	96.18%	

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

ICP Results

RAW DATA SUMMARY

Date Analyzed:	April 30, 1990	Acid Digested LMCS Standard	F0575
Procedure:	LA-505-151/A-0	Reagent Blank	F0583
Analyst:	J. A. White	Core 8 Composite	F0947
Digestion	Acid Digestion	Duplicate of Core 8 Composite	F0948
Procedure:	LA-505-159/A-0	Spike of 89-076	F0578
		Acid Digested LMCS Standard	F0579

	Instrument Starting LMCS Standard %	Acid Digest. LMCS Standard %	Reagent BLANK	Wet Weight Sample ug/g	Wet Weight Sample Duplicate ug/g	Spike Recovery %	LMCS ACID Digestion %	Closing LMCS Standard %
Aluminum	100.70%	92.02%	0.33	307798	310987	NOT CALC.	96.56%	99.27%
Antimony	103.07%	87.00%	0.02 LT	-2019 LT	-702 LT	67.00%	99.07%	
Arsenic	114.94% #	99.86%	-0.02 LT	-429 LT	-123 LT	104.44%	113.03% #	
Barium	99.30%	93.10%	0.01	-112 LT	-30 LT	9.00%	92.70%	97.17%
Beryllium	95.99%	87.90%	0.00 LT	-19 LT	-11 LT	90.60%	94.22%	
Bismuth	106.23%	94.31%	0.03 LT	-2451 LT	-1562 LT	NOT CALC.	101.54%	107.22%
Boron	100.71%	93.20%	0.06	164	439	9.34%	92.60%	98.05%
Cadmium	98.69%	93.70%	0.00 LT	-77 LT	-41 LT	8.31%	91.10%	96.89%
Calcium	102.21%	143.70%	0.78	2519	4046	17.05%	144.90%	99.95%
Cerium	92.37%	50.50%	-0.08 LT	-4512 LT	-1516 LT	-133.80%	0.80%	90.43%
Chromium	90.41%	87.60%	0.01	-170 LT	-50 LT	23.25%	85.80%	88.92% #
Cobalt	94.24%	95.40%	0.00 LT	-242 LT	69 LT	0.73%	86.60%	99.92%
Copper	100.63%	92.60%	0.01 LT	-280 LT	-76 LT	7.33%	90.60%	98.31%
Europium	98.16%	92.70%	0.00 LT	-81 LT	-25 LT	94.90%	96.39%	
Iron	103.46%	128.30%	0.58	354	632	NOT CALC.	126.30%	100.84%
Lanthanum	94.17%	89.66%	-0.01 LT	-368 LT	-103 LT	39.26%	91.90%	93.39%
Lead	105.09%	96.71%	0.03 LT	-1272 LT	-86 LT	56.37%	103.09%	108.06%
Lithium	98.13%	88.00%	-0.01 LT	-216 LT	-75 LT	1.97%	86.20%	95.95%
Magnesium	102.45%	108.40%	0.17	647	496	42.12%	107.20%	99.84%
Manganese	100.16%	97.50%	0.03	46	74	21.19%	97.00%	98.30%
Mercury	105.34%	89.88%	0.01	-73 LT	-22 LT	94.80%	104.63%	
Molybdenum	96.36%	87.60%	0.00 LT	-166 LT	-88 LT	43.03%	91.18%	94.24%
Neodymium	85.78% #	50.50%	-0.06 LT	-3368 LT	-1538 LT	-97.78%	18.90%	87.30% #
Nickel	97.87%	94.20%	0.00 LT	2104	3034	11.29%	90.70%	96.04%
Phosphorous	112.63% #	96.46%	0.10	-385 LT	149 LT	6.53%	105.20%	114.97% #
Potassium	98.37%	74.68%	-0.09 LT	0	0	-183.40%	44.60%	98.37%
Samarium	95.61%	3.00%	-0.12 LT	-4951 LT	-1643 LT	43.80%	99.90%	
Selenium	105.26%	88.26%	-0.02 LT	-1245 LT	-135 LT	95.04%	103.89%	
Silicon	90.12%	30.04%	0.82	4064	21979	53.57%	30.36%	87.78% #
Silver	102.71%	91.20%	-0.01 LT	-381 LT	-162 LT	-8.76%	96.10%	102.54%
Tantalum	98.55%	97.68%	0.35	2940	7153	NOT CALC.	85.92%	96.79%
Thallium	100.99%	96.30%	0.00	29	-5 LT	14.69%	96.65%	98.61%
Titanium	106.15%	95.42%	0.14	-200 LT	231 LT	101.22%	105.84%	
Thorium	96.79%	76.60%	-0.01 LT	-808 LT	-358 LT	-18.40%	80.42%	95.64%
Tin	101.95%	83.48%	-0.11 LT	-5676 LT	-2830 LT	91.10%	101.34%	
Tungsten	102.75%	87.41%	-0.08 LT	-3404 LT	-1345 LT	94.77%	102.26%	
Uranium	100.68%	98.20%	0.02 LT	-218 LT	-75 LT	94.72%	98.67%	
Titanium	99.79%	91.90%	0.09	-188 LT	-80 LT	94.68%	96.79%	
Tungsten	83.80% #	69.72%	0.01 LT	-387 LT	-147 LT	73.20%	81.87% #	
Vanadium	102.10%	86.90%	-0.89 LT	-32297 LT	-11835 LT	35.91%	107.36%	
Zinc	100.16%	95.20%	0.08	65	143	13.42%	93.90%	94.94%
Zirconium	98.91%	88.94%	-0.01 LT	-500 LT	-179 LT	42.85%	92.02%	98.31%

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

ICP Results

RAW DATA

Page 1 of 4

Date Analyzed:	April 30, 1990	Acid Digested LMCS Standard	F0575	Digestion Weight
Procedure:	LA-505-151/A-0	Reagent Blank	F0583	Volume
Analyst:	J. A. White	Core 8 Composite	F0947	Sample
Digestion	Acid Digestion	Duplicate of Core 8 Composite	F0948	
Procedure:	LA-505-159/A-0	Spike of 89-076	F0578	
		Acid Digested LMCS Standard	F0579	
				Dilution Three ppm
		Starting LMCS Standard	LMCS Acid Digestion Standard	Reagent Blank
		Instrument Standard	Digestion Standard	
		ppm	ppm	ppm
	SST-1	SST-2	SST-3	
Aluminum			50.35	100.70%
Antimony	10.31			4.60
Arsenic			57.47	103.07%
Barium	9.93			0.87
Beryllium			9.60	114.94% #
Bismuth		53.22		4.99
Boron	10.07			0.93
Cadmium	9.87			0.93
Calcium	10.22			0.94
Cerium	9.24			1.44
Chromium	9.04			0.51
Cobalt	9.42			0.88
Copper	10.06			0.88
Europium		9.82		0.95
Iron	10.35			0.93
Lanthanum		47.18		0.93
Lead		52.65		0.93
Lithium	9.81			0.93
Magnesium	10.25			0.93
Manganese	10.02			0.93
Mercury			26.34	98.13%
Molybdenum			48.18	105.34%
Neodymium	8.58			2.25
Nickel	9.79			4.38
Phosphorous			56.32	85.78% #
Potassium	24.59			0.51
Samarium		9.56		0.94
Selenium			52.63	97.87%
Silicon			45.06	112.63% #
Silver		10.27		0.88
Sodium	24.64			4.82
Strontium	10.10			0.88
Sulfur			53.08	98.37%
Tantalum			48.40	106.15%
Thallium			50.98	96.79%
Thorium		51.48		101.95%
Tin	50.34			4.41
Titanium			49.90	102.75%
Tungsten			20.95	97.59%
Uranium		51.15		100.68%
Vanadium			9.59	83.80% #
Zinc	10.02			1.74
Zirconium			49.46	102.10%
Dilution Factor	1.00	1.00	1.00	-0.68 LT
				69.72%
				0.01 LT
				-0.01 LT
				0.14
				0.12 LT
				-0.02 LT
				0.08
				-0.01 LT
				0.35
				0.00
				0.00
				-0.01 LT
				0.09
				0.01 LT
				-0.01 LT
				0.01 LT
				-0.01 LT
				0.08
				-0.01 LT
				0.02 LT
				0.09
				0.01 LT
				-0.89 LT
				-0.01 LT
				0.08
				-0.01 LT
				1.00
				1.00

ICP Results

RAW DATA

Page 2 of 4

	0.00271 g/mL	0.00212 g/mL	Digestion	0.00997 g/mL	0.4986 g	Weight	50.00 mL	Spike of Sample	Spike of Sample	Spike of Sample
	0.6787 g	0.5304 g	Weight	0.00997 g/mL	0.4986 g	Weight	50.00 mL	Dilution	Dilution	Dilution
	250.00 mL	250.00 mL	Volume	0.00997 g/mL	0.4986 g	Volume	50.00 mL	Two	One	One
	Sample	Sample	Sample	Sample	Sample	Sample	Sample	Dilution	Dilution	Dilution
	Dilution	Dilution	Duplicate Dilution	Duplicate Dilution	Duplicate Dilution	Dilution	Dilution	Two	One	One
	Two ppm	One ppm	Three ppm	Two ppm	One ppm	Three ppm	Dilution	ppm	ppm	ppm
Aluminum	835.61	828.64		659.79	662.02			546.54	533.49	
Antimony	-31.58	-5.48 LT		-10.74	-1.49 LT			0.00	-2.44 LT	
Arsenic	-8.27	-1.16 LT		-1.80	-0.26 LT			5.39	4.36	
Barium	-1.79	-0.30 LT		0.05	-0.06 LT			1.27	0.90	
Beryllium	-0.28	-0.05 LT		-0.04	-0.02 LT			0.97	0.96	
Bismuth	-39.20	-6.66 LT		-10.17	-3.31 LT			178.87	171.48	
Boron	1.96	0.44		5.13	0.93			4.16	0.93	
Cadmium	-1.14	-0.21 LT		-0.26	-0.09 LT			0.92	0.83	
Calcium	6.84	6.14		8.58	8.27			5.57	5.16	
Cerium	-70.80	-12.25 LT		-1.03	-3.22 LT			2.31	-13.38 LT	
Chromium	-2.59	-0.46 LT		-0.34	-0.11 LT			14.15	13.27	
Cobalt	-3.28	-0.66 LT		1.05	0.15 LT			1.29	0.07 LT	
Copper	-4.56	-0.76 LT		-0.21	-0.16 LT			1.61	0.73	
Europium	-1.30	-0.22 LT		-0.01	-0.05 LT			0.99	0.73	
Iron	0.25	0.96		1.74	1.34			262.92	258.11	
Lanthanum	-5.07	-1.00 LT		0.18	-0.22 LT			4.98	3.93	
Lead	-19.22	-3.45 LT		-6.12	-0.18 LT			15.73	8.27	
Lithium	-3.37	-0.59 LT		-0.07	-0.16 LT			0.82	0.20	
Magnesium	1.76	1.05		1.05	2.01			5.54	2.41	
Manganese	-0.18	0.13		0.10	0.16			39.70	39.05	
Mercury	-1.69	-0.20 LT		0.31	-0.05 LT			10.25	2.93	
Molybdenum	-3.01	-0.45 LT		-1.28	-0.19 LT			4.44	4.30	
Neodymium	-51.02	-9.14 LT		-4.33	-3.26 LT			-2.80	-9.78 LT	
Nickel	2.65	5.71		5.83	6.44			1.50	1.13	
Phosphorous	-8.63	-1.04 LT		1.20	0.32 LT			38.10	34.07	
Potassium	NA	NA		NA	NA			1.64	-18.34 LT	
Samarium	-79.48	-13.44 LT		-0.89	-3.49 LT			0.89	-16.19 LT	
Selenium	-29.54	-3.38 LT		-6.96	-0.29 LT			9.76	6.47	
Silicon	31.00	11.03		46.63	12.47			4.95	5.36	
Silver	-5.73	-1.03 LT		-0.50	-0.34 LT			0.12	-0.88 LT	
Sodium	0.12	7.98		43.44	15.18			923.60	911.02	
Strontium	-0.58	0.08		0.02	-0.01 LT			4.99	4.85	
Sulfur	-5.07	-0.54 LT		0.24	0.49 LT			18.84	16.44	
Tantalum	-11.68	-2.19 LT		-1.55	-0.76 LT			0.30	-1.83 LT	
Thallium	-101.10	-15.41 LT		5.18	-6.01 LT			12.16	-10.54 LT	
Thorium	-52.85	-9.24 LT		-3.43	-2.85 LT			4.46	-5.64 LT	
Tin	-3.90	-0.59 LT		-0.80	-0.16 LT			5.29	4.51	
Titanium	-2.83	-0.51 LT		-0.41	-0.17 LT			4.92	4.58	
Tungsten	-8.70	-1.05 LT		-2.32	-0.31 LT			0.61	0.33 LT	
Uranium	-509.00	-87.68 LT		-21.05	-25.11 LT			41.18	-54.14 LT	
Vanadium	-4.35	-0.58 LT		0.22	-0.39 LT			0.50	0.31 LT	
Zinc	-0.34	0.18		0.08	0.30			3.23	2.89	
Zirconium	-8.02	-1.36 LT		-0.25	-0.38 LT			5.80	4.28	
Dilution Factor	101.00	21.00	1.00	101.00	21.00	1.00	101.00	21.00	21.00	

ICP Results

RAW DATA

Page 3 of 4

	Spike Recovery	Standard LMCS Acid Digestion %	Acid Digestion Standard Recovery %	Ending LMCS Standard Recovery %	Spike Standard LMCS ppm added	Spike Standard ID Book #
		ppm	%			
				SST-1 SST-2 SST-3		
Aluminum	NOT CALC.	4.83	96.56%	49.63	99.27%	10.00
Antimony		0.67	67.00%	9.91	99.07%	
Arsenic		5.22	104.44%	56.52	113.03% #	
Barium	9.00%	0.93	92.70%	9.72	97.17%	10.00
Beryllium		0.91	90.60%		94.22%	
Bismuth	NOT CALC.	5.09	101.54%	53.72	107.22%	10.00
Boron	9.34%	0.93	92.60%	9.81	98.05%	10.00
Cadmium	8.31%	0.91	91.10%	9.69	96.89%	10.00
Calcium	17.05%	1.45	144.90%	10.00	99.95%	10.00
Cerium	-133.80%	0.01	0.80%	9.04	90.43%	10.00
Chromium	23.25%	0.86	85.80%	8.89	88.92% #	10.00
Cobalt	0.73%	0.87	86.60%	9.99	99.92%	10.00
Copper	7.33%	0.91	90.60%	9.83	98.31%	10.00
Europium		0.95	94.90%	9.64	96.39%	
Iron	NOT CALC.	1.26	126.30%	10.08	100.84%	10.00
Lanthanum	39.26%	4.60	91.90%	46.79	93.39%	10.00
Lead	56.37%	5.17	103.09%	54.14	108.06%	10.00
Lithium	1.97%	0.86	86.20%	9.60	95.95%	10.00
Magnesium	42.12%	1.07	107.20%	9.98	99.84%	10.00
Manganese	21.19%	0.97	97.00%	9.83	98.30%	10.00
Mercury		2.37	94.80%		104.63%	
Molybdenum	43.03%	4.56	91.18%		94.24%	10.00
Neodymium	-97.78%	0.19	18.90%	8.73	87.30% #	10.00
Nickel	11.29%	0.91	90.70%	9.60	96.04%	10.00
Phosphorous	6.53%	5.26	105.20%		114.97% #	10.00
Potassium	-183.40%	1.12	44.60%	24.59	98.37%	10.00
Samarium		0.44	43.80%	9.99	99.90%	
Selenium		4.75	95.04%		103.89%	
Silicon	53.57%	1.52	30.36%		43.89	87.78% #
Silver	-8.76%	0.96	96.10%	10.25	102.54%	10.00
Sodium	NOT CALC.	2.15	85.92%	24.20	96.79%	10.00
Strontium	14.69%	0.96	96.00%	9.86	98.64%	10.00
Sulfur		5.06	101.22%		52.93	105.85%
Tantalum	-18.40%	4.02	80.42%		47.82	95.64%
Thallium		4.56	91.10%		50.67	101.34%
Thorium		4.75	94.77%	51.23		102.26%
Tin	45.14%	4.74	94.72%	49.34		98.67%
Titanium	49.15%	4.73	94.68%		48.39	96.79%
Tungsten		1.83	73.20%		20.47	81.87% #
Uranium		1.80	35.91%	53.79		107.36%
Vanadium		0.91	90.90%		9.49	94.94%
Zinc	13.42%	0.94	93.90%	9.83		98.31%
Zirconium	42.85%	4.60	92.02%		48.09	96.18%
Dilution Factor		10.00		1.00	1.00	1.00

ICP Results

RAW DATA

Page 4 of 4

			LMCS Standards Values	LMCS Standard IDs Book	ACID DIGESTION LMCS STANDARD VALUES	ACID DIGEST. LMCS
	SST-1	SST-2	SST-3 ppm	#	ppm in Sample	#
Aluminum			50.00		50.00	
Antimony	10.00				10.00	
Arsenic			50.00		50.00	
Barium	10.00				10.00	
Beryllium			10.00		10.00	
Bismuth		50.10			50.10	
Boron	10.00				10.00	
Cadmium	10.00				10.00	
Calcium	10.00				10.00	
Cerium	10.00				10.00	
Chromium	10.00				10.00	
Cobalt	10.00				10.00	
Copper	10.00				10.00	
Europium		10.00			10.00	
Iron	10.00				10.00	
Lanthanum		50.10			50.10	
Lead		50.10			50.10	
Lithium	10.00				10.00	
Magnesium	10.00				10.00	
Manganese	10.00				10.00	
Mercury			25.00		25.00	
Molybdenum			50.00		50.00	
Neodymium	10.00				10.00	
Nickel	10.00				10.00	
Phosphorous			50.00		50.00	
Potassium	25.00				25.00	
Samarium		10.00			10.00	
Selenium			50.00		50.00	
Silicon			50.00		50.00	
Silver		10.00			10.00	
Sodium	25.00				25.00	
Strontium	10.00				10.00	
Sulfur			50.00		50.00	
Tantalum			50.00		50.00	
Thallium			50.00		50.00	
Thorium		50.10			50.10	
Tin	50.00				50.00	
Titanium			50.00		50.00	
Tungsten			25.00		25.00	
Uranium		50.10			50.10	
Vanadium			10.00		10.00	
Zinc	10.00				10.00	
Zirconium			50.00		50.00	
Dilution Factor					1.00	

ICP Calibration Report

Procedure: LA-505-151 Revision: A-0
Instrument: WB39939
Technologist: J.A. White
Date: April 30, 1990

Calibration Standards for ICP Program "SST"

Element	Standard	Element	Standard
Aluminum	SST-3	Antimony	SST-4
Arsenic	SST-4	Barium	SST-2
Beryllium	SST-2	Bismuth	SST-4
Boron	SST-3	Cadmium	SST-2
Calcium	SST-2	Cerium	SST-5
Chromium	SST-2	Cobalt	SST-2
Copper	SST-2	Europium	SST-5
Iron	SST-2	Lanthanum	SST-5
Lead	SST-4	Lithium	SST-1
Magnesium	SST-2	Manganese	SST-2
Mercury	SST-3	Molybdenum	SST-3
Neodymium	SST-5	Nickel	SST-2
Phosphorous	SST-3	Potassium	SST-1
Samarium	SST-5	Selenium	SST-4
Silicon	SST-3	Silver	SST-2
Sodium	SST-1	Strontium	SST-2
Sulfur	SST-3	Tantalum	SST-3
Thallium	SST-4	Thorium	SST-4
Tin	SST-4	Titanium	SST-3
Tungsten	SST-3	Uranium	SST-4
Vanadium	SST-2	Zinc	SST-2
Zirconium	SST-3		

ICP Standard Formulations

SST-0:

Calibration blank, 1 M Ultrex HNO₃.

SST-1:

Stock solutions from AESAR/John Mathey Inc., Seabrook, NH 03874.

Individual element solutions as follows:

Li LiCO₃, 10,000 ppm in 5% HNO₃, Lot# 14394A

K KNO₃, 10,000 ppm in 5% HNO₃, Lot# 14379A

Na NaCO₃, 10,000 ppm in 5% HNO₃, Lot# 14400A

200 mL of standard made by combining 25 mL HCl/HNO₃ mixed acid, 1 mL each single element standards, and water.

SST-2:

Stock solutions from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standards as follows:

SM-10 Li, Na, K, Rb, Cs, Be, Mg, Ca, Sr, & Ba 100 ppm
Lot# 0-119A
SM-20 V, Cr, Mn, Fe, Co, Ni, Cu, Zn, Ag, & Cd 100 ppm
Lot# 0-119B

50 mL of each mixed standard are added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

SST-3:

Stock solutions from AESAR/John Mathey Inc., Seabrook, NH 03874.

Individual element solutions as follows:

Al Al 10,000 ppm in 10% HCl Lot# 9-053A
B H₃BO₃ 10,000 ppm in 1% NH₄OH Lot# 9-335A
Hg Hg 10,000 ppm in 5% HNO₃ Lot# 8-656S
Mo Mo 10,000 ppm in 5% HCl Lot# 9-159T
P P 10,000 ppm in 5% HNO₃ Lot# 9-160A
Si Si 1000 ppm in KOH Lot# 086DM Spex Industries, Edison, NJ
S (NH₄)₂SO₄ in H₂O Lot# 9-231M
Ta TaCl₅ 10,000 ppm in 5% HCl/tr HF Lot# 9-335M
Ti Ti 10,000 ppm in 5% HF Lot# 9-079EE
W W 10,000 ppm in 5% HF/tr HNO₃ Lot# 8-685L
Zr ZrCl₂O 10,100 ppm in 5% HCl Lot# 9-078G

50 mL of each mixed standard are added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

SST-4:

Stock solution from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standard as follows:

SM-50 Ga, In, Tl, Ge, Sn, Pb, As, Sb, Bi, Se, Te, Th, & U 100 ppm Lot# 0-119D

Solution is used directly for calibration.

SST-5:

Stock solution from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standard as follows:

SM-60 Sc, Y, La, Ce, Pr, Nd, Sm, Eu, Gd, Tb, Dy, Ho, Er, Tm, Yb, & Lu 100 ppm Lot# 7-165F

50 mL of SM-60 is added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

ICP Calibration - April 30, 1990

Sample name	: SST0		
Programme	: SST		
	30-Apr-90 10:18:35		
NAME	MV	INT	RSD
AL	2.29	1.14	
SB	0.53	0.78	
AS	1.55	1.03	
BA	4.02	0.97	
BE	0.94	2.32	
BL	6.18	0.72	
B	5.52	1.17	
CU	3.43	0.84	
CA	0.51	1.71	
CE	5.67	1.02	
CR	1.58	1.26	
CO	0.26	0.22	
CU	3.20	0.99	
EU	4.28	1.17	
FE	1.83	0.60	
LA	0.37	1.10	
PB	0.32	0.73	
LI	3.96	0.95	
MG	0.49	0.91	
MN	1.01	1.12	
HG	5.82	0.85	
MO	2.81	0.71	
ND	5.68	1.14	
NI	5.34	0.50	
P	1.67	0.91	
K	3.20	0.53	
SM	5.17	1.03	
SE	2.48	0.87	
SI	3.87	0.16	
AG	16.70	0.91	
NA	5.60	1.23	
SR	3.81	0.83	
S	0.92	1.48	
TA	4.57	1.16	
TL	5.03	0.87	
TH	1.14	1.07	
SN	1.97	1.05	
TI	4.21	0.77	
W	2.10	1.53	
U	5.37	1.09	
V1	5.09	0.93	
ZN	4.69	0.65	
ZR	4.95	0.85	

ICP Calibration - April 30, 1990

Sample name	:	SST1	
Programme	:	SST	30-Apr-90 10:22:40

NAME	MV	INT	RSD
Li	553.61	0.25	
K	16.56	0.20	
Na	75.89	0.21	

Sample name	:	SST2	
Programme	:	SST	30-Apr-90 10:24:28

NAME	MV	INT	RSD
BA	437.78	0.60	
BE	571.45	0.61	
CD	555.48	0.56	
CA	588.05	0.58	
CR	114.65	1.83	
CO	6.01	1.37	
CU	133.33	0.58	
FE	174.15	0.59	
MG	639.16	0.41	
MN	415.50	0.44	
NI	259.77	0.49	
AG	621.48	0.46	
SR	277.57	0.56	
V1	236.32	1.15	
ZN	844.10	0.47	

Sample name	:	SST3	
Programme	:	SST	30-Apr-90 10:27:02

NAME	MV	INT	RSD
AL	26.28	0.55	
B	783.88	0.71	
HG	1144.05	0.43	
MO	456.95	0.66	
P	77.75	0.56	
SI	103.25	0.59	
S	49.36	0.80	
Ta	202.46	0.63	
TI	662.47	0.57	
W	104.41	0.63	
ZR	243.32	0.51	

Sample name	:	SST4	
Programme	:	SST	30-Apr-90 10:29:04

NAME	MV	INT	RSD
SB	10.88	1.02	
AS	175.33	0.66	
RI	155.55	0.56	
PR	8.02	0.63	
SE	75.98	0.55	
TL	59.00	0.32	

ICP Calibration - April 30, 1990

Sample name : SST4
 Programme : SST 30-Apr-90 10:29:04

NAME	MV INT	RSD
SB	10.88	1.02
AS	175.33	0.66
BI	155.55	0.56
PH	8.02	0.63
SE	75.98	0.55
TL	59.00	0.32
TH	20.76	0.50
SN	383.46	0.71
U	16.25	0.47

Sample name : SST5
 Programme : SST 30-Apr-90 10:31:36

NAME	MV INT	RSD
CE	21.38	0.28
EU	670.06	0.58
LA	8.07	0.35
ND	27.77	0.15
SM	18.02	0.28

Programme name : SST Channel name : AL Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients			
			C0	C1	C2	C3
CRV1	2.0910	27.594	-0.457031E+01	0.207647E+01		

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	2.2010	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	26.280	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : SB1 Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients			
			C0	C1	C2	C3
CRV1	0.5076	11.421	-0.516647E+01	0.966900E+01		

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.5343	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST4	0	10.877	100.00	100.00	100.00	0.0000	0.0000	CRV1

ICP Calibration - April 30, 1990

Programme name : SST Channel name : AS Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1 1.4763 184.10 -0.894243E+00 0.575446E+00

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	----------	----------	----------	-----------	------------	---------	-------

SST0 0 1.5540 0.0000 0.0000 0.0000 0.0000 CRV1
 SST4 0 175.33 100.00 100.00 100.00 0.0000 0.0000 CRV1

Programme name : SST Channel name : RA Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1 3.8152 459.67 -0.185168E+00 0.461076E-01

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	----------	----------	----------	-----------	------------	---------	-------

SST0 0 4.0160 0.0000 0.0000 -0.000 -0.000 CRV1
 SST2 0 437.78 20.000 20.000 20.000 0.0000 0.0000 CRV1

Programme name : SST Channel name : BE1 Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1 0.8955 600.02 -0.330466E-01 0.350565E-01

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	----------	----------	----------	-----------	------------	---------	-------

SST0 0 0.9427 0.0000 0.0000 -0.000 -0.000 CRV1
 SST2 0 571.45 20.000 20.000 20.000 0.0000 0.0000 CRV1

Programme name : SST Channel name : BI Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1 5.8694 163.33 -0.413622E+01 0.669471E+00

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
------	--------	------	------	------	------	------	---------	-------

ICP Calibration - April 30, 1990

Programme name : SST Channel name : B Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	5.8694	163.33	-0.413622E+01	0.669471E+00				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	6.1783	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST4	0	155.55	100.00	100.00	100.00	0.0000	0.0000	CRV1
Programme name : SST Channel name : B Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	5.2468	823.07	-0.354788E+00	0.642382E-01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	5.5230	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	783.88	50.000	50.000	50.000	-0.000	-0.000	CRV1
Programme name : SST Channel name : CD Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	3.2547	583.25	-0.124118E+00	0.362283E-01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	3.4260	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	555.48	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST Channel name : CA Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	0.4804	617.45	-0.172130E-01	0.340402E-01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	0.5057	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1

ICP Calibration - April 30, 1990

Programme name : SST			Channel name : CA			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	0.4804	617.45	-0.172130E-01	0.340402E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST10	0	0.5057	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	588.05	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SET			Channel name : CE			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	5.3859	22.449	-0.721718E+01	0.127302E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST10	0	5.6693	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST5	0	21.380	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : CR			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	1.4988	120.39	-0.279042E+00	0.176870E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST10	0	1.5777	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	114.65	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : CO			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	0.2454	6.3147	-0.897666E+00	0.347484E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : CO	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2
							C3

CRV1	0.2454	6.3147	-0.897666E+00	0.347484E+01
------	--------	--------	---------------	--------------

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	0.2583	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	6.0140	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : CU	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2
							C3

CRV1	3.0391	140.00	-0.491645E+00	0.153687E+00
------	--------	--------	---------------	--------------

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	3.1990	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST2	0	133.33	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : EU	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2
							C3

CRV1	4.0651	703.57	-0.128540E+00	0.300397E-01
------	--------	--------	---------------	--------------

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	4.2790	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST5	0	670.06	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : FE	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2
							C3

CRV1	1.7426	192.86	-0.212907E+00	0.116068E+00
------	--------	--------	---------------	--------------

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
------	--------	------	------	------	------	------	---------	-------

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : FE	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	1.7426	182.86	-0.212907E+00	0.116068E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Curve		

SST0	0	1.8343	0.0000	0.0000	-0.000	-0.000	CRV1
SST2	0	174.15	20.000	20.000	20.000	0.0000	CRV1

Programme name : SST	Channel name : LA	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	0.3490	8.4735	-0.953782E+00	0.259650E+01	
------	--------	--------	---------------	--------------	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Curve		

SST0	0	0.3673	0.0000	0.0000	0.0000	0.0000	CRV1
SST5	0	8.0700	20.000	20.000	20.000	0.0000	CRV1

Programme name : SST	Channel name : PB	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	0.3018	8.4242	-0.412269E+01	0.129780E+02	
------	--------	--------	---------------	--------------	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Curve		

SST0	0	0.3177	0.0000	0.0000	-0.000	-0.000	CRV1
SST4	0	8.0230	100.00	100.00	100.00	0.0000	CRV1

Programme name : SST	Channel name : LI	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	3.7642	581.29	-0.360442E+00	0.909672E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Curve		

ICP Calibration - April 30, 1990

Programme name : SST			Channel name : LI			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	3.7642	581.29	-0.360442E+00	0.909672E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.9623	0.0000	0.0000	-0.000	-0.000		CRV1
SST1	0	553.61	50.000	50.000	50.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : MG			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	0.4699	671.12	-0.154907E-01	0.313154E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.4947	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	639.16	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : MN			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	0.9614	436.28	-0.488312E-01	0.482522E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.0120	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	415.50	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : HG			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	5.5284	1201.3	-0.255631E+00	0.439278E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : HG	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	5.5284	1201.3	-0.255631E+00	0.439278E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	5.8193	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	1144.1	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : MD	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	2.6654	479.79	-0.308898E+00	0.110098E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	2.0057	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST3	0	456.95	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : ND	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	5.3925	29.157	-0.513873E+01	0.905291E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	5.6763	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST5	0	27.769	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : NI	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	5.0746	272.76	-0.419898E+00	0.736081E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration - April 30, 1990

Programme name : SST			Channel name : NI			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	5.0746	272.76	-0.419898E+00	0.786031E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.3417	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	259.77	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : P			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	1.5087	81.641	-0.109905E+01	0.657194E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.6723	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST3	0	77.753	50.000	50.000	50.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : K			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	3.0375	17.383	-0.119679E+02	0.374308E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.1973	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST1	0	16.555	50.000	50.000	50.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : SM			Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients					
	C0	C1	C2	C3				
CRV1	4.9071	18.919	-0.803797E+01	0.155614E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : SM	Polynomial type : CC			
Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1 4.9071 18.919 -0.803297E+01 9.155614E+01

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
SST0	0	5.1653	0.0000	0.0000	0.0000	0.0000	-0.000	CRV1
SST5	0	18.018	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : SE Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1 2.3535 79.783 -0.337022E+01 0.136042E+01

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
SST0	0	2.4773	0.0000	0.0000	-0.000	-0.000	-0.000	CRV1
SST4	0	75.984	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : SI Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1 3.6727 108.41 -0.194506E+01 0.503119E+00

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
SST0	0	3.8660	0.0000	0.0000	0.0000	0.0000	-0.000	CRV1
SST3	0	103.25	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : AG Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1 15.864 652.56 -0.552230E+00 0.330697E-01

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : AG	Polynomial type : CC		
----------------------	-------------------	----------------------	--	--

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3

CRV1	15.894	652.56	-0.552230E+00	0.330697E-01				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	16.099	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	621.48	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : NA	Polynomial type : CC		
----------------------	-------------------	----------------------	--	--

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3

CRV1	5.3184	79.688	-0.398203E+01	0.711288E+00				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	5.5983	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST1	0	75.893	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : SR	Polynomial type : CC		
----------------------	-------------------	----------------------	--	--

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3

CRV1	3.6160	816.45	-0.983851E-01	0.258477E-01				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	3.8063	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	777.57	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : S	Polynomial type : CC		
----------------------	------------------	----------------------	--	--

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3

CRV1	0.8696	51.924	-0.944798E+00	0.103219E+01				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int. (Y)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : S	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	0.8696	51.824	-0.944798E+00	0.103219E+01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	0.9153	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	49.356	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : TA	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	4.3377	212.58	-0.115365E+01	0.252660E+00				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	4.5660	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	202.46	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : TL2	Polynomial type : CC
----------------------	--------------------	----------------------

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	4.7769	61.950	-0.931668E+01	0.185284E+01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	5.0283	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST4	0	59.000	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST	Channel name : TH	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	1.0789	21.796	-0.578772E+01	0.509632E+01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : TH	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	1.0789	21.796	-0.578772E+01	0.509632E+01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.1357	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST4	0	20.758	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST	Channel name : SN	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	1.8750	402.64	-0.517357E+00	0.262130E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.9737	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST4	0	382.46	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST	Channel name : TI	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	4.0011	695.59	-0.319910E+00	0.759581E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.2117	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	662.47	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : W	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	1.9906	109.63	-0.102401E+01	0.488708E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration - April 30, 1990

Programme name : SST	Channel name : W	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2

CRV1	1.9906	109.63	-0.102401E+01	0.488708E+00			
------	--------	--------	---------------	--------------	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Calc	Conc	Error		
SST0	0	2.0953	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	104.41	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : U	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2

CRV1	5.1025	17.057	-0.493930E+02	0.919625E+01			
------	--------	--------	---------------	--------------	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Calc	Conc	Error		
SST0	0	5.3710	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST4	0	16.245	100.00	100.00	100.00	-0.000	-0.000	CRV1

Programme name : SST	Channel name : V1	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2

CRV1	4.8390	248.14	-0.440576E+00	0.864950E-01			
------	--------	--------	---------------	--------------	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Calc	Conc	Error		
EST0	0	5.0937	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	236.32	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : ZN	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min	Int	Max	Int	Curve Coefficients		
					C0	C1	C2

CRV1	4.4599	886.31	-0.111257E+00	0.238264E-01			
------	--------	--------	---------------	--------------	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Calc	Conc	Error		

ICP Calibration - April 30, 1990

Programme name : SST			Channel name : ZN			Polynomial type : CC			
Curve	Min Int	Max Int	C0	Curve Coefficients			C1	C2	C3
CRV1	4.4599	886.31	-0.111257E+00	0.238264E-01					
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve	
SST0	0	4.6947	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1	
SST2	0	844.10	20.000	20.000	20.000	0.0000	0.0000	CRV1	
Programme name : SST			Channel name : ZR			Polynomial type : CC			
Curve	Min Int	Max Int	C0	Curve Coefficients			C1	C2	C3
CRV1	4.7060	255.49	-0.103907E+01	0.209757E+00					
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve	
SST0	0	4.9537	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1	
SST3	0	243.32	50.000	50.000	50.000	0.0000	0.0000	CRV1	
Sample name : HND3									
Programme : SST									
NAME	MV	INT	CONCEN	RSD					
Al	2.07	(-0.271	-28.40						
Sb	0.52	-0.097	-47.26						
As	1.46	(-0.055	-23.84						
Ba	3.72	(-0.013	-24.03						
Be	0.89	(-0.002	-16.54						
Ri	5.86	(-0.212	-30.47						
B	5.21	(-0.020	-24.51						
Cd	3.25	(-0.006	-16.00						
Ca	0.49	-0.001	-22.50						
Ce	5.28	(-0.493	-26.71						
Cr	1.49	(-0.016	-32.16						
Co	0.26	-0.003	-416.33						
Cu	2.98	(-0.033	-22.66						
Eu	3.97	(-0.009	-22.84						
Fe	1.72	(-0.013	-39.64						
La	0.36	-0.030	-24.74						
Pb	0.31	-0.087	-30.00						
Li	3.70	(-0.024	-26.91						
Mg	0.48	-0.001	-23.32						
Mn	0.97	-0.002	-27.42						
Hg	5.39	(-0.019	-26.88						
Mo	2.67	-0.015	-18.69						
Nd	5.30	(-0.344	-34.84						
Ni	5.04	(-0.020	-14.07						

ICP Analysis - April 30, 1990

Acid Blank

Sample name	:	HNO3		
Programme	:	SST	30-Apr-90 10:43:33	
NAME	MV	INT	CONCEN	RSID
Al	2.07	(-0.271	-29.40	
Sb	0.52	-0.097	-47.26	
As	1.46	(-0.055	-23.84	
Ru	3.72	(-0.013	-24.03	
Be	0.89	(-0.002	-16.54	
Bi	5.86	(-0.212	-30.47	
R	5.21	(-0.020	-24.51	
Cd	3.25	(-0.006	-16.00	
Ca	0.49	-0.001	-27.50	
Ge	5.28	(-0.493	-26.71	
Cr	1.49	(-0.016	-32.16	
Co	0.26	-0.003	-416.33	
Cu	2.98	(-0.033	-22.66	
Eu	3.97	(-0.009	-22.84	
Fe	1.22	(-0.013	-39.64	
La	0.36	-0.039	-24.24	
Pt	0.31	-0.007	-30.00	
Li	3.70	(-0.024	-26.91	
Mg	0.48	-0.001	-23.32	
Mn	0.97	-0.002	-27.42	
Hg	5.39	(-0.019	-26.88	
Mo	2.67	-0.015	-18.69	
Nd	5.30	(-0.344	-34.84	
Ni	3.04	(-0.023	-14.02	
P	1.55	(-0.081	-36.19	
K	3.01	(-0.715	-20.14	
Sm	4.30	(-0.574	-24.73	
Se	2.34	(-0.189	-20.31	
Si	3.53	(-0.170	-17.75	
Ag	15.49	(-0.040	-25.00	
Na	5.20	(-0.284	-24.11	
Sr	3.58	(-0.006	-22.84	
S	0.87	(-0.047	-48.24	
Ta	4.35	(-0.080	-33.71	
Tl	4.64	(-0.711	-18.53	
Th	1.07	(-0.357	-24.30	
Sn	1.88	-0.025	-25.61	
Ti	3.97	(-0.018	-22.57	
W	2.01	-0.041	-55.36	
U	4.90	(-3.556	-23.85	
V	4.74	(-0.031	-15.04	
Zn	4.56	-0.003	-40.02	
Zr	4.68	(-0.057	-24.52	

Sample name : 78C11K
 Sample code 1 : SST1
 Sample code 2 : DIRECT
 Programme : SST 30-Apr-90 10:47:11

NAME	MV	INT	CONCEN	RSD
Al	2.11	-0.184	-17.70	
Sb	1.59	10.220	1.14	
As	1.60	0.028	30.89	
Pa	221.15	10.011	0.74	
Br	0.90	-0.001	-5.08	
Ri	5.86	(-0.212	-25.19	
B	164.63	10.321	0.57	
Cd	278.30	9.958	0.31	
Ca	304.51	10.348	0.63	
Ce	12.92	9.225	0.64	
Cr	53.36	9.159	0.14	
Co	3.36	10.760	1.05	
Cu	69.24	10.149	0.64	
Eu	4.69	0.012	8.16	
Fe	91.46	10.402	0.50	
La	0.38	0.021	40.18	
Pb	0.31	-0.087	-45.00	
Li	112.63	9.885	0.72	
Mg	331.14	10.354	0.55	
Mn	311.08	10.196	0.38	
Hg	5.49	(-0.014	-26.63	
Mo	2.76	-0.005	-35.28	
Nd	15.28	8.697	0.53	
Ni	131.03	9.880	0.45	
P	1.57	(-0.065	-22.18	
K	9.81	24.754	0.71	
Se	4.62	(-0.655	-7.29	
Si	5.11	3.577	0.29	
Ag	3.50	(-0.106	-6.34	
Na	15.05	(-0.054	-9.32	
Sr	40.43	24.775	0.72	
S	397.78	10.183	0.29	
Ta	1.19	0.281	5.51	
Tl	4.21	(-0.089	-9.60	
Th	4.74	(-0.031	-13.49	
Sn	1.08	-0.263	-13.41	
Ti	194.61	50.548	0.48	
W	3.88	(-0.025	-6.87	
U	2.33	0.110	19.93	
V	5.34	-0.242	-161.17	
Zn	4.65	(-0.038	-3.84	
Zr	427.59	10.076	0.38	
	4.62	(-0.070	-10.76	

ICP Analysis - April 30, 1990

LMCS Check Standard

Sample name	:	03E30A		
Sample code 1	:	SST2		
Sample code 2	:	DIRECT		
Programme	:	SST		
		30-Apr-90 10:51:22		
NAME	MV	INT	CONCEN	RSD
Al	4.83	5.463	1.06	
Si	0.59	0.506	15.44	
As	4.06	1.904	0.49	
Ba	4.18	0.008	41.72	
Be	0.95	0.000	590.95	
Bi	87.19	54.237	0.48	
B	6.43	0.058	5.12	
Cd	3.51	0.003	70.68	
Ca	0.95	0.015	0.52	
Ce	5.85	0.231	51.91	
Cr	2.01	0.076	3.89	
Co	0.26	0.022	65.74	
Cu	4.84	0.252	2.62	
Dy	332.08	9.847	0.59	
Fe	2.28	0.052	9.49	
La	18.70	147.592	0.57	
Pb	4.49	54.192	0.77	
Li	3.78	-0.017	-35.39	
Mg	0.70	0.006	2.60	
Mn	1.20	0.009	10.25	
Hg	6.61	0.035	13.56	
Mo	2.87	0.007	65.51	
Nd	6.23	0.497	13.09	
Ni	5.47	0.010	70.09	
P	2.04	0.241	16.83	
K	3.06	-0.510	-28.09	
Sm	11.52	9.893	0.94	
Se	2.61	0.186	29.70	
Si	4.97	0.554	4.10	
Ag	330.66	10.383	0.32	
Na	5.35	-0.177	-35.46	
Sr	3.93	0.003	43.12	
S	1.08	0.172	11.68	
Ta	3.08	0.130	12.59	
Tl	8.35	6.149	1.65	
Th	11.36	52.117	0.51	
Sn	2.21	0.061	7.65	
Ti	4.89	0.051	7.84	
W	2.08	-0.006	-320.63	
U	11.17	53.350	1.02	
V	7.62	0.218	2.19	
Zn	5.31	0.015	9.77	
Zr	5.39	0.091	13.82	

Sample name : 77CIIJ
 Sample code 1 : SST3
 Sample code 2 : DIRECT
 Programme : SST 30-Apr-90 10:55:14

NAME	MV	INI	CONCEN	RSD
Al	26.63	50.224	0.78	
Sb	0.66	1.100	4.00	
As	102.18	57.907	0.65	
Br	4.35	0.015	14.92	
Be	274.75	9.299	0.41	
Bi	7.64	0.976	4.50	
B	7.79	0.145	63.09	
Cd	3.78	0.013	14.22	
Ca	1.33	0.028	0.78	
Cr	5.67	-0.003	-3791.9	
Cr	1.80	0.039	8.06	
Co	0.30	0.130	4.09	
Cu	3.53	0.051	9.08	
Eu	4.31	0.001	197.69	
Fe	2.25	0.045	6.28	
La	0.37	0.002	449.97	
Pb	0.35	0.160	29.23	
Li	3.93	-0.003	-139.58	
Mg	0.75	0.008	1.41	
Mn	1.35	0.017	3.97	
Hg	610.23	26.851	1.04	
Mo	447.34	48.942	0.25	
Nd	5.76	0.078	27.28	
Ni	11.76	0.505	2.03	
P	83.81	155.297	1.90	
K	3.19	-0.021	-617.67	
Sm	5.20	0.049	223.43	
Se	41.77	53.457	0.70	
Si	94.75	45.724	0.05	
Ag	27.70	0.364	0.96	
Na	6.67	0.264	5.72	
Sr	3.93	0.003	33.90	
S	52.37	153.113	1.45	
Ta	198.74	49.059	0.82	
Tl	32.54	50.980	0.55	
Rh	1.31	0.899	6.24	
Sn	2.20	0.190	1.02	
Ti	666.34	50.294	1.21	
U	45.40	21.163	0.74	
V	6.96	14.601	0.84	
V	117.64	9.734	0.45	
Zn	6.22	0.036	3.11	
Zr	241.29	49.573	1.15	

ICP Analysis - April 30, 1990

Acid Blank

Sample name	:	HND3		
Programme	:	SST	30-Apr-90 12:34:17	
NAME	MV	INT	CONCEN	RSD
Al	2.08	(-0.259	-12.25	
Si	0.51	-0.219	-14.18	
As	1.46	(-0.055	-12.31	
Ba	3.73	(-0.013	-14.05	
Be	0.88	(-0.002	-6.72	
Ca	5.77	(-0.271	-14.47	
Cr	5.30	-0.015	-5.80	
Co	3.22	(-0.007	-14.73	
Da	0.51	0.000	1374.22	
Ge	5.28	(-0.501	-12.50	
Ir	1.48	(-0.017	-20.54	
Co	0.25	-0.032	-10.71	
Cu	2.99	(-0.032	-13.86	
Eu	3.98	(-0.069	10.05	
Fe	1.72	(-0.014	-23.18	
La	0.35	-0.038	-20.83	
Pb	0.31	-0.134	-29.57	
Li	3.69	(-0.024	-11.58	
Mg	0.48	-0.001	-16.08	
Mn	0.96	(-0.003	-22.24	
Hg	6.14	0.014	23.77	
Mo	2.61	(-0.021	-11.63	
Nd	5.22	(-0.413	-14.22	
Ni	4.98	(-0.029	-17.89	
P	1.52	(-0.099	-21.40	
K	3.01	(-0.719	-16.96	
Sm	4.80	(-0.564	-12.59	
Se	2.33	(-0.205	-6.63	
Si	3.49	(-0.188	-11.63	
As	15.49	(-0.040	-11.90	
Na	5.20	(-0.385	-11.45	
Sr	3.58	(-0.006	-13.66	
S	0.87	-0.043	-15.11	
Ta	4.26	(-0.077	-15.41	
Tl	4.66	(-0.685	-19.60	
Yt	1.06	(-0.382	-14.75	
Sn	1.87	(-0.028	-20.06	
Ti	3.97	(-0.018	-13.83	
W	1.96	(-0.065	-23.43	
U	4.99	(-3.544	-11.87	
V	4.77	(-0.028	-16.50	
Zn	4.43	(-0.006	-13.66	
Zr	4.69	(-0.055	-13.26	

NAME	MV	INT	CONCEN	RSD
Al	2.21	0.017	481.36	
Si	1.58	10.148	1.55	
As	1.65	0.058	45.93	
Ba	214.14	9.688	0.21	
Be	0.93	-0.000	-170.63	
Bi	6.02	-0.106	-66.10	
Ca	157.48	9.761	0.21	
Cr	275.01	9.839	0.95	
Co	293.26	9.965	0.35	
Ce	12.95	9.274	1.40	
Cr	52.27	8.967	0.76	
Co	3.15	10.065	1.91	
Cr	66.87	9.785	0.04	
Eu	4.90	0.019	16.64	
Fe	88.78	10.092	0.31	
La	0.36	0.038	27.22	
Pb	0.31	-0.039	-69.39	
Li	108.86	9.542	0.06	
Mg	320.92	10.034	0.15	
Mn	205.58	9.871	0.41	
Hg	5.77	-0.002	-132.93	
Mo	2.80	-0.001	-589.75	
Nd	15.44	8.836	2.72	
Ni	128.67	9.694	0.83	
P	1.70	0.020	174.66	
K	9.80	24.722	1.34	
Sm	4.89	(-0.432	-41.18	
Se	5.11	3.500	3.66	
Si	3.64	(-0.115	-34.45	
Ag	15.91	-0.026	-40.05	
Na	39.27	24.307	0.32	
Sr	384.54	9.841	0.20	
S	1.23	0.323	12.01	
Ta	4.42	-0.036	-85.06	
Tl	5.12	0.163	130.52	
Ih	1.13	-0.015	-800.96	
Sn	192.97	50.066	1.01	
Ti	4.04	-0.013	-45.76	
W	2.37	0.136	6.95	
U	5.61	2.176	51.46	
V	4.96	-0.011	-48.65	
Zn	418.64	9.863	0.56	
Zr	4.82	-0.028	-63.66	

Sample name : 82B380
 Sample code 1 : SST2
 Sample code 2 : DIRECI
 Programme : SST 30-Apr-90 12:41:50

NAME	MV	INT	CONCEN	RSD
Al	4.93	5.675	1.44	
Sc	0.60	0.632	13.20	
As	4.94	1.947	0.79	
Ba	4.46	0.020	8.93	
Be	0.99	0.002	21.32	
Bi	86.68	53.895	0.62	
B	6.76	0.080	4.01	
Cd	3.67	0.009	11.70	
Ca	0.96	0.015	0.59	
Ce	6.23	0.715	9.44	
Cr	2.10	0.093	4.29	
Co	0.37	0.031	27.96	
Cu	5.00	0.277	1.70	
Eu	321.80	9.538	0.01	
Fe	2.38	0.064	5.91	
La	18.30	146.549	0.24	
Pb	4.54	54.733	0.75	
Li	4.03	0.006	37.89	
Mg	0.72	0.007	1.59	
Mn	1.24	0.011	2.38	
Hg	7.04	0.054	10.18	
Mo	2.96	0.017	12.08	
Nd	6.55	0.793	2.43	
Ni	5.72	0.030	12.90	
P	2.16	0.218	10.32	
K	3.32	0.077	83.81	
Ca	11.66	10.191	0.72	
Br	2.72	0.331	8.45	
Si	5.13	0.636	2.00	
Ag	334.69	10.185	0.31	
Na	5.74	0.098	39.42	
Sr	4.14	0.009	8.10	
S	1.14	0.232	3.30	
Ta	5.36	0.202	7.10	
Tl	8.65	6.710	1.14	
Th	11.15	51.055	0.50	
Sn	2.28	0.081	5.42	
Ti	5.11	0.068	4.93	
U	2.16	0.033	41.26	
V	11.33	54.754	0.92	
W	7.81	0.235	2.64	
Zn	5.45	0.018	5.02	
Zr	5.64	0.143	4.96	

ICP Analysis - April 30, 1990

LMCS Check Standard

Sample name : 27011J
 Sample code 1 : SST3
 Sample code 2 : DIRECT
 Programme : SST 30-Apr-90 12:45:40

NAME	MU INT	CONCEN	RSD
Al	26.17	49.767	0.85
Si	0.67	1.286	0.25
As	100.42	56.894	0.07
Br	4.58	0.026	8.50
Fe	264.74	9.248	1.04
Bi	7.87	1.130	2.76
Be	6.72	0.077	3.70
Cd	3.94	0.019	6.82
Ca	1.32	0.028	0.76
Cr	6.01	0.437	18.10
Cr	1.86	0.050	7.68
Co	0.30	0.146	1.37
Cu	3.69	0.075	6.41
Eu	4.57	0.009	16.70
Fe	2.32	0.057	5.01
La	0.38	0.033	20.89
Pb	0.34	0.264	14.75
Li	4.15	0.017	25.80
Mg	0.76	0.008	1.12
Mn	1.39	0.018	3.80
Hg	606.61	26.391	0.48
Mo	433.92	47.465	0.72
Nd	6.09	0.375	24.29
Ni	11.89	0.515	1.50
P	88.16)56.839	0.76
K	3.34	0.523	21.48
Se	5.50	0.528	17.73
Sr	41.18	52.652	0.56
Si	90.99	43.834	0.94
Ag	28.29	0.383	0.51
Na	6.97	0.973	3.88
Sr	4.11	0.008	12.13
S	52.29)53.028	0.44
Ta	195.97	48.361	0.26
Tl	32.11	50.172	0.92
Th	1.36	1.159	3.44
Sn	2.74	0.201	5.00
Ti	640.58	48.337	1.31
W	44.26	20.607	1.30
U	7.17	16.594	2.52
V	113.77	9.400	1.24
Zn	6.35	0.039	2.82
Zr	234.08	48.061	1.00

Sample name : F575
 Sample code 1 : SST1
 Sample code 2 : DIGEST
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 13:50:22

NAME	MV	INT	CONCEN	RSD
Al	2.24	0.083	82.50	
Sb	0.62	0.870	8.41	
As	1.49	-0.037	-29.42	
Ba	24.20	0.931	0.65	
Be	0.89	(-0.002	-22.69	
Bi	5.91	-0.180	-26.61	
B	20.03	0.932	0.72	
Cd	29.26	0.937	1.16	
Ca	42.68	1.406	0.83	
Ce	6.07	0.505	25.50	
Cr	6.53	0.876	0.95	
Co	0.53	0.954	1.31	
Cu	9.23	0.926	0.98	
Eu	4.08	-0.006	-39.07	
Fe	12.89	1.283	1.13	
La	0.36	-0.023	-46.63	
Pb	0.32	-0.017	-156.12	
Li	13.64	0.880	0.49	
Mg	35.12	1.084	0.69	
Mn	21.21	0.975	0.64	
Hg	5.84	0.091	480.14	
Mo	2.68	-0.014	-20.07	
Nd	6.23	0.505	23.67	
Ni	17.23	0.942	1.17	
P	1.70	0.017	176.28	
K	3.70	1.867	8.85	
Sm	4.84	(-0.508	-28.18	
Se	2.60	0.210	32.17	
Si	5.34	0.240	23.59	
Ag	15.65	(-0.035	-31.14	
Na	9.03	2.442	2.48	
Br	41.06	0.963	0.71	
S	1.02	0.111	20.83	
Ta	4.32	(-0.063	-36.43	
Tl	4.70	(-0.616	-33.51	
Tn	1.08	(-0.294	-30.60	
Sn	20.70	4.910	1.01	
Ti	4.98	0.059	9.33	
W	2.07	-0.014	-56.03	
U	5.07	(-2.737	-34.18	
V	4.73	(-0.032	-24.14	
Zn	44.65	0.952	0.87	
Zr	4.72	-0.048	-30.10	

Sample name : F575
 Sample code 1 : GST2
 Sample code 2 : RIGEST
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 12:54:41

NAME	MV	INT	CONCEN	RSD
Al	2.35	0.315	12.90	
Sb	0.51	-0.251	-22.21	
As	1.71	0.089	8.94	
Ba	3.65	(-0.017	-11.89	
Be	0.87	(-0.002	-9.59	
Bi	13.24	4.725	0.32	
B	5.76	0.015	12.35	
Cd	3.20	(-0.008	-18.53	
Ca	12.98	0.421	1.05	
Ce	5.06	(-0.281	-11.02	
Cr	1.56	-0.003	-134.68	
Co	0.25	-0.037	-19.52	
Cu	3.08	-0.018	-21.44	
Eu	35.13	0.927	1.03	
Fe	3.50	0.194	1.25	
La	2.10	4.492	1.17	
Pb	0.69	4.845	0.71	
Li	3.52	(-0.040	-9.09	
Mg	3.01	0.079	0.68	
Mn	1.28	0.013	6.10	
Hg	5.54	-0.012	-8.57	
Mo	2.58	(-0.035	-11.39	
Nd	5.06	(-0.562	-4.27	
Ni	4.95	(-0.031	-8.96	
P	1.59	(-0.055	-30.39	
K	2.89	(-1.138	-10.76	
Sm	5.18	0.030	254.39	
Se	2.28	(-0.262	-10.54	
Si	4.54	0.336	3.14	
Ag	44.28	0.912	0.39	
Na	5.43	-0.117	-36.97	
Sr	3.61	(-0.005	-18.06	
S	0.95	0.036	18.37	
Ta	4.13	(-0.111	-13.68	
Tl	4.79	-0.443	-39.26	
Th	2.00	4.379	0.12	
Sn	1.91	-0.016	-39.51	
Ti	4.91	0.053	3.31	
W	1.91	(-0.088	-7.68	
U	5.30	-0.681	-72.57	
V	4.87	-0.019	-28.17	
Zn	5.13	0.010	9.45	
Zr	4.56	(-0.082	-11.72	

Sample name : F575
 Sample code 1 : SST3
 Sample code 2 : DIGEST
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 12:58:32

NAME	MV	INT	CONDEN	RSD
Al	4.43	4.601	0.46	
Sb	0.53	-0.003	-2163.4	
As	10.23	4.993	0.91	
Ba	3.97	-0.002	-112.71	
Be	26.02	0.879	0.58	
Bi	6.17	-0.007	-688.01	
Br	6.08	0.036	4.64	
Cd	3.38	-0.002	-103.64	
Ca	12.37	0.404	0.76	
Ce	5.40	-0.348	-24.31	
Cr	1.62	0.008	20.81	
Co	0.26	-0.000	*****	
Cu	3.12	-0.012	-40.72	
Eu	4.05	(-0.007	-24.47	
Fe	3.04	0.140	2.94	
La	0.36	-0.030	-27.55	
Pb	0.31	-0.061	-74.23	
Li	3.76	(-0.019	-22.98	
Mg	2.86	0.074	0.31	
Mn	1.29	0.013	2.01	
Hg	56.96	2.247	0.96	
Mo	42.58	4.380	0.91	
Nd	5.38	(-0.266	-25.73	
Ni	5.73	0.031	40.75	
P	9.01	4.823	3.32	
K	3.07	-0.469	-24.15	
Sm	4.90	(-0.410	-24.87	
Se	5.72	4.413	0.35	
Si	6.85	1.502	6.46	
Ag	16.78	0.003	220.71	
Na	6.03	0.307	14.03	
Sr	9.80	-0.000	-908.03	
S	5.54	4.771	0.88	
Ta	19.73	3.830	41.32	
Tl	7.28	4.174	4.39	
Th	1.10	-0.187	-29.50	
Sn	2.05	0.019	23.76	
Ti	64.70	4.595	1.64	
W	5.66	1.743	14.94	
U	5.22	-1.358	-43.38	
V	15.14	0.869	0.89	
Zn	5.30	0.014	12.49	
Zr	26.15	4.447	1.29	

ICP Analysis - April 30, 1990

Reagent Blank

Sample name : F593
 Sample code 1 : BLANK
 Sample code 2 : DIRECT
 Sample code 3 : 89976
 Programme : SST 30-Apr-90 13:03:01

NAME	MV	INT	CONCEN	RSN
Al	2.36	0.332	7.20	
Sb	0.54	0.019	202.08	
As	1.52	-0.018	-8.53	
Ba	4.22	0.009	7.76	
Be	0.95	0.000	214.93	
Bi	6.23	0.031	71.33	
B	6.44	0.059	4.47	
Cd	3.45	0.001	46.89	
Ca	23.54	0.784	0.07	
Cr	5.61	-0.076	-40.93	
Co	1.65	0.013	4.90	
Cr	0.26	0.003	152.75	
Cu	3.27	0.011	12.38	
Bu	4.21	-0.002	-26.21	
Fe	6.79	0.575	1.37	
La	0.36	-0.013	-23.69	
Pb	0.32	0.030	42.86	
Li	3.90	-0.005	-25.47	
Mg	5.22	0.165	0.40	
Mn	1.52	0.025	1.26	
Hg	6.03	0.009	30.21	
Mo	2.79	-0.002	-68.78	
Nd	5.61	-0.058	-72.86	
Ni	5.37	0.002	103.69	
P	1.82	0.095	12.72	
K	3.17	-0.086	-59.03	
Sm	5.09	-0.117	-30.15	
Se	2.46	-0.019	-100.62	
Si	5.50	0.822	3.18	
Ag	16.42	-0.009	-26.78	
Na	6.08	0.345	5.26	
Sc	3.97	0.004	7.62	
S	1.05	0.144	4.47	
Ta	4.52	-0.011	-55.83	
Tl	4.97	-0.112	-135.73	
In	1.13	-0.078	-48.95	
Sn	2.04	0.017	32.12	
Ti	5.37	0.088	1.47	
W	2.11	0.005	165.86	
U	5.27	-0.886	-28.47	
V	5.03	-0.005	-57.18	
Zn	0.14	0.082	1.24	
Zr	4.90	-0.010	-35.41	

ICP Analysis - April 30, 1990

Segment 89-076

Sample name : F576
 Sample code 1 : SAMPLE
 Sample code 2 : 100-10
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 13:07:39

NAME	MV	INT	CONCEN	DILCOR	ESD
Al	4.96	5.739	579.61	2.7%	
Si	0.53	-0.090	-9.115	-59.65	
As	1.48	-0.042	-1.243	-14.50	
Br	3.90	-0.005	-0.550	-55.76	
Re	0.91	-0.001	-0.100	-45.08	
Bi	9.20	2.032	204.22	4.69	
R	6.02	0.032	3.333	33.33	
Cd	3.31	-0.004	-0.435	-37.17	
Ca	1.75	0.042	4.277	1.23	
Ce	5.44	-0.297	-30.04	-37.36	
Cr	3.31	0.129	13.070	4.24	
Co	0.26	-0.010	-1.053	-117.06	
Cu	3.10	-0.015	-1.490	-49.88	
Eu	4.08	-0.006	-0.596	-35.44	
Fe	27.56	2.986	301.56	1.37	
La	0.36	-0.016	-1.573	-34.69	
Pb	0.32	0.043	4.369	79.37	
Li	3.79	-0.015	-1.565	-33.07	
Mg	0.96	0.015	1.469	2.25	
Mn	9.54	0.411	41.530	1.04	
Hg	6.96	0.050	5.070	10.19	
Mo	2.71	-0.011	-1.119	-23.65	
Nd	5.39	(-0.264	(-26.64	-32.70	
Ni	5.23	-0.009	-0.868	-72.39	
P	2.30	0.410	41.397	10.82	
K	3.07	-0.495	-50.03	-34.03	
Sm	4.93	-0.059	-36.25	-38.79	
Se	2.44	-0.057	-5.771	-116.89	
Si	3.80	-0.033	-3.232	-168.17	
Ag	16.03	-0.022	-2.228	-45.46	
Na	19.88	10.161	1026.3	1.87	
Sr	5.30	0.039	3.889	4.40	
S	1.04	0.125	12.580	10.59	
Ta	4.39	-0.046	-4.619	-51.46	
Tl	4.81	-0.409	-41.29	-54.29	
Th	1.09	-0.229	-23.16	-31.53	
Sn	1.94	-0.009	-0.900	-70.61	
Ti	4.09	-0.009	-0.933	-48.83	
W	2.04	-0.027	-2.682	-58.43	
U	5.17	-1.848	-186.7	-45.92	
V	4.86	-0.020	-2.047	-39.48	
Zn	5.56	0.021	2.086	8.19	
Zr	4.79	-0.035	-3.517	-40.69	

Dilution factor : 101.000

Sample name : F576
 Sample code 1 : SAMPLE
 Sample code 2 : 500-10
 Sample code 3 : 89076
 Programme : SST

30-Apr-90 13:31:53

NAME	MV	INT	CONCEN	DILUTION	RSD
Al	15.19	26.780	562.37	0.65	
Sb	0.51	-0.322	-4.670	-36.98	
As	1.43	(-0.072	(-1.511	-13.17	
Ba	3.86	-0.007	-0.154	-20.13	
Be	0.89	(-0.002	(-0.040	-18.44	
Bi	20.25	9.418	197.77	0.41	
B	5.66	0.009	0.186	149.71	
Cd	3.20	(-0.008	(-0.169	-24.60	
Ca	5.93	0.187	3.919	0.67	
Ce	5.03	(-0.817	(-17.15	-11.31	
Cr	5.07	0.617	12.953	0.59	
Co	0.25	-0.042	-0.876	-20.97	
Cu	3.06	-0.021	-0.451	-23.64	
Eu	3.78	(-0.015	(-0.316	-11.27	
Fe	119.65	13.674	287.16	0.53	
La	0.35	(-0.052	(-1.091	-22.55	
Pb	0.39	0.138	2.907	32.92	
Li	3.50	(-0.042	(-0.884	-10.39	
Mg	4.87	0.137	3.875	0.71	
Mn	39.92	1.080	39.489	0.43	
Hg	6.14	0.014	0.295	119.39	
Mo	2.61	(-0.022	(-0.452	-5.38	
Nd	5.05	(-0.571	(-11.98	-4.16	
Ni	5.42	0.006	0.127	90.59	
P	4.48	1.846	38.776	6.79	
K	2.88	(-1.184	(-24.87	-9.96	
Sm	4.55	(-0.962	(-20.20	-10.28	
Se	2.48	0.002	0.030	1061.69	
Si	3.89	0.012	0.257	47.98	
Ag	15.31	(-0.046	(-0.961	-13.60	
Na	72.14	47.333	994.00	0.74	
Sr	11.03	0.187	3.921	0.73	
G	1.49	0.595	12.493	4.43	
Ta	4.10	(-0.118	(-2.471	-11.48	
Tl	4.50	(-0.970	(-20.38	-9.80	
Th	1.02	(-0.603	(-12.66	-11.97	
Sn	1.87	(-0.026	(-0.547	-8.80	
Ta	4.03	-0.014	-0.289	-20.35	
W	1.95	(-0.069	(-1.444	-11.11	
U	4.97	(-3.676	(-77.25	-16.64	
V	4.66	(-0.037	(-0.779	-6.08	
Zn	8.58	0.093	1.945	1.98	
Zr	4.55	(-0.035	(-1.288	-10.97	

Dilution factor : 21.0000

Sample name : F527
 Sample code 1 : DUPSAM
 Sample code 2 : 100-10
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 13:16:24

NAME	MV	INT	CONCEN	OILCOR	RSU
Al	4.31	4.379	442.24	2.27	
Sb	0.52	-0.106	-10.74	-31.93	
As	1.47	(-0.048	(-4.882	-18.56	
Br	3.86	-0.007	-0.737	-30.40	
Be	0.91	-0.001	-0.125	-12.76	
Bi	8.59	1.615	163.09	1.03	
R	6.00	0.030	3.073	22.67	
Cd	3.28	-0.005	-0.517	-31.40	
Ca	1.63	0.038	3.854	1.03	
Ce	5.38	(-0.368	(-37.16	-23.27	
Cr	2.27	0.123	12.374	3.39	
Co	0.25	-0.027	-2.691	-27.15	
Cu	3.08	-0.019	-1.914	-20.47	
Eu	4.05	(-0.007	(-0.706	-17.64	
Fe	26.32	2.842	287.01	1.16	
La	0.36	-0.029	-2.885	-18.92	
Pb	0.31	-0.069	-6.991	-23.64	
Li	3.75	(-0.019	(-1.936	-19.56	
Mg	0.97	0.015	1.502	1.82	
Mn	9.03	0.387	29.064	1.07	
Hg	6.68	0.038	3.813	20.50	
Mo	2.68	-0.013	-1.353	-25.32	
Nd	5.34	(-0.308	(-31.09	-25.18	
Ni	5.27	-0.005	-0.535	-38.77	
P	2.23	0.366	36.973	11.16	
K	3.04	-0.594	-59.98	-13.83	
Sm	4.69	(-0.428	(-43.27	-32.16	
Se	2.41	-0.089	-8.977	-47.45	
Si	3.73	-0.062	-6.920	-21.21	
Ag	15.76	(-0.031	(-3.128	-18.35	
Na	18.23	8.985	907.53	1.47	
Sr	5.12	0.034	3.436	3.34	
S	0.59	0.072	7.298	10.03	
Ta	4.33	(-0.059	(-5.937	-33.78	
Tl	4.80	-0.416	-41.98	-17.10	
In	1.00	-0.375	-37.80	-21.06	
Sn	1.08	-0.026	-2.603	-27.22	
Ti	4.03	-0.015	-1.476	19.39	
W	2.01	-0.042	-4.245	-24.12	
U	5.12	-2.305	-232.8	-24.08	
V	4.90	-0.017	-1.698	-29.55	
Zn	5.41	0.017	1.710	6.87	
Zr	4.80	-0.032	-3.213	-24.64	

Dilution factor : 101.000

Sample code 1 : DUPSAM
 Sample code 2 : 500-10
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 13:20:31

NAME	MV	INT	CONCEN	DILCOR	RSN
Al	13.19	22.805	479.91	0.26	
Sb	0.54	0.045	0.948	130.34	
As	1.56	0.005	0.105	312.73	
Ba	4.32	0.014	0.291	35.69	
Be	0.97	0.001	0.021	14.87	
Bi	19.25	8.753	183.82	0.31	
Br	6.07	0.035	0.731	6.43	
Cd	3.46	0.001	0.028	61.93	
Ca	5.63	0.174	3.663	0.39	
Ce	5.69	0.030	0.633	424.46	
Cr	5.35	0.666	13.994	0.71	
Co	0.26	0.001	0.024	754.92	
Cu	3.40	0.031	0.641	28.18	
Eu	4.29	0.000	0.006	818.59	
Fe	120.94	13.824	290.30	0.38	
La	0.37	0.003	0.073	338.20	
Pb	0.34	0.298	6.268	5.02	
Li	0.94	-0.002	-0.038	-329.35	
Mg	5.87	0.168	3.532	2.70	
Mn	39.84	1.874	39.345	0.42	
Hg	6.52	0.031	0.647	17.36	
Mo	2.82	0.002	0.042	112.72	
Nd	5.67	-0.009	-0.196	-757.30	
Ni	6.23	0.070	1.466	9.12	
P	4.89	2.117	44.462	0.67	
K	3.20	0.021	0.445	939.37	
Sm	5.16	-0.010	-0.218	-1433.5	
Se	2.71	0.317	6.057	12.74	
Si	4.55	0.342	7.188	3.75	
Ag	16.74	0.001	0.031	636.67	
Na	68.33	44.619	936.99	0.08	
Sr	10.99	0.186	3.897	0.57	
S	1.45	0.548	11.517	1.52	
Ta	4.60	0.007	0.154	272.02	
Tl	5.23	0.356	7.484	16.15	
Th	1.13	-0.005	-0.107	-1751.3	
Sn	2.01	0.010	0.220	59.28	
Ti	4.26	0.004	0.080	118.46	
W	2.14	0.021	0.441	79.01	
U	5.60	2.063	43.324	43.88	
V	5.23	0.012	0.256	47.98	
Zn	8.78	0.097	2.045	0.16	
Zr	5.30	0.051	1.065	27.47	

Dilution factor : 21.0000

Sample name : F578
 Sample code 1 : SPIKE
 Sample code 2 : 100-10
 Sample code 3 : 89076
 Programme : SST

30-Apr-90 13:24:32

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	4.81	5.411	546.54	1.71	
Se	0.53	0.000	0.000		
As	1.65	0.053	5.386	51.64	
Ba	4.29	0.013	1.268	48.61	
Br	1.22	0.010	0.974	4.25	
Bi	8.82	1.771	178.07	7.09	
B	6.16	0.041	4.155	29.93	
Cd	3.68	0.009	0.917	28.74	
Ca	2.13	0.055	5.574	1.03	
Ce	5.69	0.023	2.314	1073.51	
Cr	2.37	0.140	14.148	6.35	
Co	0.26	0.013	1.287	61.82	
Cu	3.30	0.016	1.609	95.50	
Eu	4.61	0.010	0.993	44.73	
Fe	24.26	2.603	262.92	1.46	
La	0.39	0.049	4.983	33.84	
Pb	0.33	0.156	15.729	42.76	
Ti	4.05	0.008	0.824	134.72	
Mg	2.25	0.055	5.541	9.69	
Mn	9.16	0.393	39.704	0.59	
Hg	8.13	0.101	10.249	11.80	
Mo	3.20	0.044	4.437	21.69	
Nd	5.65	-0.028	-2.804	-698.22	
Ni	5.53	0.015	1.501	87.54	
P	2.25	0.377	38.100	14.26	
K	3.19	-0.016	-1.638	-2061.7	
Sr	5.17	0.009	0.891	3068.06	
Se	2.55	0.097	9.756	99.59	
Si	3.96	0.049	4.946	81.53	
Ag	16.74	0.001	0.120	1632.19	
Na	18.45	9.145	923.60	0.97	
Sr	5.72	0.049	4.987	4.62	
S	1.10	0.186	18.835	14.42	
Ta	4.58	0.003	0.298	1159.86	
Tl	5.09	0.120	12.164	210.12	
Th	1.14	0.044	4.461	398.44	
Sr	2.17	0.052	5.286	27.27	
Ti	4.85	0.049	4.915	17.91	
W	2.11	0.006	0.609	620.98	
U	5.42	0.408	41.178	415.20	
V	5.15	0.005	0.504	169.46	
Zn	6.04	0.032	3.229	9.52	
Zr	5.23	0.057	5.798	48.84	

Dilution factor : 101.000

Sample name : ES78
 Sample code 1 : SPIKE
 Sample code 2 : 500-10
 Sample code 3 : 89076
 Programme : SSI 30-Apr-90 13:26:48

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	14.44	25.404	533.49	1.19	
Si	0.52	-0.116	-2.437	-37.58	
As	1.91	0.208	4.362	9.45	
Ba	4.95	0.043	0.000	5.03	
Be	2.24	0.046	0.956	0.91	
Bi	18.38	8.156	171.48	1.30	
B	6.22	0.044	0.934	12.66	
Cd	4.52	0.040	0.831	3.16	
Ca	7.72	0.246	5.156	1.01	
Ce	5.17	(-0.637	(-13.38	-10.20	
Cr	5.15	0.632	13.371	1.27	
Co	0.26	0.003	0.074	230.94	
Cu	3.43	0.035	0.733	12.07	
Eu	5.44	0.035	0.732	4.81	
Fe	107.73	12.291	258.11	0.83	
La	0.44	0.187	3.926	4.46	
Pb	0.35	0.394	8.267	5.71	
Li	4.07	0.009	0.197	35.99	
Mg	4.16	0.115	2.409	1.21	
Mn	39.55	1.859	39.047	1.19	
Hg	9.00	0.140	2.934	9.44	
Mo	4.67	0.205	4.303	2.55	
Nd	5.16	(-0.436	(-9.778	-6.03	
Ni	6.03	0.054	1.129	6.00	
P	4.14	1.622	34.066	3.63	
K	2.06	(-0.673	(-18.34	-10.71	
Sr	4.67	(-0.771	(-16.19	-9.94	
Se	2.70	0.308	6.466	3.02	
Si	4.37	0.255	5.357	6.54	
Ag	15.44	(-0.042	(-0.876	-11.79	
Na	66.59	43.282	911.02	1.21	
Sr	12.74	0.231	4.849	1.36	
S	1.67	0.783	16.438	3.46	
Ta	4.32	(-0.087	(-1.831	-18.85	
Tl	4.76	(-0.502	(-0.54	-12.57	
Th	1.08	-0.268	-5.637	-18.70	
Sn	2.79	0.215	4.514	3.85	
Ti	7.08	0.218	4.578	2.11	
W	2.13	0.016	0.332	56.31	
U	5.09	(-2.578	(-54.14	-12.73	
V	5.27	0.015	0.312	18.75	
Zn	10.47	0.138	2.888	1.48	
Zr	5.92	0.204	4.276	4.96	

Dilution factor : 21.0000

Sample name : F579
 Sample code 1 : SST1
 Sample code 2 : DIGEST
 Sample code 3 : 89076
 Programme : SST

30-Apr-90 13:32:49

NAME	ME INT	CONCEN	RSD
Al	2.10	-0.213	-24.34
Sb	0.60	0.670	13.40
As	1.40	(-0.086	-15.06
Ba	24.11	0.527	0.74
Be	0.86	(-0.003	-15.48
Bi	5.61	(-0.381	-18.22
B	19.94	0.926	1.71
Cd	28.59	0.911	1.70
Ca	43.08	1.449	0.49
Ce	5.68	0.008	1382.82
Cr	6.43	0.858	1.25
Co	0.51	0.866	2.67
Cu	9.09	0.906	1.35
Eu	3.79	(-0.015	-12.03
Fe	12.72	1.263	1.38
La	0.35	(-0.057	-13.12
Pb	0.30	-0.199	-3.77
Li	13.44	0.862	0.90
Mg	34.72	1.072	0.85
Mn	21.12	0.970	1.35
Hg	5.88	0.003	51.46
Mo	2.56	(-0.027	-15.39
Nd	5.89	0.189	32.11
Ni	16.08	0.907	1.98
P	1.57	(-0.067	-50.86
K	3.50	1.115	16.43
Ga	4.46	(-1.066	-10.54
Se	2.50	0.024	67.92
Si	4.26	0.182	7.78
Ag	14.43	(-0.075	-9.09
Na	8.62	2.148	3.97
Sr	40.95	0.960	0.87
S	0.95	0.048	29.46
Ta	3.99	(-0.146	-9.53
Tl	4.41	(-1.145	-15.29
In	1.01	(-0.654	-11.35
Sn	20.04	4.736	1.41
Ti	4.76	0.042	10.74
W	1.92	(-0.082	-18.61
U	4.69	(-6.244	-10.51
V	4.54	(-0.048	-12.60
Zn	44.11	0.939	1.29
Zr	4.46	(-0.103	-11.56

Sample name : F579
 Sample code 1 : SST3
 Sample code 2 : DIGEST
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 13:36:26

NAME	MV	INT	CONCEN	RSD
Al	2.45	0.516	15.33	
Sn	0.53	-0.077	-36.02	
As	1.79	0.135	5.33	
Ba	3.85	-0.008	-36.29	
Be	0.91	-0.001	-6.93	
Bi	13.78	5.087	2.98	
B	5.99	0.030	21.25	
Cd	3.33	-0.004	-36.91	
Ca	13.08	0.428	1.44	
Ce	5.33	(-0.437	-23.79	
Cr	1.61	0.006	72.19	
Co	0.36	-0.012	-79.37	
Cu	3.22	0.004	202.85	
Eu	35.86	0.949	1.62	
Fe	3.62	0.207	3.50	
La	3.14	4.604	1.70	
Pb	0.72	5.165	2.57	
Li	3.70	(-0.024	-21.32	
Hg	3.09	0.081	2.00	
Mn	1.32	0.015	7.54	
Hg	5.83	0.001	157.70	
Mo	2.67	-0.015	-19.26	
Nd	5.34	(-0.307	-27.19	
Na	5.16	-0.014	-28.12	
P	1.73	0.037	92.66	
K	3.03	(-0.631	-24.49	
Sm	5.45	0.438	22.08	
Se	2.35	(-0.179	-25.74	
Si	4.46	0.297	10.06	
Ag	45.26	0.961	2.59	
Na	5.72	0.087	83.41	
Sr	3.77	-0.001	-134.98	
S	1.01	0.096	27.04	
Ta	4.34	-0.057	-29.56	
Tl	5.08	0.094	105.49	
In	2.07	4.748	2.46	
Sn	2.00	0.007	65.04	
Ti	5.11	0.068	8.28	
W	2.00	-0.047	-20.87	
U	5.57	1.799	45.94	
V	5.09	-0.000	-1296.1	
Zn	5.27	0.014	19.25	
Zr	4.75	-0.043	-28.91	

Sample name : FS79
 Sample code 1 : SST3
 Sample code 2 : DIGEST
 Sample code 3 : 89076
 Programme : SST 30-Apr-90 13:40:16

NAME	MV	INT	CONCEN	RSD
Al	4.53	4.828	1.06	
Sb	0.54	0.039	52.04	
As	10.03	5.222	0.96	
Ba	4.07	0.002	110.87	
Be	26.80	0.506	0.69	
Bi	6.21	0.018	213.22	
H	6.17	0.042	5.80	
Cd	3.44	0.000	234.17	
Ca	12.67	0.414	0.27	
Ce	5.53	-0.182	-60.49	
Cr	1.66	0.015	32.60	
Co	0.26	0.012	17.32	
Cu	3.19	-0.002	-310.16	
Ru	4.16	-0.003	-56.26	
Fe	3.09	0.146	3.10	
La	0.36	-0.015	-56.73	
Pb	0.32	-0.022	-103.93	
Li	3.85	-0.010	-46.53	
Mg	2.92	0.076	0.99	
Mn	1.31	0.014	6.39	
Hg	59.78	2.320	1.68	
Mo	44.22	4.559	1.09	
Nd	5.49	-0.170	-56.37	
Ni	5.77	0.033	14.43	
P	9.68	5.230	3.29	
K	3.12	-0.281	-56.48	
Sm	5.03	-0.218	-51.59	
Se	5.97	4.752	3.60	
Si	6.80	1.518	1.21	
Ag	17.13	0.014	51.50	
Na	6.18	0.416	13.86	
Sr	3.88	0.002	66.31	
S	5.82	5.061	1.15	
Ta	20.48	4.021	4.37	
Tl	7.49	4.555	1.75	
In	1.13	-0.053	-128.51	
Sn	3.07	0.024	15.67	
Ti	66.54	4.734	0.30	
W	5.84	1.820	0.44	
U	5.35	-0.181	-393.91	
V	15.61	0.909	1.08	
Zn	5.37	0.016	9.75	
Zr	26.89	4.601	0.60	

ICP Analysis - April 30, 1990

Acid Blank

Sample name	:	HNO3		
Programme	:	SST	30-Apr-90 13:44:04	
NAME	MV	INT	CONCEN	RSD
Al	2.13	-0.149	-57.35	
Sb	0.52	-0.119	-70.69	
As	1.49	-0.035	-42.07	
Ba	3.86	-0.007	-49.89	
Be	0.91	-0.001	-54.73	
Bi	5.92	-0.172	-37.67	
B	5.60	0.005	19.14	
Cd	3.31	-0.004	-36.91	
Ca	0.53	0.001	30.03	
Cr	5.47	-0.258	-56.69	
Co	1.51	-0.012	-34.09	
Co	0.25	-0.014	-62.92	
Cu	3.08	-0.019	-46.56	
Eu	4.12	-0.005	-49.93	
Fe	1.79	-0.006	-68.81	
La	0.36	-0.015	-53.91	
Pb	0.32	-0.025	-112.50	
Li	3.82	-0.013	-55.34	
Mg	0.45	-0.000	-83.89	
Mn	0.99	-0.001	-79.25	
Hg	6.26	0.019	48.04	
Mo	2.68	-0.014	-39.32	
Nd	5.45	-0.206	-41.34	
Ni	5.15	-0.015	-36.32	
P	1.62	-0.037	-84.24	
K	3.08	-0.439	-42.25	
Sm	4.98	-0.295	-53.00	
Se	2.38	-0.126	-46.57	
Si	3.60	(-0.136	-30.29	
Ag	15.96	-0.024	-44.31	
Na	5.32	-0.162	-46.05	
Sr	3.69	-0.003	-49.73	
S	0.90	-0.021	-122.95	
Ta	4.39	-0.043	-57.12	
Tl	4.81	-0.408	-52.76	
Th	1.09	-0.212	-47.21	
Sn	1.92	-0.014	-89.84	
Ti	4.06	-0.011	-45.56	
W	2.02	-0.037	-45.59	
U	5.15	-1.993	-47.78	
V	4.84	-0.023	-47.71	
Zn	4.60	-0.002	-63.91	
Zr	4.61	-0.020	-51.54	

Sample name	:	78C11K		
Sample code 1	:	SST1		
Sample code 3	:	DIRECT		
Programme	:	SST		
		30-Apr-90 13:47:42		
NAME	MV	INT	CONCEN	RSD
Al	2.12	-0.170	-25.16	
B	1.60	10.307	1.61	
As	1.51	0.033	26.02	
Br	319.39	9.930	1.13	
Ca	0.90	-0.001	-20.30	
Cl	5.83	(-0.231	-13.13	
K	162.30	10.071	0.85	
Cd	275.83	9.969	1.59	
Co	300.78	10.221	0.96	
Cu	12.93	9.237	1.66	
Cr	52.69	9.041	1.28	
Ge	2.97	9.424	1.55	
Li	68.07	10.063	1.09	
Eu	4.22	0.013	13.39	
Fe	90.97	10.346	0.91	
Ta	0.38	0.031	20.97	
Pb	0.32	-0.017	-114.56	
Li	111.84	9.813	1.06	
Mo	327.65	10.245	1.10	
Mn	208.58	10.016	1.22	
Hg	5.54	0.001	641.29	
Ho	2.73	-0.008	-18.92	
Nd	15.15	8.578	3.05	
Ni	129.94	9.787	1.19	
P	1.66	-0.006	-352.32	
K	9.77	24.592	1.68	
Sm	4.66	(-0.791	-11.63	
Se	5.06	3.515	1.89	
Si	3.48	(-0.192	-10.27	
Ag	15.11	(-0.053	-12.51	
Na	40.24	34.637	1.25	
Sr	394.51	10.099	1.08	
S	1.22	0.309	0.56	
Ta	4.25	(-0.081	-15.16	
Tl	4.78	-0.406	-8.86	
Th	1.09	-0.220	-24.78	
Sn	194.01	50.339	1.35	
Ti	3.88	(-0.025	-12.08	
W	2.31	0.107	1.85	
U	5.37	-0.037	-1621.1	
V	4.56	(-0.037	-13.17	
Zn	425.07	10.016	1.30	
Zr	4.65	(-0.063	-19.55	

ICP Analysis - April 30, 1990

LMCS Check Standard

NAME	MV	INI	CONCEN	RSD
Al	4.71	5.202	0.75	
Se	0.57	0.361	9.41	
As	4.70	1.812	1.07	
Ba	4.02	0.000	9500.53	
Be	0.92	-0.001	-32.43	
Bi	85.67	53.219	0.62	
B	6.44	0.039	3.75	
Cd	3.39	-0.001	-167.29	
Ca	0.93	0.015	0.49	
Co	5.62	-0.066	-181.76	
Cr	1.94	0.064	6.91	
Co	0.35	-0.034	-36.33	
Cu	4.69	0.230	2.62	
Eu	331.05	9.916	1.01	
Fe	2.27	0.050	11.96	
La	10.54	147.179	1.01	
Pb	4.37	52.648	0.72	
Li	3.61	(-0.032	-18.68	
Mg	0.68	0.036	1.95	
Mn	1.16	0.007	11.27	
Hg	7.05	0.054	15.71	
Mo	2.76	-0.005	-110.56	
Nd	6.01	0.299	35.09	
Ni	5.29	-0.004	-210.29	
P	1.97	0.198	22.63	
K	2.93	(-1.002	-13.94	
Sm	11.31	9.561	0.79	
Se	2.51	0.046	108.08	
Si	4.79	0.458	5.17	
Ag	337.29	10.271	0.70	
Na	5.12	(-0.339	-29.02	
Sr	3.80	-0.000	-953.70	
S	1.05	0.136	14.02	
Ta	4.89	0.082	31.37	
Tl	8.14	5.757	3.53	
In	11.24	51.476	0.84	
Sn	2.13	0.042	11.97	
Ti	4.70	0.037	10.01	
W	1.99	(-0.053	-13.60	
U	10.93	51.150	0.65	
V	7.40	0.199	2.08	
Zn	5.17	0.011	11.13	
Zr	5.23	0.058	21.24	

NAME	MV	INT	CONCEN	RSD
Al	26.45	50.351	0.84	
Sb	0.65	1.131	12.13	
As	101.43	57.470	0.30	
Ba	4.31	0.014	30.87	
Be	274.76	9.599	0.72	
Bi	7.57	0.929	6.87	
B	7.01	0.096	36.85	
Cd	3.75	0.012	14.34	
Ca	1.33	0.028	0.69	
Ce	5.62	-0.062	-281.29	
Cr	1.78	0.036	18.26	
Co	0.28	0.091	4.95	
Cu	3.50	0.047	19.55	
Bu	4.27	-0.000	-1564.3	
Fe	2.34	0.047	9.32	
La	0.37	0.000	*****	
Pb	0.33	0.125	31.60	
Li	0.89	-0.007	-16.33	
Mg	0.75	0.008	2.39	
Mn	1.34	0.016	6.52	
Hg	605.34	26.336	0.60	
Mo	440.45	48.181	0.40	
Nd	5.68	0.005	1661.82	
Ni	11.67	0.497	1.07	
P	87.36	156.315	1.63	
K	3.14	-0.301	-113.53	
Sm	5.15	-0.029	-664.92	
Se	41.17	52.632	0.98	
Si	93.43	45.062	0.52	
Ag	37.49	0.357	1.68	
Na	6.61	0.719	12.11	
Sr	3.91	0.003	73.73	
S	52.34	153.077	1.14	
Ta	196.11	48.395	0.36	
Tl	32.54	50.976	0.69	
Th	1.30	0.849	13.83	
Sn	2.68	0.185	3.01	
Ti	661.11	49.696	1.42	
W	44.96	20.549	0.52	
U	6.94	14.420	3.27	
V	115.93	9.592	0.76	
Zn	6.19	0.036	3.13	
Zr	240.73	49.456	1.23	

Sample name : F947
 Sample code 1 : SAMPLE
 Sample code 2 : 100-10
 Sample code 3 : 000008
 Programme : SST 30-Apr-90 15:00:01

NAME	MV	INI	CONCEN	DILCOR	RSD
Al	6.15	8.273	835.01	0.40	
Sb	0.50	(-0.313	(-31.56	-5.36	
As	1.41	(-0.082	(-8.222	-7.99	
Ba	3.63	(-0.018	(-1.787	-8.53	
Be	0.86	(-0.003	(-0.280	-8.98	
Bi	5.60	(-0.388	(-39.20	-15.20	
B	5.82	0.019	1.955	13.05	
Cd	3.11	(-0.011	(-1.142	-4.52	
Ca	2.50	0.068	6.032	0.30	
Ce	5.13	(-0.701	(-70.80	-7.77	
Cr	1.43	(-0.026	(-2.590	-6.91	
Co	0.25	-0.032	-3.376	-21.43	
Cu	2.91	(-0.045	(-4.558	-7.00	
Eu	3.85	(-0.013	(-1.298	-8.10	
Fe	1.86	0.002	0.250	53.92	
La	0.35	(-0.050	(-5.070	-13.69	
Pb	0.30	-0.190	-19.22	-13.64	
Li	3.63	(-0.033	(-3.369	-8.83	
Mg	1.05	0.017	1.756	0.78	
Mn	0.98	-0.002	-0.177	-1.59	
Hg	5.44	(-0.017	(-1.686	-0.92	
Mo	2.53	(-0.030	(-3.013	-4.69	
Nd	5.12	(-0.505	(-51.02	-13.45	
Ni	5.68	0.026	2.652	10.03	
P	1.54	(-0.085	(-8.629	-9.74	
K	36.33)124.00) 12524	0.24	
Sm	4.66	(-0.787	(-79.48	-8.28	
Se	2.26	(-0.292	(-29.54	-9.50	
Si	4.48	0.307	30.997	3.90	
Ag	14.99	(-0.057	(-5.725	-8.09	
Na	5.60	0.001	0.120	2910.03	
Sr	3.58	(-0.006	(-0.583	-10.89	
S	0.87	(-0.050	(-5.074	-28.79	
Ta	4.11	(-0.116	(-11.68	-9.64	
Tl	4.49	(-1.001	(-101.1	-6.72	
Th	1.03	(-0.523	(-52.85	-8.66	
Sn	1.83	(-0.039	(-3.901	-8.65	
Ti	3.84	(-0.028	(-2.826	-6.29	
W	1.92	(-0.086	(-8.704	-8.84	
U	4.82	(-5.040	(-500.0	-8.40	
V	4.60	(-0.043	(-4.345	-5.75	
Zn	4.55	-0.003	-0.340	-6.42	
Zr	4.50	(-0.079	(-8.015	-6.11	

Dilution factor : 101.000

ICP Analysis - April 30, 1990

Core 8 Composite

Sample name : F947
 Sample code 1 : SAMPLE
 Sample code 2 : 500-10
 Sample code 3 : 000000
 Programme : SST 30-Apr-90 15:04:10

NAME	MV	INT	CONCEN	DILCOK	RSD
Al	21.20	39.459	828.64	0.83	
Sb	0.51	(-0.261	(-5.482	-22.63	
As	1.46	(-0.035	(-1.164	-15.02	
Ba	3.70	(-0.014	(-0.304	-25.75	
Be	0.87	(-0.002	(-0.051	-25.29	
Bi	5.70	(-0.317	(-6.658	-20.08	
B	5.85	0.021	0.444	35.08	
Cd	3.15	(-0.010	(-0.210	-25.44	
Ca	9.09	0.292	6.137	0.77	
Co	5.21	(-0.583	(-12.25	-23.80	
Cr	1.45	(-0.022	(-0.462	-24.58	
Co	0.35	-0.031	-0.657	-27.96	
Cu	2.96	(-0.036	(-0.761	-25.01	
Eu	3.93	(-0.011	(-0.221	-23.57	
Fe	2.23	0.046	0.960	4.70	
La	0.35	-0.048	-1.000	-23.28	
Pb	0.31	-0.164	-2.452	-13.79	
Li	3.66	(-0.028	(-0.586	-24.69	
Mg	2.10	0.050	1.053	1.37	
Mn	1.15	0.006	0.125	5.59	
Hg	5.61	-0.009	-0.197	-42.70	
Mo	2.61	(-0.021	(-0.451	-19.19	
Nd	5.20	(-0.435	(-9.144	-21.81	
Ni	8.80	0.272	5.711	4.02	
P	1.60	-0.050	-1.044	-97.16	
K	159.11	1583.60	12256	0.91	
Se	4.75	(-0.640	(-13.44	-24.10	
Se	2.36	-0.161	-3.381	-31.06	
Si	4.91	0.525	11.034	7.61	
Ag	15.21	(-0.049	(-1.034	-20.61	
Na	6.13	0.380	2.981	21.24	
Sr	3.95	0.004	0.079	44.76	
S	0.89	-0.026	-0.542	-79.43	
Ta	4.15	(-0.104	(-2.193	-20.83	
Tl	4.63	(-0.734	(-15.41	-27.17	
Th	1.05	(-0.440	(-9.240	-20.86	
Sn	1.87	(-0.028	(-0.593	-43.00	
Ti	3.09	(-0.024	(-0.510	-19.64	
W	1.99	-0.050	-1.050	-30.39	
U	4.92	(-4.175	(-87.68	-23.85	
V	4.78	(-0.028	(-0.570	-29.25	
Zn	3.05	0.008	0.177	13.80	
Zr	4.65	(-0.065	(-1.357	-24.93	

Dilution factor : 21.0000

Sample name : F948
 Sample code 1 : DUPSAM
 Sample code 2 : 100-10
 Sample code 3 : 000008
 Programme : SST

30-Apr-90 15:08:27

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	5.35	6.533	659.79	0.58	
Sb	0.52	-0.106	-10.74	-27.77	
As	1.52	-0.018	-1.602	-50.39	
Ba	4.03	0.001	0.053	267.10	
Be	0.93	-0.000	-0.042	-67.87	
Bi	6.03	-0.101	-10.17	-35.98	
B	6.31	0.051	5.130	3.74	
Cd	3.35	-0.003	-0.261	-21.28	
Ca	3.00	0.085	8.583	0.42	
Ce	5.66	-0.010	-1.029	-562.72	
Cr	1.56	-0.003	-0.339	-140.27	
Co	0.26	0.010	1.053	38.49	
Cu	3.19	-0.002	-0.207	-168.76	
Eu	4.27	-0.000	-0.014	-685.74	
Fe	1.98	0.017	1.735	17.75	
La	0.37	0.002	0.175	396.84	
Pb	0.31	-0.061	-0.117	-56.69	
Li	3.95	-0.001	-0.074	-375.24	
Mg	0.83	0.010	1.053	1.25	
Mn	1.03	0.001	0.101	40.29	
Hg	5.89	0.003	0.312	115.33	
Mo	2.69	-0.013	-1.375	-15.13	
Nd	5.63	-0.043	-4.328	-70.10	
Ni	6.08	0.058	5.825	4.98	
P	1.69	0.012	1.195	99.59	
K	35.75)121.05) 12307	0.87	
Sm	5.16	0.009	-0.891	-646.51	
Se	2.43	-0.069	-0.962	-46.76	
Si	4.78	0.462	46.631	3.54	
Ag	16.55	-0.005	-0.497	-81.05	
Na	6.20	0.430	43.439	6.45	
Sr	3.81	0.000	0.021	302.16	
S	0.92	0.002	0.243	656.04	
Ta	4.51	-0.015	-1.348	-59.37	
Tl	5.06	0.051	5.177	231.81	
Th	1.13	-0.034	-3.432	-134.99	
Sn	1.94	-0.008	-0.803	-133.92	
Ti	4.16	-0.004	-0.407	-45.49	
W	2.05	-0.023	-2.320	-22.19	
U	5.35	-0.208	-21.05	-200.19	
V	5.12	0.002	0.218	287.44	
Zn	4.73	0.001	0.082	90.19	
Zr	4.94	-0.002	-0.247	-231.90	

Dilution factor : 101.000

ICP Analysis - April 30, 1990

Duplicate of Core 8 Composite

Sample name : 2948
 Sample code 1 : DUPSAM
 Sample code 2 : 500-10
 Sample code 3 : 000008
 Programme : SST 30-Apr-90 15:12:28

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	17.38	31.535	663.02	0.70	
Si	0.53	-0.071	-1.489	-59.44	
As	1.53	-0.012	-0.262	-223.38	
Ba	3.93	-0.003	-0.063	-177.09	
Be	0.91	-0.001	-0.024	-53.79	
Bi	5.94	-0.158	-3.313	-65.23	
Br	6.21	0.044	0.931	16.14	
Cd	3.31	-0.004	-0.086	-53.19	
Ca	12.07	0.394	8.266	1.29	
Ce	5.55	-0.153	-3.217	-135.00	
Cr	1.55	-0.005	-0.106	-134.74	
Co	0.26	0.007	0.146	152.75	
Cu	3.15	-0.008	-0.162	-178.39	
Eu	4.19	-0.003	-0.053	-150.34	
Fe	2.38	0.064	1.341	4.26	
La	0.36	-0.010	-0.218	-128.29	
Pb	0.32	-0.009	-0.182	-540.82	
Li	3.88	-0.008	-0.159	135.17	
Mg	3.54	0.095	2.005	0.77	
Mn	1.17	0.008	0.158	14.15	
Hg	5.77	-0.002	-0.047	-334.87	
Mo	2.73	-0.009	-0.186	-77.19	
Nd	5.50	-0.155	-3.264	-89.32	
Ni	9.24	0.306	6.436	2.43	
P	1.70	0.015	0.317	284.45	
K	161.97	1594.29	12480	0.81	
Sm	5.06	-0.166	-3.406	-140.34	
Se	3.47	-0.014	-0.286	-750.03	
Si	5.05	0.594	12.467	7.05	
Ag	16.20	-0.016	-0.344	-95.41	
Na	6.61	0.723	15.176	14.96	
Sr	3.79	-0.001	-0.011	-463.61	
S	0.94	0.023	0.491	110.56	
Ta	4.42	-0.036	-0.739	-73.09	
Tl	4.87	-0.286	-6.005	-69.83	
Th	1.11	-0.136	-2.054	-105.80	
Sn	1.94	-0.008	-0.160	-109.17	
Ti	4.11	-0.008	-0.170	-95.75	
W	2.07	-0.015	-0.311	-204.97	
U	5.24	-1.196	-23.11	-131.36	
V	4.68	-0.019	-0.391	-58.47	
Zn	5.30	0.014	0.503	17.95	
Zr	4.87	-0.018	-0.379	-128.36	

Dilution factor : 21.0000

ICP Analysis - April 30, 1990

Acid Blank

Sample Name	:	HNO3		
Programme	:	6SI	30-Apr-90 15:16:50	
NAME	MV	INI	CONCEN	RSD
Al	2.03	(-0.350	-9.84	
Sb	0.50	(-0.332	-15.41	
As	1.43	(-0.071	-7.79	
Ba	3.65	(-0.017	-10.03	
Be	0.87	(-0.003	-14.86	
Bi	5.63	(-0.365	-12.58	
B	5.30	-0.014	-30.20	
Cd	3.12	(-0.011	-12.74	
Ca	0.48	(-0.001	-1.90	
Cr	5.17	(-0.635	-9.74	
Cr	1.43	(-0.026	-2.95	
Co	0.25	-0.038	-5.25	
Cu	2.93	(-0.041	-10.37	
Eu	3.90	(-0.011	-11.66	
Fe	1.69	(-0.016	-5.37	
La	0.35	-0.045	-23.08	
Pb	0.30	-0.182	-10.91	
Li	3.63	(-0.030	-10.61	
Mg	0.47	(-0.001	-11.08	
Mn	0.94	(-0.004	-8.22	
Hg	6.09	0.012	63.11	
Mo	2.56	(-0.028	-10.89	
Nd	5.15	(-0.464	-0.51	
Ni	4.82	(-0.037	-14.03	
P	1.51	(-0.105	-15.96	
K	3.04	-0.598	-43.33	
Sm	4.70	(-0.719	-9.33	
Se	2.25	(-0.309	-10.34	
Si	3.40	(-0.235	-5.91	
Ag	15.09	(-0.053	-9.98	
Na	5.09	(-0.364	-10.66	
Sr	3.52	(-0.007	-10.24	
S	0.85	(-0.070	-14.63	
Ta	4.13	(-0.111	-3.49	
Tl	4.56	(-0.874	-15.88	
Th	1.04	(-0.484	-9.49	
Sn	1.81	(-0.042	-12.77	
Ti	3.88	(-0.026	-8.86	
W	1.93	(-0.082	-5.54	
U	4.87	(-4.574	-9.56	
V	4.67	(-0.037	-10.54	
Zn	4.36	(-0.008	-4.78	
Zr	4.61	(-0.072	-10.10	

Sample name : F950
 Sample code 1 : 78C11K
 Sample code 2 : SST1
 Sample code 3 : DIRECT
 Programme : SST

30-Apr-90 15:20:35

NAME	MV	INI	CONCEN	RSD
Al	2.15	-0.114	-60.60	
Sb	1.56	9.907	0.70	
As	1.60	0.038	63.36	
Na	214.77	9.717	1.64	
Be	0.91	-0.001	-36.65	
Bi	5.80	(-0.254	-36.99	
R	158.16	9.805	1.16	
Cd	270.88	9.689	0.37	
Ca	294.14	9.995	1.67	
Co	12.77	9.043	0.57	
Cr	51.05	8.892	0.55	
Co	3.13	9.992	3.40	
Cu	57.17	9.831	1.30	
Eu	4.78	0.015	15.65	
Fe	88.73	10.084	0.95	
La	0.38	0.028	24.80	
Pb	0.31	-0.108	-18.33	
Li	109.44	9.595	1.36	
Mg	319.31	9.984	1.21	
Mn	304.73	9.830	0.81	
Hg	5.58	-0.010	-17.90	
Mo	2.71	-0.011	-43.65	
Nd	15.32	8.730	1.18	
Ni	127.52	9.604	0.61	
P	1.63	-0.029	-91.87	
K	9.77	24.593	0.52	
Sm	4.74	(-0.662	-24.29	
Se	5.03	3.476	1.55	
Si	3.52	(-0.176	-17.02	
Ag	15.31	(-0.046	-23.26	
Na	39.62	24.198	1.36	
Sr	385.43	9.864	1.63	
S	1.19	0.279	9.19	
Ta	4.29	(-0.069	-26.41	
Tl	4.92	-0.204	-95.10	
In	1.10	-0.173	-55.91	
Sn	190.18	49.335	0.49	
Ti	3.92	(-0.022	-23.68	
W	2.30	0.098	12.51	
U	5.44	0.619	156.29	
V	4.81	(-0.025	-03.91	
Zn	417.29	9.831	0.72	
Zr	4.71	-0.052	-29.95	

Sample name : F950
 Sample code 1 : 83E38A
 Sample code 2 : SSI2
 Sample code 3 : DIRECT
 Programme : SST

30-Apr-90 15:24:24

NAME	MV	INT	CONCEN	RSD
Al	4.87	5.550	2.59	
Sb	0.58	0.487	6.98	
As	4.87	1.907	3.00	
Ba	4.34	0.015	15.56	
Be	0.96	0.001	41.62	
Bi	66.42	53.719	1.78	
R	6.81	0.083	6.19	
Cd	3.55	0.004	34.06	
Ca	0.95	0.015	2.47	
Ce	6.07	0.507	17.36	
Cr	2.04	0.082	5.70	
Co	0.26	0.014	38.19	
Cu	4.92	0.264	3.01	
Bu	325.16	9.639	1.05	
Fe	2.33	0.058	2.04	
La	18.39	146.786	1.33	
Pb	4.49	54.140	1.59	
Li	3.92	-0.004	-87.97	
Hg	0.70	0.007	2.98	
Mn	1.21	0.010	7.90	
Hg	6.83	0.045	12.70	
Mo	2.87	0.007	38.23	
Nd	6.35	0.614	9.37	
Hi	5.57	0.018	35.31	
P	2.10	0.293	5.39	
K	3.25	0.208	40.49	
Sm	11.59	9.990	1.86	
Se	2.64	0.217	16.61	
Si	5.03	0.587	4.07	
Ag	326.75	10.254	1.33	
Na	5.58	-0.011	-421.45	
Sr	4.06	0.006	13.80	
S	1.12	0.211	3.18	
Ta	5.21	0.162	6.23	
Tl	8.50	6.431	0.96	
Th	11.19	51.233	1.47	
Sr	2.19	0.057	11.16	
Ti	4.96	0.057	7.24	
W	2.09	-0.002	-482.82	
U	11.22	53.789	2.14	
V	7.72	0.228	2.04	
Zn	5.28	0.014	7.03	
Zr	5.53	0.121	7.89	

Sample name : F950
 Sample code 1 : 77C11J
 Sample code 2 : 65T3
 Sample code 3 : DIRECT
 Programme : SST 30-Apr-90 15:28:08

NAME	MV	INT	CONCEN	RSD
Al	26.10	49.634	0.07	
Sb	0.66	1.193	2.71	
As	99.77	56.317	1.16	
Br	4.49	0.032	4.81	
Be	269.72	9.422	0.83	
Bi	7.61	0.958	4.91	
H	6.74	0.078	4.43	
Cd	3.82	0.014	9.62	
Ca	1.32	0.028	1.10	
Cr	5.88	0.269	15.14	
Co	1.83	0.045	3.56	
Cr	0.29	0.124	2.80	
Cu	3.62	0.064	4.15	
Eu	4.47	0.006	17.39	
Fe	2.29	0.053	2.47	
La	0.38	0.022	42.14	
Pb	0.33	0.190	10.41	
Li	4.07	0.010	14.66	
Mg	0.75	0.008	1.35	
Mn	1.37	0.017	2.55	
Hg	601.29	26.157	1.09	
Mo	430.80	47.121	1.07	
Nd	5.98	0.279	14.12	
Ni	11.70	9.500	1.19	
P	89.14	152.483	1.05	
K	3.31	0.423	10.56	
Sm	5.39	0.349	14.56	
Se	49.66	51.947	1.51	
Si	91.10	43.891	1.36	
Ag	27.92	0.371	0.83	
Na	6.84	0.886	3.55	
Sr	4.04	0.006	8.96	
S	52.19	152.926	1.13	
Ta	193.83	47.819	1.36	
Tl	32.38	50.670	1.68	
Th	1.34	1.053	3.36	
Sn	2.68	0.105	3.67	
Tl	641.33	48.394	0.72	
W	43.98	20.467	0.99	
U	7.07	15.664	2.71	
V	114.86	9.494	0.99	
Zn	6.20	0.036	1.05	
Zr	234.32	48.091	0.82	

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	E60044
PROCEDURE/REV	LA-503-156/C-1
TECHNOLOGIST	R. D. Hale
DATE	February 08, 1990
TEMPERATURE	23 C
STARTING TIME	0900 02-07-90
ENDING TIME	1500 02-08-90
CHEMIST	S. A. Catlow

Plutonium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0903
2	Reagent Blank	F0946
3	Sample Composite 5	F0899
4	Duplicate Sample Composite 5	F0900
5	Sample Composite 5	F0905
6	Duplicate Sample Composite 5	F0906
7	Sample Composite 6	F0923
8	Duplicate Sample Composite 6	F0924
9	Sample Composite 6	F0929
10	Duplicate Sample Composite 6	F0930
11	Sample Composite 8	F0947

	DESCRIPTION	LAB ID
12	Duplicate Sample Composite 8	F0948
13	Sample Composite 8	F0953
14	Duplicate Sample Composite 8	F0954
15	Spike Composite 8	F0949
16	Final LMCS Check Std.	F0950
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	16B43/1 uL			N/A
Spike	16B43/1 uL	F0947/1 mL	10B43-B/50 uL	N/A

Single Shell Tank Calibration Record

ANALYTE:	Pu-238		
PROCEDURE:	LA-508-051	REVISION:	A-2
INSTRUMENT:	Canberra Jupiter System	PROPERTY NUMBER:	E60044
TECHNOLOGIST:	Varies	PAYROLL NUMBER:	Varies
DATE:	See Attached Sheets		
CALIBRATION STANDARD ID: N/A			
ANALYTE CONCENTRATION: N/A			
TYPE OF CALIBRATION: N/A			
COMMENTS: Detectors are aligned not calibrated.			

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F903 SEG/COMP/#13 PU
File ID: SD4709.SPC

Counted on: 2/ 9/90 @ 0: 0
Detector/Geometry number: 4/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height Initial	Peak height Final	Peak center Initial	Peak center Final	FWHM Initial	FWHM Final	Tau Initial	Tau Final
1	5.2	4.8	469.869	469.869	20.000	12.660	10.000	5.524
2	2145.9	2208.4	358.677	358.677	20.000	10.661	10.000	4.945
3	280.4	285.9	302.189	302.189	20.000	10.454	10.000	3.516
4	229.4	64.8	264.079	264.079	12.000	6.706	6.000	4.662
5	2612.8	2618.0	229.858	229.858	20.000	10.762	10.000	5.781

PEAK RESULTS

Peak ID	AEA Isotope	AEA Fract.	Peak Exp.	Centroid Obs.	Count Diff.	Rate FWHM c/m	d/m	Activity uCi/ea
1		0.0010		6.273		0.09	0.47	0.213E-06
2	Pu236	0.4328	5.756	5.751	0.005	0.05	39.74	204.28
3	Pu238	0.0630	5.499	5.485	0.014	0.05	5.79	40.50
4	Am241			5.480	5.485	-0.005		0.140E-04
5	Pu239	0.0096		5.306		0.03	0.88	4.44
	Pu240	0.4935	5.143	5.145	-0.002	0.05	45.32	0.200E-05
				5.144	5.145	-0.001	228.30	0.103E-03
								0.103E-03

DETECTOR CALIBRATION

$$\text{Energy(MEV)} = 4.065 + (0.0047) * \text{Channel}$$

Energy range (MeV): 4.065 TO 6.471

Efficiency = 0.1985 CPM/DPM

TOTAL COUNT DATA:


Item	Total	% Recovery
Raw spectrum	45919.0	100.000
Smoothed	45918.7	99.999
Composite fit	45910.5	99.982
Residuals	8.1	0.018

Analyzed by: _____
VR

SPECTRUM SD4709.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

9724.5



Raw Data Dump for AEA Spectrum: SP:SD4709.SPC

1	0.	0.	0.	0.	0.	0.	0.	1.	0.	0.
11	1.	1.	0.	0.	0.	1.	1.	1.	0.	2.
21	1.	0.	0.	1.	0.	0.	1.	0.	1.	0.
31	2.	0.	0.	0.	1.	1.	0.	1.	0.	1.
41	1.	1.	0.	0.	0.	2.	0.	2.	1.	0.
51	1.	1.	0.	0.	1.	0.	0.	1.	4.	0.
61	0.	1.	0.	1.	1.	0.	1.	0.	1.	1.
71	0.	1.	0.	0.	1.	0.	1.	1.	0.	0.
81	0.	0.	2.	1.	1.	1.	1.	0.	0.	1.
91	2.	1.	1.	1.	1.	0.	2.	2.	0.	1.
101	1.	0.	1.	1.	0.	1.	1.	0.	1.	1.
111	0.	3.	0.	0.	0.	0.	2.	2.	0.	1.
121	1.	0.	0.	1.	1.	0.	3.	0.	0.	0.
131	2.	0.	3.	0.	1.	3.	5.	2.	2.	0.
141	1.	1.	2.	4.	1.	5.	1.	4.	1.	1.
151	6.	4.	2.	1.	3.	2.	2.	7.	4.	3.
161	2.	1.	7.	4.	3.	7.	8.	2.	4.	4.
171	5.	10.	7.	8.	5.	7.	11.	11.	7.	6.
181	9.	9.	8.	12.	5.	6.	8.	9.	7.	11.
191	9.	7.	11.	13.	6.	8.	10.	12.	11.	11.
201	15.	22.	26.	29.	37.	37.	70.	47.	85.	97.
211	128.	136.	207.	238.	290.	347.	427.	535.	585.	700.
221	784.	890.	972.	1153.	1192.	1345.	1426.	1577.	1629.	1426.
231	1296.	1248.	1035.	787.	555.	407.	263.	132.	81.	59.
241	20.	15.	7.	8.	12.	8.	10.	8.	19.	24.
251	20.	21.	21.	30.	27.	27.	29.	36.	31.	35.
261	37.	35.	37.	40.	35.	41.	33.	28.	19.	15.
271	15.	9.	15.	7.	12.	8.	14.	14.	9.	27.
281	29.	25.	36.	39.	44.	36.	53.	55.	66.	74.
291	88.	80.	82.	100.	99.	139.	114.	139.	150.	170.
301	172.	150.	148.	143.	120.	106.	81.	46.	34.	25.
311	21.	9.	9.	4.	3.	5.	13.	6.	12.	18.
321	6.	14.	14.	8.	11.	18.	16.	10.	17.	14.
331	23.	32.	40.	44.	50.	49.	56.	87.	111.	142.
341	156.	223.	240.	320.	349.	455.	532.	592.	653.	754.
351	805.	890.	954.	999.	1084.	1256.	1220.	1250.	1184.	1191.
361	976.	851.	680.	466.	302.	176.	75.	43.	26.	11.
371	3.	0.	0.	1.	0.	0.	0.	1.	0.	1.
381	0.	0.	0.	0.	0.	0.	0.	2.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	1.	1.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.	1.
411	0.	1.	0.	0.	0.	1.	1.	1.	1.	0.
421	1.	0.	1.	0.	1.	0.	1.	0.	0.	0.
431	0.	0.	1.	0.	1.	0.	0.	0.	0.	0.
441	0.	1.	0.	0.	0.	0.	1.	0.	0.	1.
451	2.	1.	1.	0.	0.	0.	1.	0.	3.	3.
461	1.	1.	4.	1.	2.	2.	3.	5.	3.	3.
471	3.	0.	1.	3.	1.	3.	1.	0.	0.	0.
481	0.	1.	0.	0.	0.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F946 SEG/COMP/#8
File ID: SD2714.SPC

Counted on: 2/ 9/90 @ 0: 0
Detector/Geometry number: 2/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	4.2	4.2	468.114	468.114	28.000	16.828	14.000	13.274
2	1894.2	1914.8	357.234	357.234	20.000	12.011	10.000	5.995
3	83.9	85.9	299.394	299.394	20.000	14.183	10.000	2.399
4	57.9	57.7	262.857	262.857	20.000	7.005	10.000	2.100
5	21.9	23.3	227.770	227.770	20.000	6.104	10.000	2.418
6	4.0	2.6	172.563	172.563	20.000	59.890	10.000	4.825

PEAK RESULTS

Peak ID	AEA Isotope	Fract.	Peak Exp.	Centroid Obs.	Diff.	FWHM	Count Rate c/m	d/m	Activity uCi/ea
1		0.0021		6.277		0.08	0.08	0.41	0.185E-06
2	Pu236	0.8871	5.756	5.755	0.001	0.06	35.19	178.28	0.803E-04
3	Pu238	0.0686	5.499	5.484	0.015	0.07	2.72	18.77	0.845E-05
	Am241		5.480	5.484	-0.004				0.648E-05
4		0.0283		5.312		0.03	1.12	5.58	0.251E-05
5	Pu239	0.0096	5.143	5.147	-0.004	0.03	0.38	1.88	0.848E-06
	Pu240		5.144	5.147	-0.003				0.848E-06
6	Np237	0.0043	4.781	4.887	-0.106	0.28	0.17	0.98	0.441E-06

DETECTOR CALIBRATION
Energy(MEV) = 4.076 + (0.0047)*Channel
Energy range (MeV): 4.076 TO 6.483
Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	19661.0	100.000
Smoothed	19661.0	100.000
Composite fit	19834.1	100.880
Residuals	-173.1	-0.880

Analyzed by: _____
VR

SPECTRUM SD2714.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

7179.2

6
6
6
6
6
6
6
6
6
6
6
6
6
6
6
6
6
65
54
4
4.
4
3
3
.3
.3
32
.. 2
.....2
.....2...
.....2
.....21
156

Raw Data Dump for AEA Spectrum: SP:SD2714.SPC

1	0.	0.	0.	0.	0.	0.	0.	0.	1.	0.
11	1.	0.	0.	1.	0.	0.	1.	0.	0.	0.
21	1.	0.	0.	2.	0.	0.	0.	1.	0.	0.
31	0.	0.	0.	1.	0.	0.	1.	0.	0.	0.
41	0.	0.	0.	0.	0.	0.	0.	0.	2.	0.
51	0.	0.	0.	0.	0.	0.	0.	1.	0.	0.
61	0.	1.	0.	0.	0.	0.	0.	0.	1.	0.
71	0.	0.	1.	0.	0.	0.	0.	0.	1.	1.
81	0.	0.	0.	0.	0.	0.	0.	0.	0.	1.
91	1.	1.	1.	0.	0.	0.	1.	0.	0.	0.
101	0.	0.	0.	0.	0.	1.	0.	1.	0.	0.
111	1.	0.	0.	0.	0.	0.	1.	2.	0.	0.
121	1.	0.	1.	1.	1.	0.	2.	0.	0.	1.
131	2.	1.	0.	1.	1.	0.	1.	0.	0.	1.
141	1.	1.	0.	1.	1.	1.	0.	2.	1.	1.
151	2.	0.	0.	2.	0.	1.	0.	1.	1.	0.
161	0.	1.	3.	1.	2.	0.	1.	1.	1.	4.
171	4.	4.	1.	1.	1.	1.	2.	1.	1.	0.
181	0.	3.	2.	2.	2.	0.	0.	2.	1.	2.
191	0.	2.	1.	0.	1.	3.	4.	4.	0.	2.
201	0.	3.	0.	2.	1.	0.	3.	4.	2.	5.
211	3.	4.	6.	3.	3.	3.	10.	6.	9.	15.
221	14.	13.	15.	13.	22.	8.	15.	15.	23.	10.
231	10.	5.	14.	12.	5.	3.	4.	5.	1.	7.
241	10.	8.	6.	5.	16.	11.	17.	14.	21.	12.
251	25.	25.	33.	24.	24.	38.	26.	25.	28.	40.
261	41.	52.	52.	33.	27.	26.	18.	19.	20.	22.
271	14.	10.	10.	18.	10.	17.	13.	17.	13.	18.
281	14.	27.	30.	28.	23.	24.	33.	35.	27.	36.
291	41.	34.	39.	40.	38.	51.	38.	42.	44.	48.
301	45.	48.	34.	25.	25.	24.	19.	7.	11.	8.
311	5.	6.	7.	5.	7.	6.	4.	5.	7.	15.
321	10.	6.	9.	21.	12.	12.	12.	17.	16.	

											18.
331	21.	44.	35.	38.	46.	56.	66.	101.	127.	133.	
341	205.	250.	257.	334.	415.	511.	550.	597.	683.	687.	
351	786.	904.	913.	1084.	1035.	1116.	1072.	1028.	939.	811.	
361	684.	536.	405.	268.	192.	128.	66.	36.	16.	9.	
371	5.	2.	2.	0.	0.	0.	0.	1.	0.	0.	
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	
401	0.	0.	0.	0.	1.	0.	1.	1.	0.	2.	
411	0.	0.	0.	0.	1.	1.	0.	0.	2.	0.	
421	0.	2.	0.	0.	1.	1.	0.	1.	0.	0.	
431	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	
441	0.	0.	0.	0.	1.	0.	0.	0.	0.	0.	
451	0.	0.	1.	0.	1.	0.	1.	1.	2.	2.	
461	1.	1.	3.	5.	0.	0.	4.	3.	3.	0.	
471	2.	1.	2.	2.	3.	1.	0.	0.	1.	0.	
481	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	
511	0.	0.									

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-947 SEG.COMP #9 PU
File ID: SD4714.SPC

Counted on: 2/10/90 @13: 0
Detector/Geometry number: 4/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	1429.4	1453.8	357.590	357.590	20.000	10.411	10.000	4.684
2	62.3	64.6	301.013	301.013	24.000	11.716	12.000	3.575
3	151.2	0.0	255.938	255.938	12.000	12.123	6.000	6.102
4	209.1	208.9	229.099	229.099	20.000	10.816	10.000	5.712

PEAK RESULTS

Peak ID	AEA Isotope	Fract.	Peak Exp.	Centroid Obs.	Diff.	FWHM	Count Rate c/m	Activity d/m uCi/ea
1	Cm243	0.8384	5.786	5.810	-0.024	0.05	26.21	154.30 0.695E-04
	Cm244		5.796	5.810	-0.014			0.507E-04
2	Pu238	0.0451	5.499	5.539	-0.040	0.06	1.41	8.42 0.379E-05
3		0.0000		5.323		0.06	0.00	0.000E+00
4		0.1164		5.194		0.05	3.64	15.64 0.705E-05

DETECTOR CALIBRATION

$$\text{Energy(MEV)} = 4.094 + (0.0048) * \text{Channel}$$

Energy range (MeV): 4.094 TO 6.552

Efficiency = 0.2327 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	15638.0	100.000
Smoothed	15637.3	99.996
Composite fit	15631.3	99.957
Residuals	6.0	0.039

Analyzed by: _____
DM

SPECTRUM SD4714.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

5344.2

4
....4
.....4
....4

2
.2
.2
2

1
.. 1
..... 1
.....1.....
.....1
...1

Raw Data Dump for AEA Spectrum: SP:SD4714.SPC

1	0.	0.	0.	0.	0.	1.	0.	0.	1.	0.
11	0.	0.	0.	0.	1.	2.	0.	0.	1.	1.
21	0.	0.	0.	0.	1.	0.	0.	0.	0.	0.
31	0.	0.	0.	0.	0.	0.	0.	0.	1.	0.
41	0.	0.	0.	2.	1.	0.	0.	1.	0.	1.
51	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
61	0.	1.	1.	0.	0.	0.	0.	0.	0.	0.
71	0.	0.	0.	0.	0.	0.	0.	1.	0.	0.
81	0.	0.	0.	0.	0.	1.	0.	0.	1.	1.
91	0.	0.	0.	0.	0.	0.	0.	1.	0.	2.
101	0.	0.	0.	1.	0.	0.	1.	1.	0.	0.
111	0.	1.	0.	0.	0.	1.	1.	0.	0.	0.
121	0.	2.	0.	0.	0.	0.	1.	0.	0.	0.
131	0.	0.	1.	1.	0.	1.	0.	1.	0.	2.
141	0.	0.	0.	1.	0.	0.	1.	0.	0.	1.
151	1.	0.	1.	0.	1.	0.	1.	1.	0.	0.
161	0.	2.	1.	1.	1.	2.	4.	0.	1.	2.
171	1.	3.	1.	0.	0.	2.	0.	6.	1.	1.
181	0.	3.	0.	1.	1.	0.	0.	3.	1.	4.
191	0.	0.	5.	1.	1.	2.	2.	1.	2.	1.
201	1.	3.	4.	4.	5.	4.	6.	8.	8.	12.
211	12.	14.	21.	24.	28.	39.	33.	50.	42.	50.
221	67.	73.	83.	116.	110.	119.	115.	98.	146.	110.
231	99.	93.	58.	54.	36.	17.	14.	10.	7.	1.
241	4.	2.	2.	2.	1.	4.	4.	3.	5.	3.
251	8.	8.	10.	6.	5.	4.	4.	9.	8.	5.
261	4.	7.	4.	7.	6.	4.	2.	4.	5.	4.
271	1.	3.	6.	2.	6.	7.	2.	6.	7.	4.
281	7.	6.	8.	14.	15.	12.	19.	17.	14.	19.
291	23.	25.	10.	31.	27.	36.	34.	35.	40.	35.
301	34.	30.	24.	37.	28.	20.	16.	12.	13.	3.
311	7.	5.	4.	4.	9.	3.	4.	7.	9.	5.
321	8.	10.	8.	4.	8.	14.	8.	10.	21.	23.
331	14.	17.	33.	26.	31.	51.	55.	68.	75.	118.
341	155.	168.	216.	260.	315.	361.	404.	456.	514.	527.
351	598.	653.	665.	700.	776.	776.	818.	811.	786.	691.
361	512.	392.	292.	171.	94.	47.	31.	10.	4.	2.
371	1.	1.	0.	0.	0.	0.	0.	0.	0.	1.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	2.	0.	0.	0.
401	1.	1.	0.	1.	0.	0.	0.	0.	0.	0.
411	0.	0.	0.	0.	1.	1.	1.	0.	0.	0.
421	0.	0.	1.	0.	0.	1.	0.	1.	0.	3.
431	0.	0.	0.	0.	0.	0.	1.	0.	1.	0.
441	0.	1.	0.	0.	0.	0.	0.	1.	0.	0.
451	0.	0.	0.	0.	0.	0.	1.	0.	0.	1.
461	0.	0.	3.	1.	1.	3.	1.	4.	3.	1.
471	3.	0.	1.	1.	0.	0.	0.	0.	0.	0.
481	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.								

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-948 SEG.COMP#10 PU
File ID: SD3951.SPC

Counted on: 2/10/90 @13: 0
Detector/Geometry number: 3/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	5.5	5.6	470.699	470.699	20.000	14.974	10.000	14.969
2	1879.1	1897.9	359.467	359.467	20.000	13.884	10.000	7.499
3	74.4	77.8	302.256	302.256	24.000	12.474	12.000	2.388
4	105.2	104.2	229.933	229.933	20.000	11.801	10.000	6.978

PEAK RESULTS

Peak ID	AEA Isotope	AEI Fract.	Peak Centroid	Count	Activity
		Exp.	Obs.	Rate c/m	d/m uCi/ea
1	Pu236	0.0026	6.279	0.07	0.10 0.234E-06
2	Pu239	0.8969	5.756	5.745 0.011	0.07 36.20 183.41 0.826E-04
3	Am241	0.0552	5.480	5.471 0.009	0.06 2.23 11.77 0.530E-05
4		0.0453	5.143	5.124 0.019	0.06 1.83 9.08 0.409E-05

DETECTOR CALIBRATION
Energy(MEV) = 4.020 + (0.0048)*Channel
Energy range (MeV): 4.020 TO 6.477
Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	20050.0	100.000
Smoothed	20050.0	100.000
Composite fit	20180.8	100.652
Residuals	-130.8	-0.652

Analyzed by: _____
DM

SPECTRUM SD3951.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

6820.6

4.
...4
.4

3
3
.3
..3
3.

.2
..... 2
..... 2...
..... 2
..... 2
2

Raw Data Dump for AEA Spectrum: SP:SD3951.SPC

1	0.	0.	0.	0.	0.	0.	0.	0.	0.	1.
11	0.	1.	0.	1.	0.	0.	2.	0.	0.	0.
21	0.	0.	1.	1.	1.	1.	1.	0.	0.	0.
31	1.	0.	1.	0.	0.	0.	0.	0.	0.	1.
41	1.	0.	1.	1.	0.	2.	0.	0.	0.	0.
51	0.	2.	1.	0.	1.	1.	0.	0.	0.	0.
61	0.	0.	2.	1.	1.	0.	0.	0.	1.	0.
71	0.	0.	3.	1.	1.	2.	0.	1.	1.	0.
81	1.	0.	0.	1.	0.	0.	0.	1.	2.	1.
91	0.	0.	0.	1.	0.	0.	1.	0.	0.	1.
101	0.	0.	0.	0.	0.	1.	1.	0.	0.	0.
111	0.	0.	1.	0.	2.	2.	0.	0.	1.	0.
121	0.	3.	0.	0.	0.	2.	0.	2.	2.	1.
131	1.	0.	0.	0.	2.	1.	3.	1.	2.	1.
141	2.	1.	0.	1.	1.	1.	1.	0.	1.	0.
151	1.	0.	1.	0.	0.	1.	0.	1.	2.	0.
161	1.	0.	3.	1.	1.	0.	1.	0.	1.	4.
171	1.	1.	0.	2.	1.	1.	3.	1.	2.	0.
181	1.	2.	2.	1.	2.	1.	1.	1.	0.	0.
191	1.	0.	1.	0.	1.	3.	0.	1.	1.	1.
201	0.	2.	1.	0.	4.	0.	3.	4.	4.	1.
211	4.	6.	6.	10.	8.	16.	15.	24.	17.	33.
221	28.	38.	44.	58.	54.	60.	51.	46.	52.	81.
231	56.	48.	47.	31.	21.	17.	15.	9.	12.	3.
241	6.	6.	3.	1.	0.	1.	1.	1.	2.	1.
251	1.	4.	4.	2.	2.	2.	6.	5.	1.	7.
261	6.	6.	7.	9.	10.	7.	8.	8.	6.	9.
271	5.	4.	8.	5.	6.	9.	7.	12.	5.	16.
281	21.	22.	25.	14.	17.	30.	23.	22.	26.	25.
291	34.	28.	25.	34.	35.	27.	37.	38.	40.	34.
301	40.	46.	41.	35.	32.	38.	24.	19.	16.	13.
311	10.	7.	3.	2.	2.	2.	3.	4.	3.	1.
321	4.	5.	2.	3.	5.	4.	7.	9.	4.	6.
331	9.	14.	10.	11.	20.	37.	38.	57.	73.	73.
341	123.	173.	203.	226.	275.	361.	403.	461.	533.	562.
351	722.	748.	807.	886.	954.	1039.	1057.	1014.	1051.	1037.
361	930.	836.	765.	642.	483.	393.	263.	193.	119.	75.
371	41.	26.	14.	7.	1.	3.	0.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	0.	0.	0.	0.	0.	0.	1.	1.
421	0.	1.	1.	0.	1.	2.	0.	1.	0.	0.
431	2.	0.	0.	0.	0.	0.	0.	1.	0.	1.
441	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
451	0.	0.	0.	0.	0.	1.	0.	1.	0.	1.
461	1.	3.	3.	3.	3.	3.	3.	2.	4.	1.
471	5.	3.	2.	1.	4.	1.	2.	0.	2.	1.
481	0.	0.	1.	0.	1.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.								

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-949 SEG.COMP#11 PU
File ID: SD3954.SPC

Counted on: 2/11/90 @11: 0
Detector/Geometry number: 3/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	10.4	10.0	471.543	471.543	20.000	13.382	10.000	6.489
2	1898.2	1910.1	359.114	359.114	20.000	13.459	10.000	7.396
3	85.1	87.0	301.260	301.260	20.000	13.453	10.000	2.603
4	50.6	52.5	264.610	264.610	20.000	8.169	10.000	1.755
5	149.1	151.5	229.417	229.417	20.000	10.611	10.000	7.113

PEAK RESULTS

Peak ID	Isotope	AEA Fract.	Peak Centroid			Count Rate c/m	Activity	
			Exp.	Obs.	Diff.		d/m	uCi/ea
1	Pu236	0.0045		6.283	0.06	0.19	0.96	0.430E-06
2	Pu236	0.8469	5.756	5.744	0.012	0.06	35.86	181.69 0.818E-04
3	Th228	0.0593	5.430	5.466	-0.036	0.06	2.51	17.54 0.790E-05
	Am241		5.480	5.466	0.014			0.597E-05
4		0.0305		5.290		0.04	1.29	6.41 0.289E-05
5		0.0588		5.121		0.05	2.49	12.35 0.556E-05

DETECTOR CALIBRATION

Energy(MEV) = 4.020 + (0.0048)*Channel
Energy range (MeV): 4.020 TO 6.477
Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	21109.0	100.000
Smoothed	21107.7	99.994
Composite fit	21170.5	100.291
Residuals	-62.9	-0.298

Analyzed by: _____
DM

Raw Data Dump for AEA Spectrum: SP:SD3954.SPC

1	0.	0.	0.	0.	0.	1.	1.	1.	1.	1.
11	0.	0.	0.	0.	0.	2.	3.	2.	0.	2.
21	0.	0.	0.	1.	0.	0.	2.	0.	0.	0.
31	0.	0.	0.	0.	1.	0.	1.	0.	1.	0.
41	0.	0.	2.	0.	0.	1.	1.	0.	1.	1.
51	0.	0.	0.	1.	0.	1.	0.	0.	1.	0.
61	0.	1.	0.	0.	0.	0.	0.	1.	2.	0.
71	0.	0.	0.	0.	1.	1.	1.	1.	0.	0.
81	1.	1.	0.	0.	2.	0.	1.	1.	0.	0.
91	1.	0.	0.	1.	0.	0.	0.	0.	0.	0.
101	1.	0.	1.	0.	0.	0.	1.	0.	1.	1.
111	1.	0.	1.	1.	0.	1.	1.	1.	0.	1.
121	3.	1.	0.	2.	2.	0.	1.	3.	0.	0.
131	0.	1.	0.	0.	1.	2.	1.	0.	2.	1.
141	2.	1.	1.	0.	1.	3.	3.	2.	0.	1.
151	2.	2.	3.	1.	2.	1.	0.	0.	0.	2.
161	3.	3.	1.	0.	2.	1.	0.	1.	0.	0.
171	1.	3.	0.	2.	2.	0.	1.	0.	2.	1.
181	5.	0.	0.	2.	3.	0.	1.	3.	1.	2.
191	4.	0.	1.	1.	0.	0.	0.	5.	0.	5.
201	2.	5.	3.	1.	1.	2.	1.	33.	34.	41.
211	1.	6.	8.	14.	18.	24.	26.	33.	34.	86.
221	53.	59.	70.	87.	77.	77.	100.	79.	96.	10.
231	80.	69.	58.	42.	43.	28.	20.	17.	6.	10.
241	7.	5.	7.	6.	12.	12.	9.	15.	14.	10.
251	21.	28.	16.	22.	19.	25.	30.	26.	26.	29.
261	32.	46.	31.	38.	32.	25.	30.	30.	25.	24.
271	19.	11.	12.	9.	10.	8.	13.	7.	11.	9

281	25.	24.	19.	15.	27.	27.	32.	31.	21.	17.
291	39.	32.	29.	37.	36.	39.	41.	53.	48.	46.
301	44.	39.	46.	50.	38.	25.	19.	11.	15.	14.
311	13.	10.	3.	3.	0.	1.	1.	2.	1.	1.
321	1.	2.	4.	3.	4.	8.	2.	6.	5.	12.
331	15.	11.	19.	28.	19.	44.	58.	66.	61.	79.
341	111.	133.	223.	251.	317.	337.	410.	462.	517.	649.
351	696.	725.	856.	938.	951.	1047.	1069.	1106.	1083.	981.
361	942.	817.	655.	565.	445.	311.	234.	159.	99.	75.
371	48.	23.	21.	5.	6.	0.	2.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	1.	0.	1.	0.	2.	2.	1.	1.
421	3.	1.	1.	1.	0.	0.	1.	3.	0.	0.
431	1.	0.	0.	0.	0.	0.	1.	0.	0.	0.
441	0.	0.	0.	0.	0.	0.	0.	1.	0.	0.
451	0.	0.	0.	2.	2.	1.	0.	2.	0.	2.
461	7.	2.	5.	2.	6.	1.	5.	4.	8.	7.
471	4.	7.	7.	2.	2.	3.	5.	1.	2.	0.
481	2.	0.	0.	1.	0.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.

SPECTRUM SD3954.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

6956.3

.5.
....5.
.5.
4
4
4.
4.
3
3
.3
.3
3.

.2
..... 2
..... 2...
..... 2
..... 2
.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F950 SEG/COMP/#12 PU
File ID: SD3946.SPC

Counted on: 2/ 9/90 @ 0: 0
Detector/Geometry number: 3/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	1946.0	1958.5	357.840	357.840	24.000	14.662	12.000	8.261
2	245.9	249.9	300.354	300.354	24.000	12.967	12.000	4.179
3	321.6	69.1	262.412	262.412	12.000	5.250	6.000	6.220
4	2343.9	2333.2	228.108	228.108	24.000	13.601	12.000	8.431
5	5.2	8.2	150.480	150.480	80.000	2.000	40.000	0.200
6	1.6	0.9	126.257	126.257	8.000	0.382	4.000	0.057

PEAK RESULTS

Peak ID	Isotope	AEA Fract.	Peak Centroid			Count Rate c/m	d/m	Activity uCi/ea	
			Exp.	Obs.	Diff.				
1	Pu236	0.4328	5.756	5.738	0.018	0.07	37.89	191.98	0.865E-04
2	Th228	0.0625	5.430	5.462	-0.032	0.06	5.48	38.29	0.172E-04
	Am241		5.480	5.462	0.018				0.130E-04
3		0.0089		5.279		0.03	0.78	3.85	0.173E-05
4		0.4919		5.115		0.07	43.06	213.81	0.963E-04
5		0.0037		4.742		0.01	0.32	1.59	0.715E-06
6	Np237	0.0003	4.640	4.626	0.014	0.00	0.02	1.85	0.835E-06

DETECTOR CALIBRATION
Energy(MEV) = 4.020 + (0.0048)*Channel
Energy range (MeV): 4.020 TO 6.477
Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:


Item	Total	% Recovery
Raw spectrum	43612.0	100.000
Smoothed	43611.1	99.998
Composite fit	43772.9	100.369
Residuals	-161.8	-0.371

Analyzed by: _____
VR

SPECTRUM SD3946.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

8821.5

6
6
6
6
6
5
5
5

Raw Data Dump for AEA Spectrum: SP:SD3946.SPC

1	0.	0.	0.	0.	0.	2.	3.	1.	0.
11	2.	0.	1.	2.	1.	1.	1.	0.	0.
21	1.	1.	2.	0.	0.	1.	1.	1.	0.
31	1.	0.	1.	2.	1.	0.	0.	0.	0.
41	0.	1.	2.	2.	0.	0.	1.	2.	1.
51	0.	2.	0.	1.	1.	1.	0.	2.	1.
61	0.	0.	1.	0.	1.	0.	2.	3.	1.
71	0.	2.	1.	2.	1.	0.	0.	0.	1.
81	1.	0.	1.	0.	1.	2.	0.	1.	0.
91	2.	0.	0.	2.	0.	1.	1.	1.	2.
101	2.	2.	2.	0.	1.	1.	2.	2.	0.
111	2.	1.	3.	0.	3.	7.	1.	1.	2.
121	2.	2.	3.	2.	3.	4.	5.	0.	1.
131	3.	0.	1.	0.	0.	1.	0.	3.	4.
141	1.	4.	7.	0.	5.	0.	2.	0.	3.
151	4.	3.	2.	1.	3.	0.	2.	0.	1.
161	2.	4.	1.	1.	3.	1.	1.	3.	0.
171	6.	4.	4.	2.	6.	4.	2.	2.	1.
181	0.	2.	4.	2.	1.	3.	0.	5.	4.
191	4.	4.	7.	5.	2.	7.	7.	6.	9.
201	16.	21.	23.	23.	42.	47.	66.	72.	112.
211	164.	186.	224.	334.	394.	473.	562.	603.	726.
221	902.	1109.	1134.	1198.	1312.	1294.	1379.	1310.	1233.
231	1017.	829.	709.	489.	402.	304.	204.	145.	82.
241	36.	21.	16.	9.	13.	13.	16.	11.	18.
251	23.	16.	20.	26.	25.	22.	16.	36.	35.
261	27.	36.	30.	22.	29.	28.	21.	26.	22.
271	12.	10.	4.	11.	18.	12.	14.	15.	24.
281	38.	40.	34.	42.	43.	44.	69.	55.	73.
291	86.	88.	107.	91.	121.	125.	121.	146.	126.
301	123.	141.	115.	88.	73.	57.	41.	37.	24.
311	12.	8.	7.	3.	2.	5.	3.	3.	5.
321	6.	5.	1.	4.	6.	5.	4.	4.	8.
331	24.	15.	24.	34.	31.	52.	68.	104.	118.
341	169.	210.	290.	338.	347.	489.	518.	610.	674.
351	844.	914.	957.	1047.	1099.	1043.	1095.	1059.	992.
361	826.	722.	560.	460.	351.	230.	183.	130.	85.
371	30.	14.	14.	6.	1.	2.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	0.	0.	2.	0.	0.	0.	0.
421	0.	0.	2.	0.	0.	0.	0.	0.	0.
431	1.	0.	0.	0.	0.	0.	0.	0.	0.
441	0.	0.	0.	0.	0.	0.	1.	0.	0.
451	0.	0.	1.	0.	1.	0.	2.	4.	1.
461	0.	1.	1.	1.	1.	1.	2.	1.	2.
471	3.	2.	1.	0.	0.	1.	2.	1.	0.
481	0.	0.	0.	0.	0.	0.	1.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.							

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	E60044
PROCEDURE/Rev	LA-503-156/C-2
TECHNOLOGIST	R. D. Hale
DATE	February 08, 1990
TEMPERATURE	23 C
STARTING TIME	0900 02-07-90
ENDING TIME	1500 02-08-90
CHEMIST	S. A. Catlow

Americium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0897
2	Reagent Blank	F0946
3	Sample Composite 5	F0899
4	Duplicate Sample Composite 5	F0900
5	Sample Composite 5	F0905
6	Duplicate Sample Composite 5	F0906
7	Sample Composite 6	F0923
8	Duplicate Sample Composite 6	F0924
9	Sample Composite 6	F0929
10	Duplicate Sample Composite 6	F0930
11	Sample Composite 8	F0947

	DESCRIPTION	LAB ID
12	Duplicate Sample Composite 8	F0948
13	Sample Composite 8	F0953
14	Duplicate Sample Composite 8	F0954
15	Spike Composite 8	F0949
16	Final LMCS Check Std.	F0950
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	16B43/10 uL			N/A
Spike	16B43/10 uL	F0947/1 mL	9B43/100 uL	N/A

Single Shell Tank Calibration Record

ANALYTE: Am-241

PROCEDURE: LA-508-051

REVISION: A-2

INSTRUMENT: Canberra Jupiter System

PROPERTY NUMBER: E60044

TECHNOLOGIST: Varies

PAYROLL NUMBER: Varies

DATE: See Attached Sheets

CALIBRATION STANDARD ID: N/A

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: N/A

COMMENTS: Detectors are aligned not calibrated.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-897 SEG.COMP#7 AM
File ID: SD2726.SPC

Counted on: 2/13/90 @ 0: 0
Detector/Geometry number: 2/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	2841.1	2830.9	298.349	298.349	24.000	16.162	12.000	5.853
2	3932.2	3937.6	253.170	253.170	20.000	13.999	10.000	4.917

PEAK RESULTS

Peak ID	AEA Isotope	AE AEA	Peak Fract.	Centroid Exp.	Count Obs.	Rate Diff.	FWHM c/m	d/m	Activity uCi/ea
1	Pu238	0.4269	5.499	5.483	0.016	0.08	63.53	443.59	0.200E-03
	Am241			5.480	5.483	-0.003			0.153E-03
2	Am243	0.5731	5.234	5.271	-0.037	0.07	85.29	3898.24	0.176E-02

DETECTOR CALIBRATION

$$\text{Energy(MEV)} = 4.081 + (0.0047) * \text{Channel}$$

Energy range (MeV): 4.081 TO 6.487

Efficiency = 0.1989 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	75197.0	100.000
Smoothed	75196.7	100.000
Composite fit	74407.8	98.950
Residuals	788.9	1.049

Analyzed by: _____
MAX

2.
...2
.....2
.....2
.....2..
1.....2
..1...2....
.....1
.....1
.....1
.....1
..1

Raw Data Dump for AEA Spectrum: SP:SD2726.SPC

1	0.	0.	0.	0.	0.	0.	1.	0.	0.	0.	0.
11	0.	0.	3.	1.	1.	2.	0.	0.	1.	1.	1.
21	0.	2.	0.	0.	0.	3.	0.	2.	0.	2.	2.
31	0.	1.	2.	1.	0.	3.	1.	3.	0.	0.	0.
41	2.	1.	2.	1.	0.	1.	0.	0.	2.	0.	0.
51	1.	3.	2.	1.	1.	2.	1.	1.	0.	2.	0.
61	2.	3.	0.	1.	2.	2.	0.	1.	2.	0.	0.
71	1.	1.	2.	0.	4.	3.	0.	2.	1.	1.	1.
81	0.	0.	3.	1.	1.	3.	1.	0.	1.	2.	2.
91	1.	1.	0.	0.	3.	1.	1.	5.	1.	3.	3.
101	0.	2.	2.	1.	0.	0.	0.	1.	0.	2.	2.
111	1.	3.	1.	1.	4.	2.	6.	2.	2.	0.	0.
121	3.	2.	4.	2.	2.	2.	1.	4.	1.	3.	3.
131	1.	2.	1.	1.	0.	4.	0.	2.	4.	2.	2.
141	3.	5.	3.	2.	4.	1.	3.	1.	3.	0.	0.
151	5.	4.	4.	0.	5.	1.	3.	2.	4.	5.	5.
161	5.	5.	2.	5.	5.	4.	4.	7.	5.	3.	3.
171	5.	7.	9.	8.	9.	9.	4.	3.	8.	8.	8.
181	7.	6.	8.	8.	12.	10.	16.	11.	20.	12.	12.
191	10.	12.	8.	19.	19.	24.	16.	11.	18.	29.	29.
201	28.	25.	27.	33.	30.	33.	54.	49.	54.	52.	52.
211	51.	63.	71.	83.	82.	88.	97.	95.	124.	150.	150.
221	133.	181.	173.	204.	215.	224.	237.	237.	281.	330.	330.
231	331.	354.	403.	433.	533.	506.	580.	676.	788.	843.	843.
241	946.	1078.	1170.	1345.	1457.	1612.	1749.	1823.	2038.	2181.	2181.
251	2189.	2326.	2241.	2102.	1961.	1704.	1479.	1218.	972.	729.	729.
261	589.	448.	393.	342.	265.	225.	192.	180.	203.	151.	151.
271	145.	137.	171.	170.	185.	209.	236.	259.	274.	332.	332.
281	396.	421.	508.	541.	628.	660.	766.	872.	995.	1063.	1063.
291	1157.	1288.	1385.	1402.	1481.	1579.	1557.	1612.	1547.	1444.	1444.
301	1185.	1132.	923.	796.	635.	528.	407.	333.	242.	160.	160.
311	130.	99.	75.	57.	45.	29.	18.	12.	5.	2.	2.
321	2.	4.	0.	1.	0.	1.	1.	1.	0.	0.	0.
331	1.	1.	2.	1.	2.	2.	1.	1.	2.	2.	2.
341	3.	1.	4.	4.	3.	0.	0.	0.	2.	0.	0.
351	1.	2.	3.	1.	0.	0.	0.	0.	2.	0.	0.
361	0.	0.	1.	0.	0.	3.	1.	0.	1.	0.	0.
371	0.	0.	0.	0.	1.	0.	0.	0.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	1.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	1.	0.	1.	2.	0.	0.	0.	0.	0.
421	1.	0.	0.	0.	0.	0.	0.	0.	0.	1.	0.
431	0.	0.	0.	0.	0.	0.	0.	0.	0.	1.	0.
441	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
451	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
461	0.	0.	0.	0.	0.	1.	0.	0.	2.	0.	0.
471	1.	0.	1.	1.	0.	1.	0.	1.	0.	1.	1.
481	0.	0.	0.	0.	1.	0.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	1.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F946 AM
File ID: SD3956.SPC

Counted on: 2/12/90 @15: 0
Detector/Geometry number: 3/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	4.9	4.3	353.061	353.061	24.000	27.195	12.000	4.586
2	122.1	47.0	296.965	296.965	12.000	0.111	6.000	4.586
3	2724.3	2794.8	253.936	253.936	24.000	18.856	12.000	4.432
4	4.3	3.1	108.186	108.186	72.000	295.052	36.000	17.485

PEAK RESULTS

Peak ID	Isotope	AEA Fract.	Peak Exp.	Centroid Obs.	Diff.	FWHM	Count Rate c/m	Activity d/m uCi/ea
1	Ra224	0.0020	5.680	5.715	-0.035	0.13	0.15	0.82 0.368E-06
2	Th228	0.0007	5.430	5.445	-0.015	0.00	0.05	0.38 0.171E-06
3	Am243	0.9935	5.234	5.239	-0.005	0.09	78.29	3533.97 0.159E-02
4	U 235	0.0038	4.396	4.539	-0.143	1.42	0.30	2.64 0.119E-05

DETECTOR CALIBRATION

$$\text{Energy(MEV)} = 4.020 + (0.0048) * \text{Channel}$$

Energy range (MeV): 4.020 TO 6.477

Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	39211.0	100.000
Smoothed	39209.6	99.996
Composite fit	39401.6	100.486
Residuals	-192.0	-0.490

Analyzed by: _____
MAX

SPECTRUM SD3956.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

10532.2

3
.3
.3
.... 3
.....3
.....3
.....3..
.....3...
.....3
.....3
3.

111111

Raw Data Dump for AEA Spectrum: SP:SD3956.SPC

1	0.	0.	0.	0.	0.	2.	0.	2.	0.	0.
11	1.	1.	0.	0.	1.	1.	0.	0.	0.	1.
21	3.	2.	1.	0.	0.	0.	3.	1.	1.	1.
31	3.	0.	1.	2.	0.	0.	1.	1.	0.	1.
41	0.	1.	2.	4.	1.	0.	1.	1.	0.	1.
51	0.	0.	3.	0.	0.	0.	1.	0.	0.	0.
61	0.	0.	1.	3.	1.	1.	1.	1.	1.	2.
71	0.	1.	1.	4.	2.	1.	0.	3.	3.	2.
81	1.	1.	1.	0.	0.	3.	2.	1.	0.	0.
91	1.	0.	0.	1.	1.	0.	0.	2.	3.	0.
101	1.	2.	2.	3.	3.	1.	4.	4.	1.	0.
111	2.	3.	2.	1.	1.	1.	2.	0.	4.	3.
121	1.	1.	1.	1.	2.	0.	3.	3.	3.	1.
131	2.	2.	3.	1.	5.	2.	2.	5.	1.	2.
141	3.	0.	1.	4.	3.	4.	2.	3.	2.	2.
151	3.	3.	3.	1.	2.	9.	2.	3.	3.	3.
161	5.	8.	6.	9.	0.	4.	5.	5.	7.	7.
171	5.	11.	2.	5.	5.	8.	12.	7.	8.	6.
181	11.	13.	15.	17.	9.	15.	21.	19.	14.	20.
191	28.	26.	22.	24.	31.	47.	38.	33.	49.	42.
201	42.	43.	40.	50.	57.	48.	62.	66.	86.	70.
211	84.	95.	99.	130.	148.	116.	141.	174.	159.	214.
221	197.	216.	235.	228.	257.	304.	342.	330.	370.	386.
231	442.	468.	496.	541.	546.	628.	598.	665.	778.	826.
241	863.	911.	967.	1074.	1099.	1169.	1251.	1278.	1305.	1377.
251	1445.	1512.	1452.	1456.	1360.	1349.	1273.	1129.	961.	830.
261	725.	583.	443.	341.	246.	222.	159.	122.	101.	72.
271	65.	43.	44.	39.	28.	13.	14.	6.	9.	5.
281	6.	6.	3.	0.	6.	5.	8.	2.	9.	5.
291	9.	4.	8.	5.	3.	5.	5.	10.	8.	9.
301	2.	6.	2.	1.	5.	3.	2.	5.	1.	1.
311	1.	2.	0.	0.	2.	0.	0.	1.	0.	2.
321	0.	0.	3.	1.	1.	0.	1.	0.	2.	1.
331	0.	2.	0.	1.	0.	2.	1.	1.	1.	2.
341	3.	1.	0.	1.	0.	2.	2.	3.	2.	4.
351	2.	5.	2.	0.	1.	4.	2.	3.	1.	0.
361	1.	0.	1.	0.	2.	1.	1.	0.	1.	0.
371	0.	1.	0.	0.	0.	0.	0.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	1.	0.	0.	0.	0.	1.	0.	0.
421	0.	0.	0.	0.	0.	3.	0.	1.	1.	0.
431	0.	1.	1.	0.	1.	2.	1.	0.	0.	0.
441	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
451	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
461	0.	0.	0.	0.	0.	1.	0.	0.	0.	0.
471	0.	0.	1.	0.	2.	2.	1.	2.	2.	3.
481	1.	0.	0.	1.	0.	0.	0.	0.	1.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.								

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-947 SEG.COMP#9 AM
File ID: SD5591.SPC

Counted on: 2/13/90 @ 1: 0
Detector/Geometry number: 5/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak		Peak height		Peak center		FWHM		Tau	
ID		Initial	Final	Initial	Final	Initial	Final	Initial	Final
1		90.2	45.9	297.390	297.390	12.000	14.564	6.000	0.000
2		2201.3	2284.0	253.753	253.753	24.000	16.826	12.000	4.315
3		0.0	0.1	117.607	117.607	0.000	0.200	0.000	0.200

PEAK RESULTS

Peak		AEA		Peak Centroid		Count		Activity	
ID	Isotope	Fract.		Exp.	Obs.	Diff.	FWHM	Rate c/m	d/m uCi/ea
1	Pu238	0.1885		5.499	5.495	0.004	0.07	13.84	95.23 0.429E-04
	Am241			5.480	5.495	-0.015			0.329E-04
2		0.8115			5.290		0.08	59.58	295.12 0.133E-03
3	Np237	0.0000		4.640	4.650	-0.010	0.00	0.00	0.04 0.184E-07

DETECTOR CALIBRATION

$$\text{Energy(MeV)} = 4.097 + (0.0047) * \text{Channel}$$

Energy range (MeV): 4.097 TO 6.504

Efficiency = 0.2019 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	33335.0	100.000
Smoothed	33334.3	99.998
Composite fit	36714.0	110.137
Residuals	-3379.7	-10.139

Analyzed by: _____
MAX

SPECTRUM SD5591.SPC LEGEND: RAW = MODELLED PEAKS = 1,2,..., ETC
8708.8

Raw Data Dump for AEA Spectrum: SP:SD5591.SPC
 1 0. 0. 0. 0. 0. 0. 1. 3. 1. 3.
 11 1. 1. 2. 2. 7. 6. 1. 2. 3. 4.
 21 2. 3. 4. 1. 6. 2. 5. 3. 2. 2.
 31 2. 4. 3. 3. 3. 5. 4. 1. 4. 4.
 41 5. 4. 4. 3. 3. 3. 5. 4. 4. 3.
 51 3. 2. 5. 1. 5. 2. 5. 5. 2. 5.
 61 3. 3. 3. 3. 6. 4. 5. 2. 6. 6.
 71 3. 7. 4. 5. 3. 13. 2. 3. 3. 4.
 81 1. 10. 6. 5. 4. 4. 4. 3. 7. 5.
 91 4. 2. 5. 4. 7. 3. 9. 8. 10. 3.
 101 5. 4. 6. 3. 6. 13. 6. 5. 6. 6.
 111 11. 7. 10. 11. 6. 9. 8. 6. 7. 12.
 121 6. 11. 4. 8. 8. 9. 7. 3. 6. 6.
 131 4. 8. 10. 8. 6. 8. 11. 8. 8. 3.
 141 5. 10. 8. 13. 14. 12. 13. 14. 10. 9.
 151 16. 18. 15. 16. 14. 11. 13. 15. 16. 19.
 161 13. 10. 16. 19. 13. 14. 24. 17. 21. 13.
 171 13. 19. 21. 29. 21. 22. 25. 18. 30. 12.
 181 30. 29. 24. 41. 29. 24. 29. 44. 33. 40.
 191 33. 40. 32. 49. 33. 36. 43. 42. 58. 57.
 201 49. 48. 44. 61. 86. 71. 62. 91. 71. 74.
 211 82. 82. 103. 119. 118. 104. 106. 136. 154. 129.
 221 127. 139. 169. 182. 216. 219. 251. 244. 265. 304.
 231 311. 337. 353. 461. 422. 490. 519. 590. 649. 662.
 241 665. 787. 803. 858. 987. 972. 982. 1113. 1102. 1164.
 251 1198. 1189. 1216. 1154. 1175. 1097. 1017. 934. 804. 649.
 261 504. 419. 322. 219. 176. 106. 100. 88. 78. 73.
 271 41. 54. 35. 22. 14. 11. 7. 7. 14. 11.
 281 6. 9. 13. 4. 10. 8. 12. 9. 18. 18.
 291 20. 19. 20. 16. 16. 27. 29. 19. 17. 17.
 301 15. 11. 13. 16. 10. 7. 7. 2. 2. 3.
 311 1. 2. 3. 2. 1. 1. 0. 0. 0. 0.
 321 0. 0. 1. 2. 1. 0. 2. 0. 0. 0.
 331 1. 0. 0. 0. 1. 0. 0. 0. 0. 0.
 341 0. 0. 0. 0. 0. 0. 2. 0. 0. 0.
 351 3. 3. 1. 0. 0. 0. 0. 1. 0. 1.
 361 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 371 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 381 0. 0. 0. 1. 0. 0. 0. 0. 0. 0.
 391 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 401 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 411 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 421 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 431 0. 1. 0. 0. 0. 0. 0. 0. 0. 0.
 441 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 451 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 461 0. 0. 0. 0. 0. 0. 0. 0. 1. 0.
 471 2. 1. 2. 1. 0. 0. 0. 0. 0. 0.
 481 0. 2. 1. 0. 0. 0. 0. 0. 0. 0.
 491 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-948 SEG.COMP#10 AM
File ID: SD4722.SPC

Counted on: 2/13/90 @ 1: 0
Detector/Geometry number: 4/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	52.0	26.1	294.392	294.392	12.000	12.053	6.000	0.000
2	1089.1	1144.6	250.312	250.312	28.000	21.345	14.000	2.211

PEAK RESULTS

Peak ID	Isotope	AEA Fract.	Peak Exp.	Centroid Obs.	Diff. Diff.	FWHM	Count Rate c/m	Activity d/m uCi/ea
1	Pu238	0.1259	5.499	5.507	-0.008	0.06	7.78	46.46 0.209E-04
	Am241		5.480	5.507	-0.027			0.160E-04
2		0.8741		5.295		0.10	54.04	232.23 0.105E-03

DETECTOR CALIBRATION
Energy(MEV) = 4.094 + (0.0048)*Channel
Energy range (MeV): 4.094 TO 6.552
Efficiency = 0.2327 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	29296.0	100.000
Smoothed	29295.3	99.998
Composite fit	30911.4	105.514
Residuals	-1616.0	-5.516

Analyzed by: _____
MAX

Raw Data Dump for AEA Spectrum: SP:SD4722.SPC
 1 0. 0. 0. 0. 0. 0. 1. 3. 4. 1.
 11 3. 3. 5. 4. 6. 3. 6. 3. 3. 6.
 21 2. 4. 2. 2. 3. 5. 5. 3. 5. 3.
 31 5. 4. 1. 1. 4. 3. 2. 4. 6. 5.
 41 6. 6. 8. 4. 4. 7. 5. 5. 5. 8.
 51 8. 4. 4. 6. 5. 7. 5. 10. 6. 4.
 61 7. 9. 10. 7. 5. 10. 5. 4. 6. 10.
 71 12. 3. 9. 6. 7. 6. 7. 11. 6. 9.
 81 16. 13. 9. 13. 9. 6. 6. 9. 5. 7.
 91 21. 10. 13. 9. 11. 23. 10. 13. 14. 16.
 101 16. 16. 15. 23. 20. 16. 17. 14. 20. 13.
 111 22. 12. 18. 17. 24. 21. 22. 15. 20. 25.
 121 15. 23. 25. 29. 26. 33. 20. 21. 27. 20.
 131 29. 25. 33. 30. 25. 30. 30. 39. 41. 27.
 141 31. 35. 29. 43. 45. 38. 40. 42. 35. 47.
 151 42. 28. 36. 42. 58. 53. 59. 54. 58. 45.
 161 53. 50. 50. 63. 61. 64. 81. 56. 60. 66.
 171 77. 66. 70. 72. 86. 78. 76. 72. 86. 104.
 181 93. 93. 93. 93. 92. 110. 103. 109. 108. 122.
 191 118. 120. 117. 125. 115. 153. 143. 149. 159. 170.
 201 164. 148. 174. 184. 191. 187. 203. 204. 224. 246.
 211 228. 232. 243. 247. 238. 239. 241. 249. 296. 277.
 221 296. 333. 341. 321. 333. 344. 355. 397. 354. 403.
 231 372. 388. 424. 441. 461. 449. 469. 458. 470. 503.
 241 474. 526. 496. 496. 556. 538. 571. 571. 627. 579.
 251 554. 545. 580. 468. 500. 453. 384. 340. 280. 229.
 261 146. 128. 108. 82. 56. 45. 32. 33. 23. 26.
 271 19. 15. 13. 11. 9. 3. 9. 6. 6. 3.
 281 8. 9. 7. 5. 10. 9. 7. 6. 14. 4.
 291 6. 11. 17. 7. 11. 10. 10. 8. 4. 3.
 301 7. 4. 1. 6. 4. 4. 3. 0. 2. 0.
 311 2. 0. 2. 0. 0. 0. 0. 0. 0. 0.
 321 0. 1. 0. 2. 0. 0. 0. 1. 1. 1.
 331 0. 1. 1. 0. 1. 0. 2. 0. 1. 1.
 341 1. 1. 0. 2. 0. 2. 2. 2. 1. 1.
 351 1. 1. 1. 1. 1. 0. 1. 1. 0. 0.
 361 0. 1. 0. 0. 1. 0. 2. 0. 1. 0.
 371 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 381 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 391 0. 0. 0. 0. 1. 0. 1. 0. 0. 0.
 401 0. 0. 0. 0. 0. 0. 0. 0. 1. 0.
 411 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 421 0. 0. 0. 2. 0. 0. 0. 0. 1. 1.
 431 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 441 0. 0. 0. 0. 0. 0. 0. 0. 0. 1.
 451 0. 1. 0. 0. 0. 1. 0. 1. 0. 0.
 461 0. 0. 1. 0. 0. 2. 1. 2. 0. 0.
 471 0. 1. 1. 1. 0. 0. 1. 1. 0. 0.
 481 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 491 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-949 SEG.COMP#11 AM
File ID: SD3958.SPC

Counted on: 2/13/90 @ 1: 0
Detector/Geometry number: 3/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	69.9	45.7	294.281	294.281	16.000	8.685	8.000	0.000
2	1416.7	1464.9	248.325	248.325	32.000	25.605	16.000	4.657
3	2.4	3.3	101.979	101.979	152.000	2.000	76.000	0.200
4	0.0	0.1	27.155	27.155	0.000	0.200	0.000	0.200

PEAK RESULTS

Peak ID	AEA Isotope	Fract.	Peak Exp.	Centroid Obs.	Diff.	FWHM	Count Rate c/m	Activity d/m uCi/ea
1	Th228	0.2115	5.430	5.432	-0.002	0.04	13.54	94.68 0.426E-04
2	Am243	0.7866	5.234	5.212	0.022	0.12	50.35	2272.65 0.102E-02
3		0.0019		4.509		0.01	0.12	0.61 0.274E-06
4		0.0000		4.150		0.00	0.00	0.00 0.106E-08

DETECTOR CALIBRATION
Energy(MEV) = 4.020 + (0.0048)*Channel
Energy range (MeV): 4.020 TO 6.477
Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	31305.0	100.000
Smoothed	31295.7	99.970
Composite fit	32005.0	102.236
Residuals	-709.3	-2.266

Analyzed by: _____
MAX

SPECTRUM SD3958.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC 5540.0

1
1
.1
41
.1
.1
31
31
31
31
31
31
31
31
.1
.1
.1
.1
.1.
.1.
.1..
21..
21..
.2...
.1.2..
.1...2..
.1.....2..
.1.....2..
.1.....2..
.1.....2...
.1.....2...
.1.....2...
.1.....2...
21
.1
.1
1

Raw Data Dump for AEA Spectrum: SP:SD3958.SPC
 1 0. 0. 0. 0. 0. 8. 10. 10. 11. 10.
 11 11. 11. 18. 16. 6. 10. 10. 14. 7. 12.
 21 16. 15. 9. 10. 17. 10. 16. 15. 9. 10.
 31 9. 17. 16. 4. 11. 8. 10. 11. 16. 14.
 41 17. 9. 11. 14. 14. 19. 23. 12. 11. 17.
 51 18. 9. 12. 14. 20. 17. 16. 12. 18. 11.
 61 18. 17. 12. 15. 8. 20. 17. 11. 17. 14.
 71 12. 20. 20. 21. 20. 17. 13. 18. 16. 25.
 81 17. 22. 18. 14. 24. 15. 19. 20. 14. 21.
 91 27. 25. 23. 20. 22. 15. 24. 22. 30. 29.
 101 24. 23. 20. 23. 29. 17. 23. 19. 26. 18.
 111 22. 24. 25. 23. 29. 22. 26. 18. 24. 33.
 121 24. 33. 25. 30. 29. 28. 27. 24. 31. 23.
 131 19. 29. 28. 36. 31. 30. 29. 33. 27. 27.
 141 28. 29. 31. 41. 32. 44. 46. 42. 28. 49.
 151 54. 34. 47. 33. 31. 38. 37. 50. 42. 51.
 161 51. 47. 41. 45. 60. 37. 60. 43. 44. 38.
 171 37. 40. 59. 48. 55. 59. 60. 65. 57. 60.
 181 53. 59. 68. 65. 64. 60. 74. 56. 86. 84.
 191 68. 75. 82. 82. 76. 93. 101. 86. 95. 102.
 201 110. 109. 110. 144. 129. 131. 137. 140. 152. 151.
 211 155. 170. 165. 181. 183. 201. 199. 213. 208. 236.
 221 216. 270. 261. 292. 303. 324. 347. 335. 400. 403.
 231 396. 472. 456. 515. 498. 565. 564. 588. 650. 672.
 241 661. 696. 733. 764. 768. 747. 758. 762. 760. 739.
 251 693. 664. 626. 613. 511. 472. 422. 360. 297. 263.
 261 177. 187. 139. 101. 85. 61. 52. 35. 41. 26.
 271 25. 18. 16. 19. 17. 18. 7. 16. 12. 14.
 281 13. 16. 11. 11. 10. 16. 12. 12. 14. 7.
 291 9. 15. 16. 16. 17. 10. 8. 17. 9. 9.
 301 5. 7. 5. 9. 5. 1. 3. 2. 2. 0.
 311 1. 1. 2. 3. 1. 1. 0. 0. 2. 0.
 321 2. 0. 1. 1. 0. 1. 1. 1. 2. 0.
 331 0. 1. 1. 4. 2. 0. 1. 1. 2. 1.
 341 1. 2. 1. 1. 0. 1. 1. 1. 2. 1.
 351 1. 1. 0. 0. 1. 1. 0. 0. 0. 0.
 361 0. 0. 0. 1. 0. 0. 0. 0. 0. 0.
 371 0. 0. 1. 0. 0. 0. 0. 0. 0. 0.
 381 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 391 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 401 0. 1. 0. 0. 1. 0. 0. 0. 0. 0.
 411 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 421 0. 0. 0. 1. 0. 0. 0. 0. 0. 0.
 431 0. 1. 0. 0. 0. 0. 0. 0. 1. 0.
 441 1. 0. 0. 0. 1. 0. 0. 1. 0. 0.
 451 0. 1. 2. 0. 0. 1. 0. 0. 0. 0.
 461 0. 1. 1. 0. 1. 1. 1. 1. 0. 0.

281	25.	24.	19.	15.	27.	27.	32.	31.	21.	17.
291	39.	32.	29.	37.	36.	39.	41.	53.	48.	46.
301	44.	39.	46.	50.	38.	25.	19.	11.	15.	14.
311	13.	10.	3.	3.	0.	1.	1.	2.	1.	1.
321	1.	2.	4.	3.	4.	8.	2.	6.	5.	12.
331	15.	11.	19.	28.	19.	44.	58.	66.	61.	79.
341	111.	133.	223.	251.	317.	337.	410.	462.	517.	649.
351	696.	725.	856.	938.	951.	1047.	1069.	1106.	1083.	981.
361	942.	817.	655.	565.	445.	311.	234.	159.	99.	75.
371	48.	23.	21.	5.	6.	0.	2.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	1.	0.	1.	0.	2.	2.	1.	1.
421	3.	1.	1.	1.	0.	0.	1.	3.	0.	0.
431	1.	0.	0.	0.	0.	0.	1.	0.	0.	0.
441	0.	0.	0.	0.	0.	0.	0.	1.	0.	2.
451	0.	0.	0.	2.	2.	1.	0.	2.	4.	8.
461	7.	2.	5.	2.	6.	1.	5.	4.	2.	0.
471	4.	7.	7.	2.	2.	3.	5.	1.	2.	0.
481	2.	0.	0.	1.	0.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F950 AM
File ID: SD2724.SPC

Counted on: 2/12/90 @15: 0
Detector/Geometry number: 2/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	17.8	11.2	347.151	347.151	12.000	0.091	6.000	0.000
2	2259.9	2267.7	299.307	299.307	24.000	17.119	12.000	4.348
3	3066.1	3106.7	253.961	253.961	24.000	14.243	12.000	3.364

PEAK RESULTS

Peak ID	AEA Isotope	Fract.	Peak Exp.	Centroid Obs.	Diff.	FWHM	Count Rate c/m	d/m	Activity uCi/ea
1	Ra224	0.0265	5.680	5.713	-0.033	0.00	3.83	20.48	0.922E-05
2	Pu238	0.4131	5.499	5.488	0.011	0.08	59.70	416.86	0.188E-03
	Am241		5.480	5.488	-0.008				0.144E-03
3		0.5604		5.275		0.07	80.98	407.15	0.183E-03

DETECTOR CALIBRATION

$$\text{Energy(MEV)} = 4.081 + (0.0047) * \text{Channel}$$

Energy range (MeV): 4.081 TO 6.487

Efficiency = 0.1989 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	71370.0	100.000
Smoothed	71369.7	100.000
Composite fit	72254.9	101.240
Residuals	-885.3	-1.240

Analyzed by: _____
MAX

SPECTRUM SD2724.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,..., ETC

12207.0

Raw Data Dump for AEA Spectrum: SP:SD2724.SPC

1	0.	0.	0.	0.	0.	1.	0.	0.	3.
11	2.	1.	0.	0.	1.	0.	1.	2.	0.
21	0.	0.	1.	0.	2.	0.	1.	1.	2.
31	1.	1.	2.	0.	1.	0.	1.	2.	1.
41	0.	0.	0.	0.	1.	1.	1.	1.	1.
51	0.	0.	0.	3.	0.	1.	0.	1.	1.
61	1.	0.	3.	0.	0.	0.	1.	1.	3.
71	1.	3.	0.	1.	0.	0.	1.	1.	1.
81	2.	1.	3.	2.	1.	3.	0.	2.	3.
91	0.	3.	3.	4.	1.	3.	4.	3.	2.
101	1.	0.	2.	2.	2.	5.	1.	2.	0.
111	1.	0.	2.	0.	4.	0.	1.	2.	0.
121	2.	4.	2.	0.	2.	1.	2.	0.	2.
131	1.	0.	1.	4.	2.	3.	4.	3.	5.
141	3.	4.	3.	5.	3.	2.	5.	6.	3.
151	6.	5.	10.	10.	2.	4.	7.	7.	8.
161	6.	9.	2.	1.	8.	6.	10.	7.	8.
171	9.	10.	9.	12.	9.	20.	22.	10.	13.
181	19.	17.	20.	14.	34.	24.	24.	21.	27.
191	43.	42.	29.	45.	45.	46.	53.	58.	48.
201	64.	60.	70.	83.	97.	82.	93.	116.	116.
211	121.	147.	163.	150.	174.	187.	188.	193.	213.
221	288.	298.	313.	329.	324.	372.	383.	403.	413.
231	449.	479.	519.	562.	548.	572.	626.	662.	750.
241	894.	933.	1006.	1146.	1214.	1338.	1373.	1513.	1536.
251	1686.	1740.	1708.	1741.	1678.	1583.	1410.	1245.	1020.
261	701.	564.	388.	337.	309.	280.	270.	278.	227.
271	211.	244.	256.	239.	264.	270.	296.	300.	339.
281	435.	446.	466.	483.	567.	652.	671.	675.	733.
291	934.	972.	1045.	1059.	1103.	1226.	1223.	1235.	1222.
301	1132.	1017.	891.	839.	693.	545.	470.	350.	298.
311	171.	115.	93.	70.	50.	40.	21.	12.	8.
321	3.	3.	0.	3.	0.	1.	0.	0.	0.
331	0.	0.	0.	0.	0.	1.	2.	4.	2.
341	1.	1.	2.	3.	1.	5.	1.	2.	0.
351	2.	2.	1.	0.	0.	0.	1.	0.	0.
361	2.	0.	0.	0.	0.	0.	0.	0.	0.
371	0.	0.	0.	0.	1.	0.	0.	0.	0.
381	0.	0.	1.	0.	0.	1.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	1.	1.	0.	0.	0.	0.	0.	0.	0.
411	0.	0.	2.	0.	0.	0.	0.	0.	0.
421	0.	0.	1.	2.	1.	2.	0.	0.	0.
431	1.	2.	0.	0.	1.	0.	1.	0.	0.
441	0.	0.	0.	2.	0.	0.	0.	0.	1.
451	0.	0.	0.	0.	0.	0.	0.	0.	0.
461	2.	1.	0.	1.	0.	0.	0.	0.	2.
471	0.	0.	1.	1.	1.	4.	1.	0.	1.
481	0.	0.	0.	1.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	Tennelec
PROCEDURE/REV	LA-933-141/G-1
TECHNOLOGIST	R. D. Hale
DATE	March 12, 1990
TEMPERATURE	23 C
STARTING TIME	1000
ENDING TIME	1700
CHEMIST	S. A. Catlow

Neptunium Analysis

Fusion Dissolution

Mount Volume = 500 uL

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0897
2	Reagent Blank	F0898
3	Sample Composite 5	F0899
4	Duplicate Sample Composite 5	F0900
5	Sample Composite 6	F0923
6	Duplicate Sample Composite 6	F0924
7	Sample Composite 8	F0947
8	Duplicate Sample Composite 8	F0948
9	Sample Composite 7	F0977
10	Duplicate Sample Composite 7	F0978
11	Spike Sample Composite 7	F0979

	DESCRIPTION	LAB ID
12	Final LMCS Check Std.	F0980
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	148B33/100 uL			N/A
Spike	148B33/100 uL	F0947/250 uL		N/A

SST-102 Rev. I 10/2/90 Interim

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	WA77930
PROCEDURE/REV	LA-438-101/C-2
TECHNOLOGIST	S. Lai
DATE	March 07, 1990
TEMPERATURE	N/A
STARTING TIME	0800
ENDING TIME	1530
CHEMIST	S. A. Catlow

Technetium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0945
2	Reagent Blank	F0946
3	Sample Composite 8	F0947
4	Duplicate Sample Composite 8	F0948
5	Spike Composite 8	F0949
6	Final LMCS Check Std.	F0950
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	68B39/250 uL			20 mL
Spike	68B39/250 uL	F0947/1.0 mL	49B39/100 uL	20 mL

Single Shell Tank Calibration Record

ANALYTE:	TC 99		
PROCEDURE:	LA-508-121	REVISION:	A-0
INSTRUMENT:	Liquid Scintillation Counter		
TECHNOLOGIST:	R. A. Jones		
DATE:	September 02, 1988		
CALIBRATION STANDARD ID: Packard 6008502 #2			
ANALYTE CONCENTRATION: See attached calibration sheets.			
TYPE OF CALIBRATION: Quench Curve			
COMMENTS: Quench Curve			

SST-103 Rev. A 9/25/90 Interim

（三）在於社會的問題上，我們應當有更廣泛的知識，更廣泛的見解，更廣泛的了解。

REFERENCES AND NOTES

（三）在本办法施行前，已经完成的工程，其质量缺陷由建设单位负责组织维修，所需费用从工程价款中扣除。

¹ See also the discussion of the relationship between the two concepts in the section on "The Concept of Social Capital."

Planning area	Planning period	Planning target	Planning content
Beijing	1991-2000	Urbanization	Urbanization, urban system, urban economy, urban society, urban environment
Guangzhou	1991-2000	Urbanization	Urbanization, urban system, urban economy, urban society, urban environment
Shanghai	1991-2000	Urbanization	Urbanization, urban system, urban economy, urban society, urban environment
Tianjin	1991-2000	Urbanization	Urbanization, urban system, urban economy, urban society, urban environment

TABLE FIVE. CHINESE CITY PLANNING: THE FIVE-THREE-TWO PLANNING MODEL

THE FIVE-THREE-TWO PLANNING MODEL

the first time in the history of the world, the people of the United States have been compelled to go to war without having been invaded by another nation.

THE WAR OF 1812

The cause of the war was the desire of the United States to have a free and independent foreign trade. The British government, however, did not want the United States to have a free and independent foreign trade. They wanted to control it. They did not want the United States to have a free and independent foreign trade. They wanted to control it.

The United States declared war on Great Britain on June 18, 1812. The war lasted until December 24, 1814. The United States won the war.

THE WAR OF 1812

The cause of the war was the desire of the United States to have a free and independent foreign trade. The British government, however, did not want the United States to have a free and independent foreign trade. They wanted to control it. They did not want the United States to have a free and independent foreign trade. They wanted to control it.

THE WAR OF 1812

The cause of the war was the desire of the United States to have a free and independent foreign trade. The British government, however, did not want the United States to have a free and independent foreign trade. They wanted to control it. They did not want the United States to have a free and independent foreign trade. They wanted to control it.

THE WAR OF 1812

The cause of the war was the desire of the United States to have a free and independent foreign trade. The British government, however, did not want the United States to have a free and independent foreign trade. They wanted to control it. They did not want the United States to have a free and independent foreign trade. They wanted to control it.

J945

F945+

<

- F946
- F946+
- F947
- F947+
- F948
- F948+
- F949
- F949+
- F950
- F950+

Analytical Batch

LAB SEGMENT SERIAL #: F0941

CUSTOMER ID: 000008

INSTRUMENT	WA77390
PROCEDURE/REV	LA-378-103/A-2
TECHNOLOGIST	M. Myers
DATE	June 12, 1990
TEMPERATURE	21 C
STARTING TIME	0800
ENDING TIME	1500
CHEMIST	S. A. Catlow

Iodine 129

Fusion Dissolution

* Total volume sent for counting

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0945
2	Reagent Blank	F0946
3	Sample Composite 8	F0947
4	Duplicate Sample Composite 8	F0948
5	Spike Composite 8	F0949
6	Final LMCS Check Std.	F0950
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	124B44/1.0 mL			2 mL *
Spike	124B44/1.0 mL	F0947/1.0 mL		2 mL *

Single Shell Tank Calibration Record

ANALYTE: I-129

PROCEDURE: LA-508-152

REVISION: A-1

INSTRUMENT: TN-4500

PROPERTY NUMBER: WA45242

TECHNOLOGIST: R. A. Jones

PAYROLL NUMBER: 65801

DATE: January 09, 1989

CALIBRATION STANDARD ID: 45B40A & B

ANALYTE CONCENTRATION: Se⁷⁵ = 4.06 uci, SB¹²⁵ = 4.67 uci, I¹²⁹ = 57.8 uci

TYPE OF CALIBRATION: Efficiency

COMMENTS: T zero = June 06, 1988

— 1 —

K-2 130, INPUT FILE

#	Isotope	Half-life	MIC Value	Calc. Error
1	1129	1.000E+00	---	0.00
		39.8	2.50	
2	232311	1.000E+07	---	0.00
		55.0	25.90	
3	232413	1.000E+06	---	0.00
		74.7	66.00	
4	232425	1.000E+06	---	0.00
		178.3	1.00	
5	232426	1.000E+06	---	0.00
		136.0	59.00	
		121.1	17.30	

Minimum Energy Error for Isotope Input Attraction = 1.5 keV

All values are corrected for decay.

Comments?

* GAMMA SPECTRUM ANALYSIS *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

18-JUN-90 15:29:53

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 4.0
DETECTOR NUMBER: 6 / GEOMETRY NUMBER: 1
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 80.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLLET ANALYSIS PERFORMED

SPECTRAL DATA READ DIRECTLY FROM MULTICHANNEL ANALYZER AN1:
ANALYZED BY: 69549

SAMPLE DESCRIPTION: F945-6585

GEOMETRY DESCRIPTION: I-129/CULTURE TUBE

SAMPLE SIZE: 1.0000E+00 EA / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL129

COLLECT STARTED ON 18-JUN-90 AT 14:39:43

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3004. SECONDS

DEAD TIME: 0.13 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 15-JUN-90

EFFICIENCY CALIBRATION PERFORMED 18-JUN-90

18-JUN-90 15:29:53

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
PEAK AT CHANNEL 134.4 DROPPED FROM MULTIPLET ANALYSIS							
1C	148.67	29.63	1.60	817.	8127.	2.9	
2C	169.08	33.71	1.60	482.	1830.	6.3	CE-144
3C	198.48	39.58	1.33	172.	1223.	7.1	I-129, BI-212, CE-144

ERROR QUOTATION AT 1.96 SIGMA
PEAK CONFIDENCE LEVEL AT 80.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0024
BACKGROUND DESCRIPTION: BKG
BACKGROUND COLLECT STARTED ON 5-JUN-90 AT 13:00:00
BACKGROUND LIVE TIME: 3000. SECONDS
BACKGROUND WAS INSIGNIFICANT

18-JUN-90 15:29:53

SAMPLE: F945-6585

DATA COLLECTED ON 18-JUN-90 AT 14:39:43
DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/EA			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AM-241	LLD<8.86E-07		LLD<8.86E-07		59.54	
AM-243	LLD<4.74E-07		LLD<4.74E-07		74.67	
I-129	2.82E-04	+2.00E-05	2.82E-04	+2.00E-05	39.60	-0.02
SB-125	LLD<9.30E-06		LLD<9.30E-06		176.33	
SE-75	LLD<7.44E-07		LLD<7.44E-07		136.00	
SN-113	LLD<1.59E-06		LLD<1.59E-06		391.67	
TOTAL	2.82E-04	+2.00E-05	2.82E-04	+2.00E-05		

E BAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 5.77E-03 UC/EA

TOTAL MEASURED ACTIVITY = 2.82E-04 (+-2.00E-05) UC/EA

% TECH. SPEC. = 4.89 (+-0.35)

ERROR QUOTATION AT 1.96 SIGMA

LLD CONFIDENCE LEVEL AT 80.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
148.67	29.63	8127.	2.9	1.13E+01
169.08	33.71	1830.	6.3	1.73E+00