

0012371

SINGLE-SHELL TANK WASTE CHARACTERIZATION FOR TANK 241-U-110 CORE 7
COMPOSITE SEGMENTS 1 2 3 4

DATA PACKAGE

SECTION

1 OF 12



Westinghouse
Hanford Company

10612

P.O. Box 1970 Richland, WA 99352

222-S/RCRA Analytical Laboratories

Project: Single - Shell Tank Waste
Characterization

Tank: 241-U-110

Core: 7

Customer Id. Number:
Core 7 Composite

Report Revision: 1

Date Printed: October 12, 1990




Table of Contents

Signature Form.....	4
Introduction.....	5
Sampling Data.....	8
Sample Data Summary.....	11
Physical Test Results.....	16
Thermo Gravimetric Analysis.....	17
Differential Scanning Calorimeter.....	17
Undigested Sample Analysis Results.....	20
Untreated Sample Results Summary for Wet Weight.....	21
pH Analysis.....	22
Percent Water.....	23
Mercury.....	24
Cyanide.....	29
KOH Fusion Results.....	31
Fusion Analysis Results Summary for Solids.....	32
ICP Data Summary.....	33
Fusion Analysis Results Summary for Lab Digestion.....	34
Fusion Dissolution.....	35
Total Alpha and Total Beta Analysis.....	36
GEA Analysis.....	41
Uranium Analysis.....	78
Inductively Coupled Plasma Spectrographic Analysis.....	79
Plutonium.....	119
Americium 241.....	138
Neptunium 237.....	157
Technetium 99.....	158
Iodine 129.....	165
Strontium 89/90.....	188
Water Digestion Test Results.....	193
Water Digestion Results in Wet Weight 1st Leaching.....	194
Water Digestion Results in Wet Weight 2nd Leaching.....	195
Water Digestion Results in Wet Weight 3rd Leaching.....	196
ICP Data Summary.....	197
Water Digestion Results for Lab Digestion 1st Leaching.	198
Water Digestion Results for Lab Digestion 2nd Leaching.	199
Water Digestion Results for Lab Digestion 3rd Leaching.	200
Water Digestion 1st Leaching.....	201
Water Digestion 2nd Leaching.....	202
Water Digestion 3rd Leaching.....	203

pH Analysis.....	205
Ion Chromatographic Analysis.....	206
Inductively Coupled Plasma Spectrographic Analysis.....	227
Total Organic Carbon Analysis.....	265
Ammonia.....	272
Carbonate.....	273
Nitrite.....	280
Total Alpha and Total Beta Analysis.....	282
GEA Analysis.....	287
Plutonium.....	327
Americium 241.....	346
Carbon 14.....	365
Iodine 129.....	371
Neptunium 237.....	388
Strontium 89/90.....	389
Technetium 99.....	392
Tritium.....	399
Arsenic.....	403
Mercury.....	406
Selenium.....	408
 Acid Digestion Test Results.....	412
Acid Digestion Results in Wet Weight.....	413
ICP Data Summary.....	414
Acid Digestion Results for Laboratory Digestion.....	415
Acid Digestion.....	416
Inductively Coupled Plasma Specrographic Analysis	417
ICP Raw Data Summary.....	418
Arsenic.....	454
Mercury.....	456
Selenium.....	458
 Appendix A.....	461
Analytical Cards	
 Appendix B.....	462
Analytical Detection Limits	

This report consists of pages 1 - 462, plus page 79.1.

Appendix A consists of pages 1 - 126.

Appendix B consists of pages 1 - 3.

I have reviewed this report and certify that the package is in compliance with "Quality Assurance Project Plan for the Chemical Analysis of Highly Radioactive Samples in Support of Environmental Activities on the Hanford Site", WHC-SD-CP-QAPP-002. I found it to be a true and accurate accounting both technically and for completeness of the laboratory analyses performed on this sample.

Shirley A. Cervantes
Shirley A. Cervantes
Data Coordinator

Date October 15, 1990

Cary M. Seidel
Cary M. Seidel
Unit Manager

Date October 15, 1990

Larry H. Taylor
Larry H. Taylor
Laboratory Q.A. Officer

Date October 23, 1990

INTRODUCTION

INTRODUCTION

Westinghouse Hanford Company Analytical Laboratories are supporting the characterization efforts of the single shell tanks. The characterization of tank 241-U-110 was performed under Phase 1A and 1B of the "Waste Characterization Plan for the Hanford Site Single-Shelled Tanks" (WHC-EP-0210).

Tank 241-U-110 has a 500,000 gallon capacity. Construction was completed in 1944. The tank received first cycle waste, REDOX (Reduction-Oxidation) high-level waste, coating waste, and laboratory waste until 1975. Between July 7, 1975, and February 2, 1976, P-10 pumps were installed, and 41,700 gallons of liquid waste were pumped from the tank. Tank 241-U-110 still contains an estimated 195,000 gallons of waste.

Analytical Laboratories performs all analytical analysis to the specifications of the "Quality Assurance Project Plan for the Chemical Analysis of Highly Radioactive Samples in Support of Environmental Activities on the Hanford Site," WHC-SD-CP-QAPP-002. In accordance with WHC-SD-CP-QAPP-002, the following laboratory policies are being followed. Spikes are performed on either the undissolved sample, or the sample after dissolution, as directed by the scientist. If the spike addition is found to be less than 20% of an analyte concentration, the spike recovery is not reported due to errors introduced by the precision of the sample analysis. The concentration of spike additions will be re-evaluated before the start of Phase 1C. Two spiking routines are being used during Phase 1A and 1B. For the following analyses, Ion Chromatography (IC), Inductively Coupled Plasma (ICP), Mercury Hydride, Total Organic Carbon (TOC), and Carbonate analyses, the solid sample is spiked independently from the sample digestion. Any non-homogeneity of the sample could adversely affect the spike recoveries. For the radioisotopic analysis and other analyses not specified above, the spikes were performed by spiking an aliquot of sample after digestion.

The laboratory does not report sample results from batch analyses that are questionable. The results from questionable batches are discarded, and the analysis is repeated. Sample cards (laboratory travelers) for the repeated analysis are reissued for analysis after they have been stamped "rerun." Laboratory travelers are issued using a computerized routine according to a "sample point." This sample point label (segment-n) on the laboratory travelers and on the gamma energy analysis (GEA) analysis reports has no relationship to the sampling activities or the sample identification. All results in this data package relate only to the composite of Sample 89-046, Sample 89-047, Sample 89-048 and Sample 89-049 which comprises core 7 from riser 7 of tank 241-U-110. The Core 7 Composite Sample was prepared by compositing 37.3 grams of segment 1 (89-046), 58.2 grams of segment 2 (89-047), 24.5 grams of segment 3 (89-048), and 30.5 grams of segment 4 (89-049).

The organic analysis of this sample will be performed by Pacific Northwest Laboratories (PNL). Due to instrument and procedure problems, PNL has been unable to separate organics from the normal paraffin hydrocarbon present in the samples. The results from the organic analysis will be provided when available.

Carbon-14 analysis on the undigested sample was not performed as the 222-S laboratory does not have analytical procedures that will analyze low levels of carbon 14 in solids. The chrome-VI analysis on the water digestion was not performed because sufficient sample to complete this analysis was not available. Sample for additional digestions was not available as this sample was completely consumed performing other analyses.

All sample results reported here by weight are reported as the "wet weight" of the sample. Some samples noticeably lost moisture during the process of aliquoting and weighing for digestion. In order to minimize errors due to loss of moisture, the percent moisture was determined at the earliest opportunity. Attempts to dry the sample before analysis resulted in approximately a tenfold increase in radiation levels. In order to reduce and control radiation exposure to laboratory personnel, the samples were not dried before aliquoting and digestion. This may result in some laboratory results being biased high.

This report is formatted into sections corresponding to the type of dissolutions performed prior to analysis. A brief summary of analytical results is reported, followed by calibration data and an analysis batch report. Any notable observations regarding an analysis are noted on the batch report for that analysis. Copies of laboratory travelers can be found in Appendix A.

SAMPLING DATA

Single Shell Tank Waste Characterization Summary of Core Sample

TANK ID:	241-U-110
RISER ID:	#7
CORE ID:	#007

DATE SAMPLING INITIATED:	11-15-89
DATE SAMPLING COMPLETED:	11-16-89

SEGMENT	
1	Lab Serial No. F0197
1	Customer ID No. 89-046
1	Last Segment? NO
2	Lab Serial No. F0125
2	Customer ID No. 89-047
2	Last Segment? NO
3	Lab Serial No. F0149
3	Customer ID No. 89-048
3	Last Segment? NO
4	Lab Serial No. F0173
4	Customer ID No. 89-049
4	Last Segment? YES
5	Lab Serial No.
5	Customer ID No.
5	Last Segment?
6	Lab Serial No.
6	Customer ID No.
6	Last Segment?
7	Lab Serial No.
7	Customer ID No.
7	Last Segment?

SEGMENT	
8	Lab Serial No.
8	Customer ID No.
8	Last Segment?
9	Lab Serial No.
9	Customer ID No.
9	Last Segment?
10	Lab Serial No.
10	Customer ID No.
10	Last Segment?
11	Lab Serial No.
11	Customer ID No.
11	Last Segment?
12	Lab Serial No.
12	Customer ID No.
12	Last Segment?
13	Lab Serial No.
13	Customer ID No.
13	Last Segment?
14	Lab Serial No.
14	Customer ID No.
14	Last Segment?

Single Shell Tank Core Composite

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: Core 000007

SIMI-VOLATILE ORGANIC ANALYSIS

SIMI-VOA SAMPLE

LAB SERIAL #: N/A

DATE SAMPLED: N/A

PARTICLE SIZE DISTRIBUTION ANALYSIS

PARTICLE SIZE SAMPLE

LAB SERIAL #: N/A

DATE SAMPLED: N/A

Homogenized Solids

UNDIGESTED SOLIDS ANALYSIS

LABORATORY SERIAL NUMBER FOR SAMPLE: F0893

DATE SAMPLED: 02-06-90

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0894

FUSION ANALYSIS OF SOLIDS

LABORATORY SERIAL NUMBER FOR SAMPLE: F0977

DATE SAMPLED: 02-06-90

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0978

LABORATORY SERIAL NUMBER OF SPIKED SAMPLE: F0979

ACID DIGESTION ANALYSIS OF SOLIDS

LABORATORY SERIAL NUMBER FOR SAMPLE: F0989

DATE SAMPLED: 02-06-90

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0990

LABORATORY SERIAL NUMBER OF SPIKED SAMPLE: F0991

WATER DIGESTION ANALYSIS OF SOLIDS

LABORATORY SERIAL NUMBER FOR SAMPLE: F0983

DATE SAMPLED: 02-06-90

LABORATORY SERIAL NUMBER OF DUPLICATE SAMPLE: F0984

LABORATORY SERIAL NUMBER OF SPIKED SAMPLE: F0985

Laboratory Notebook Reference

WHC-N-313-4

20

Notebook No.

Page No.

SAMPLE DATA SUMMARY

Analytical Laboratory Data Summary
SINGLE SHELL TANK PROJECT

The next four pages of this report (including this page) summarizes the results for the analysis of the

**Core 7 Composite Sample
Tank 241-U-110**

UNTREATED SAMPLE RESULTS

	Sample	Duplicate
pH	12.33	12.99
% H ₂ O	23.79%	27.83%
Mercury	4.43 ug/g	1.26 ug/g
Cyanide	<1.0 ug/g	<1.0 ug/g
Carbon 14	This Analysis was not completed	

DATA SUMMARY

Sample units are Wet Weight

Core 7 Composite Fusion Dissolution

Tank: 241-U-110

Customer ID: Core Composite 7

ICP Results

Radiological Analysis

	Sample	Duplicate Sample	Sample	Duplicate
Fusion	3.02 g/L	3.57 g/L	Aluminum	52011 ug/g
Total Alpha	1.64E-01 uci/g	2.11E-01 uci/g	Antimony	LT
Total Beta	6.13E+02 uci/g	6.39E+02 uci/g	Barium	27 ug/g
GEA Cs-137	1.81E+01 uci/g	1.74E+01 uci/L	Beryllium	LT
Uranium	3.91E+03 ug/g	4.26E+03 ug/g	Bismuth	6055 ug/g
Plutonium	1.82E-01 uci/g	2.08E-01 uci/g	Boron	50 ug/g
Americium 241	6.16E-02 uci/g	6.83E-02 uci/g	Cadmium	LT
Neptunium	<3.58E-01 uci/g	<3.03E-01 uci/g	Calcium	758 ug/g
Technetium 99	<6.22E-03 uci/g	<5.24E-03 uci/g	Cerium	669 ug/g
Iodine 129	<1.07E-02 uci/g	<9.47E-03 uci/g	Chromium	120 ug/g
Strontium 90	2.91E+02 uci/g	2.46E+02 uci/g	Copper	112 ug/g
			Europium	12 ug/g
			Iron	3859 ug/g
			Lanthanum	LT
			Lead	93 ug/g
			Lithium	LT
			Magnesium	303 ug/g
			Manganese	708 ug/g
			Mercury	LT
			Molybdenum	32 ug/g
			Neodymium	LT
			Nickel	2356 ug/g
			Samarium	726 ug/g
			Selenium	364 ug/g
			Silicon	3364 ug/g
			Silver	LT
			Sodium	33649 ug/g
			Strontium	135 ug/g
			Sulfur	159 ug/g
			Tantalum	102 ug/g
			Thallium	5577 ug/g
			Thorium	1516 ug/g
			Tin	49 ug/g
			Titanium	28 ug/g
			Vanadium	56 ug/g
			Zinc	55 ug/g
			Zirconium	113 ug/g

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

DATA SUMMARY

Units For Samples Are Wet Weight

Core 7 Composite Water Digestion

Tank:	241-U-110	ICP Results			
Customer Id.:	Core 7 Composite			Sample	Duplicate
		Sample	Duplicate		
pH of Digested Solution				Aluminum	2533 ug/g
pH	10.97	10.55		Antimony	LT
				Barium	LT
				Beryllium	LT
				Boron	294 ug/g
				Cadmium	LT
				Calcium	219 ug/g
				Cerium	LT
				Chromium	163 ug/g
Fluoride	6.01E+03 ug/g	5.79E+03 ug/g		Cobalt	LT
Chloride	7.62E+02 ug/g	1.12E+03 ug/g		Copper	LT
Nitrate	2.81E+04 ug/g	2.83E+04 ug/g		Europium	LT
Phosphate	3.94E+04 ug/g	3.30E+04 ug/g		Iron	LT
Sulfate	<2.04E+3 ug/g	<2.10E+3 ug/g		Lanthanum	LT
Total Organic Carbon	1.09E+03 ug/g	8.76E+02 ug/g		Lithium	LT
Ammonia	<1.73E+03 ug/g	<1.64E+03 ug/g		Magnesium	288 ug/g
Carbonate	5.25E+03 ug/g	5.12E+03 ug/g		Manganese	LT
Nitrite	3.76E+03 ug/g	5.94E+03 ug/g		Mercury	36 ug/g
				Molybdenum	LT
				Neodymium	LT
				Nickel	LT
				Potassium	LT
				Selenium	LT
Total Alpha	1.46E-03 uci/g	7.00E-04 uci/g		Silver	LT
Total Beta	3.49 uci/g	4.04 uci/g		Sodium	57752 ug/g
GEA Cs-137	2.16 uci/g	2.09 uci/g		Strontium	18219 ug/g
Americium 241	<2.31E-03 uci/g	<1.49E-03 uci/g		Sulfur	LT
Carbon 14	<1.14E-04 uci/g	<1.13E-04 uci/g		Tantalum	112 ug/g
Iodine 129	<2.86E-03 uci/g	<5.10E-03 uci/g		Thallium	225 ug/g
Neptunium 237	<1.13E-01 uci/g	<1.07E-01 uci/g		Tin	LT
Plutonium	1.54E-03 uci/g	<8.58E-04 uci/g		Titanium	LT
Strontium	4.19E-01 uci/g	2.72E-01 uci/g		Vanadium	LT
Technetium 99	2.86E-03 uci/g	3.24E-03 uci/g		Zinc	11 ug/g
Tritium	<1.14E-03 uci/g	<1.12E-03 uci/g		Zirconium	23 ug/g
					LT
					LT
Atomic Absorption Spectroscopy					
Arsenic	2.50E-01 ug/g	3.83E-01 ug/g			
Mercury	3.68E-02 ug/g	<1.69E-01 ug/g			
Selenium	<5.06E-01 ug/g	<4.98E-01 ug/g			

DATA SUMMARY
Units For Samples Are Wet Weight

**Core 7 Composite
Acid Digestion**

Tank: 241-U-110
Customer Id.: Core 7 Composite

				ICP Results	
				Sample	Duplicate
Atomic Absorption Spectroscopy					
Hydride Analysis					
Arsenic	Sample 3.11E-01 ug/g	Duplicate 4.38E-01 ug/g		Aluminum	144784 ug/g
Mercury	1.05 ug/g	1.53 ug/g		Antimony	LT 667 ug/g
Selenium	<3.70 ug/g	<5.20 ug/g		Arsenic	114 ug/g 200 ug/g
				Barium	27 ug/g 43 ug/g
				Beryllium	LT 2 ug/g
				Bismuth	8829 ug/g 12220 ug/g
				Boron	LT LT
				Cadmium	LT 21 ug/g
				Calcium	354 ug/g 321 ug/g
				Cerium	LT 1082 ug/g
				Chromium	344 ug/g 443 ug/g
				Cobalt	LT 283 ug/g
				Copper	290 ug/g 299 ug/g
				Europium	LT 17 ug/g
				Iron	8568 ug/g 9064 ug/g
				Lead	284 ug/g 674 ug/g
				Lithium	LT 25 ug/g
				Magnesium	346 ug/g 320 ug/g
				Manganese	2389 ug/g 2148 ug/g
				Mercury	1032 ug/g 647 ug/g
				Molybdenum	41 ug/g 78 ug/g
				Neodymium	LT LT
				Nickel	80 ug/g 127 ug/g
				Phosphorous	8209 ug/g 18341 ug/g
				Potassium	LT 1611 ug/g
				Samarium	LT 949 ug/g
				Selenium	706 ug/g 1041 ug/g
				Silver	LT 80 ug/g
				Sodium	60976 ug/g 83949 ug/g
				Strontium	358 ug/g 330 ug/g
				Sulfur	159 ug/g 247 ug/g
				Tantalum	LT 237 ug/g
				Thallium	572 ug/g 4972 ug/g
				Thorium	107 ug/g 2326 ug/g
				Tin	95 ug/g 163 ug/g
				Titanium	40 ug/g 71 ug/g
				Vanadium	32 ug/g 63 ug/g
				Zinc	1284 ug/g 81 ug/g
				Zirconium	61 ug/g 191 ug/g

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

PHYSICAL TEST RESULTS

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007


INSTRUMENT	WA63090/WA58053
PROCEDURE/REV	L1-000-200
TECHNOLOGIST	D. B. Bechtold
DATE	03-08-90, 03-12-90
TEMPERATURE	N/A
STARTING TIME	0912 03-08-90
ENDING TIME	1304 03-12-90
CHEMIST	D. B. Bechtold

Thermographic/Differential
Scanning Calorimeter Analysis

	DESCRIPTION	LAB ID
1	Thermographic Analysis	F0971
2	Diff. Scanning Calorimeter	F0971
3		
4		
5		
6		
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQT.VOL.	FINAL VOL. OF STD.
N/A				




DBR, SBK FILE: F0971.TG

Temperature (C)

TG

DATE: 90/03/12 TIME: 13:04



DBB/SBK FILE: F0971.D4

TEMPERATURE (C)

DSC

DATE: 90/03/08 TIME: 09:12

UNDIGESTED SAMPLE ANALYSIS RESULTS

Single Shell Tank Project

**Undigested Sample
Analysis Results
Units For Samples Are Wet Weight**

Tank: 241-U-110
 Core: 7
 Segment: F0971
 Customer ID: Core Composite 7

	Check Standard	Blank	Sample	Duplicate Sample	Spike of Sample	Check Standard
Laboratory ID:	F0969	F0970	F0971	F0972	N/A	F0974
pH	100.70%	6.72	12.33	12.99	N/A	100.20%
Laboratory ID:	F0969	F0970	F0971	F0972	N/A	F0974
% Water	96.80%	-6.40	mg	23.79%	27.83%	N/A
Laboratory ID:	F0969	F0970	F0971	F0972	F0973	F0974
Mercury	101.60%	<1.00E-02	ug/g	4.43	1.26	66.80%
Laboratory ID:	F0969	F0970	F0971	F0972	F0973	F0974
Cyanide	100.90%	0.3	ug	<1.0	ug/g	99.50%

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	A110653
PROCEDURE/REV	LA-212-103/A-3
TECHNOLOGIST	M. Franz
DATE	Feb. 08, 1990
TEMPERATURE	22.9 C
STARTING TIME	0800
ENDING TIME	1330
CHEMIST	R. E. Brandt

pH analysis of the solid sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0969
2	Reagent Blank	F0970
3	Sample Composite 7	F0971
4	Duplicate Sample Composite 7	F0972
5	Final LMCS Check Std.	F0974
6		
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	72C11/1.0 ml			1.0 ml

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	N/A	
PROCEDURE/REV	LA-564-101/D-0	
TECHNOLOGIST	R. Hale	
DATE	Feb. 14, 1990	
TEMPERATURE	120 C	
STARTING TIME	1000	02-07-90
ENDING TIME	1400	02-08-90
CHEMIST	R. E. Brandt	

Percent Water
Undigested Sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0969
2	Reagent Blank	F0970
3	Sample Composite 7	F0971
4	Duplicate Sample Composite 7	F0972
5	Final LMCS Check Std.	F0974
6		
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQAT.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	11C11AH/1.0 g			1.0 g

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	Perkin-Elmer
PROCEDURE/REV	LA-325-102/A-2
TECHNOLOGIST	M. Myers
DATE	July 17, 1990
TEMPERATURE	22 C
STARTING TIME	1100
ENDING TIME	1200
CHEMIST	R. K. Fuller

Mercury Analysis
Undigested Sample

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0969
2	Reagent Blank	F0970
3	Sample	F0971
4	Duplicate Sample	F0972
5	Spike	F0973
6	Final LMCS Check Std.	F0974
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	58C11-CE/25 ul			25ml
Spike	58C11-CE/15 ul	F0971/0.0136 g		25 ml

Single Shell Tank Calibration Record

ANALYTE: Hg

PROCEDURE: LA-325-102

REVISION: A-2

INSTRUMENT: Perkins Elmer

PROPERTY NUMBER: WA77479

TECHNOLOGIST: Melanie Myers

PAYROLL NUMBER: 6C823

DATE: July 17, 1990

CALIBRATION STANDARD ID: 102C3.AG

ANALYTE CONCENTRATION: 1.00ppm

TYPE OF CALIBRATION: Linear Regression

Aliquot	Weight	Instrument Reading Units= mm
0ul	0ng	1.50
10ul	10ng	33.00
20ul	20ng	58.00
40ul	40ng	105.00

COMMENTS:

25ml S8C1-CE Sample F974 n54

2ml of 25ml .013log (F970) + 15ml S8C11-CE

7.17-9D
10mL/10mL
6C823

Sample Spike F973

Hg

23ml of 25ml .022log Sample Duplicate F974

17ml of 25ml .013log n25ml used 2ml Sample

F970 .013log n Sample 106ml

1ml F970 ml Super Blank

Hg
7.17-9D
10mL/10mL

6C823

25ml S8C1-CE Sample F974
n54

40ml 102C3. PG

107ml

Hg

7.17.90
10m / 10m

1m 1970 Mi Sauer Band

LOC 823

25m Social-CE Sample 510 F 9169
85m

10m 102C3. PG

10m

4Dm 102C3. AG

10m

10m 102C3 - PG

50m

Hg

7.17.90

10m 10m
volcanic lenses

LOC 823

33m
102C3 - AG15m
15m
15m

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	WA66684	
PROCEDURE/REV	LA-695-101/A-2	
TECHNOLOGIST	Ed Colvin	
DATE	March 07, 1990	
TEMPERATURE	N/A	
STARTING TIME	0900	03-05-90
ENDING TIME	1400	03-07-90
CHEMIST	S. A. Catlow	

Cyanide Analysis

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0969
2	Reagent Blank	F0970
3	Sample Composite 7	F0971
4	Duplicate Sample Composite 7	F0972
5	Spike Composite 7	F0973
6	Final LMCS Check Std.	F0974
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	75C11-C/10.0 ul			50 ml
Spike	75C11-C/10.0 ul	F0971/0.4042g		50 ml

Single Shell Tank Calibration Record

ANALYTE:	CN-		
PROCEDURE:	LA-695-101	REVISION:	A-1
INSTRUMENT:	Bausch & Lomb Spectronic 21	PROPERTY NUMBER:	WA66684
TECHNOLOGIST:	R.Brandt	PAYROLL NUMBER:	69090
DATE:	July 20, 1989		

CALIBRATION STANDARD ID: 88C15C

ANALYTE CONCENTRATION: 817 ug/ml

TYPE OF CALIBRATION: Least Square Linear Regression

Dilution	Concentration	Instrument Reading Units= Abs.
Blank	0	0.016
100 ul	81.7 ug	0.091
200 ul	163.4 ug	0.150
500 ul	408.5 ug	0.354
1000 ul	817.0 ug	0.663
2000 ul	1634.0 ug	1.275
3000 ul	2451.0 ug	1.720

COMMENTS: Y - intercept - 0.01682

Slope - 0.076317

Correlation Coefficient - 0.999874

KOH FUSION RESULTS

Single Shell Tank Project

**Core 7 Composite
Fusion Analysis
Units For Samples Are Wet Weight**

Tank: 241-U-110
Core: 7
Segment: F0971
Customer ID: Core Composite 7

	Check Standard	Blank	Sample	Duplicate Sample	Spike of Sample	Check Standard
Laboratory ID: Fusion	N/A N/A	F0976 N/A	F0977 3.02 g/L	F0978 3.57 g/L	N/A N/A	N/A g/L
Laboratory ID: Total Alpha Total Beta	F0975 102.10% 103.50%	F0976 <1.60E-04 uci/L <1.30E-03 uci/L	F0977 1.64E-01 uci/g 6.13E+02 uci/g	F0978 2.11E-01 uci/g 6.39E+02 uci/g	F0979 91.70% 150.48%	F0989 95.50% 100.98%
Laboratory ID: GEA Cs-137	F0975 103.60%	F0976 <5.19E-02 uci/L	F0977 1.81E+01 uci/g	F0978 1.74E+01 uci/g	F0979 95.50%	F0980 102.80%
Laboratory ID: Uranium	F0975 99.50%	F0976 <3.59E-07 g/L	F0977 3.91E+03 ug/g	F0978 4.26E+03 ug/g	F0979 *	F0980 99.50%
Laboratory ID: Plutonium	F0975 115.10%	F0976 2.45E-02 uci/L	F0977 1.82E-01 uci/g	F0978 2.08E-01 uci/g	F1027 109.90%	F1028 102.50%
Laboratory ID: Americium 241	F0975 107.10%	F0976 <3.52E-02 uci/L	F0977 6.16E-02 uci/g	F0978 6.83E-02 uci/g	F1033 108.30%	F1034 108.10%
Laboratory ID: Neptunium	F0897 80.50%	F0898 <1.08 uci/L	F0977 <3.58E-01 uci/g	F0978 <3.03E-01 uci/g	F0979 71.20%	F0980 63.30%
Laboratory ID: Technetium 99	F0975 116.00%	F0976 <1.83E-02 uci/L	F0977 <6.22E-03 uci/g	F0978 <5.24E-03 uci/g	F0979 97.70%	F0980 90.30%
Laboratory ID: Iodine 129	F0975 95.70%	F0976 <3.22E-02 uci/L	F0977 <1.07E-02 uci/g	F0978 <9.47E-03 uci/g	F0979 97.70%	F0980 90.30%
Laboratory ID: Strontium 90	F0975 102.50%	F0976 6.36E-02 uci/L	F0977 2.91E+02 uci/g	F0978 2.46E+02 uci/g	F0979 114.60%	F0980 101.60%

*Ratio Of Standard To Sample Insufficient To Calculate Spike Recovery.

ICP Results

Data Summary

Date Analyzed:	April 20, 1990	Reagent Blank	F0976
Procedure:	LA-505-151/A-0	Core 7 Composite	F0977
Analyst:	J. A. White	Duplicate of Core 7 Composite	F0978
Digestion	Acid Digestion	Spike of Core 7 Composite	F0979
Procedure:	LA-505-159/A-0		

	Instrument Starting LMCS Standard %	Acid Digest. LMCS Standard %	Reagent BLANK	Wet Weight Sample	Wet Weight Sample	Duplicate	Spike Recovery %	LMCS ACID Digestion %	Closing LMCS Standard %
Aluminum	103.23%	NOT RUN	-0.78 LT	52011	61606		NOT RUN		101.37%
Antimony	100.45%		-2.24 LT	160 LT	223 LT	85.43%			99.82%
Barium	97.11%		-0.03 LT	27	22	92.43%			96.95%
Beryllium	97.96%		-0.01 LT	1 LT	0 LT				98.10%
Bismuth	106.18%		-0.62 LT	6055	6686				107.82%
Boron	98.16%		0.07 LT	50	16 LT	92.28%			98.20%
Cadmium	100.20%		-0.05 LT	8 LT	6 LT	95.05%			99.97%
Calcium	99.66%		1.65	758	1690	97.02%			99.49%
Cerium	91.19%		-1.75 LT	669	480	41.86%			92.81%
Chromium	92.49%		-0.10 LT	120	138	87.23%			91.85%
Copper	99.05%		-0.20 LT	112	143	92.64%			98.94%
Europium	98.44%		-0.02 LT	12	8				99.95%
Iron	99.15%		0.10 LT	3859	4396	98.09%			99.27%
Lanthanum	93.83%		-0.31 LT	35 LT	44 LT				95.34%
Lead	105.10%		-1.47 LT	93	323				106.36%
Lithium	95.70%		-1.50 LT	-122 LT	-123 LT	83.23%			95.69%
Magnesium	100.11%		1.19	303	806	105.33%			100.45%
Manganese	99.23%		0.03 LT	708	799	95.58%			98.78%
Mercury	107.34%		0.01 LT	10 LT	11 LT				105.06%
Molybdenum	101.02%		-0.02 LT	32	29				98.62%
Neodymium	92.52%		-1.14 LT	545 LT	630 LT	68.62%			90.79%
Nickel	99.44%		18.11	2356	2207	95.17%			99.49%
Potassium	99.70%		NA	0	0	0.00%			101.87%
Samarium	100.68%		-1.93 LT	726	530				102.43%
Selenium	107.43%		-0.63 LT	364	365				105.43%
Silicon	92.44%		1.09	3364	3988				90.62%
Silver	105.03%		-0.14 LT	42 LT	29 LT				106.65%
Sodium	96.81%		10.66	33649	37361	94.32%			96.99%
Strontium	98.22%		-0.01 LT	135	182	94.60%			98.34%
Sulfur	106.14%		0.03 LT	159	144				105.95%
Tantalum	100.56%		-0.31 LT	102	74 LT				98.56%
Thallium	107.92%		-0.09 LT	5577	6924				107.06%
Thorium	105.08%		-2.62 LT	1516	3422				106.97%
Tin	97.87%		0.07 LT	49	55	93.82%			98.31%
Titanium	103.51%		-0.08 LT	28	25				101.17%
Vanadium	99.71%		0.05 LT	56	33 LT				98.46%
Zinc	98.83%		0.09	55	72	94.44%			98.97%
Zirconium	101.83%		-0.20 LT	113	78				99.75%

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

Single Shell Tank Project
**Core 7 Composite
Fusion Analysis
Results On Laboratory Digestions**

Tank: 241-U-110
Core: 7
Segment: F0971
Customer ID: Core Composite 7

	Check Standard	Blank	Sample	Duplicate Sample	Spike of Sample	Check Standard
Laboratory ID: Fusion	N/A N/A	F0976 N/A	F0977 3.02 g/L	F0978 3.57 g/L	N/A N/A	N/A N/A
Laboratory ID: Total Alpha	F0975 102.10%	F0976 <1.60E-04 uci/L	F0977 4.96E-01 uci/L	F0978 7.54E-01 uci/L	F0979 91.70%	F0980 95.50%
Total Beta	103.50%	<1.30E-03 uci/L	1.85E+03 uci/L	2.28E+03 uci/L	150.48%	100.98%
Laboratory ID: GEA Cs-137	F0975 103.60%	F0976 <5.19E-02 uci/L	F0977 5.48E+01 uci/L	F0978 6.21E+01 uci/L	F0979 95.50%	F0980 102.80%
Laboratory ID: Uranium	F0975 99.50%	F0976 <3.59E-07 g/L	F0977 1.18E-02 g/L	F0978 1.52E-02 g/L	F0979 *	980 99.50%
Laboratory ID: Plutonium	F0975 115.10%	F0976 2.45E-02 uci/L	F0977 5.51E-01 uci/L	F0978 7.44E-01 uci/L	F1027 109.90%	F1028 102.50%
Laboratory ID: Americium 241	F0975 107.10%	F0976 <3.52E-02 uci/L	F0977 1.86E-01 uci/L	F0978 2.44E-01 uci/L	F1033 108.30%	F1034 108.10%
Laboratory ID: Neptunium 237	F0897 80.50%	F0898 <1.08 uci/L	F0977 <1.08 uci/L	F0978 <1.08 uci/L	F0979 71.20%	F0980 63.30%
Laboratory ID: Technetium 99	F0975 116.00%	F0976 <1.83E-02 uci/L	F0977 <1.88E-02 uci/L	F0978 <1.87E-02 uci/L	F0979 114.70%	F0980 112.40%
Laboratory ID: Iodine 129	F0975 95.70%	F0976 <3.22E-02 uci/L	F0977 <3.22E-02 uci/L	F0978 <3.38E-02 uci/L	F0979 97.70%	F0980 90.30%
Laboratory ID: Strontium 90	F0975 102.50%	F0976 6.36E-02 uci/L	F0977 8.79E+02 uci/L	F0978 8.79E+02 uci/L	F0979 114.60%	F0980 101.60%

*Ratio Of Standard To Sample Insufficient To Calculate Spike Recovery.

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	N/A
PROCEDURE/Rev	LA-549-141/A-1
TECHNOLOGIST	R. Hale
DATE	Feb. 12, 1990
TEMPERATURE	450 C
STARTING TIME	1300
ENDING TIME	1400
CHEMIST	S. A. Catlow

KOH Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	N/A
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5		
6		
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD Bk# & ALQ.T.VOL.	FINAL VOL. OF STD.
N/A				

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	HW45676
PROCEDURE/REV	LA-508-101/C-2
TECHNOLOGIST	M. Franz
DATE	Feb. 14, 1990
TEMPERATURE	N/A
STARTING TIME	0800
ENDING TIME	0930
CHEMIST	S. A. Catlow

Total Alpha and Total Beta
Fusion Dissolution
Detector #14

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Spike Composite 7	F0979
6	Final LMCS Check Std.	F0989
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	102B44/10ml			N/A
Spike	102B44/10ml	F0977/5.0 ul		N/A

Single Shell Tank

Calibration Record

ANALYTE:	Am ²⁴¹		
PROCEDURE:	LQ-508-002	REVISION:	A-0
INSTRUMENT:	Detector #14	PROPERTY NUMBER:	WA45709
TECHNOLOGIST:	R.A. Jones	PAYROLL NUMBER:	65801
DATE:	November 28, 1988		
CALIBRATION STANDARD ID: 36B40A8; 36B40B7; 36B40C7; 36B40A3; 36B40B3; 36B40C3; 36B40A6; 36B40B6; 36B40C5			
ANALYTE CONCENTRATION: N/A			
TYPE OF CALIBRATION: Efficiency			

SST-103 Rev. (Draft) 9/15/90 Short Interim

CALIBRATION SHEET FOR ALPHA/BETA SYSTEMS: USING PROCEDURE LQ-508-002

DETECTOR No. 14

TIME ZERO DATE (HD): 15897

RADIOMUCLIDE: Am-241

HALF LIFE: 154497

DATE COUNTED (HD): 16135

COUNT TIME: 5

CPM BKG: 0.5

CALIBRATED BY: RA JONES HD 0 = 09/25/44

STANDARD ID	SIZE	DATE	TIME	COUNTS @ 0 DEG.	COUNTS @ 90 DEG.	COUNTS @ 180 DEG.	COUNTS @ 270 DEG.
36B40A8	1	11/28/88	1115	83719	83889	83820	84087
36B40B7	1	11/28/88	1128	147778	147414	147378	147313
36B40C7	1	11/28/88	1142	212324	211727	211106	211442
36B40A3	2	11/28/88	1155	67029	66485	66532	66137
36B40B3	2	11/28/88	1207	116432	117580	116643	116507
36B40C3	2	11/28/88	1221	167025	166472	166682	166167
36B40A6	5	11/28/88	1234	64835	64744	63542	64860
36B40B6	5	11/28/88	1246	132366	127335	127267	127511
36B40C5	5	11/28/88	1300	176904	172226	170187	173840

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
36B40A8	1"	60570	16775	1.00	16793	0.2773
36B40B7	1"	109900	29494	1.00	29525	0.2687
36B40C7	1"	159700	42329	1.00	42375	0.2653
AVERAGE, 1" =		0.2704 +/- @95%	0.0121	4.46 %	ON	11/28/88

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
36B40A3	2"	61800	13309	1.00	13323	0.2156
36B40B3	2"	110700	23358	1.00	23383	0.2112
36B40C3	2"	161400	33317	1.00	33352	0.2066
AVERAGE, 2" =		0.2111 +/- @95%	0.0088	4.15 %	ON	11/28/88

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
36B40A6	5"	59470	12899	1.00	12912	0.2171
36B40B6	5"	109800	25723	1.00	25751	0.2345
36B40C5	5"	160100	34657	1.00	34694	0.2167
AVERAGE, 5" =		0.2228 +/- @95%	0.0199	8.95 %	ON	11/28/88

NEW EFFS FOR DET	14 Am-241	1" =	0.2704	2" =	0.2111
		5" =	0.2228		

Single Shell Tank

Calibration Record

ANALYTE:	Co ⁶⁰	
PROCEDURE:	LQ-508-002	REVISION: A-0
INSTRUMENT:	Detector #14	PROPERTY NUMBER: WA57276
TECHNOLOGIST:	R.A. Jones	PAYROLL NUMBER: 65801
DATE:	November 28, 1988	
CALIBRATION STANDARD ID: 32B40A8; 32B40B7; 32B40C7; 32B40A4; 32B40B3; 32B40C4; 32B40A5; 32B40B6; 32B40C5		
ANALYTE CONCENTRATION:	N/A	
TYPE OF CALIBRATION:	Efficiency	

SST-103 Rev. (Draft) 9/15/90 Short Interim

CALIBRATION SHEET FOR ALPHA/BETA SYSTEMS: USING PROCEDURE LQ-508-002

DETECTOR No. 14

RADIOMUCLIDE:	Co-60	2", 5" STD TIME ZERO DATE (HD):	15883
HALF LIFE:	1925	1" STD TIME ZERO DATE (HD):	15883
COUNT TIME:	5	DATE COUNTED (HD):	16135
CPM BKG:	19	DATE COUNTED 1" (HD)	16135
CPM 1" BKG:	19		

CALIBRATED BY: RA JONES HD 0 = 09/25/44

STANDARD ID	SIZE	DATE	TIME	COUNTS @ 0 DEG.	COUNTS @ 90 DEG.	COUNTS @ 180 DEG.	COUNTS @ 270 DEG.
32B40A8	1	11/28/88	1313	94851	93909	94136	94073
32B40B7	1	11/28/88	1325	180320	178550	178878	179065
32B40C7	1	11/28/88	1338	260104	258654	259795	259469
32B40A4	2	11/28/88	1349	90411	89596	89705	90717
32B40B3	2	11/28/88	1527	170657	169556	169500	170301
32B40C4	2	11/28/88	1540	244082	244246	243016	249016
32B40A5	5	11/28/88	1551	83403	82448	82728	84312
32B40B6	5	11/28/88	1603	160402	163149	162823	159622
32B40C5	5	11/28/88	1616	237343	232578	231827	23179
STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY	
32B40A8	1"	69550	18829	1.09	20618	0.2964	
32B40B7	1"	134700	35822	1.09	39224	0.2912	
32B40C7	1"	201000	51882	1.09	56810	0.2826	
AVERAGE, 1" =		0.2901 +/- @95%	0.0137	4.71 %	ON	11/28/88	
STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY	
32B40A4	2"	70480	18002	1.09	19712	0.2797	
32B40B3	2"	135100	33982	1.09	37209	0.2754	
32B40C4	2"	202400	48999	1.09	53653	0.2651	
AVERAGE, 2" =		0.2734 +/- @95%	0.0147	5.38 %	ON	11/28/88	
STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY	
32B40A5	5"	70160	16626	1.09	18205	0.2595	
32B40B6	5"	135700	32281	1.09	35347	0.2605	
32B40C5	5"	201900	46658	1.09	51090	0.2530	
AVERAGE, 5" =		0.2577 +/- @95%	0.0079	3.07 %	ON	11/28/88	
NEW EFFS FOR DET		14 Co-60	1" =	0.2901	2" =	0.2734	
			5" =	0.2577			

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	WA77228/401934
PROCEDURE/REV	LA-548-121/C-1
TECHNOLOGIST	M. Franz
DATE	Feb. 13, 1990
TEMPERATURE	N/A
STARTING TIME	1000
ENDING TIME	1130
CHEMIST	S. A. Catlow

GEA Analysis

Fusion Dissolution

Samples are run in batch, but
counted randomly.

Detectors #2 & #3

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Spike Composite 7	F0979
6	Final LMCS Check Std.	F0980
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQT.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	89B44/500 uL			22 mL
Spike	89B44/500 uL	F0977/100 uL		22 mL

*
*
*
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

08-OCT-90 13:52:42

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 2.0
DETECTOR NUMBER: 2 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD2010
ANALYZED BY: DM

SAMPLE DESCRIPTION: F-975 SEG.COMP#7
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 13-FEB-90 AT 14:56:53

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3005. SECONDS
DEAD TIME: 0.17 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-MAR-89
EFFICIENCY CALIBRATION PERFORMED 21-OCT-88

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1127.54	563.40	1.53	561.	544.	13.4	CS-134, EU-152
2C	1139.68	569.47	1.53	536.	1028.	10.9	CS-134, BI-207
3	1210.43	604.84	1.62	525.	6083.	2.8	CS-134
4	1324.25	661.74	1.67	389.	9158.	2.2	CS-137
4B		661.85			36.	13.9	
5C	1592.48	795.84	1.68	302.	4110.	3.8	CS-134
6C	1604.68	801.93	1.68	249.	443.	12.6	CS-134
7	2347.04	1173.08	2.01	246.	3670.	3.5	CO-60
8	2665.48	1332.28	2.18	37.	3503.	3.4	CO-60
8B		1332.24			9.	37.4	
9	2730.73	1364.91	2.24	22.	105.	24.4	CS-134
10	2922.26	1460.67	2.92	15.	160.	17.6	K-40
10B		1460.85			156.	3.8	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY
 B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0012

BACKGROUND DESCRIPTION: BKG

BACKGROUND COLLECT STARTED ON 30-AUG-88 AT 16:46:00

BACKGROUND LIVE TIME: 60000. SECONDS

222-S COUNTING ROOM

08-OCT-90 13:52:42

SAMPLE: F-975 SEG.COMP#7

DATA COLLECTED ON 13-FEB-90 AT 14:56:53

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<1.18E+00		LLD<1.18E+00		911.07	
AG-108M	LLD<2.86E-01		LLD<2.86E-01		433.94	
AG-110M	LLD<1.39E+00		LLD<1.39E+00		657.76	
AM-241	LLD<1.31E+00		LLD<1.31E+00		59.54	
AM-243	LLD<3.45E-01		LLD<3.45E-01		74.67	
AR-41	LLD<2.22E-01		LLD<2.22E-01		1293.64	
AU-198	LLD<2.54E-01		LLD<2.54E-01		411.80	
BA-133	LLD<3.42E-01		LLD<3.42E-01		356.02	
BA-139	LLD<7.17E-01		LLD<7.17E-01		165.85	
BA-140	LLD<1.02E+00		LLD<1.02E+00		537.27	
BA-141	LLD<7.05E-01		LLD<7.05E-01		190.23	
BE-7	LLD<2.38E+00		LLD<2.38E+00		477.59	
BI-207	LLD<2.65E-01		LLD<2.65E-01		569.70	
BI-212	LLD<3.57E+00		LLD<3.57E+00		727.27	
BI-214	LLD<2.05E+00		LLD<2.05E+00		609.32	
CD-109	LLD<4.32E+00		LLD<4.32E+00		88.03	
CE-139	LLD<1.62E-01		LLD<1.62E-01		165.85	
CE-141	LLD<2.66E-01		LLD<2.66E-01		145.44	
CEPR144	LLD<2.09E+00		LLD<2.09E+00		133.51	
CO-56	LLD<2.50E-01		LLD<2.50E-01		846.76	
CO-57	LLD<1.36E-01		LLD<1.36E-01		122.06	
CO-58	LLD<2.29E-01		LLD<2.29E-01		810.75	
CO-60	2.29E+01	+8.23E-01	2.29E+01	+8.23E-01	1332.50	-0.22
					1173.24	-0.16
CR-51	LLD<1.95E+00		LLD<1.95E+00		320.09	
CS-134	2.07E+01	+8.23E-01	2.07E+01	+8.23E-01	795.84	-0.01
					604.70	0.14
CS-136	LLD<2.58E-01		LLD<2.58E-01		818.51	
CS-137	3.94E+01	+9.81E-01	3.94E+01	+9.81E-01	661.65	0.09
CS-138	LLD<1.91E-01		LLD<1.91E-01		1435.86	
EU-152	LLD<7.64E-01		LLD<7.64E-01		1408.01	
EU-154	LLD<4.77E-01		LLD<4.77E-01		1274.45	
EU-155	LLD<6.00E-01		LLD<6.00E-01		105.31	
FE-59	LLD<6.30E-01		LLD<6.30E-01		1099.25	
HF-181	LLD<3.02E-01		LLD<3.02E-01		482.20	
HG-203	LLD<2.05E-01		LLD<2.05E-01		279.20	
I-131	LLD<2.68E-01		LLD<2.68E-01		364.48	
I-132	LLD<7.43E-01		LLD<7.43E-01		667.69	
I-133	LLD<2.66E-01		LLD<2.66E-01		529.69	
I-134	LLD<3.83E-01		LLD<3.83E-01		847.03	
I-135	LLD<6.06E-01		LLD<6.06E-01		1260.41	
K-40	LLD<2.07E+00		LLD<2.07E+00		1460.75	
KR-85	LLD<5.86E+01		LLD<5.86E+01		513.99	
KR-85M	LLD<1.62E-01		LLD<1.62E-01		151.17	
KR-87	LLD<5.94E-01		LLD<5.94E-01		402.58	
KR-89	LLD<8.68E+00		LLD<8.68E+00		220.90	
LA-140	LLD<1.25E-01		LLD<1.25E-01		1596.20	

LA-142	LLD<5.76E-01	LLD<5.76E-01	641.83
MN-54	LLD<2.33E-01	LLD<2.33E-01	834.83
MN-56	LLD<2.82E-01	LLD<2.82E-01	846.76
NA-22	LLD<1.69E-01	LLD<1.69E-01	1274.55
NA-24	LLD<2.21E-01	LLD<2.21E-01	1368.60
NB-94	LLD<2.38E-01	LLD<2.38E-01	702.63
NB-95	LLD<2.28E-01	LLD<2.28E-01	765.78
NB-97	LLD<1.57E+00	LLD<1.57E+00	657.92
NP-237	LLD<1.28E+00	LLD<1.28E+00	86.50
NP-238	LLD<1.12E+00	LLD<1.12E+00	984.45
NP-239	LLD<1.32E+00	LLD<1.32E+00	277.60
PA-233	LLD<4.78E-01	LLD<4.78E-01	311.98
PA-234M	LLD<5.24E+01	LLD<5.24E+01	1001.03
PB-210	LLD<6.12E+00	LLD<6.12E+00	465.03
PB-212	LLD<3.99E-01	LLD<3.99E-01	239.00
PB-214	LLD<5.46E-01	LLD<5.46E-01	351.92
PO-210	LLD<2.01E+04	LLD<2.01E+04	804.00
PO-214	LLD<9.92E+03	LLD<9.92E+03	799.70
PO-216	LLD<1.62E+04	LLD<1.62E+04	804.90
PU-239	LLD<1.96E+03	LLD<1.96E+03	129.30
PU-241	LLD<6.24E+04	LLD<6.24E+04	148.57
RA-224	LLD<4.15E+00	LLD<4.15E+00	240.99
RA-226	LLD<3.75E+00	LLD<3.75E+00	186.10
RB-88	LLD<6.30E-01	LLD<6.30E-01	1836.00
RB-89	LLD<1.44E+00	LLD<1.44E+00	1031.88
RN-220	LLD<2.30E+02	LLD<2.30E+02	549.73
RU-103	LLD<2.56E-01	LLD<2.56E-01	497.08
RURH106	LLD<4.76E+00	LLD<4.76E+00	621.80
SB-124	LLD<5.21E-01	LLD<5.21E-01	602.72
SB-125	LLD<1.96E+00	LLD<1.96E+00	176.33
SC-46	LLD<3.25E-01	LLD<3.25E-01	1120.45
SE-75	LLD<3.04E-01	LLD<3.04E-01	264.66
SN-113	LLD<3.56E-01	LLD<3.56E-01	391.67
SR-85	LLD<2.57E-01	LLD<2.57E-01	513.99
SR-91	LLD<4.50E-01	LLD<4.50E-01	555.60
SR-92	LLD<9.63E-02	LLD<9.63E-02	1383.94
TA-182	LLD<9.58E-01	LLD<9.58E-01	1121.30
TC-99M	LLD<1.38E-01	LLD<1.38E-01	140.51
TE-123M	LLD<1.52E-01	LLD<1.52E-01	159.00
TE-125M	LLD<4.17E+01	LLD<4.17E+01	109.27
TE-132	LLD<1.83E-01	LLD<1.83E-01	228.16
TH-228	LLD<1.42E+01	LLD<1.42E+01	84.37
TL-208	LLD<3.19E-01	LLD<3.19E-01	583.14
U-235	LLD<2.50E-01	LLD<2.50E-01	185.71
U-237	LLD<7.21E-01	LLD<7.21E-01	208.00
W-187	LLD<8.13E-01	LLD<8.13E-01	685.74
XE-131M	LLD<6.58E+00	LLD<6.58E+00	163.98
XE-133	LLD<4.84E-01	LLD<4.84E-01	81.00
XE-133M	LLD<1.64E+00	LLD<1.64E+00	233.21
XE-135	LLD<1.87E-01	LLD<1.87E-01	249.79
XE-138	LLD<1.41E+00	LLD<1.41E+00	258.41
Y-88	LLD<5.98E-02	LLD<5.98E-02	1836.06
Y-91	LLD<7.19E+01	LLD<7.19E+01	1204.90
Y-91M	LLD<3.40E-01	LLD<3.40E-01	555.60
ZN-65	LLD<6.68E-01	LLD<6.68E-01	1115.55
ZR-95	LLD<4.27E-01	LLD<4.27E-01	756.73
ZR-97	LLD<2.42E-01	LLD<2.42E-01	743.33
TOTAL	8.30E+01 +-1.52E+00	8.30E+01 +-1.52E+00	

STANDARD DEVIATION = 0.15

E BAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.48E-09 UC/LI
TOTAL MEASURED ACTIVITY = 8.30E+01 (+-1.52E+00) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1127.54	563.40	544.	13.4	3.21E+01
1139.68	569.47	1028.	10.9	6.12E+01
1604.68	801.93	443.	12.6	3.55E+01
2730.73	1364.91	105.	24.4	1.30E+01

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
2922.26	1460.67	160.	17.6	2.10E+01

*
* G A M M A S P E C T R U M A N A L Y S I S *
*

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

08-OCT-90 13:56:26

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 2.0
DETECTOR NUMBER: 2 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD2011

ANALYZED BY: EMB

SAMPLE DESCRIPTION: F976

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 13-FEB-90 AT 16:09:47

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3001. SECONDS

DEAD TIME: 0.03 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-MAR-89

EFFICIENCY CALIBRATION PERFORMED 21-OCT-88

222-S COUNTING ROOM

08-OCT-90 13:56:26

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	2922.97	1461.02	2.64	12.	158.	17.3	K-40
1B		1460.85			156.	3.8	

ERROR QUOTATION AT 1.96 SIGMA
PEAK CONFIDENCE LEVEL AT 85.0%

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0012
BACKGROUND DESCRIPTION: BKG
BACKGROUND COLLECT STARTED ON 30-AUG-88 AT 16:46:00
BACKGROUND LIVE TIME: 60000. SECONDS

222-S COUNTING ROOM

08-OCT-90 13:56:26

SAMPLE: F976

DATA COLLECTED ON 13-FEB-90 AT 16:09:47

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<1.57E-01		LLD<1.57E-01		911.07	
AG-108M	LLD<3.18E-02		LLD<3.18E-02		433.94	
AG-110M	LLD<5.66E-02		LLD<5.66E-02		657.76	
AM-241	LLD<2.52E-01		LLD<2.52E-01		59.54	
AM-243	LLD<6.52E-02		LLD<6.52E-02		74.67	
AR-41	LLD<4.97E-02		LLD<4.97E-02		1293.64	
AU-198	LLD<3.18E-02		LLD<3.18E-02		411.80	
BA-133	LLD<5.30E-02		LLD<5.30E-02		356.02	
BA-139	LLD<1.27E-01		LLD<1.27E-01		165.85	
BA-140	LLD<1.49E-01		LLD<1.49E-01		537.27	
BA-141	LLD<1.17E-01		LLD<1.17E-01		190.23	
BE-7	LLD<3.49E-01		LLD<3.49E-01		477.59	
BI-207	LLD<3.28E-02		LLD<3.28E-02		569.70	
BI-212	LLD<6.29E-01		LLD<6.29E-01		727.27	
BI-214	LLD<9.28E-02		LLD<9.28E-02		609.32	
CD-109	LLD<8.26E-01		LLD<8.26E-01		88.03	
CE-139	LLD<2.88E-02		LLD<2.88E-02		165.85	
CE-141	LLD<4.69E-02		LLD<4.69E-02		145.44	
CEPR144	LLD<4.08E-01		LLD<4.08E-01		133.51	
CO-56	LLD<3.20E-02		LLD<3.20E-02		846.76	
CO-57	LLD<2.50E-02		LLD<2.50E-02		122.06	
CO-58	LLD<4.08E-02		LLD<4.08E-02		810.75	
CO-60	LLD<5.24E-02		LLD<5.24E-02		1332.50	
CR-51	LLD<2.89E-01		LLD<2.89E-01		320.09	
CS-134	LLD<4.42E-02		LLD<4.42E-02		795.84	
CS-136	LLD<4.79E-02		LLD<4.79E-02		818.51	
CS-137	LLD<6.02E-02		LLD<6.02E-02		661.65	
CS-138	LLD<1.11E-01		LLD<1.11E-01		1435.86	
EU-152	LLD<2.10E-01		LLD<2.10E-01		1408.01	
EU-154	LLD<1.18E-01		LLD<1.18E-01		1274.45	
EU-155	LLD<1.13E-01		LLD<1.13E-01		105.31	
FE-59	LLD<7.87E-02		LLD<7.87E-02		1099.25	
HF-181	LLD<3.82E-02		LLD<3.82E-02		482.20	
HG-203	LLD<2.80E-02		LLD<2.80E-02		279.20	
I-131	LLD<3.50E-02		LLD<3.50E-02		364.48	
I-132	LLD<4.42E-02		LLD<4.42E-02		667.69	
I-133	LLD<3.96E-02		LLD<3.96E-02		529.69	
I-134	LLD<5.49E-02		LLD<5.49E-02		847.03	
I-135	LLD<1.98E-01		LLD<1.98E-01		1260.41	
K-40	LLD<1.03E+00		LLD<1.03E+00		1460.75	
KR-85	LLD<1.05E+01		LLD<1.05E+01		513.99	
KR-85M	LLD<3.16E-02		LLD<3.16E-02		151.17	
KR-87	LLD<8.49E-02		LLD<8.49E-02		402.58	
KR-89	LLD<1.32E+00		LLD<1.32E+00		220.90	
LA-140	LLD<5.34E-02		LLD<5.34E-02		1596.20	
LA-142	LLD<9.02E-02		LLD<9.02E-02		641.83	
MN-54	LLD<4.48E-02		LLD<4.48E-02		834.83	

MN-56	LLD<3.61E-02	LLD<3.61E-02	846.76
NA-22	LLD<4.18E-02	LLD<4.18E-02	1274.55
NA-24	LLD<3.30E-02	LLD<3.30E-02	1368.60
NB-94	LLD<3.94E-02	LLD<3.94E-02	702.63
NB-95	LLD<3.56E-02	LLD<3.56E-02	765.78
NB-97	LLD<6.48E-02	LLD<6.48E-02	657.92
NP-237	LLD<2.46E-01	LLD<2.46E-01	86.50
NP-238	LLD<1.38E-01	LLD<1.38E-01	984.45
NP-239	LLD<1.91E-01	LLD<1.91E-01	277.60
PA-233	LLD<6.77E-02	LLD<6.77E-02	311.98
PA-234M	LLD<7.19E+00	LLD<7.19E+00	1001.03
PB-210	LLD<6.73E-01	LLD<6.73E-01	465.03
PB-212	LLD<6.43E-02	LLD<6.43E-02	239.00
PB-214	LLD<8.93E-02	LLD<8.93E-02	351.92
PO-210	LLD<3.22E+03	LLD<3.22E+03	804.00
PO-214	LLD<3.96E+02	LLD<3.96E+02	799.70
PO-216	LLD<2.20E+03	LLD<2.20E+03	804.90
PU-239	LLD<3.58E+02	LLD<3.58E+02	129.30
PU-241	LLD<1.08E+04	LLD<1.08E+04	148.57
RA-224	LLD<6.40E-01	LLD<6.40E-01	240.99
RA-226	LLD<5.92E-01	LLD<5.92E-01	186.10
RB-88	LLD<5.17E-02	LLD<5.17E-02	1836.00
RB-89	LLD<2.38E-01	LLD<2.38E-01	1031.88
RN-220	LLD<2.40E+01	LLD<2.40E+01	549.73
RU-103	LLD<3.38E-02	LLD<3.38E-02	497.08
RURH106	LLD<7.21E-01	LLD<7.21E-01	621.80
SB-124	LLD<3.95E-02	LLD<3.95E-02	602.72
SB-125	LLD<3.30E-01	LLD<3.30E-01	176.33
SC-46	LLD<5.53E-02	LLD<5.53E-02	1120.45
SE-75	LLD<4.24E-02	LLD<4.24E-02	264.66
SN-113	LLD<3.93E-02	LLD<3.93E-02	391.67
SR-85	LLD<4.62E-02	LLD<4.62E-02	513.99
SR-91	LLD<6.80E-02	LLD<6.80E-02	555.60
SR-92	LLD<7.67E-02	LLD<7.67E-02	1383.94
TA-182	LLD<1.73E-01	LLD<1.73E-01	1121.30
TC-99M	LLD<2.34E-02	LLD<2.34E-02	140.51
TE-123M	LLD<2.78E-02	LLD<2.78E-02	159.00
TE-125M	LLD<8.47E+00	LLD<8.47E+00	109.27
TE-132	LLD<2.73E-02	LLD<2.73E-02	228.16
TH-228	LLD<2.86E+00	LLD<2.86E+00	84.37
TL-208	LLD<4.56E-02	LLD<4.56E-02	583.14
U-235	LLD<3.83E-02	LLD<3.83E-02	185.71
U-237	LLD<1.12E-01	LLD<1.12E-01	208.00
W-187	LLD<1.20E-01	LLD<1.20E-01	685.74
XE-131M	LLD<1.20E+00	LLD<1.20E+00	163.98
XE-133	LLD<9.50E-02	LLD<9.50E-02	81.00
XE-133M	LLD<2.43E-01	LLD<2.43E-01	233.21
XE-135	LLD<3.00E-02	LLD<3.00E-02	249.79
XE-138	LLD<1.88E-01	LLD<1.88E-01	258.41
Y-88	LLD<4.90E-03	LLD<4.90E-03	1836.06
Y-91	LLD<1.44E+01	LLD<1.44E+01	1204.90
Y-91M	LLD<5.14E-02	LLD<5.14E-02	555.60
ZN-65	LLD<1.39E-01	LLD<1.39E-01	1115.55
ZR-95	LLD<6.84E-02	LLD<6.84E-02	756.73
ZR-97	LLD<3.83E-02	LLD<3.83E-02	743.33

TOTAL 0.00E-01 +-0.00E-01 0.00E-01 +-0.00E-01

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
2922.97	1461.02	158.	17.3	2.07E+01

*
*
* G A M M A S P E C T R U M A N A L Y S I S *
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD 08-OCT-90 14:07:38

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 41
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3123
ANALYZED BY: EMB

SAMPLE DESCRIPTION: F977
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 13-FEB-90 AT 16:10:38

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3004. SECONDS
DEAD TIME: 0.13 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-OCT-89
EFFICIENCY CALIBRATION PERFORMED 31-JUL-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	64.00	32.59	1.26	1434.	808.	14.3	CE-144
2	1166.46	583.27	1.11	155.	76.	54.7	EU-154,
2B		583.13			94.	24.1	TL-208
3	1218.63	609.34	1.55	121.	169.	24.8	BI-214,
3B		609.19			122.	21.0	RU-103
4	1323.24	661.62	1.59	120.	4146.	3.1	CS-137
4B		661.41			81.	28.8	
5	1821.96	910.91	0.85	76.	78.	42.1	
5B		910.98			84.	23.3	
6	2921.03	1460.61	1.93	23.	680.	7.9	K-40
6B		1460.58			611.	5.5	
7	3526.45	1763.61	3.13	10.	49.	36.7	BI-214
7B		1764.79			47.	25.0	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0013
 BACKGROUND DESCRIPTION: BKG
 BACKGROUND COLLECT STARTED ON 15-JAN-90 AT 11:00:00
 BACKGROUND LIVE TIME: 7000. SECONDS

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:07:38

SAMPLE: F977

DATA COLLECTED ON 13-FEB-90 AT 16:10:38

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<2.36E+00		LLD<2.36E+00		911.07	
AG-108M	LLD<4.92E-01		LLD<4.92E-01		433.94	
AG-110M	LLD<2.75E+00		LLD<2.75E+00		657.76	
AM-241	LLD<7.99E-01		LLD<7.99E-01		59.54	
AM-243	LLD<4.80E-01		LLD<4.80E-01		74.67	
AR-41	LLD<6.89E-01		LLD<6.89E-01		1293.64	
AU-198	LLD<4.70E-01		LLD<4.70E-01		411.80	
BA-133	LLD<6.42E-01		LLD<6.42E-01		356.02	
BA-139	LLD<1.71E+00		LLD<1.71E+00		165.85	
BA-140	LLD<1.84E+00		LLD<1.84E+00		537.27	
BA-141	LLD<1.69E+00		LLD<1.69E+00		190.23	
BE-7	LLD<4.74E+00		LLD<4.74E+00		477.59	
BI-207	LLD<4.25E-01		LLD<4.25E-01		569.70	
BI-212	LLD<6.93E+00		LLD<6.93E+00		727.27	
BI-214	LLD<1.24E+00		LLD<1.24E+00		609.32	
CD-109	LLD<8.03E+00		LLD<8.03E+00		88.03	
CE-139	LLD<3.87E-01		LLD<3.87E-01		165.85	
CE-141	LLD<6.18E-01		LLD<6.18E-01		145.44	
CEPR144	LLD<5.58E+00		LLD<5.58E+00		133.51	
CO-56	LLD<4.46E-01		LLD<4.46E-01		846.76	
CO-57	LLD<3.42E-01		LLD<3.42E-01		122.06	
CO-58	LLD<4.42E-01		LLD<4.42E-01		810.75	
CO-60	LLD<5.39E-01		LLD<5.39E-01		1332.50	
CR-51	LLD<3.61E+00		LLD<3.61E+00		320.09	
CS-134	LLD<5.25E-01		LLD<5.25E-01		795.84	
CS-136	LLD<4.33E-01		LLD<4.33E-01		818.51	
CS-137	5.48E+01 +-1.95E+00		5.48E+01 +-1.95E+00		661.65 -0.03	
CS-138	LLD<1.10E+00		LLD<1.10E+00		1435.86	
EU-152	LLD<2.46E+00		LLD<2.46E+00		1408.01	
EU-154	LLD<1.61E+00		LLD<1.61E+00		1274.45	
EU-155	LLD<1.31E+00		LLD<1.31E+00		105.31	
FE-59	LLD<1.03E+00		LLD<1.03E+00		1099.25	
HF-181	LLD<5.89E-01		LLD<5.89E-01		482.20	
HG-203	LLD<4.35E-01		LLD<4.35E-01		279.20	
I-131	LLD<4.76E-01		LLD<4.76E-01		364.48	
I-132	LLD<6.93E-01		LLD<6.93E-01		667.69	
I-133	LLD<5.04E-01		LLD<5.04E-01		529.69	
I-134	LLD<6.97E-01		LLD<6.97E-01		847.03	
I-135	LLD<1.90E+00		LLD<1.90E+00		1260.41	
K-40	1.46E+01 +-1.34E+01		1.46E+01 +-1.34E+01		1460.75 -0.14	
KR-85	LLD<1.24E+02		LLD<1.24E+02		513.99	
KR-85M	LLD<4.82E-01		LLD<4.82E-01		151.17	
KR-87	LLD<1.05E+00		LLD<1.05E+00		402.58	
KR-89	LLD<1.76E+01		LLD<1.76E+01		220.90	
LA-140	LLD<4.30E-01		LLD<4.30E-01		1596.20	
LA-142	LLD<1.03E+00		LLD<1.03E+00		641.83	
MN-54	LLD<4.90E-01		LLD<4.90E-01		834.83	

MN-56	LLD<5.03E-01	LLD<5.03E-01	846.76
NA-22	LLD<5.90E-01	LLD<5.90E-01	1274.55
NA-24	LLD<4.73E-01	LLD<4.73E-01	1368.60
NB-94	LLD<4.77E-01	LLD<4.77E-01	702.63
NB-95	LLD<4.26E-01	LLD<4.26E-01	765.78
NB-97	LLD<3.33E+00	LLD<3.33E+00	657.92
NP-237	LLD<2.19E+00	LLD<2.19E+00	86.50
NP-238	LLD<1.62E+00	LLD<1.62E+00	984.45
NP-239	LLD<2.55E+00	LLD<2.55E+00	277.60
PA-233	LLD<9.68E-01	LLD<9.68E-01	311.98
PA-234M	LLD<8.92E+01	LLD<8.92E+01	1001.03
PB-210	LLD<1.31E+01	LLD<1.31E+01	465.03
PB-212	LLD<8.56E-01	LLD<8.56E-01	239.00
PB-214	LLD<1.30E+00	LLD<1.30E+00	351.92
PO-210	LLD<3.32E+04	LLD<3.32E+04	804.00
PO-214	LLD<4.87E+03	LLD<4.87E+03	799.70
PO-216	LLD<2.38E+04	LLD<2.38E+04	804.90
PU-239	LLD<4.63E+03	LLD<4.63E+03	129.30
PU-241	LLD<1.67E+05	LLD<1.67E+05	148.57
RA-224	LLD<9.47E+00	LLD<9.47E+00	240.99
RA-226	LLD<1.01E+01	LLD<1.01E+01	186.10
RB-88	LLD<2.92E+00	LLD<2.92E+00	1836.00
RB-89	LLD<2.43E+00	LLD<2.43E+00	1031.88
RN-220	LLD<4.03E+02	LLD<4.03E+02	549.73
RU-103	LLD<4.84E-01	LLD<4.84E-01	497.08
RURH106	LLD<8.52E+00	LLD<8.52E+00	621.80
SB-124	LLD<4.28E-01	LLD<4.28E-01	602.72
SB-125	LLD<4.81E+00	LLD<4.81E+00	176.33
SC-46	LLD<8.03E-01	LLD<8.03E-01	1120.45
SE-75	LLD<5.96E-01	LLD<5.96E-01	264.66
SN-113	LLD<6.26E-01	LLD<6.26E-01	391.67
SR-85	LLD<5.45E-01	LLD<5.45E-01	513.99
SR-91	LLD<6.91E-01	LLD<6.91E-01	555.60
SR-92	LLD<7.47E-01	LLD<7.47E-01	1383.94
TA-182	LLD<1.81E+00	LLD<1.81E+00	1121.30
TC-99M	LLD<3.42E-01	LLD<3.42E-01	140.51
TE-123M	LLD<3.62E-01	LLD<3.62E-01	159.00
TE-125M	LLD<1.05E+02	LLD<1.05E+02	109.27
TE-132	LLD<4.13E-01	LLD<4.13E-01	228.16
TH-228	LLD<2.21E+01	LLD<2.21E+01	84.37
TL-208	LLD<6.17E-01	LLD<6.17E-01	583.14
U-235	LLD<6.17E-01	LLD<6.17E-01	185.71
U-237	LLD<1.76E+00	LLD<1.76E+00	208.00
W-187	LLD<1.56E+00	LLD<1.56E+00	685.74
XE-131M	LLD<1.59E+01	LLD<1.59E+01	163.98
XE-133	LLD<7.08E-01	LLD<7.08E-01	81.00
XE-133M	LLD<3.61E+00	LLD<3.61E+00	233.21
XE-135	LLD<3.80E-01	LLD<3.80E-01	249.79
XE-138	LLD<2.94E+00	LLD<2.94E+00	258.41
Y-88	LLD<2.77E-01	LLD<2.77E-01	1836.06
Y-91	LLD<2.04E+02	LLD<2.04E+02	1204.90
Y-91M	LLD<5.23E-01	LLD<5.23E-01	555.60
ZN-65	LLD<1.44E+00	LLD<1.44E+00	1115.55
ZR-95	LLD<7.84E-01	LLD<7.84E-01	756.73
ZR-97	LLD<3.94E-01	LLD<3.94E-01	743.33

TOTAL 6.94E+01 +-1.35E+01 6.94E+01 +-1.35E+01

STANDARD DEVIATION = 0.07

E BAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.46E-08 UC/LI
TOTAL MEASURED ACTIVITY = 6.94E+01 (+-1.35E+01) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
64.00	32.59	808.	14.3	1.26E+01

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1166.46	583.27	76.	54.7	2.86E+00
1218.63	609.34	169.	24.8	6.65E+00
1821.96	910.91	78.	42.1	4.39E+00
3526.45	1763.61	49.	36.7	4.67E+00

*
*
* G A M M A S P E C T R U M A N A L Y S I S *
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:12:31

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 41
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3124
ANALYZED BY: EMB

SAMPLE DESCRIPTION: F978
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 13-FEB-90 AT 18:52:33

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3003. SECONDS
DEAD TIME: 0.10 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-OCT-89
EFFICIENCY CALIBRATION PERFORMED 31-JUL-89

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:12:31

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	63.87	32.52	1.08	1628.	1024.	12.2	CE-144
2	1020.52	510.34	1.65	248.	118.	43.3	RN-222, I-133,
2B		510.92			134.	19.6	TL-208, NA-22, ZN-65
3	1166.31	583.19	1.49	150.	122.	35.1	EU-154,
3B		583.13			94.	24.1	TL-208
4	1218.61	609.33	1.37	143.	134.	31.8	BI-214,
4B		609.19			122.	21.0	RU-103
5	1323.25	661.63	1.60	140.	4683.	3.0	CS-137
5B		661.41			81.	28.8	
6	1822.14	911.00	1.59	75.	101.	33.4	
6B		910.98			84.	23.3	
7	2921.09	1460.64	2.22	27.	687.	7.9	K-40
7B		1460.58			611.	5.5	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0013
 BACKGROUND DESCRIPTION: BKG
 BACKGROUND COLLECT STARTED ON 15-JAN-90 AT 11:00:00
 BACKGROUND LIVE TIME: 7000. SECONDS

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:12:31

SAMPLE: F978

DATA COLLECTED ON 13-FEB-90 AT 18:52:33

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN			ENERGY COMPARISON	
	MEASURED	ERROR	DECAY CORRECTED	uCi/LI	(KEV)
				EXPECT	DIFF
AC-228	LLD<2.35E+00		LLD<2.35E+00		911.07
AG-108M	LLD<5.08E-01		LLD<5.08E-01		433.94
AG-110M	LLD<2.92E+00		LLD<2.92E+00		657.76
AM-241	LLD<8.40E-01		LLD<8.40E-01		59.54
AM-243	LLD<5.04E-01		LLD<5.04E-01		74.67
AR-41	LLD<7.27E-01		LLD<7.27E-01		1293.64
AU-198	LLD<4.49E-01		LLD<4.49E-01		411.80
BA-133	LLD<6.58E-01		LLD<6.58E-01		356.02
BA-139	LLD<1.78E+00		LLD<1.78E+00		165.85
BA-140	LLD<1.82E+00		LLD<1.82E+00		537.27
BA-141	LLD<1.76E+00		LLD<1.76E+00		190.23
BE-7	LLD<5.06E+00		LLD<5.06E+00		477.59
BI-207	LLD<4.22E-01		LLD<4.22E-01		569.70
BI-212	LLD<6.88E+00		LLD<6.88E+00		727.27
BI-214	LLD<1.29E+00		LLD<1.29E+00		609.32
CD-109	LLD<8.20E+00		LLD<8.20E+00		88.03
CE-139	LLD<4.03E-01		LLD<4.03E-01		165.85
CE-141	LLD<6.56E-01		LLD<6.56E-01		145.44
CEPR144	LLD<5.64E+00		LLD<5.64E+00		133.51
CO-56	LLD<4.65E-01		LLD<4.65E-01		846.76
CO-57	LLD<3.50E-01		LLD<3.50E-01		122.06
CO-58	LLD<4.39E-01		LLD<4.39E-01		810.75
CO-60	LLD<5.39E-01		LLD<5.39E-01		1332.50
CR-51	LLD<3.64E+00		LLD<3.64E+00		320.09
CS-134	LLD<5.34E-01		LLD<5.34E-01		795.84
CS-136	LLD<4.21E-01		LLD<4.21E-01		818.51
CS-137	6.21E+01	+-2.09E+00	6.21E+01	+-2.09E+00	661.65 -0.02
CS-138	LLD<8.37E-01		LLD<8.37E-01		1435.86
EU-152	LLD<2.75E+00		LLD<2.75E+00		1408.01
EU-154	LLD<1.83E+00		LLD<1.83E+00		1274.45
EU-155	LLD<1.34E+00		LLD<1.34E+00		105.31
FE-59	LLD<1.02E+00		LLD<1.02E+00		1099.25
HF-181	LLD<6.27E-01		LLD<6.27E-01		482.20
HG-203	LLD<4.25E-01		LLD<4.25E-01		279.20
I-131	LLD<4.94E-01		LLD<4.94E-01		364.48
I-132	LLD<7.86E-01		LLD<7.86E-01		667.69
I-133	LLD<5.03E-01		LLD<5.03E-01		529.69
I-134	LLD<7.21E-01		LLD<7.21E-01		847.03
I-135	LLD<2.26E+00		LLD<2.26E+00		1260.41
K-40	1.61E+01	+-1.35E+01	1.61E+01	+-1.35E+01	1460.75 -0.11
KR-85	LLD<1.30E+02		LLD<1.30E+02		513.99
KR-85M	LLD<4.95E-01		LLD<4.95E-01		151.17
KR-87	LLD<1.06E+00		LLD<1.06E+00		402.58
KR-89	LLD<1.83E+01		LLD<1.83E+01		220.90
LA-140	LLD<5.96E-01		LLD<5.96E-01		1596.20
LA-142	LLD<1.09E+00		LLD<1.09E+00		641.83
MN-54	LLD<4.52E-01		LLD<4.52E-01		834.83

MN-56	LLD<5.25E-01	LLD<5.25E-01	846.76
NA-22	LLD<6.90E-01	LLD<6.90E-01	1274.55
NA-24	LLD<5.04E-01	LLD<5.04E-01	1368.60
NB-94	LLD<4.21E-01	LLD<4.21E-01	702.63
NB-95	LLD<4.29E-01	LLD<4.29E-01	765.78
NB-97	LLD<3.53E+00	LLD<3.53E+00	657.92
NP-237	LLD<2.27E+00	LLD<2.27E+00	86.50
NP-238	LLD<2.01E+00	LLD<2.01E+00	984.45
NP-239	LLD<2.51E+00	LLD<2.51E+00	277.60
PA-233	LLD<9.82E-01	LLD<9.82E-01	311.98
PA-234M	LLD<9.12E+01	LLD<9.12E+01	1001.03
PB-210	LLD<1.34E+01	LLD<1.34E+01	465.03
PB-212	LLD<8.98E-01	LLD<8.98E-01	239.00
PB-214	LLD<1.31E+00	LLD<1.31E+00	351.92
PO-210	LLD<3.61E+04	LLD<3.61E+04	804.00
PO-214	LLD<3.92E+03	LLD<3.92E+03	799.70
PO-216	LLD<2.38E+04	LLD<2.38E+04	804.90
PU-239	LLD<4.81E+03	LLD<4.81E+03	129.30
PU-241	LLD<1.70E+05	LLD<1.70E+05	148.57
RA-224	LLD<9.71E+00	LLD<9.71E+00	240.99
RA-226	LLD<1.04E+01	LLD<1.04E+01	186.10
RB-88	LLD<5.84E+00	LLD<5.84E+00	1836.00
RB-89	LLD<2.18E+00	LLD<2.18E+00	1031.88
RN-220	LLD<3.83E+02	LLD<3.83E+02	549.73
RU-103	LLD<4.96E-01	LLD<4.96E-01	497.08
RURH106	LLD<9.43E+00	LLD<9.43E+00	621.80
SB-124	LLD<4.74E-01	LLD<4.74E-01	602.72
SB-125	LLD<4.88E+00	LLD<4.88E+00	176.33
SC-46	LLD<7.71E-01	LLD<7.71E-01	1120.45
SE-75	LLD<6.10E-01	LLD<6.10E-01	264.66
SN-113	LLD<6.97E-01	LLD<6.97E-01	391.67
SR-85	LLD<5.72E-01	LLD<5.72E-01	513.99
SR-91	LLD<7.07E-01	LLD<7.07E-01	555.60
SR-92	LLD<7.16E-01	LLD<7.16E-01	1383.94
TA-182	LLD<1.73E+00	LLD<1.73E+00	1121.30
TC-99M	LLD<3.62E-01	LLD<3.62E-01	140.51
TE-123M	LLD<3.84E-01	LLD<3.84E-01	159.00
TE-125M	LLD<1.06E+02	LLD<1.06E+02	109.27
TE-132	LLD<4.19E-01	LLD<4.19E-01	228.16
TH-228	LLD<2.32E+01	LLD<2.32E+01	84.37
TL-208	LLD<6.12E-01	LLD<6.12E-01	583.14
U-235	LLD<6.28E-01	LLD<6.28E-01	185.71
U-237	LLD<1.70E+00	LLD<1.70E+00	208.00
W-187	LLD<1.57E+00	LLD<1.57E+00	685.74
XE-131M	LLD<1.65E+01	LLD<1.65E+01	163.98
XE-133	LLD<7.60E-01	LLD<7.60E-01	81.00
XE-133M	LLD<3.76E+00	LLD<3.76E+00	233.21
XE-135	LLD<4.27E-01	LLD<4.27E-01	249.79
XE-138	LLD<3.10E+00	LLD<3.10E+00	258.41
Y-88	LLD<5.54E-01	LLD<5.54E-01	1836.06
Y-91	LLD<2.14E+02	LLD<2.14E+02	1204.90
Y-91M	LLD<5.34E-01	LLD<5.34E-01	555.60
ZN-65	LLD<1.39E+00	LLD<1.39E+00	1115.55
ZR-95	LLD<7.32E-01	LLD<7.32E-01	756.73
ZR-97	LLD<4.39E-01	LLD<4.39E-01	743.33

TOTAL 7.82E+01 +-1.37E+01 7.82E+01 +-1.37E+01

STANDARD DEVIATION = 0.06

E BAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.46E-08 UC/LI
TOTAL MEASURED ACTIVITY = 7.82E+01 (+-1.37E+01) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
63.87	32.52	1024.	12.2	1.59E+01

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1020.52	510.34	118.	43.3	3.94E+00
1166.31	583.19	122.	35.1	4.62E+00
1218.61	609.33	134.	31.8	5.27E+00
1822.14	911.00	101.	33.4	5.73E+00

GAMMA SPECTRUM ANALYSIS

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD 08-OCT-90 14:17:32

ANALYSIS PARAMETERS

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 41
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

ENVIRONMENTAL BACKGROUND : LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLICITY ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3125

ANALYZED BY: EMB

SAMPLE DESCRIPTION: F979

GEOMETRY DESCRIPTION

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E-01

STANDARD SIZE: 1.0000E+00 EA

ANALYSTS LIBRARY FILE: ANI000

COLLECT STARTED ON 13-FEB-90 AT 19:59:18

COLLECT LIVE TIME: 3000 SECONDS

LIVE TIME: 3000. SECONDS
REAL TIME: 3013 SECONDS

REAL TIME: 3012.3
DEAD TIME: 0.40 %

DECAYED TO 0 DAYS 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION REPERFORMED 17 OCT 89

ENERGY CALIBRATION PERFORMED 17-OCT-89
EFFICIENCY CALIBRATION REPERFORMED 31 JUL 89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1?	59.37	30.27	1.37	3075.	607.	34.1	
2?	63.92	32.54	1.37	2994.	4449.	8.5	CE-144
3?	72.72	36.94	1.37	2837.	968.	22.2	TE-125M
4C	1126.37	563.24	1.52	929.	800.	11.5	CS-134, EU-152
5C	1138.57	569.34	1.52	909.	1445.	9.7	CS-134, BI-207
6C	1209.36	604.71	1.51	887.	8875.	2.7	CS-134
7C	1219.28	609.66	1.51	748.	149.	33.2	BI-214, RU-103
8	1323.26	661.63	1.59	656.	17613.	1.5	CS-137
8B		661.41			81.	28.8	
9C	1591.51	795.70	1.64	545.	6273.	3.2	CS-134
10C	1603.65	801.77	1.64	477.	596.	10.1	CS-134
11C	2335.16	1167.53	1.83	330.	111.	33.8	CS-134
12C	2345.98	1172.94	1.83	298.	5775.	3.1	CO-60
13	2664.44	1332.24	2.02	115.	5393.	2.8	CO-60
14	2729.78	1364.93	1.70	55.	141.	24.7	CS-134
15	2920.93	1460.57	1.97	54.	625.	8.9	K-40
15B		1460.58			611.	5.5	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY
 ? - MULTIPLET ANALYSIS CONVERGED BUT GFIT > 4
 B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0013
 BACKGROUND DESCRIPTION: BKG
 BACKGROUND COLLECT STARTED ON 15-JAN-90 AT 11:00:00
 BACKGROUND LIVE TIME: 7000. SECONDS

222-S COUNTING ROOM WESTINGHOUSE HANFORD

08-OCT-90 14:17:32

SAMPLE: F979

DATA COLLECTED ON 13-FEB-90 AT 19:59:18

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<4.89E+00		LLD<4.89E+00		911.07	
AG-108M	LLD<1.05E+00		LLD<1.05E+00		433.94	
AG-110M	LLD<5.66E+00		LLD<5.66E+00		657.76	
AM-241	LLD<1.17E+00		LLD<1.17E+00		59.54	
AM-243	LLD<6.55E-01		LLD<6.55E-01		74.67	
AR-41	LLD<8.85E-01		LLD<8.85E-01		1293.64	
AU-198	LLD<9.87E-01		LLD<9.87E-01		411.80	
BA-133	LLD<1.26E+00		LLD<1.26E+00		356.02	
BA-139	LLD<2.73E+00		LLD<2.73E+00		165.85	
BA-140	LLD<4.11E+00		LLD<4.11E+00		537.27	
BA-141	LLD<2.93E+00		LLD<2.93E+00		190.23	
BE-7	LLD<1.02E+01		LLD<1.02E+01		477.59	
BI-207	LLD<1.07E+00		LLD<1.07E+00		569.70	
BI-212	LLD<1.50E+01		LLD<1.50E+01		727.27	
BI-214	LLD<7.84E+00		LLD<7.84E+00		609.32	
CD-109	LLD<1.13E+01		LLD<1.13E+01		88.03	
CE-139	LLD<6.19E-01		LLD<6.19E-01		165.85	
CE-141	LLD<9.65E-01		LLD<9.65E-01		145.44	
CEPR144	LLD<8.21E+00		LLD<8.21E+00		133.51	
CO-56	LLD<1.05E+00		LLD<1.05E+00		846.76	
CO-57	LLD<5.08E-01		LLD<5.08E-01		122.06	
CO-58	LLD<1.01E+00		LLD<1.01E+00		810.75	
CO-60	1.13E+02 +-3.45E+00		1.13E+02 +-3.45E+00		1332.50 -0.26	
					1173.24 -0.29	
CR-51	LLD<7.12E+00		LLD<7.12E+00		320.09	
CS-134	9.95E+01 +-3.41E+00		9.95E+01 +-3.41E+00		795.84 -0.14	
					604.70 0.01	
CS-136	LLD<1.02E+00		LLD<1.02E+00		818.51	
CS-137	2.37E+02 +-4.96E+00		2.37E+02 +-4.96E+00		661.65 -0.02	
CS-138	LLD<9.21E-01		LLD<9.21E-01		1435.86	
EU-152	LLD<4.64E+00		LLD<4.64E+00		1408.01	
EU-154	LLD<2.04E+00		LLD<2.04E+00		1274.45	
EU-155	LLD<1.91E+00		LLD<1.91E+00		105.31	
FE-59	LLD<2.77E+00		LLD<2.77E+00		1099.25	
HF-181	LLD<1.28E+00		LLD<1.28E+00		482.20	
HG-203	LLD<8.34E-01		LLD<8.34E-01		279.20	
I-131	LLD<1.03E+00		LLD<1.03E+00		364.48	
I-132	LLD<1.62E+00		LLD<1.62E+00		667.69	
I-133	LLD<1.07E+00		LLD<1.07E+00		529.69	
I-134	LLD<1.60E+00		LLD<1.60E+00		847.03	
I-135	LLD<2.71E+00		LLD<2.71E+00		1260.41	
K-40	LLD<1.50E+01		LLD<1.50E+01		1460.75	
KR-85	LLD<2.33E+02		LLD<2.33E+02		513.99	
KR-85M	LLD<7.34E-01		LLD<7.34E-01		151.17	
KR-87	LLD<2.31E+00		LLD<2.31E+00		402.58	
KR-89	LLD<3.16E+01		LLD<3.16E+01		220.90	
LA-140	LLD<5.32E-01		LLD<5.32E-01		1596.20	

LA-142	LLD<2.39E+00	LLD<2.39E+00	641.83
MN-54	LLD<1.10E+00	LLD<1.10E+00	834.83
MN-56	LLD<1.19E+00	LLD<1.19E+00	846.76
NA-22	LLD<7.69E-01	LLD<7.69E-01	1274.55
NA-24	LLD<6.70E-01	LLD<6.70E-01	1368.60
NB-94	LLD<9.44E-01	LLD<9.44E-01	702.63
NB-95	LLD<9.36E-01	LLD<9.36E-01	765.78
NB-97	LLD<6.87E+00	LLD<6.87E+00	657.92
NP-237	LLD<3.20E+00	LLD<3.20E+00	86.50
NP-238	LLD<4.99E+00	LLD<4.99E+00	984.45
NP-239	LLD<4.65E+00	LLD<4.65E+00	277.60
PA-233	LLD<1.92E+00	LLD<1.92E+00	311.98
PA-234M	LLD<2.25E+02	LLD<2.25E+02	1001.03
PB-210	LLD<2.63E+01	LLD<2.63E+01	465.03
PB-212	LLD<1.56E+00	LLD<1.56E+00	239.00
PB-214	LLD<2.38E+00	LLD<2.38E+00	351.92
PO-210	LLD<8.70E+04	LLD<8.70E+04	804.00
PO-214	LLD<3.87E+04	LLD<3.87E+04	799.70
PO-216	LLD<6.50E+04	LLD<6.50E+04	804.90
PU-239	LLD<7.05E+03	LLD<7.05E+03	129.30
PU-241	LLD<2.49E+05	LLD<2.49E+05	148.57
RA-224	LLD<1.61E+01	LLD<1.61E+01	240.99
RA-226	LLD<1.70E+01	LLD<1.70E+01	186.10
RB-88	LLD<6.44E+00	LLD<6.44E+00	1836.00
RB-89	LLD<5.94E+00	LLD<5.94E+00	1031.88
RN-220	LLD<9.54E+02	LLD<9.54E+02	549.73
RU-103	LLD<1.08E+00	LLD<1.08E+00	497.08
RURH106	LLD<1.93E+01	LLD<1.93E+01	621.80
SB-124	LLD<1.98E+00	LLD<1.98E+00	602.72
SB-125	LLD<7.68E+00	LLD<7.68E+00	176.33
SC-46	LLD<1.46E+00	LLD<1.46E+00	1120.45
SE-75	LLD<1.11E+00	LLD<1.11E+00	264.66
SN-113	LLD<1.43E+00	LLD<1.43E+00	391.67
SR-85	LLD<1.02E+00	LLD<1.02E+00	513.99
SR-91	LLD<1.76E+00	LLD<1.76E+00	555.60
SR-92	LLD<7.62E-01	LLD<7.62E-01	1383.94
TA-182	LLD<3.66E+00	LLD<3.66E+00	1121.30
TC-99M	LLD<5.48E-01	LLD<5.48E-01	140.51
TE-123M	LLD<5.71E-01	LLD<5.71E-01	159.00
TE-125M	LLD<1.50E+02	LLD<1.50E+02	109.27
TE-132	LLD<7.26E-01	LLD<7.26E-01	228.16
TH-228	LLD<3.16E+01	LLD<3.16E+01	84.37
TL-208	LLD<1.23E+00	LLD<1.23E+00	583.14
U-235	LLD<1.03E+00	LLD<1.03E+00	185.71
U-237	LLD<3.01E+00	LLD<3.01E+00	208.00
W-187	LLD<3.23E+00	LLD<3.23E+00	685.74
XE-131M	LLD<2.56E+01	LLD<2.56E+01	163.98
XE-133	LLD<1.06E+00	LLD<1.06E+00	81.00
XE-133M	LLD<6.46E+00	LLD<6.46E+00	233.21
XE-135	LLD<7.23E-01	LLD<7.23E-01	249.79
XE-138	LLD<5.54E+00	LLD<5.54E+00	258.41
Y-88	LLD<6.10E-01	LLD<6.10E-01	1836.06
Y-91	LLD<3.13E+02	LLD<3.13E+02	1204.90
Y-91M	LLD<1.33E+00	LLD<1.33E+00	555.60
ZN-65	LLD<2.56E+00	LLD<2.56E+00	1115.55
ZR-95	LLD<1.67E+00	LLD<1.67E+00	756.73
ZR-97	LLD<9.65E-01	LLD<9.65E-01	743.33
TOTAL	4.50E+02 +-6.94E+00	4.50E+02 +-6.94E+00	

STANDARD DEVIATION = 0.14

E_{BAR} = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.62E-09 UC/LI
TOTAL MEASURED ACTIVITY = 4.50E+02 (+-6.94E+00) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
59.37	30.27	607.	34.1	9.98E+00
63.92	32.54	4449.	8.5	6.93E+01
72.72	36.94	968.	22.2	1.39E+01
1126.37	563.24	800.	11.5	2.93E+01
1138.57	569.34	1445.	9.7	5.35E+01
1603.65	801.77	596.	10.1	3.01E+01
2335.16	1167.53	111.	33.8	7.76E+00
2729.78	1364.93	141.	24.7	1.12E+01

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1219.28	609.66	149.	33.2	5.86E+00
2920.93	1460.57	625.	8.9	5.22E+01

*
*
*
*
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

08-OCT-90 14:00:36

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 2.0
DETECTOR NUMBER: 2 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD2013

ANALYZED BY: EMB

SAMPLE DESCRIPTION: F980

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 13-FEB-90 AT 19:58:25

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3007. SECONDS

DEAD TIME: 0.23 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-MAR-89

EFFICIENCY CALIBRATION PERFORMED 21-OCT-88

222-S COUNTING ROOM

08-OCT-90 14:00:36

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1127.33	563.30	1.55	594.	452.	14.8	CS-134, EU-152
2C	1139.73	569.49	1.55	563.	974.	12.1	CS-134, BI-207
3	1210.41	604.83	1.62	545.	6028.	2.8	CS-134
4	1324.26	661.74	1.59	342.	9096.	2.1	CS-137
4B		661.85			36.	13.9	
5C	1592.45	795.82	1.68	348.	4223.	3.9	CS-134
6C	1604.49	801.84	1.68	351.	379.	14.7	CS-134
7	2347.02	1173.07	1.93	257.	3733.	3.5	CO-60
8	2665.51	1332.30	2.20	46.	3426.	3.4	CO-60
8B		1332.24			9.	37.4	
9	2729.91	1364.50	1.59	16.	109.	22.5	CS-134
10	2921.97	1460.53	2.63	14.	170.	16.8	K-40
10B		1460.85			156.	3.8	

ERROR QUOTATION AT 1.96 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY
 B - ENVIRONMENTAL BACKGROUND PEAK

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0012
 BACKGROUND DESCRIPTION: BKG
 BACKGROUND COLLECT STARTED ON 30-AUG-88 AT 16:46:00
 BACKGROUND LIVE TIME: 60000. SECONDS

222-S COUNTING ROOM

08-OCT-90 14:00:36

SAMPLE: F980

DATA COLLECTED ON 13-FEB-90 AT 19:58:25

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/LI			ENERGY COMPARISON (KEV)		
	MEASURED	ERROR	DECAY CORRECTED	ERROR	EXPECT	DIFF
AC-228	LLD<1.11E+00		LLD<1.11E+00		911.07	
AG-108M	LLD<2.99E-01		LLD<2.99E-01		433.94	
AG-110M	LLD<1.39E+00		LLD<1.39E+00		657.76	
AM-241	LLD<1.37E+00		LLD<1.37E+00		59.54	
AM-243	LLD<3.45E-01		LLD<3.45E-01		74.67	
AR-41	LLD<1.98E-01		LLD<1.98E-01		1293.64	
AU-198	LLD<2.62E-01		LLD<2.62E-01		411.80	
BA-133	LLD<3.51E-01		LLD<3.51E-01		356.02	
BA-139	LLD<7.16E-01		LLD<7.16E-01		165.85	
BA-140	LLD<1.02E+00		LLD<1.02E+00		537.27	
BA-141	LLD<7.20E-01		LLD<7.20E-01		190.23	
BE-7	LLD<2.41E+00		LLD<2.41E+00		477.59	
BI-207	LLD<2.66E-01		LLD<2.66E-01		569.70	
BI-212	LLD<3.72E+00		LLD<3.72E+00		727.27	
BI-214	LLD<2.04E+00		LLD<2.04E+00		609.32	
CD-109	LLD<4.25E+00		LLD<4.25E+00		88.03	
CE-139	LLD<1.62E-01		LLD<1.62E-01		165.85	
CE-141	LLD<2.64E-01		LLD<2.64E-01		145.44	
CEPR144	LLD<2.03E+00		LLD<2.03E+00		133.51	
CO-56	LLD<2.57E-01		LLD<2.57E-01		846.76	
CO-57	LLD<1.34E-01		LLD<1.34E-01		122.06	
CO-58	LLD<2.62E-01		LLD<2.62E-01		810.75	
CO-60	2.24E+01	+ -8.16E-01	2.24E+01	+ -8.16E-01	1332.50	-0.20
					1173.24	-0.17
CR-51	LLD<1.94E+00		LLD<1.94E+00		320.09	
CS-134	2.13E+01	+ -8.70E-01	2.13E+01	+ -8.70E-01	795.84	-0.03
					604.70	0.13
CS-136	LLD<2.68E-01		LLD<2.68E-01		818.51	
CS-137	3.91E+01	+ -9.73E-01	3.91E+01	+ -9.73E-01	661.65	0.09
CS-138	LLD<1.27E-01		LLD<1.27E-01		1435.86	
EU-152	LLD<7.43E-01		LLD<7.43E-01		1408.01	
EU-154	LLD<5.40E-01		LLD<5.40E-01		1274.45	
EU-155	LLD<6.15E-01		LLD<6.15E-01		105.31	
FE-59	LLD<5.89E-01		LLD<5.89E-01		1099.25	
HF-181	LLD<3.07E-01		LLD<3.07E-01		482.20	
HG-203	LLD<2.11E-01		LLD<2.11E-01		279.20	
I-131	LLD<2.65E-01		LLD<2.65E-01		364.48	
I-132	LLD<7.16E-01		LLD<7.16E-01		667.69	
I-133	LLD<2.61E-01		LLD<2.61E-01		529.69	
I-134	LLD<4.00E-01		LLD<4.00E-01		847.03	
I-135	LLD<7.91E-01		LLD<7.91E-01		1260.41	
K-40	LLD<2.12E+00		LLD<2.12E+00		1460.75	
KR-85	LLD<5.91E+01		LLD<5.91E+01		513.99	
KR-85M	LLD<1.64E-01		LLD<1.64E-01		151.17	
KR-87	LLD<5.95E-01		LLD<5.95E-01		402.58	
KR-89	LLD<8.44E+00		LLD<8.44E+00		220.90	
LA-140	LLD<1.25E-01		LLD<1.25E-01		1596.20	

LA-142	LLD<5.69E-01	LLD<5.69E-01	641.83
MN-54	LLD<2.35E-01	LLD<2.35E-01	834.83
MN-56	LLD<2.90E-01	LLD<2.90E-01	846.76
NA-22	LLD<1.92E-01	LLD<1.92E-01	1274.55
NA-24	LLD<2.13E-01	LLD<2.13E-01	1368.60
NB-94	LLD<2.07E-01	LLD<2.07E-01	702.63
NB-95	LLD<2.47E-01	LLD<2.47E-01	765.78
NB-97	LLD<1.57E+00	LLD<1.57E+00	657.92
NP-237	LLD<1.24E+00	LLD<1.24E+00	86.50
NP-238	LLD<1.09E+00	LLD<1.09E+00	984.45
NP-239	LLD<1.31E+00	LLD<1.31E+00	277.60
PA-233	LLD<4.94E-01	LLD<4.94E-01	311.98
PA-234M	LLD<5.25E+01	LLD<5.25E+01	1001.03
PB-210	LLD<6.47E+00	LLD<6.47E+00	465.03
PB-212	LLD<3.96E-01	LLD<3.96E-01	239.00
PB-214	LLD<5.57E-01	LLD<5.57E-01	351.92
PO-210	LLD<2.23E+04	LLD<2.23E+04	804.00
PO-214	LLD<1.02E+04	LLD<1.02E+04	799.70
PO-216	LLD<1.72E+04	LLD<1.72E+04	804.90
PU-239	LLD<2.01E+03	LLD<2.01E+03	129.30
PU-241	LLD<6.24E+04	LLD<6.24E+04	148.57
RA-224	LLD<4.09E+00	LLD<4.09E+00	240.99
RA-226	LLD<3.77E+00	LLD<3.77E+00	186.10
RB-88	LLD<8.49E-01	LLD<8.49E-01	1836.00
RB-89	LLD<1.42E+00	LLD<1.42E+00	1031.88
RN-220	LLD<2.25E+02	LLD<2.25E+02	549.73
RU-103	LLD<2.47E-01	LLD<2.47E-01	497.08
RURH106	LLD<4.77E+00	LLD<4.77E+00	621.80
SB-124	LLD<5.19E-01	LLD<5.19E-01	602.72
SB-125	LLD<2.05E+00	LLD<2.05E+00	176.33
SC-46	LLD<3.16E-01	LLD<3.16E-01	1120.45
SE-75	LLD<3.10E-01	LLD<3.10E-01	264.66
SN-113	LLD<3.66E-01	LLD<3.66E-01	391.67
SR-85	LLD<2.59E-01	LLD<2.59E-01	513.99
SR-91	LLD<4.74E-01	LLD<4.74E-01	555.60
SR-92	LLD<9.63E-02	LLD<9.63E-02	1383.94
TA-182	LLD<8.97E-01	LLD<8.97E-01	1121.30
TC-99M	LLD<1.37E-01	LLD<1.37E-01	140.51
TE-123M	LLD<1.53E-01	LLD<1.53E-01	159.00
TE-125M	LLD<4.23E+01	LLD<4.23E+01	109.27
TE-132	LLD<1.82E-01	LLD<1.82E-01	228.16
TH-228	LLD<1.45E+01	LLD<1.45E+01	84.37
TL-208	LLD<3.20E-01	LLD<3.20E-01	583.14
U-235	LLD<2.49E-01	LLD<2.49E-01	185.71
U-237	LLD<7.18E-01	LLD<7.18E-01	208.00
W-187	LLD<8.24E-01	LLD<8.24E-01	685.74
XE-131M	LLD<6.77E+00	LLD<6.77E+00	163.98
XE-133	LLD<4.86E-01	LLD<4.86E-01	81.00
XE-133M	LLD<1.60E+00	LLD<1.60E+00	233.21
XE-135	LLD<1.78E-01	LLD<1.78E-01	249.79
XE-138	LLD<1.41E+00	LLD<1.41E+00	258.41
Y-88	LLD<8.05E-02	LLD<8.05E-02	1836.06
Y-91	LLD<7.12E+01	LLD<7.12E+01	1204.90
Y-91M	LLD<3.58E-01	LLD<3.58E-01	555.60
ZN-65	LLD<6.63E-01	LLD<6.63E-01	1115.55
ZR-95	LLD<4.43E-01	LLD<4.43E-01	756.73
ZR-97	LLD<2.57E-01	LLD<2.57E-01	743.33
TOTAL	8.28E+01 +-1.54E+00	8.28E+01 +-1.54E+00	

STANDARD DEVIATION = 0.15

E BAR = ***** MEV/DISINTEGRATION
MAXIMUM PERMISSABLE ACTIVITY = 1.47E-09 UC/LI
TOTAL MEASURED ACTIVITY = 8.28E+01 (+-1.54E+00) UC/LI
% TECH. SPEC. = ***** (+-*****)

ERROR QUOTATION AT 1.96 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1127.33	563.30	452.	14.8	2.66E+01
1139.73	569.49	974.	12.1	5.80E+01
1604.49	801.84	379.	14.7	3.03E+01
2729.91	1364.50	109.	22.5	1.35E+01

PEAKS ELIMINATED BY BACKGROUND SUBTRACTION

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
2921.97	1460.53	170.	16.8	2.23E+01

Single Shell Tank

Calibration Record

ANALYTE: Mixed Isotope Standards

PROCEDURE: LQ-508-003

REVISION: A-0

INSTRUMENT: GEA Detector #2

PROPERTY NUMBER: 401934

TECHNOLOGIST: J. L. Anderson

PAYROLL NUMBER: 61413

DATE: October 21, 1988

CALIBRATION STANDARD ID: 56B40 D1

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: Gamma Energy Analysis (Efficiency)

DETECTOR: 2
 GEOMETRY CODE: 42
 GEOMETRY DECSRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 21-Oct-88
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	3.417000E-03
88.032	1.090000E-02
122.0614	1.408000E-02
165.853	1.516000E-02
279.1967	9.929000E-03
391.668	7.578000E-03
513.99	5.875000E-03
661.65	4.927000E-03
898.021	3.727000E-03
1173.237	3.085000E-03
1332.501	2.683000E-03
1836.129	2.102000E-03

EQUATION 0-122 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -6.654070\text{E+01} \\
 & + 2.583780\text{E+01} * \text{LOG(ENERGY)} \\
 & + -2.677550\text{E+00} * \text{LOG(ENERGY)}^2
 \end{aligned}$$

EQUATION 122-1836 KEV

$$\begin{aligned}
 \text{LOG(EFF)} = & -1.050740\text{E+02} \\
 & + 6.428950\text{E+01} * \text{LOG(ENERGY)} \\
 & + -1.503170\text{E+01} * \text{LOG(ENERGY)}^2 \\
 & + 1.533670\text{E+00} * \text{LOG(ENERGY)}^3 \\
 & + -5.838530\text{E-02} * \text{LOG(ENERGY)}^4
 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 2
 GEOMETRY CODE: 43
 GEOMETRY DECSRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 28-Sep-88
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	1.476000E-03
88.032	4.721000E-03
122.0614	6.589000E-03
165.853	6.613000E-03
279.1967	4.692000E-03
391.668	3.542000E-03
513.99	2.810000E-03
661.65	2.327000E-03
898.021	1.790000E-03
1173.237	1.437000E-03
1332.501	1.277000E-03
1836.129	9.824000E-04

EQUATION 0-165 KEV

```
LOG(EFF) = -5.826830E+01  
+ 2.165450E+01 *LOG(ENERGY)  
+ -2.198930E+00 *LOG(ENERGY)^2
```

EQUATION 165-1836 KEV

```
LOG(EFF) = -2.233890E+01  
+ 1.174520E+01 *LOG(ENERGY)  
+ -2.739550E+00 *LOG(ENERGY)^2  
+ 2.655450E-01 *LOG(ENERGY)^3  
+ -9.668420E-03 *LOG(ENERGY)^4
```

Single Shell Tank

Calibration Record

ANALYTE:0 Mixed Isotope Standards

PROCEDURE: LQ-508-003

REVISION: B-1

INSTRUMENT: GEA Detector #3

PROPERTY NUMBER: 401934

TECHNOLOGIST: J. L. Anderson

PAYROLL NUMBER: 61413

DATE: July 2, 1989

CALIBRATION STANDARD ID: 56B40 D1

ANALYTE CONCENTRATION: N/A

TYPE OF CALIBRATION: Gamma Energy Analysis (Efficiency)

DETECTOR: 3
 GEOMETRY CODE: 41
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 1
 CALIBRATION DATE: 2-Jul-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV) EFFICIENCY (COUNTS/GAMMA)

59.536	2.833765E-02
88.032	2.881764E-02
122.0614	2.756557E-02
165.853	2.270614E-02
279.1967	
391.668	1.285730E-02
513.99	
661.65	7.841011E-03
898.021	5.779292E-03
1173.237	4.773005E-03
1332.501	4.278530E-03
1836.129	3.371238E-03

EQUATION 0-165 KEV

$$\text{LOG(EFF)} = -1.113845E+01 + 3.484260E+00 * \text{LOG(ENERGY)} + -3.990659E-01 * \text{LOG(ENERGY)}^2$$

EQUATION 165-1836 KEV

$$\text{LOG(EFF)} = -2.052334E+01 + 9.121738E+00 * \text{LOG(ENERGY)} + -1.553578E+00 * \text{LOG(ENERGY)}^2 + 8.018036E-02 * \text{LOG(ENERGY)}^3$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 3
 GEOMETRY CODE: 42
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 2-Jul-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV) EFFICIENCY (COUNTS/GAMMA)

59.536	7.455306E-03
88.032	7.462748E-03
122.0614	7.578302E-03
165.853	6.965814E-03
279.1967	
391.668	3.596591E-03
513.99	
661.65	2.318396E-03
898.021	1.024191E-03
1173.237	1.461179E-03
1332.501	1.321243E-03
1836.129	1.011332E-03

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -6.838496\text{E+00} \\ & + 8.819509\text{E-01} * \text{LOG(ENERGY)} \\ & + -9.970528\text{E-02} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & 3.082260\text{E-01} \\ & + -1.410839\text{E+00} * \text{LOG(ENERGY)} \\ & + 1.042898\text{E-01} * \text{LOG(ENERGY)}^2 \\ & + -5.874725\text{E-03} * \text{LOG(ENERGY)}^3 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 3
 GEOMETRY CODE: 43
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 2-Jul-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	2.020462E-03
88.032	1.924344E-03
122.0614	2.027231E-03
165.853	1.712371E-03
279.1967	
391.668	1.056509E-03
513.99	
661.65	7.115743E-04
890.021	5.243928E-04
1173.237	4.551585E-04
1332.501	4.223636E-04
1836.129	3.139091E-04

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -5.300788\text{E+00} \\ & + -3.550643\text{E-01} * \text{LOG(ENERGY)} \\ & + 3.272635\text{E-02} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -9.815549\text{E+00} \\ & + 2.402920\text{E+00} * \text{LOG(ENERGY)} \\ & + -4.428877\text{E-01} * \text{LOG(ENERGY)}^2 \\ & + 2.059131\text{E-02} * \text{LOG(ENERGY)}^3 \end{aligned}$$

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	WA77344
PROCEDURE/REV	LA-925-106/A-1
TECHNOLOGIST	M. Franz
DATE	Feb. 14, 1990
TEMPERATURE	N/A
STARTING TIME	1230
ENDING TIME	1520
CHEMIST	S. A. Catlow

Uranium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Spike Composite 7	F0979
6	Final LMCS Check Std.	F0980
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	58B38/1.0 ul			5.7 ml
Spike	58B38/1.0 ul	F0977/0.25 ul		5.725 ml

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	WB39939
PROCEDURE/Rev	LA-505-151/A-0
TECHNOLOGIST	J. A. White
DATE	April 20, 1990
TEMPERATURE	N/A
STARTING TIME	0800
ENDING TIME	1410
CHEMIST	S. A. Jones

ICP
Fusion Digestion

	DESCRIPTION	LAB ID
1	LMCS Check Std.	NA
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Spike Composite 7	F0979
6	LMCS Check Std.	NA
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BOOK # & ALIQUOT VOL.	FINAL VOL. OF STD.
LMCS Check Std.	78C11J/1.0 mL	82B3BF/1.0 mL	77C11I/1.0 mL	1.0 mL
Spike	78C11J/1.0 mL	F0977/0.5 mL		11.5 mL

DATA SUMMARY
Sample units are Wet Weight

**Core 7 Composite
Fusion Dissolution**

Tank: 241-U-110
Customer ID: Core Composite 7

ICP Results

Radiological Analysis

			Sample	Duplicate
	Sample	Duplicate Sample		
Fusion	3.02 g/L	3.57 g/L	Aluminum	52011 ug/g
Total Alpha	1.64E-01 uci/g	2.11E-01 uci/g	Antimony	LT
Total Beta	6.13E+02 uci/g	6.39E+02 uci/g	Barium	27 ug/g
GEA Cs-137	1.81E+01 uci/g	1.74E+01 uci/L	Beryllium	LT
Uranium	3.91E+03 ug/g	4.26E+03 ug/g	Bismuth	6055 ug/g
Plutonium	1.82E-01 uci/g	2.08E-01 uci/g	Boron	50 ug/g
Americium 241	6.16E-02 uci/g	6.83E-02 uci/g	Cadmium	LT
Neptunium	<3.58E-01 uci/g	<3.03E-01 uci/g	Calcium	758 ug/g
Technetium 99	<6.22E-03 uci/g	<5.24E-03 uci/g	Cerium	669 ug/g
Iodine 129	<1.07E-02 uci/g	<9.47E-03 uci/g	Chromium	120 ug/g
Strontium 90	2.91E+02 uci/g	2.46E+02 uci/g	Copper	112 ug/g
			Europium	12 ug/g
			Iron	3859 ug/g
			Lanthanum	LT
			Lead	93 ug/g
			Lithium	LT
			Magnesium	303 ug/g
			Manganese	708 ug/g
			Mercury	LT
			Molybdenum	32 ug/g
			Neodymium	LT
			Nickel	2356 ug/g
			Samarium	726 ug/g
			Selenium	364 ug/g
			Silicon	3364 ug/g
			Silver	LT
			Sodium	33649 ug/g
			Strontium	135 ug/g
			Sulfur	159 ug/g
			Tantalum	102 ug/g
			Thallium	5577 ug/g
			Thorium	1516 ug/g
			Tin	49 ug/g
			Titanium	28 ug/g
			Vanadium	56 ug/g
			Zinc	55 ug/g
			Zirconium	113 ug/g

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

ICP Results

Raw Data Summary

Date Analyzed: April 20, 1990
 Procedure: LA-505-151/A-0
 Analyst: J. A. White
 Digestion: Acid Digestion
 Procedure: LA-505-159/A-0

Reagent Blank	F0976
Core 7 Composite	F0977
Duplicate of Core 7 Composite	F0978
Spike of Core 7 Composite	F0979

	Instrument Starting Standard %	Acid Digest. Standard %	Reagent BLANK ppm	Wet Weight Sample ug/g	Wet Weight Sample ug/g	Duplicate ug/g	Spike Recovery %	LMCS ACID Digestion %	Closing LMCS Standard %
Aluminum	103.23%	NOT RUN	-0.78 LT	52011	61606		NOT RUN		101.37%
Antimony	100.45%		-2.24 LT	160 LT	223 LT	82	85.43%		99.82%
Arsenic	116.51% #		0.10 LT	100					114.04% #
Barium	97.11%		-0.03 LT	27	22		92.43%		96.95%
Beryllium	97.96%		-0.01 LT	1 LT	0 LT				98.10%
Bismuth	106.18%		-0.62 LT	6055	6686				107.82%
Boron	98.16%		0.07 LT	50	16 LT	16 LT	92.28%		98.20%
Cadmium	100.20%		-0.05 LT	8 LT	6 LT	6 LT	95.05%		99.97%
Calcium	99.66%		1.65	758	1690	1690	97.02%		99.49%
Cerium	91.19%		-1.75 LT	669	480	480	41.86%		92.81%
Chromium	92.49%		-0.10 LT	120	138	138	87.23%		91.85%
Cobalt	82.57% #		-1.10 LT	-47 LT	-56 LT	-56 LT	73.05%		90.18%
Copper	99.05%		-0.20 LT	112	143	143	92.64%		98.94%
Europium	98.44%		-0.02 LT	12	8	8			99.95%
Iron	99.15%		0.10 LT	3859	4396	4396	98.09%		99.27%
Lanthanum	93.83%		-0.31 LT	35 LT	44 LT	44 LT			95.34%
Lead	105.10%		-1.47 LT	93	323	323			106.36%
Lithium	95.70%		-1.50 LT	-122 LT	-123 LT	-123 LT	83.23%		95.69%
Magnesium	100.11%		1.19	303	806	806	105.33%		100.45%
Manganese	99.23%		0.03 LT	708	799	799	95.58%		98.78%
Mercury	107.34%		0.01 LT	10 LT	11 LT	11 LT			105.06%
Molybdenum	101.02%		-0.02 LT	32	29	29			98.62%
Neodymium	92.52%		-1.14 LT	545 LT	630 LT	630 LT	68.62%		90.79%
Nickel	99.44%		18.11	2356	2207	2207	95.17%		99.49%
Phosphorous	110.15% #		-0.13 LT	7891	9207	9207			112.79% #
Potassium	99.70%		NA	0	0	0	0.00%		101.87%
Samarium	100.68%		-1.93 LT	726	530	530			102.43%
Selenium	107.43%		-0.63 LT	364	365	365			105.43%
Silicon	92.44%		1.09	3364	3988	3988			90.62%
Silver	105.03%		-0.14 LT	42 LT	29 LT	29 LT			106.65%
Sodium	96.81%		10.66	33649	37361	37361	94.32%		96.99%
Strontium	98.22%		-0.01 LT	135	182	182	94.60%		98.34%
Sulfur	106.14%		0.03 LT	159	144	144			105.95%
Tantalum	100.56%		-0.31 LT	102	74 LT	74 LT			98.56%
Thallium	107.92%		-0.09 LT	5577	6924	6924			107.06%
Thorium	105.08%		-2.62 LT	1516	3422	3422			106.97%
Tin	97.87%		0.07 LT	49	55	55	93.82%		98.31%
Titanium	103.51%		-0.08 LT	28	25	25			101.17%
Tungsten	86.82% #		-0.40 LT	131	145	145			84.18% #
Uranium	109.57%		-14.40 LT	5496	4526	4526			111.52% #
Vanadium	99.71%		0.05 LT	56	33 LT	33 LT			98.46%
Zinc	98.83%		0.09	55	72	72	94.44%		98.97%
Zirconium	101.83%		-0.20 LT	113	78	78			99.75%

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

ICP Results

Raw Data Report

Page 1 of 4

Date Analyzed:	April 20, 1990	Reagent Blank	F0976
Procedure:	LA-505-151/A-0	Core 7 Composite	F0977
Analyst:	J. A. White	Duplicate of Core 7 Composite	F0978
Digestion	Acid Digestion	Spike of Core 7 Composite	F0979
Procedure:	LA-505-159/A-0		

			Starting LMCS Standard	LMCS Instrument Standard	Acid Digestion Standard	Reagent Blank	Weight Volume Sample
			Recovery	Recovery	Recovery	ppm	Dilution Three ppm
	SST-1	SST-2	%	ppm	ppm	%	ppm
	SST-3						
Aluminum			51.62	103.23%	NOT RUN	-0.78 LT	
Antimony	10.05			100.45%		-2.24 LT	
Arsenic			58.26	116.51% #		0.10 LT	
Barium	9.71			97.11%		-0.03 LT	
Beryllium			9.80	97.96%		-0.01 LT	
Bismuth		53.19		106.18%		-0.62 LT	
Boron	9.82			98.16%		0.07 LT	
Cadmium	10.02			100.20%		-0.05 LT	
Calcium	9.97			99.66%		1.65	
Cerium	9.12			91.19%		-1.75 LT	
Chromium	9.25			92.49%		-0.10 LT	
Cobalt	8.26			82.57% #		-1.10 LT	
Copper	9.91			99.05%		-0.20 LT	
Europium		9.84		98.44%		-0.02 LT	
Iron	9.92			99.15%		0.10 LT	
Lanthanum		47.01		93.83%		-0.31 LT	
Lead		52.66		105.10%		-1.47 LT	
Lithium	9.57			95.70%		-1.50 LT	
Magnesium	10.01			100.11%		1.19	
Manganese	9.92			99.23%		0.03 LT	
Mercury			26.84	107.34%		0.01 LT	
Molybdenum			50.51	101.02%		-0.02 LT	
Neodymium	9.25			92.52%		-1.14 LT	
Nickel	9.94			99.44%		18.11	
Phosphorous			55.07	110.15% #		-0.13 LT	
Potassium	24.93			99.70%		NA	
Samarium		10.07		100.68%		-1.93 LT	
Selenium			53.72	107.43%		-0.63 LT	
Silicon			46.22	92.44%		1.09	
Silver		10.50		105.03%		-0.14 LT	
Sodium	24.20			96.81%		10.66	
Strontium	9.82			98.22%		-0.01 LT	
Sulfur			53.07	106.14%		0.03 LT	
Tantalum			50.28	100.56%		-0.31 LT	
Thallium			53.96	107.92%		-0.09 LT	
Thorium		52.64		105.08%		-2.62 LT	
Tin	48.94			97.87%		0.07 LT	
Titanium			51.76	103.51%		-0.08 LT	
Tungsten			21.70	86.82% #		-0.40 LT	
Uranium		54.90		109.57%		-14.40 LT	
Vanadium			9.97	99.71%		0.05 LT	
Zinc	9.88			98.83%		0.09	
Zirconium			50.91	101.83%		-0.20 LT	
Dilution Factor	1.00	1.00	1.00		10.00	21.00	1.00

ICP Results

Raw Data Report

Page 2 of 4

	0.4778 g 50.00 mL	Sample	Weight Volume	0.5018 g 50.00 mL	Sample	Weight Volume	0.5143 g 50.00 mL	Sample	Sample	Spike of Sample	Spike of Sample	Spike of Sample	Spike Recovery
	Dilution	Dilution	Duplicate	Dilution	Duplicate	Dilution	Dilution	Dilution	Dilution	Dilution	Dilution	Dilution	%
	Two ppm	One ppm	Three ppm	Two ppm	One ppm	Three ppm	Two ppm	One ppm	Two ppm	One ppm	Two ppm	One ppm	
Aluminum	497.02	492.75		618.28	594.70		490.29	494.80					
Antimony	2.45	1.53 LT		10.76	2.24 LT		85.43	22.05					85.43%
Arsenic	2.07	0.96		4.21	0.82		-0.48	0.78					
Barium	0.75	0.25		1.40	0.22		93.12	19.83					92.43%
Beryllium	0.04	0.01 LT		0.10	0.01 LT		-0.08	0.01 LT					
Bismuth	64.16	57.86		82.55	67.10		51.24	56.74					
Boron	0.98	0.48		0.71	0.16 LT		93.19	19.73					92.28%
Cadmium	0.22	0.07 LT		0.47	0.06 LT		95.05	20.35					95.05%
Calcium	7.24	6.93		16.96	16.19		103.75	26.81					97.02%
Cerium	23.49	6.40		46.33	4.82		63.68	23.02					41.86%
Chromium	1.46	1.15		2.81	1.39		88.59	19.72					87.23%
Cobalt	-3.51	-0.45 LT		-0.95	-0.56 LT		73.05	17.14					73.05%
Copper	1.70	1.08		3.17	1.44		94.21	20.95					92.64%
Europium	0.45	0.12		0.87	0.08		-0.20	0.13					
Iron	36.88	36.34		44.11	42.30		132.35	56.55					98.09%
Lanthanum	1.07	0.33 LT		3.20	0.44 LT		-2.49	0.27 LT					
Lead	-7.09	0.88		8.51	3.24		-15.58	-0.16 LT					
Lithium	-5.86	-1.17 LT		-4.94	-1.24 LT		83.23	17.93					83.23%
Magnesium	2.90	1.24		8.09	1.82		108.02	22.73					105.33%
Manganese	6.76	6.64		8.02	7.75		101.86	26.66					95.58%
Mercury	0.39	0.09 LT		0.47	0.11 LT		0.94	0.34					
Molybdenum	0.70	0.31		1.43	0.29		-0.14	0.30					
Neodymium	21.66	5.21 LT		41.61	6.33 LT		68.62	21.91					68.62%
Nickel	22.52	21.84		22.15	20.13		116.09	41.90					95.17%
Phosphorous	75.41	76.33		92.40	76.06		66.28	79.70					
Potassium	NA	NA		NA	NA		NA	NA					0.00%
Samarium	27.33	6.94		53.88	5.32		-27.62	4.69 LT					
Selenium	8.46	3.48		16.04	3.66		23.36	9.48					
Silicon	32.15	26.24		40.02	30.46		23.85	26.00					
Silver	1.50	0.40 LT		3.00	0.29 LT		-1.85	0.27 LT					
Sodium	321.55	297.07		374.95	326.12		534.53	341.24					94.32%
Strontium	1.29	1.07		1.83	1.32		95.80	21.01					94.60%
Sulfur	3.58	1.52		5.91	1.44		3.15	2.26					
Tantalum	2.65	0.98		7.61	0.75 LT		-2.88	0.51 LT					
Thallium	53.30	11.63		69.49	8.28		-2.92	11.65					
Thorium	14.49	4.52		34.34	3.68		-18.58	4.22					
Tin	1.41	0.47		3.09	0.55		470.40	100.71					93.82%
Titanium	0.84	0.27		1.71	0.25		-0.88	0.19					
Tungsten	3.48	1.25		6.04	1.45		-0.12	1.72					
Uranium	163.26	52.52		319.04	45.42		-130.10	45.28					
Vanadium	2.10	0.54		3.18	0.33 LT		0.05	0.40 LT					
Zinc	0.83	0.53		1.11	0.72		95.21	20.61					94.44%
Zirconium	3.30	1.08		5.68	0.78		-2.03	0.89					
Dilution Factor	101.00	21.00		1.00	101.00	21.00	1.00	111.00	23.00				

ICP Results

Raw Data Report

Page 3 of 4

	Standard LMCS Acid Digestion ppm	Acid Digestion Standard Recovery %	Ending Standard LMCS	Standard Recovery %	Spike Standard LMCS	Spike Standard ID Book #	78C11J	SST-1
			SST-1	SST-2	SST-3			
Aluminum	NOT RUN			50.69	101.37%			
Antimony		9.98			99.82%		10.00	10.00
Arsenic				57.02	114.04% #			
Barium		9.70			96.95%		10.00	10.00
Beryllium				9.81	98.10%			
Bismuth		54.02			107.82%			
Boron		9.82			98.20%		10.00	10.00
Cadmium		10.00			99.97%		10.00	10.00
Calcium		9.95			99.49%		10.00	10.00
Cerium		9.28			92.81%		10.00	10.00
Chromium		9.19			91.85%		10.00	10.00
Cobalt		9.02			90.18%		10.00	10.00
Copper		9.89			98.94%		10.00	10.00
Europium			10.00		99.95%			
Iron		9.93			99.27%		10.00	10.00
Lanthanum			47.77		95.34%			
Lead			53.29		106.36%			
Lithium		9.57			95.69%		10.00	10.00
Magnesium		10.05			100.45%		10.00	10.00
Manganese		9.88			98.78%		10.00	10.00
Mercury			26.27		105.06%			
Molybdenum			49.31		98.62%			
Neodymium		9.08			90.79%		10.00	10.00
Nickel		9.95			99.49%		10.00	10.00
Phosphorous			56.40		112.79% #			
Potassium		25.47			101.87%		25.00	25.00
Samarium			10.24		102.43%			
Selenium				52.72	105.43%			
Silicon				45.31	90.62%			
Silver			10.67		106.65%			
Sodium		24.25			96.99%		25.00	25.00
Strontium		9.83			98.34%		10.00	10.00
Sulfur				52.98	105.95%			
Tantalum				49.28	98.56%			
Thallium				53.53	107.06%			
Thorium		53.59			106.97%			
Tin		49.16			98.31%		50.00	50.00
Titanium				50.58	101.17%			
Tungsten				21.04	84.18% #			
Uranium			55.87		111.52% #			
Vanadium				9.85	98.46%			
Zinc		9.90			98.97%		10.00	10.00
Zirconium				49.87	99.75%			
Dilution Factor		1.00	1.00	1.00				

ICP Results

Raw Data Report

Page 4 of 4

	LMCS Standards Values	LMCS Standard IDs Book	ACID DIGESTION STANDARD VALUES	ACID DIGEST. LMCS IDs Book
	SST-2 ppm	SST-3 #	ppm in Sample	ppm
Aluminum	50.00		100.00	
Antimony				
Arsenic	50.00			
Barium			100.00	
Beryllium	10.00			
Bismuth	50.10		100.00	
Boron			100.00	
Cadmium			100.00	
Calcium			100.00	
Cerium			100.00	
Chromium			100.90	
Cobalt			100.00	
Copper			100.00	
Europium	10.00			
Iron			100.00	
Lanthanum	50.10		100.00	
Lead	50.10		100.00	
Lithium			100.00	
Magnesium			100.00	
Manganese			100.00	
Mercury	25.00			
Molybdenum	50.00		99.80	
Neodymium			100.00	
Nickel			100.00	
Phosphorous	50.00		100.00	
Potassium			100.00	
Samarium	10.00			
Selenium	50.00			
Silicon	50.00		100.00	
Silver	10.00			
Sodium			100.00	
Strontium			100.00	
Sulfur	50.00			
Tantalum	50.00		99.50	
Thallium	50.00			
Thorium	50.10			
Tin			100.00	
Titanium	50.00		100.10	
Tungsten	25.00			
Uranium	50.10			
Vanadium	10.00			
Zinc			100.00	
Zirconium	50.00		99.80	
Dilution Factor			10.00	

ICP Calibration Report

Procedure: LA-505-151 Revision: A-0
Instrument: WB39939
Technologist: J. A. White
Date: April 20, 1990 Time: 08:08

Calibration Standards for ICP Program "SST"

Element	Standard	Element	Standard
Aluminum	SST-3	Antimony	SST-4
Arsenic	SST-4	Barium	SST-2
Beryllium	SST-2	Bismuth	SST-4
Boron	SST-3	Cadmium	SST-2
Calcium	SST-2	Cerium	SST-5
Chromium	SST-2	Cobalt	SST-2
Copper	SST-2	Europium	SST-5
Iron	SST-2	Lanthanum	SST-5
Lead	SST-4	Lithium	SST-1
Magnesium	SST-2	Manganese	SST-2
Mercury	SST-3	Molybdenum	SST-3
Neodymium	SST-5	Nickel	SST-2
Phosphorous	SST-3	Potassium	SST-1
Samarium	SST-5	Selenium	SST-4
Silicon	SST-3	Silver	SST-2
Sodium	SST-1	Strontium	SST-2
Sulfur	SST-3	Tantalum	SST-3
Thallium	SST-4	Thorium	SST-4
Tin	SST-4	Titanium	SST-3
Tungsten	SST-3	Uranium	SST-4
Vanadium	SST-2	Zinc	SST-2
Zirconium	SST-3		

ICP Standard Formulations

SST-0:
Calibration blank, 1 M ultrex HNO₃.

SST-1:

Stock solutions from AESAR/John Mathey Inc., Seabrook, NH 03874.
Individual element solutions as follows:

Li LiCO₃ 10,000 ppm in 5% HNO₃ Lot# 14394A

K KNO₃ 10,000 ppm in 5% HNO₃ Lot# 14379A

Na NaCO₃ 10,000 ppm in 5% HNO₃ Lot# 14400A

200 mL of standard made by combining 25 mL HCl/HNO₃ mixed acid, 1 mL each single element standards, and water.

SST-2:

Stock solutions from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standards as follows:

SM-10 Li, Na, K, Rb, Cs, Be, Mg, Ca, Sr, & Ba 100 ppm
Lot# 0-119A

SM-20 V, Cr, Mn, Fe, Co, Ni, Cu, Zn, Ag, & Cd 100 ppm
Lot# 0-119B

50 mL of each mixed standard are added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

SST-3:

Stock solutions from AESAR/John Mathey Inc., Seabrook, NH 03874.
Individual element solutions as follows:

Al Al 10,000 ppm in 10% HCl Lot# 9-053A

B H₃BO₃ 10,000 ppm in 1% NH₄OH Lot# 9-335A

Hg Hg 10,000 ppm in 5% HNO₃ Lot# 8-656S

Mo Mo 10,000 ppm in 5% HCl Lot# 9-159T

P P 10,000 ppm in 5% HNO₃ Lot# 9-160A

Si Si 1000 ppm in KOH Lot# 086DM Spex Industries, Edison, NJ

S (NH₄)₂SO₄ in H₂O Lot# 9-231M

Ta TaCl₅ 10,000 ppm in 5% HCl/tr HF Lot# 9-335M

Ti Ti 10,000 ppm in 5% HF Lot# 9-079EE

W W 10,000 ppm in 5% HF/tr HNO₃ Lot# 8-685L

Zr ZrCl₂O 10,100 ppm in 5% HCl Lot# 9-078G

50 mL of each mixed standard are added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

SST-4:

Stock solution from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standard as follows:

SM-50 Ga, In, Tl, Ge, Sn, Pb, As, Sb, Bi, Se, Te, Th, & U 100 ppm Lot# 0-119D

Solution is used directly for calibration.

SST-5:

Stock solution from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standard as follows:

SM-60 Sc, Y, La, Ce, Pr, Nd, Sm, Eu, Gd, Tb, Dy, Ho, Er, Tm, Yb, & Lu 100 ppm Lot# 7-165F

50 mL of SM-60 is added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

ICP Calibration April 20, 1990

20-Apr-90 08:08:44

Condition	Value	Min	/	Max
VACUUM	= 18.52	7.000	/	50.00
SPTEMP	= 38.80	37.00	/	39.00
MAINS	= 233.2	220.0	/	247.0
-1000V	= -1005	-1010	/	-990
CTEMP	= 24.90	19.00	/	35.00
+5V	= 5.160	4.750	/	5.250
+12V	= 12.16	11.70	/	12.30
-12V	= -12.2	-12.3	/	-11.7
+24V	= 23.19	22.50	/	26.50
-100V	= -100	-101	/	-99.0
+5VSD	= 5.160	4.750	/	5.250
-12VSD	= 15.16	14.70	/	15.30
-15VSD	= -15.2	-15.3	/	-14.7

Position Calibration in Progress

SATI	PM	ALPHA	BETA	ALPHA	BETA	ALPHA	BETA
0.0000	0.0000	SLIT	SLIT	LAMBDA1	LAMBDA1	LAMBDA2	LAMBDA2

Previous data :

INWTH 0.00000 587.454 1.00102 0.31641 1.00005 -0.0667 0.00000 0.00000

Current data :

INCTR 0.00000 587.454 1.00099 -0.6958 1.00009 -0.0666 0.00000 0.00000

Last TIME PLASMA WNS. PLASMA, 20-Apr-90 08:10:26

ICP Calibration April 20, 1990

Sample name : SST0	
Programme : SST	20-Apr-90 10:53:32

NAME	MV INT	RSD
AL	2.00	1.18
SE	0.38	0.79
AS	1.09	0.49
RA	3.95	1.25
RE	0.71	0.85
BI	3.83	1.08
R	4.81	1.39
CD	2.31	0.87
CA	0.51	0.49
CE	5.34	1.43
CR	1.33	1.77
CO	0.26	0.70
CU	2.96	1.21
EU	4.14	1.42
FE	1.64	1.65
LA	0.36	0.98
PB	0.27	0.21
LI	4.56	1.90
MG	0.46	0.89
MN	0.77	0.91
HG	3.89	1.33
HO	1.68	1.48
NB	5.49	1.66
SI	3.40	1.52
P	1.21	1.82
F	3.25	1.90
SM	5.12	1.32
SH	1.75	1.31
S"	2.34	1.13
AB	15.34	1.44
HA	5.50	1.17
SR	3.70	1.07
S	0.71	0.99
TA	3.73	1.59
TL	4.31	1.36
TH	1.07	1.07
SN	1.24	1.99
TI	3.55	1.09
W	1.35	2.00
U	5.18	1.34
VI	4.30	1.11
ZN	2.39	1.66
ZR	4.58	1.04

Sample name : SST1	
Programme : SST	20-Apr-90 10:58:03

NAME	MV INT	RSD
LJ	427.08	0.08
K	13.54	0.23
NA	60.97	0.20

Sample name : SST2	
Programme : SST	20-Apr-90 11:00:02

ICP Calibration April 20, 1990

Sample name : SST2
 Programme : SST 20-Apr-90 11:00:02

NAME	MV	INT	RSD
BA	283.45	0.36	
BE	483.09	0.38	
CI	315.70	0.13	
CA	397.23	0.42	
CR	68.24	0.92	
CO	5.35	2.65	
CU	96.22	0.31	
FE	122.89	0.06	
MG	417.01	0.18	
MN	269.24	0.44	
NI	136.22	0.21	
AG	447.45	0.20	
SR	502.07	0.28	
V1	167.58	0.77	
ZN	610.77	0.15	

Sample name : SST3
 Programme : SST 20-Apr-90 11:02:45

NAME	MV	INT	RSD
AL	20.85	0.23	
B	643.56	0.06	
HG	243.64	0.24	
HO	287.55	0.40	
P	52.83	1.55	
SI	76.48	0.43	
S	38.34	1.35	
TA	120.81	0.44	
TI	427.88	0.11	
W	69.24	0.20	
ZR	150.47	0.13	

Sample name : SST4
 Programme : SST 20-Apr-90 11:04:50

NAME	MV	INT	RSD
SB	7.26	0.57	
AS	123.39	0.31	
RI	103.37	0.48	
PB	5.02	0.44	
SE	51.49	0.76	
TL	43.60	0.55	
TH	13.62	0.33	
SN	237.74	0.49	
U	12.37	0.31	

Sample name : SST5
 Programme : SST 20-Apr-90 11:07:30

NAME	MV	INT	RSD
------	----	-----	-----

ICP Calibration April 20, 1990

Sample name : SST5
 Programme : SST 20-Apr-90 11:07:30

NAME	MV	INI	RSD
CE	15.71	0.39	
EU	431.60	1.00	
LA	5.41	0.81	
ND	16.86	0.83	
SH	13.70	0.44	

Programme name : SST Channel name : AL Polynomial type : CC

Curve	Min	Int	Max	Int	C0	C1	C2	C3
-------	-----	-----	-----	-----	----	----	----	----

CRV1 1.9016 21.896 -0.530909E+01 0.265233E+01

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST10	0	2.0017	0.0000	0.0000	-0.000	-0.000		CRV1
SST13	0	20.853	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : SB1 Polynomial type : CC

Curve	Min	Int	Max	Int	C0	C1	C2	C3
-------	-----	-----	-----	-----	----	----	----	----

CRV1 0.3591 7.6272 -0.548940E+01 0.145222E+02

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST10	0	0.3780	0.0000	0.0000	-0.000	-0.000		CRV1
SST14	0	7.2640	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : AS Polynomial type : CC

Curve	Min	Int	Max	Int	C0	C1	C2	C3
-------	-----	-----	-----	-----	----	----	----	----

CRV1 1.0365 129.56 -0.892054E+00 0.817648E+00

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST10	0	1.0910	0.0000	0.0000	0.0000	0.0000		CRV1
SST14	0	122.29	100.00	100.00	100.00	0.0000	0.0000	CRV1

ICP Calibration April 20, 1990

Programme name : SST	Channel name : BA	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	CO	CO	C1	C2	CO
CRV1	3.7522	297.62	-0.282624E+00	0.715565E-01	

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Error		
SST0	0	3.9497	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	283.45	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : BE1	Polynomial type : CC
----------------------	--------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	CO	CO	C1	C2	CO
CRV1	0.6726	507.24	-0.293546E-01	0.414613E-01	

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Error		
SST0	0	0.7080	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	483.09	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : RI	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	CO	CO	C1	C2	CO
CRV1	3.6353	108.54	-0.384404E+01	0.100454E+01	

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Error		
SST0	0	3.8267	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST4	0	103.37	100.00	100.00	100.00	-0.000	-0.000	CRV1

Programme name : SST	Channel name : R	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	CO	CO	C1	C2	CO
CRV1	4.5679	675.74	-0.376386E+00	0.782778E-01	

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
(X)	(Y)	(Y)	Conc	Error	Conc	Error		

ICP Calibration April 20, 1990

Programme name : SST	Channel name : B	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	4.5679	675.74	-0.376386E+00	0.782778E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.8083	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	643.56	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : CD	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	2.1929	331.48	-0.147313E+00	0.638181E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	2.3083	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	315.70	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : CA	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	0.4886	417.09	-0.259298E-01	0.504143E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.5143	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	397.23	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : CE	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0	C1	C2	C3	

CRV1	5.0698	16.499	-0.102856E+02	0.192734E+01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration April 20, 1990

Programme name : SST	Channel name : CE	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	C0	Curve Coefficients			
				C1	C2	C3	
CRV1	5.0698	16.499	-0.102856E+02	0.192734E+01			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.3367	0.0000	0.0000	-0.000	-0.000	CRV1	
SST5	0	15.714	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : CR	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	C0	Curve Coefficients			
				C1	C2	C3	
CRV1	1.2603	71.647	-0.396563E+00	0.298916E+00			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.3267	0.0000	0.0000	0.0000	0.0000	CRV1	
SST2	0	68.233	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : CO	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	C0	Curve Coefficients			
				C1	C2	C3	
CRV1	0.2502	5.5101	-0.105664E+01	0.401257E+01			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.2633	0.0000	0.0000	-0.000	-0.000	CRV1	
SST2	0	5.3477	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : CU	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	C0	Curve Coefficients			
				C1	C2	C3	
CRV1	2.8164	101.03	-0.635815E+00	0.214464E+00			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration April 20, 1990

Programme name : SST			Channel name : CU			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	2.8164	101.03	-0.635815E+00	0.214464E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	2.9647	0.0000	0.0000	0.0000	0.0000	-0.000	CRV1
SST2	0	96.220	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : EU			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	3.9292	453.18	-0.193516E+00	0.467881E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.1360	0.0000	0.0000	-0.000	-0.000	-0.000	CRV1
SST5	0	431.60	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : EE			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	1.5539	129.03	-0.269793E+00	0.164944E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.6357	0.0000	0.0000	0.0000	0.0000	-0.000	CRV1
SST2	0	122.89	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : LA			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	0.3398	5.6795	-0.141613E+01	0.395935E+01				
Name	Number	Int. (Y)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration April 20, 1990

Programme name : SST	Channel name : LA	Polynomial type : CC			
Curve	Min Int Max Int		Curve Coefficients		
		C0	C1	C2	C3

CRV1	0.3398	5.6795	-0.141513E+01	0.395935E+01
------	--------	--------	---------------	--------------

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.3577	0.0000	0.0000	0.0000	0.0000	-0.000	CRV1
SST5	0	5.4090	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : PB	Polynomial type : CC			
Curve	Min Int Max Int		Curve Coefficients		
		C0	C1	C2	C3

CRV1	0.2571	3.2713	-0.569863E+01	0.210541E+02
------	--------	--------	---------------	--------------

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.2707	0.0000	0.0000	0.0000	0.0000	-0.000	CRV1
SST4	0	5.0203	100.00	100.00	100.00	-0.000	-0.000	CRV1

Programme name : SST	Channel name : LI	Polynomial type : CC			
Curve	Min Int Max Int		Curve Coefficients		
		C0	C1	C2	C3

CRV1	4.3317	448.43	-0.539581E+00	0.118338E+00
------	--------	--------	---------------	--------------

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.5597	0.0000	0.0000	-0.000	-0.000	-0.000	CRV1
SST1	0	427.08	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : MG	Polynomial type : CC			
Curve	Min Int Max Int		Curve Coefficients		
		C0	C1	C2	C3

CRV1	0.4335	437.86	-0.219100E-01	0.480132E-01
------	--------	--------	---------------	--------------

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
------	--------	------	------	------	------	------	---------	-------

ICP Calibration April 20, 1990

Programme name : SSI	Channel name : HG	Polynomial type : CC	
Curve	Min Int Max Int		Curve Coefficients
		C0	C1 C2 C3

CRV1	0.4335	437.86	-0.219100E-01	0.480132E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.4563	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	417.01	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SSI	Channel name : MN	Polynomial type : CC	
Curve	Min Int Max Int		Curve Coefficients
		C0	C1 C2 C3

CRV1	0.7306	282.70	-0.572873E-01	0.744959E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.7690	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST2	0	269.24	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SSI	Channel name : HG	Polynomial type : CC	
Curve	Min Int Max Int		Curve Coefficients
		C0	C1 C2 C3

CRV1	3.6958	780.82	-0.262951E+00	0.675908E-01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.8903	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	743.64	50.000	50.000	30.000	-0.000	-0.000	CRV1

Programme name : SSI	Channel name : MO	Polynomial type : CC	
Curve	Min Int Max Int		Curve Coefficients
		C0	C1 C2 C3

CRV1	1.5925	301.92	-0.393199E+00	0.174905E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration April 20, 1990

Programme name : SST			Channel name : M0			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients				
				C1	C2	C3		
CRV1	1.5925	301.92	-0.293199E+00	0.174905E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.6763	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	287.55	50.000	50.000	50.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : ND			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients				
				C1	C2	C3		
CRV1	5.2108	17.705	-0.964226E+01	0.175793E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.4850	0.0000	0.0000	0.0000	0.0000		CRV1
SST5	0	16.862	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : NI			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients				
				C1	C2	C3		
CRV1	3.2338	164.03	-0.445497E+00	0.130875E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.4040	0.0000	0.0000	-0.000	-0.000		CRV1
SST2	0	156.22	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : P			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients				
				C1	C2	C3		
CRV1	1.1527	55.468	-0.117541E+01	0.960748E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration April 20, 1990

Programme name : SST	Channel name : P	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1	1.1527	58.468	-0.117591E+01	0.968748E+00	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	1.2133	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	52.826	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST	Channel name : K	Polynomial type : CC
----------------------	------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1	3.1787	14.216	-0.164192E+02	0.490533E+01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	3.3460	0.0000	0.0000	-0.000	-0.000		CRV1
SST1	0	13.539	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : SM	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1	4.8684	14.383	-0.119554E+02	0.233291E+01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

SST0	0	5.1247	0.0000	0.0000	-0.000	-0.000		CRV1
SST5	0	13.698	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST	Channel name : SE	Polynomial type : CC
----------------------	-------------------	----------------------

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3

CRV1	1.6603	54.061	-0.351370E+01	0.201051E+01	
------	--------	--------	---------------	--------------	--

Name	Number	Int. (X)	Cone (Y)	True (Y)	Calc Cone	Cone Error	% Error	Curve
------	--------	-------------	-------------	-------------	--------------	---------------	---------	-------

ICP Calibration April 20, 1990

Programme name : SST			Channel name : SE			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C2	C3
				C1				
CRV1	1.6603	54.061	-0.351370E+01	0.201051E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.7477	0.0000	0.0000	0.0000	0.0000		CRV1
SST4	0	51.486	100.00	100.00	100.00	-0.000	-0.000	CRV1
Programme name : SST			Channel name : SI			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C2	C3
				C1				
CRV1	3.1689	80.309	-0.228005E+01	0.683536E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.3357	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	76.485	50.000	50.000	50.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : AB			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C2	C3
				C1				
CRV1	14.465	469.83	-0.704536E+00	0.462719E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	15.226	0.0000	0.0000	-0.000	-0.000		CRV1
SST2	0	447.45	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : NA			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C2	C3
				C1				
CRV1	3.2234	64.023	-0.495557E+01	0.901285E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration April 20, 1990

Programme name : SSI			Channel name : NA			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	5.2234	64.023	-0.495557E+01	0.901285E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.4983	0.0000	0.0000	0.0000	0.0000		CRV1
SST1	0	60.975	50.000	50.000	50.000	-0.000	-0.000	CRV1
Programme name : SST			Channel name : SR			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	3.5166	527.17	-0.148553E+00	0.401313E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.7017	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	502.07	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : S			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	0.6780	40.261	-0.948276E+00	0.132874E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.7137	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	38.343	50.000	50.000	50.000	-0.000	-0.000	CRV1
Programme name : SSI			Channel name : TA			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	3.5416	126.85	-0.159201E+01	0.427043E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration April 20, 1990

Programme name : SST Channel name : TA Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients	C1	C2	C3
CRV1	3.5416	126.85	-0.159201E+01	0.427043E+00			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.7280	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SSI3	0	120.81	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : IL2 Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients	C1	C2	C3
CRV1	4.0986	45.785	-0.109807E+02	0.254516E+01			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.3143	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SSI4	0	43.605	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : TH Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients	C1	C2	C3
CRV1	1.0194	14.303	-0.855071E+01	0.796897E+01			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.0730	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SSI4	0	13.622	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : SN Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients	C1	C2	C3
CRV1	1.1755	249.63	-0.523174E+00	0.422823E+00			

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
------	--------	------	------	------	------	------	---------	-------

ICP Calibration April 20, 1990

Programme name : SST			Channel name : SN			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	1.1755	249.63	-0.523174E+00	0.422823E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.2373	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST4	0	237.74	100.00	100.00	100.00	0.0000	0.0000	CRV1
Programme name : SST			Channel name : TI			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	3.3697	449.28	-0.417949E+00	0.117832E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.5470	0.0000	0.0000	-0.000	-0.000	0.0000	CRV1
SST3	0	427.88	50.000	50.000	50.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : W			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	1.2841	66.402	-0.109202E+01	0.907907E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.3517	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	63.240	50.000	50.000	50.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : U			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	4.9178	12.992	-0.719315E+02	0.138953E+02				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration April 20, 1990

Programme name : SST			Channel name : U			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	4.9178	12.992	-0.719315E+02	0.138953E+02				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.1767	0.0000	0.0000	-0.000	-0.000		CRV1
SST4	0	12.373	100.00	100.00	100.00	0.0001	0.0001	CRV1
Programme name : SST			Channel name : V1			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	4.0894	175.96	-0.527284E+00	0.122491E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.3047	0.0000	0.0000	-0.000	-0.000		CRV1
SST2	0	167.58	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : ZN			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	2.2702	641.30	-0.785590E-01	0.328744E-01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	2.3897	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	610.77	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST			Channel name : ZR			Polynomial type : CC		
Curve	Min Int	Max Int	C0	Curve Coefficients			C3	
				C1	C2			
CRV1	4.4485	157.99	-0.160602E+01	0.342972E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve

ICP Calibration April 20, 1990

Programme name : SST			Channel name : ZR		Polynomial type : CC		
Curve	Min Int	Max Int	Curve Coefficients				
	C0	C1	C2	C3			
CRV1	4.4485	157.99	-0.160602E+01	0.342972E+00			
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error Curve
SST0	0	4.6827	0.0000	0.0000	-0.000	-0.000	CRV1
SST3	0	150.47	50.000	50.000	50.000	-0.000	-0.000 CRV1

Sample name : HN03
 Programme : SST 20-Apr-90 12:42:11

NAME	MV	INT	CONCEN	RSD
Al	1.94	-0.169	-23.77	
Sb	0.37	-0.174	-14.43	
As	1.07	-0.016	-53.89	
Ba	3.85	-0.007	-33.25	
Be	0.69	-0.001	-25.46	
Bi	3.75	-0.073	-34.45	
B	4.86	0.004	26.95	
Cd	2.25	-0.004	-22.46	
Ca	0.48	(-0.002	-4.82	
Cr	5.19	-0.279	-39.35	
Cr	1.30	-0.009	-34.49	
Co	0.24	(-0.028	-5.17	
Cu	2.87	-0.019	-34.83	
Eu	4.03	-0.005	-36.87	
Fe	1.56	-0.013	-13.44	
La	0.35	-0.038	-20.69	
Pb	0.27	-0.119	-35.29	
Li	3.90	(-0.078	-3.90	
Mg	0.44	-0.001	-20.93	
Mn	0.75	-0.001	-24.22	
Hg	4.88	0.067	5.86	
Mo	1.63	-0.007	-41.18	
Nd	5.37	-0.209	-54.88	
Ni	3.32	-0.011	-10.08	
P	1.18	-0.034	-90.00	
K	3.26	-0.437	-29.45	

ICP Analysis April 20, 1990 Acid Blank

NAME	MV	INT	CONCEN	RSD
Al	1.94	-0.169	-23.77	
Sb	0.37	-0.174	-14.43	
As	1.07	-0.016	-53.89	
B ₃	3.85	-0.007	-33.25	
Be	0.69	-0.001	-25.46	
Bi	3.75	-0.073	-34.45	
B	4.86	0.004	26.93	
Cd	2.25	-0.004	-22.46	
Ca	0.48	(-0.002	-4.82	
Ce	5.19	-0.279	-20.35	
Cr	1.30	-0.009	-34.49	
Co	0.24	(-0.078	-5.17	
Cu	2.87	-0.019	-24.83	
Eu	4.03	-0.005	-36.87	
Fe	1.56	-0.013	-13.44	
La	0.35	-0.038	-20.69	
Pb	0.37	-0.119	-35.29	
Li	3.90	(-0.078	-3.90	
Mg	0.44	-0.001	-20.93	
Mn	0.75	-0.001	-24.22	
Hg	4.88	0.067	5.86	
Mo	1.63	-0.007	-41.18	
Nd	5.37	-0.209	-54.88	
Ni	3.32	-0.011	-10.08	
P	1.18	-0.034	-90.00	
K	3.26	-0.437	-29.45	
Sm	4.99	-0.316	-30.51	
Se	1.72	-0.062	-72.62	
Si	3.23	-0.073	-22.98	
Ag	14.80	-0.020	-27.84	
Na	5.35	-0.138	-32.66	
Sr	3.62	-0.003	-30.68	
S	0.69	-0.037	-53.01	
Ta	3.64	-0.039	-46.98	
Tl	4.22	-0.232	-32.09	
I _b	1.04	-0.250	-28.60	
Sn	1.21	-0.012	-67.93	
Ti	3.46	-0.010	-28.53	
W	1.32	-0.028	-55.62	
U	5.03	-2.006	-27.02	
V	4.25	-0.007	-22.94	
Zn	2.30	-0.003	-24.34	
Zr	4.59	-0.031	-33.91	

ICP Analysis April 20, 1990 LMCS Check Standard

E975

Sample name : 78C11J
 Sample code 1 : SST1
 Sample code 2 : DIRECT
 Programme : SST

20-Apr-90 12:46:22

NAME	MV	INT	CONCEN	RSD
Al	2.06	0.143	26.98	
Si	1.07	10.045	0.80	
As	1.20	0.087	2.47	
Re	139.67	9.711	0.60	
Be	0.72	0.001	61.99	
Bi	3.99	0.167	26.14	
B	130.21	9.816	0.09	
Cd	159.31	10.020	0.13	
Ca	198.21	9.956	0.59	
Ce	10.07	9.119	0.16	
Cr	32.27	9.249	0.07	
Co	2.32	0.257	0.47	
Cu	49.15	9.905	0.39	
Eu	4.70	0.036	5.16	
Fe	61.75	9.915	0.31	
La	0.37	0.053	7.50	
Pb	0.27	-0.007	-173.20	
Li	85.43	9.570	0.36	
Mg	208.96	10.011	0.54	
Mn	133.98	9.923	0.33	
Hg	4.50	0.041	15.59	
Mo	1.77	0.017	15.00	
Nd	10.75	9.352	2.39	
Ni	79.38	9.944	0.03	
P	1.30	0.096	13.12	
K	8.43	24.926	0.47	
Sm	5.13	0.022	429.81	
Se	3.41	3.346	1.00	
Si	3.38	0.028	50.79	
Ag	15.35	0.006	88.79	
Na	32.35	34.202	0.47	
Sr	248.45	9.822	0.62	
S	0.91	0.261	2.84	
Ta	3.81	0.035	50.09	
Tl	4.56	0.626	14.14	
Th	1.10	0.252	20.30	
Sn	116.97	48.935	0.31	
Ti	3.56	0.002	184.39	
W	1.61	0.310	6.10	
U	5.49	4.340	12.68	
V	4.42	0.014	27.67	
Zn	303.03	9.883	0.18	
Zr	4.73	0.017	52.68	

ICP Analysis April 20, 1990 LMCS Check Standard

C975

Sample name : 82B38F
 Sample code 1 : SST2
 Sample code 2 : DIRECT
 Programme : SST 20-Apr-90 12:51:05

NAME	MV	INT	CONCEN	RSD
Al	3.65	4.383	1.02	
Sb	0.42	0.542	4.09	
As	2.98	1.541	1.58	
Be	4.33	0.027	7.42	
Bi	56.78	53.194	0.27	
B	5.74	0.073	8.75	
Cd	2.49	0.012	8.18	
Ca	0.75	0.012	1.13	
Ce	5.80	0.894	6.69	
Cr	1.66	0.101	3.43	
Co	0.26	-0.016	-28.87	
Cu	4.11	0.245	0.88	
Eu	214.54	9.844	0.27	
Fe	1.99	0.058	8.42	
La	12.23	147.007	0.12	
Pb	2.77	52.656	0.35	
Li	4.48	-0.009	-92.76	
Mg	0.59	0.007	1.12	
Mn	0.93	0.012	5.70	
Hg	5.03	0.077	12.82	
Mo	1.84	0.028	11.97	
Nd	6.15	1.166	9.43	
Ni	3.73	0.042	6.34	
P	1.57	0.348	7.05	
K	3.41	0.324	32.81	
Sm	9.44	10.068	0.70	
Se	1.92	0.345	6.23	
Si	4.23	0.612	2.13	
Ag	242.22	10.503	0.21	
Na	5.73	0.207	11.32	
Sr	3.99	0.011	7.19	
S	0.85	0.178	3.84	
Ta	4.29	0.240	4.62	
Tl	6.82	6.389	2.28	
Th	7.68	52.643	0.25	
Sn	1.46	0.093	3.77	
Ti	4.16	0.072	3.65	
W	1.41	0.050	27.41	
U	9.13	54.896	0.90	
V	6.37	0.253	1.91	
Zn	2.67	0.009	10.80	
Zr	5.18	0.170	4.96	

ICP Analysis April 20, 1990 LMCS Check Standard

F975

Sample name : 77C111
 Sample code 1 : SST3
 Sample code 2 : DIRECT
 Programme : SST 20-Apr-90 12:55:23

NAME	MV	INT	CONCEN	RSD
Al	21.46	51.617	0.96	
Si	0.47	1.346	9.18	
As	72.34	58.256	0.99	
Ba	4.39	0.032	6.18	
Be	236.97	9.796	1.10	
Bi	4.97	1.149	2.94	
B	5.73	0.073	6.37	
Cd	2.65	0.022	4.52	
Ca	0.76	0.012	1.04	
Ge	5.65	0.597	14.34	
Cr	1.54	0.064	6.14	
Co	0.29	0.107	7.50	
Cu	3.34	0.080	4.34	
Eu	4.39	0.012	9.70	
Fe	1.99	0.058	2.22	
La	0.37	0.042	10.83	
Pb	0.28	0.295	8.25	
Li	4.26	(-0.036	-1.82	
Mg	0.53	0.003	3.35	
Mn	1.05	0.021	2.32	
Hg	400.92	26.836	1.21	
Mo	290.47	50.511	1.15	
Nd	5.83	0.611	7.45	
Ni	7.53	0.540	1.73	
P	58.06	155.074	0.93	
K	3.47	0.607	17.46	
Sm	5.45	0.757	11.77	
Se	28.47	53.717	1.58	
Si	70.96	46.222	0.97	
Ag	22.77	0.349	0.78	
Na	5.93	0.389	10.38	
Sr	3.95	0.010	8.88	
S	40.66	153.072	1.54	
Ta	121.47	50.281	1.41	
Tl	25.51	53.958	1.38	
Th	1.25	1.371	4.97	
Sn	1.77	0.225	2.98	
Ti	443.79	51.756	0.91	
W	28.22	21.704	0.58	
U	6.34	16.179	1.29	
V	85.70	9.971	0.50	
Zn	3.63	0.041	0.93	
Zr	153.13	50.913	0.97	

ICP Analysis April 20, 1990 Reagent Blank

Sample code 1	:	REAGEN
Sample code 2	:	500-10
Sample code 3	:	000007
Programme	:	SST

20-Apr-90 13:05:41

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	1.99	-0.037	-0.780	-82.48	
Sb	0.37	-0.106	-2.236	-7.87	
As	1.10	0.005	0.103	367.91	
Ba	3.93	-0.002	-0.034	-84.05	
Be	0.70	-0.000	-0.006	-67.64	
Bi	3.80	-0.029	-0.619	-173.31	
B	4.85	0.003	0.066	14.10	
Cd	2.27	-0.002	-0.049	-39.02	
Ca	2.08	0.079	1.653	0.55	
Cr	5.29	-0.084	-1.754	-63.30	
Cr	1.31	-0.005	-0.103	-49.49	
Co	0.25	-0.052	-1.095	-16.01	
Cu	2.92	-0.009	-0.197	-28.14	
Eu	4.11	-0.001	-0.024	-82.12	
Fe	1.66	0.005	0.100	61.33	
La	0.35	-0.015	-0.303	-27.27	
Pb	0.27	-0.070	-1.474	-62.45	
Li	3.96	(-0.071	(-1.495	-3.41	
Mg	1.64	0.057	1.189	1.17	
Mn	0.79	0.001	0.028	19.80	
Hg	3.90	0.001	0.014	232.94	
Mo	1.67	-0.001	-0.021	-327.94	
Nd	5.45	-0.054	-1.144	-43.64	
Ni	9.99	0.862	18.109	1.25	
P	1.21	-0.006	-0.129	-289.87	
K	166.08)798.25) 16763	0.36	
Sm	5.09	-0.092	-1.927	-65.43	
Se	1.73	-0.030	-0.633	-26.94	
Si	3.41	0.052	1.091	38.05	
Ag	15.08	-0.007	-0.142	-53.89	
Na	6.06	0.507	10.656	6.10	
Sr	3.69	-0.001	-0.012	-107.46	
S	0.71	0.001	0.028	1365.02	
Ta	3.69	-0.015	-0.308	-94.57	
Tl	4.31	-0.004	-0.089	-809.82	
Th	1.06	-0.125	-2.622	-31.49	
Sn	1.25	0.003	0.068	34.51	
Ti	3.52	-0.004	-0.079	-51.63	
W	1.33	-0.019	-0.402	-45.70	
U	5.13	-0.686	-14.40	-54.78	
V	4.33	0.003	0.054	176.67	
Zn	2.53	0.004	0.094	16.46	
Zr	4.65	-0.010	-0.202	-78.68	

Dilution factor : 21.0000

ICP Analysis April 20, 1990 Core 7 Composite Fusion Digestion

Sample name : F977
 Sample code 1 : SAMPLE
 Sample code 2 : 100-10
 Sample code 3 : 000007
 Programme : SST

20-Apr-90 13:10:41

NAME	MV	INI	CONCEN	DILCOR	RSD
Al	3.86	4.921	497.02	0.43	
Sb	0.38	0.024	2.445	91.65	
As	1.12	0.020	2.065	42.33	
Br	4.05	0.007	0.752	38.15	
Be	0.72	0.000	0.040	63.21	
Bi	4.46	0.635	64.156	3.24	
B	4.93	0.010	0.978	29.19	
Cd	2.34	0.002	0.221	27.06	
Ca	1.94	0.072	7.242	1.17	
Ce	5.46	0.233	23.489	32.23	
Cr	1.38	0.014	1.459	10.95	
Co	0.25	-0.035	-3.512	-17.63	
Cu	3.04	0.017	1.697	23.85	
Eu	4.23	0.004	0.451	23.27	
Fe	3.85	0.365	36.878	1.62	
La	0.36	0.011	1.066	57.28	
Pb	0.27	-0.070	-7.080	-45.82	
Li	4.07	(-0.059	(-5.861	-5.10	
Mg	1.05	0.029	2.898	0.84	
Mn	1.67	0.067	6.764	0.33	
Hg	3.95	0.004	0.391	44.82	
Mo	1.72	0.007	0.695	26.95	
Nd	5.61	0.214	21.661	15.18	
Ni	5.11	0.223	22.515	1.29	
P	1.98	0.747	75.405	5.27	
K	36.15)160.91) 16252	1.15	
Sm	5.24	0.371	27.333	29.77	
Se	1.79	0.084	8.461	20.13	
Si	3.80	0.318	32.148	2.54	
Ag	15.55	0.015	1.495	40.02	
Na	9.03	3.184	321.55	0.18	
Sr	4.02	0.013	1.286	5.38	
S	0.74	0.035	3.579	15.16	
Ta	3.79	0.026	2.645	48.10	
Tl	4.52	0.528	53.297	8.30	
Th	1.09	0.143	14.488	30.93	
Sn	1.27	0.014	1.409	42.57	
Ti	3.62	0.008	0.841	32.59	
W	1.39	0.034	3.482	25.06	
U	5.29	1.616	163.26	28.52	
V	4.47	0.021	2.095	6.71	
Zn	2.64	0.008	0.829	6.67	
Zr	4.78	0.033	3.302	27.13	

Dilution factor : 101.000

ICP Analysis April 20, 1990 Core 7 Composite Fusion Digestion

Sample name : E977
 Sample code 1 : SAMPLE
 Sample code 2 : 500-10
 Sample code 3 : 000007
 Programme : SSI 20-Apr-90 13:14:44

NAME	MV	INT	CONCEN	DILCOR	XSD
Al	10.85	23.464	492.75	0.15	
Sb	0.38	0.073	1.325	52.92	
As	1.15	0.046	0.956	16.69	
Ba	4.12	0.012	0.254	17.16	
Be	0.72	0.001	0.012	68.14	
Bi	6.57	2.755	57.958	1.00	
B	5.10	0.023	0.476	9.87	
Cd	2.36	0.003	0.073	19.33	
Ca	7.06	0.330	6.934	0.35	
Cr	5.49	0.305	6.395	22.47	
Cr	1.51	0.055	1.147	9.86	
Co	0.26	-0.021	-0.449	-18.75	
Cu	3.20	0.051	1.075	6.40	
Eu	4.26	0.006	0.118	27.93	
Fe	12.13	1.730	36.339	0.43	
La	0.36	0.016	0.333	76.38	
Pb	0.27	0.042	0.884	208.17	
Li	4.09	(-0.056	(-1.166	-5.43	
Mg	1.69	0.059	1.240	0.29	
Mn	5.02	0.316	6.544	0.67	
Hg	3.96	0.004	0.093	48.41	
Ho	1.76	0.015	0.307	7.27	
Nd	5.63	0.248	5.205	42.91	
Ni	11.35	1.040	21.844	0.68	
P	4.97	3.635	76.330	0.91	
K	158.37)760.45) 15969	0.56	
Sm	5.27	0.330	6.940	20.49	
Se	1.83	0.166	3.476	21.07	
Si	5.16	1.249	26.235	1.26	
Ag	15.64	0.019	0.404	23.11	
Na	21.19	14.146	297.07	0.29	
Sr	4.97	0.051	1.066	1.14	
S	0.77	0.073	1.516	5.52	
Ta	3.84	0.046	0.975	26.56	
Tl	4.53	0.354	11.634	5.18	
Th	1.10	0.213	4.318	23.13	
Sn	1.29	0.022	0.463	13.01	
Ti	3.65	0.013	0.267	15.82	
W	1.43	0.060	1.250	13.60	
U	5.36	2.501	52.524	17.23	
V	4.51	0.026	0.539	8.11	
Zn	3.16	0.035	0.530	2.51	
Zr	4.83	0.052	1.083	15.04	

Dilution factor : 21.0000

ICP Analysis April 20, 1990 Duplicate of Core 7 Composite

Sample name : F978
 Sample code 1 : DUPSAN
 Sample code 2 : 100-10
 Sample code 3 : 000007
 Programme : 951 20-Apr-90 13:18:50

NAME	MV	INT	CONCEN	DILCOR	RSB
Al	4.31	6.122	618.38	0.98	
Sb	0.39	0.106	10.756	20.83	
As	1.14	0.042	4.212	22.61	
Ba	4.14	0.014	1.395	6.44	
Be	0.73	0.001	0.099	17.08	
Ri	4.64	0.817	82.553	5.89	
B	4.90	0.007	0.706	37.23	
Cd	2.38	0.005	0.473	43.39	
Ca	3.84	0.168	16.956	1.26	
Co	5.57	0.459	46.329	7.05	
Cr	1.42	0.028	2.808	12.92	
Co	0.26	-0.009	-0.946	-24.23	
Cu	3.11	0.031	3.170	6.07	
Eu	4.32	0.009	0.874	6.09	
Fe	4.28	0.437	44.114	1.56	
La	0.37	0.032	3.199	7.22	
Pb	0.27	0.084	8.506	38.19	
Li	4.15	(-0.049)	(-4.936)	-1.78	
Hg	2.12	0.080	8.090	1.18	
Mn	1.84	0.079	8.021	0.84	
Hg	3.96	0.005	0.471	17.29	
Mo	1.76	0.014	1.425	11.83	
Nd	5.72	0.412	41.606	6.91	
Ni	5.08	0.219	22.143	2.21	
P	2.16	0.915	92.397	1.06	
K	33.50	1147.90	14938	1.09	
Sn	5.35	0.533	53.879	8.76	
Se	1.83	0.159	16.042	16.03	
Si	3.92	0.396	40.019	0.36	
Ag	15.87	0.030	2.999	7.07	
Na	9.62	3.712	374.95	0.87	
Sr	4.15	0.018	1.828	1.91	
S	0.76	0.058	5.905	17.31	
Ta	3.90	0.075	7.605	7.72	
Tl	4.58	0.688	69.492	1.07	
Th	1.12	0.340	34.341	5.90	
Sn	1.31	0.031	3.089	19.57	
Ti	3.69	0.017	1.714	8.01	
W	1.43	0.060	6.038	5.12	
U	5.40	3.159	319.04	7.63	
V	4.56	0.031	3.179	4.87	
Zn	2.72	0.011	1.108	2.27	
Zr	4.85	0.056	5.681	4.28	

Dilution factor : 101.000

ICP Analysis

April 20, 1990

Duplicate of Core 7 Composite

Sample name : F978
 Sample code 1 : DUPSAM
 Sample code 2 : 500-10
 Sample code 3 : 000007
 Programme : GST 20-Apr-90 13:23:03

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	12.68	28.319	594.70	0.52	
Bb	0.39	0.106	2.236	56.77	
As	1.14	0.039	0.824	34.80	
Br	4.10	0.011	0.224	28.22	
Be	0.71	0.000	0.005	180.17	
Bi	7.01	3.195	67.104	2.03	
B	4.90	0.007	0.156	30.30	
Cd	2.35	0.003	0.061	17.10	
Ca	15.81	0.771	16.190	0.43	
Cr	5.46	0.239	4.816	46.72	
Cr	1.55	0.066	1.387	9.05	
Co	0.26	-0.027	-0.362	-37.73	
Cu	3.28	0.068	1.435	9.26	
Eu	4.22	0.004	0.083	54.08	
Fe	13.85	2.014	42.299	0.68	
La	0.36	0.021	0.443	64.95	
Pb	0.28	0.154	3.242	13.64	
Li	4.06	(-0.059	(-1.338	-8.24	
Hg	2.26	0.087	1.820	0.60	
Mn	5.73	0.369	7.753	0.62	
Hg	3.97	0.005	0.113	57.94	
Mo	1.76	0.014	0.294	12.77	
Nd	5.66	0.301	6.325	54.86	
Ni	10.73	0.959	20.131	1.31	
P	4.95	3.622	76.058	4.27	
K	146.19	1700.72	> 14715	0.65	
Sm	5.23	0.254	5.324	53.87	
Sr	1.83	0.174	3.659	4.66	
Si	5.46	1.450	30.460	1.90	
Ag	15.53	0.014	0.392	58.78	
Na	22.73	15.530	326.12	0.64	
Sr	5.27	0.063	1.321	2.41	
S	0.77	0.069	1.442	43.12	
Ta	3.81	0.036	0.747	34.83	
Tl	4.47	0.394	8.284	47.09	
Th	1.10	0.175	3.682	47.89	
Sn	1.30	0.026	0.548	52.47	
Ti	3.65	0.012	0.247	32.19	
W	1.44	0.069	1.453	10.20	
U	5.33	2.163	45.424	35.98	
V	4.43	0.016	0.334	55.50	
Zn	3.44	0.034	0.723	3.10	
Zr	4.79	0.037	0.783	34.05	

Dilution factor : 21.0000

ICP Analysis April 20, 1990 Spike of Core 7 Composite

Sample name : F970200
 Sample code 1 : SPIKE
 Sample code 2 : 100-10
 Sample code 3 : 000007
 Programme : SSI 20-Apr-90 13:29:43

NAME	MV	INT	CONCEN	DILCUR	RSD
Al	3.67	4.417	490.29	1.04	
Sb	0.43	0.770	85.434	1.89	
As	1.09	-0.004	-0.484	-290.67	
Ba	13.67	0.839	93.124	0.70	
Be	0.69	-0.001	-0.078	-11.77	
Bi	4.29	0.462	51.329	10.76	
B	15.53	0.840	93.188	0.71	
Cd	15.73	0.856	95.046	0.83	
Ca	19.05	0.935	103.75	0.93	
Ce	5.63	0.374	63.681	16.87	
Cr	4.00	0.798	88.590	0.70	
Co	0.43	0.658	73.045	1.86	
Cu	6.92	0.849	94.214	0.62	
Eu	4.10	-0.002	-0.201	-117.84	
Fe	8.86	1.192	132.35	0.26	
La	0.35	-0.022	-2.490	-35.29	
Pb	0.26	-0.140	-15.58	-15.00	
Li	10.90	0.750	83.231	0.59	
Mg	20.73	0.973	108.02	0.82	
Mn	13.09	0.918	101.86	0.51	
Hg	4.02	0.008	0.943	20.67	
Mo	1.67	-0.001	-0.136	-189.71	
Nd	5.84	0.618	68.621	34.43	
Ni	11.40	1.046	116.09	0.32	
P	1.83	0.597	66.275	7.40	
K	33.27	1146.78	16292	0.57	
Sm	5.02	-0.249	-27.62	-51.77	
Se	1.85	0.310	23.358	20.07	
Si	3.65	0.215	23.849	10.23	
Ag	14.07	-0.017	-1.851	-47.12	
Na	10.84	4.816	534.53	0.77	
Sr	25.21	0.863	95.796	0.86	
S	0.74	0.028	3.146	48.94	
Ia	3.67	-0.026	-2.876	-44.67	
Tl	4.30	-0.026	-2.919	-396.75	
Th	1.05	-0.167	-18.58	-42.32	
Sn	11.26	4.238	470.40	0.78	
Ti	3.48	-0.008	-0.276	-53.42	
W	1.35	-0.001	-0.120	-1242.1	
U	5.09	-1.172	-130.1	-65.91	
V	4.31	0.000	0.050	513.51	
Zn	28.48	0.858	95.210	0.70	
Zr	4.63	-0.018	-2.030	-62.93	

Dilution factor : 111.000

ICP Analysis April 20, 1990 Spike of Core 7 Composite

Sample name : F979
 Sample code 1 : SPIKE
 Sample code 2 : 500-10
 Sample code 3 : 000007
 Programme : SST

20-Apr-90 13:36:08

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	10.11	21.513	494.80	0.85	
Sb	0.44	0.958	22.045	1.52	
As	1.13	0.034	0.784	15.90	
Ba	16.00	0.862	19.825	0.92	
Be	0.72	0.000	0.007	27.15	
Bi	6.28	2.467	56.737	1.34	
B	15.77	0.858	19.729	0.93	
Cd	16.17	0.885	20.346	0.64	
Ca	23.64	1.166	26.813	1.00	
Ce	5.86	1.001	23.021	4.43	
Cr	4.19	0.857	19.718	1.42	
Co	0.45	0.745	17.135	5.39	
Cu	7.21	0.911	20.949	0.83	
Eu	4.26	0.006	0.132	9.58	
Fe	16.54	2.459	56.547	0.71	
La	0.36	0.012	0.273	38.49	
Pb	0.27	-0.007	-0.161	-173.30	
Li	11.15	0.780	17.929	0.90	
Hg	21.04	0.988	22.730	0.93	
Mn	16.33	1.159	26.661	0.85	
Hg	4.11	0.015	0.339	12.37	
Mo	1.75	0.013	0.300	8.15	
Nd	6.03	0.953	21.914	5.68	
Ni	17.32	1.822	41.897	1.06	
P	4.79	3.465	79.700	2.57	
K	145.58	1697.70	16047	0.86	
Sm	5.21	0.204	4.686	16.63	
Se	1.95	0.412	9.480	3.97	
Si	4.99	1.130	25.998	0.82	
Ag	15.48	0.012	0.271	20.44	
Na	21.96	14.837	341.24	0.95	
Sr	26.46	0.913	21.009	0.99	
S	0.79	0.098	2.262	8.79	
Ta	3.78	0.022	0.511	37.88	
Tl	4.51	0.506	11.649	14.08	
Th	1.10	0.183	4.216	15.68	
Gn	11.59	4.379	100.71	0.89	
Ti	3.62	0.008	0.193	16.25	
W	1.44	0.075	1.716	6.76	
U	5.32	1.968	45.275	9.19	
V	4.45	0.018	0.403	9.39	
Zn	29.64	0.896	20.605	0.60	
Zr	4.80	0.039	0.894	9.21	

Dilution factor : 23.0000

ICP Analysis April 20, 1990 Acid Blank

Sample name : HNU3
Programme : SST 20-Apr-90 13:52:41

NAME	MV	INT	CONCEN	RSD
Al	1.93	-0.197	-13.07	
Sb	0.37	-0.184	-9.12	
As	1.06	-0.029	-16.58	
Ba	3.80	-0.011	-4.99	
Be	0.68	-0.001	-21.71	
Bi	3.69	-0.148	-12.15	
R	4.49	(-0.025	-4.74	
Cd	2.20	-0.007	-6.17	
Ca	0.47	(-0.002	-2.71	
Ce	5.13	-0.395	-4.40	
Cr	1.27	-0.015	-18.67	
Co	0.25	(-0.054	-7.50	
Cu	2.83	-0.029	-4.04	
Eu	3.97	-0.008	-7.83	
Fe	1.55	(-0.014	-6.72	
La	0.35	-0.038	-20.69	
Pb	0.26	-0.154	-39.36	
Li	3.84	(-0.086	-1.34	
Mg	0.44	-0.001	-3.40	
Mn	0.74	-0.002	-15.23	
Hg	4.08	0.013	18.77	
Mo	1.62	-0.010	-16.10	
Nd	5.30	-0.330	-49.97	
Ni	3.27	-0.018	-16.50	
P	1.18	-0.035	-23.51	
K	3.32	-0.126	-53.75	
Gm	4.93	-0.456	-3.98	
Se	1.69	-0.115	-23.95	
Si	3.19	-0.101	-8.98	
Ag	14.58	-0.030	-4.58	
Na	5.28	-0.201	-5.26	
Sr	3.58	-0.005	-2.39	
S	0.69	-0.036	-42.12	
Ta	3.57	-0.066	-6.99	
Tl	4.17	-0.372	-14.35	
Th	1.03	-0.332	-3.67	
Sn	1.20	-0.016	-21.06	
Ti	3.41	-0.016	-10.01	
W	1.28	(-0.057	-11.38	
U	4.96	-2.960	-4.46	
V	4.20	-0.013	-34.75	
Zn	2.28	-0.003	-7.51	
Zr	4.55	-0.046	-6.33	

ICP Analysis April 20, 1990 LMCS Check Standard

Sample name : F980
Sample code 1 : 78C11J
Sample code 2 : SST1
Sample code 3 : DIRECT
Programme : SSI 20-Apr-90 13:56:56

NAME	MV	INI	CONCEN	RSO
Al	2.08	0.197	29.96	
Sb	1.07	9.983	1.31	
As	1.21	0.100	15.54	
Ba	139.44	9.695	1.32	
Be	0.73	0.001	18.65	
Bi	4.01	0.181	39.58	
B	130.27	9.820	1.22	
Cd	158.96	9.997	1.06	
Ca	197.85	9.949	1.26	
Ce	10.15	9.281	1.01	
Cr	32.05	9.185	1.39	
Co	2.51	9.018	1.76	
Cu	49.10	9.894	1.19	
Eu	4.72	0.027	6.94	
Fe	61.82	9.927	1.00	
La	0.38	0.073	5.45	
Pb	0.27	0.028	75.00	
Li	85.42	9.569	1.24	
Hg	209.66	10.045	1.09	
Mn	133.36	9.878	1.31	
Hg	4.24	0.023	25.10	
Mo	1.79	0.019	12.06	
Nd	10.65	9.079	2.37	
Ni	79.42	9.949	1.07	
P	1.32	0.106	9.81	
K	8.54	25.468	0.74	
Sm	5.18	0.117	115.18	
Se	3.39	9.305	1.66	
Si	3.40	0.042	47.78	
Ag	13.45	0.010	80.95	
Na	32.40	24.248	0.98	
Sr	248.75	9.834	1.24	
S	0.91	0.267	6.09	
Ta	3.82	0.040	44.90	
Tl	4.60	0.737	15.58	
Th	1.12	0.335	25.75	
Sn	117.49	49.156	0.87	
Ti	3.58	0.004	89.72	
W	1.62	0.218	6.51	
U	5.52	4.817	15.05	
V	4.45	0.018	36.74	
Zn	303.44	9.897	1.03	
Zr	4.76	0.028	48.50	

ICP Analysis

April 20, 1990

LMCS Check Standard

Sample name : F980
 Sample code 1 : 82B38F
 Sample code 2 : SST2
 Sample code 3 : DIRECT
 Programme : SST 20-Apr-90 14:01:13

NAME	MV	INT	CONCEN	RSD
Al	3.69	4.483	1.80	
Si	0.42	0.595	10.63	
As	2.98	1.546	2.51	
Ba	4.34	0.028	2.32	
Be	0.75	0.002	6.96	
Bi	57.60	54.016	2.14	
B	5.55	0.058	5.97	
Cd	2.50	0.012	8.79	
Ca	0.76	0.013	2.13	
Ce	5.81	0.910	2.23	
Cr	1.66	0.100	4.25	
Co	0.26	0.001	173.23	
Cu	4.12	0.248	1.87	
Eu	217.76	9.995	2.03	
Fe	2.02	0.063	5.86	
La	12.42	147.767	2.04	
Pb	2.80	53.288	2.00	
Li	4.34	-0.025	-21.64	
Mg	0.60	0.007	1.88	
Mn	0.93	0.012	1.90	
Hg	5.03	0.077	8.29	
Mo	1.84	0.028	6.85	
Nd	6.18	1.221	4.50	
Ni	3.71	0.040	1.37	
P	1.61	0.383	1.86	
K	3.52	0.852	7.86	
Sm	9.52	10.243	1.77	
Se	1.93	0.361	12.23	
Bi	4.24	0.617	2.31	
Ag	245.71	10.665	2.03	
Na	5.73	0.205	8.81	
Sr	3.99	0.012	1.89	
S	0.85	0.182	10.64	
Ta	4.29	0.241	1.16	
Tl	6.83	6.401	1.05	
Ih	7.80	53.594	2.08	
Sn	1.46	0.095	4.52	
Ii	4.17	0.073	1.30	
W	1.42	0.053	30.15	
U	9.20	55.873	1.93	
V	6.38	0.255	1.56	
Zn	2.69	0.010	2.83	
Zr	5.19	0.175	2.30	

ICP Analysis April 20, 1990 LMCS Check Standard

Sample name	:	F980		
Sample code 1	:	77C111		
Sample code 2	:	SST3		
Sample code 3	:	DIRECT		
Programme	:	SST	20-Apr-90 14:05:16	
NAME	MV	INT	CONCEN	RSID
Al	21.11	50.686	1.03	
Sb	0.47	1.283	8.34	
As	70.83	57.021	1.35	
Ba	4.37	0.030	8.58	
Be	237.31	9.810	0.85	
Bi	4.96	1.138	2.26	
B	5.53	0.056	5.84	
Cd	2.63	0.021	3.39	
Ca	0.75	0.012	2.01	
Ce	5.63	0.360	18.77	
Cr	1.51	0.054	7.83	
Co	0.29	0.090	6.84	
Cu	3.31	0.074	6.84	
Eu	4.38	0.011	16.67	
Fe	1.95	0.052	9.71	
Li	0.37	0.040	30.55	
Pb	0.28	0.295	16.50	
Li	4.23	(-0.039	-3.03	
Mg	0.52	0.003	4.70	
Mn	1.03	0.020	6.71	
Hg	392.48	26.265	1.49	
Mo	283.59	49.308	1.59	
Nd	5.83	0.599	11.16	
Ni	7.40	0.523	2.26	
P	59.43	756.396	2.06	
K	3.53	0.927	7.50	
Sm	5.43	0.201	16.41	
Se	27.97	52.717	1.76	
Si	69.63	45.311	1.53	
Ag	22.62	0.342	1.26	
Na	5.91	0.372	12.77	
Sr	3.94	0.009	11.44	
S	40.58	752.976	1.93	
Ta	119.13	49.282	1.65	
Tl	25.35	53.528	1.72	
In	1.24	1.299	4.42	
Sn	1.73	0.210	2.79	
Ti	432.84	50.584	0.74	
W	27.40	21.044	1.24	
U	6.28	15.285	2.23	
V	84.68	9.846	0.51	
Zn	3.58	0.039	1.96	
Zr	150.10	49.874	0.78	

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	E60044
PROCEDURE/Rev	LA-503-156/C-2
TECHNOLOGIST	R. Hale
DATE	Feb. 21, 1990
TEMPERATURE	23 C
STARTING TIME	0900
ENDING TIME	1500
CHEMIST	S. A. Catlow

Plutonium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Sample Composite 7	F0983
6	Duplicate Sample Composite 7	F0984
7	Sample Composite 14	F1001
8	Duplicate Sample Composite 14	F1002
9	Sample Composite 14	F1007
10	Duplicate Sample Composite 14	F1008
11	Sample Composite 15	F1025

	DESCRIPTION	LAB ID
12	Duplicate Sample Comp. 15	F1026
13	Sample Composite 15	F1031
14	Duplicate Sample Comp. 15	F1032
15	Spike Composite 15	F1027
16	Final LMCS Check Std.	F1028
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQT.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	16B43/1 uL			N/A
Spike	16B43/1 uL	F1032/1.0 mL		N/A

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-975 PU
File ID: SD4738.SPC

Counted on: 2/21/90 @14: 0
Detector/Geometry number: 4/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
	ID	Initial	Final	Initial	Final	Initial	Final	Initial
1	Pu236	1529.4	1627.2	362.610	362.610	20.000	12.525	10.000
2	Cm243	197.5	216.7	304.295	304.295	20.000	9.257	10.000
3	Pu238	2108.5	2157.0	231.404	231.404	20.000	13.223	10.000
	Am241							3.173
	Pu239							1.946
	Pu240							4.050

PEAK RESULTS

Peak	AEA	Peak Centroid				Count	Activity		
ID	Isotope	Fract.	Exp.	Obs.	Diff.	FWHM	Rate c/m	d/m	uCi/ea
1	Pu236	0.4389	5.756	5.774	-0.018	0.06	39.67	122.13	0.865E-04
	Cm243		5.706	5.774	0.012				0.116E-03
2	Pu238	0.0612	5.499	5.500	-0.001	0.04	5.53	36.47	0.164E-04
	Am241		5.480	5.500	-0.020				0.126E-04
3	Pu239	0.4999	5.143	5.157	-0.014	0.06	45.10	214.45	0.966E-04
	Pu240		5.144	5.157	-0.013				0.966E-04

DETECTOR CALIBRATION
Energy(MEV) = 4.070 + (0.0047)*Channel
Energy range (MeV): 4.070 TO 6.476
Efficiency = 0.2107 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	45200.0	100.000
Smoothed	45199.4	99.999
Composite fit	45195.0	99.999
Residuals	4.4	0.010

Analyzed by: -----
DM

Raw Data Dump for AEA Spectrum: SF:SD4730.SPC
 1 0. 0. 0. 0. 0. 1. 0. 0. 0. 0.
 11 1. 0. 0. 0. 0. 0. 3. 1. 0. 0.
 21 1. 0. 1. 0. 1. 0. 0. 0. 0. 1.
 31 1. 0. 0. 2. 1. 2. 4. 2. 0. 1.
 41 1. 1. 1. 1. 0. 1. 2. 0. 1. 2.
 51 2. 1. 1. 0. 0. 0. 0. 0. 1. 0.
 61 1. 0. 2. 0. 2. 1. 3. 0. 2. 0.
 71 0. 1. 2. 2. 2. 0. 1. 1. 1. 1.
 81 1. 0. 4. 4. 2. 1. 2. 1. 1. 1.
 91 1. 0. 2. 2. 3. 0. 1. 0. 2. 0.
 101 2. 2. 1. 3. 1. 0. 1. 3. 5. 2.
 111 3. 4. 3. 0. 1. 1. 2. 3. 0. 3.
 121 4. 1. 3. 2. 3. 4. 1. 2. 3. 4.
 131 3. 3. 2. 3. 2. 2. 4. 4. 6. 3.
 141 2. 0. 1. 0. 1. 2. 5. 2. 6. 7.
 151 10. 6. 7. 6. 7. 7. 2. 9. 5. 5.
 161 6. 10. 4. 6. 4. 9. 13. 9. 7. 11.
 171 9. 12. 10. 17. 16. 16. 16. 16. 18. 14.
 181 23. 17. 18. 23. 20. 25. 26. 33. 24. 34.
 191 29. 30. 29. 40. 32. 44. 52. 44. 52. 59.
 201 53. 61. 72. 90. 91. 120. 114. 115. 145. 162.
 211 198. 214. 275. 252. 309. 356. 440. 465. 543. 558.
 221 637. 720. 760. 899. 942. 1025. 1061. 1118. 1167. 1135.
 231 1103. 1123. 1071. 1001. 840. 706. 532. 440. 237. 191.
 241 132. 71. 45. 27. 18. 9. 6. 12. 6. 4.
 251 13. 1. 6. 7. 9. 13. 15. 11. 21. 16.
 261 9. 19. 18. 15. 15. 14. 12. 17. 21. 22.
 271 15. 20. 15. 16. 24. 17. 23. 21. 29. 24.
 281 26. 33. 30. 44. 49. 54. 62. 52. 66. 83.
 291 74. 71. 83. 92. 90. 120. 113. 102. 104. 113.
 301 115. 128. 135. 106. 120. 108. 114. 106. 95. 85.
 311 48. 50. 33. 29. 34. 17. 22. 26. 29. 21.
 321 32. 34. 37. 33. 36. 43. 47. 59. 65. 70.
 331 83. 71. 98. 129. 124. 146. 120. 170. 162. 210.
 341 237. 257. 272. 293. 367. 348. 398. 414. 410. 529.
 351 560. 593. 673. 642. 674. 709. 718. 682. 756. 784.
 361 838. 860. 822. 765. 773. 727. 602. 423. 320. 193.
 371 155. 86. 33. 25. 9. 4. 3. 0. 0. 0.
 381 0. 0. 1. 0. 0. 0. 0. 1. 0. 1.
 391 0. 0. 0. 0. 0. 0. 0. 1. 0. 1.
 401 0. 0. 0. 0. 1. 0. 0. 1. 1. 0.
 411 0. 1. 0. 0. 0. 0. 0. 0. 1. 0.
 421 0. 0. 0. 0. 0. 0. 0. 1. 0. 1.
 431 0. 0. 0. 1. 0. 0. 1. 0. 0. 0.
 441 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 451 0. 1. 0. 0. 0. 0. 0. 0. 0. 0.
 461 0. 1. 1. 0. 0. 0. 0. 0. 0. 0.
 471 0. 1. 0. 0. 2. 0. 0. 0. 2. 0.
 481 0. 0. 0. 3. 0. 0. 1. 1. 0. 0.
 491 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-976
File ID: SD5610.SPC

Counted on: 2/21/90 014: 0
Detector/Geometre number: 5/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
ID	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	2051.1	2090.0	364.404	364.404	20.000	7.453	10.000	4.302
2	187.8	187.1	306.570	306.570	20.000	7.400	10.000	2.889
3	38.4	16.2	269.027	269.027	12.000	4.544	6.000	3.636
4	596.0	397.6	233.123	233.123	16.000	9.713	8.000	5.134

PEAK RESULTS

Peak	AEA	Peak Centroid				Count	Activity		
ID	Isotope	Fract.	Exp.	Obs.	Diff.	FWHM	Rate c/m	d/m	uCi/ea
1	Cm244	0.7201	5.793	5.705	0.011	0.04	36.14	155.30	0.700E-04
	Cm243		5.786	5.705	0.001				0.959E-04
2	Pu238	0.0767	5.499	5.513	-0.014	0.04	3.85	22.98	0.104E-04
	Am241		5.480	5.513	-0.033				0.793E-05
3		0.0037		5.336		0.02	0.18	0.79	0.356E-06
4	Pu239	0.1995	5.143	5.167	-0.024	0.05	10.01	43.04	0.194E-04
	Pu240		5.144	5.167	-0.023				0.194E-04

DETECTOR CALIBRATION
Energy(MEV) = 4.072 + (0.0047)*Channel
Energy range (MeV): 4.072 TO 6.478
Efficiency = 0.2326 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	25113.0	100.000
Smoothed	25113.0	100.000
Composite fit	25092.6	99.919
Residuals	20.4	0.081

Analyzed by: -----
DM

Raw Data Dump for AEA Spectrum: SF:SD5610.SPC
 .1 0. 0. 0. 0. 0. 0. 0. 0. 0.
 11 0. 0. 1. 0. 0. 0. 0. 0. 0.
 21 1. 1. 0. 0. 1. 1. 0. 0. 0.
 31 0. 0. 0. 1. 0. 0. 0. 0. 0.
 41 0. 1. 0. 0. 0. 0. 1. 0. 0.
 51 0. 0. 0. 0. 2. 1. 0. 0. 0.
 61 0. 0. 1. 0. 0. 0. 3. 0. 0.
 71 1. 0. 0. 1. 0. 1. 1. 0. 2.
 81 0. 0. 0. 1. 0. 0. 1. 0. 2.
 91 2. 1. 0. 0. 1. 0. 1. 0. 0.
 101 1. 0. 1. 0. 1. 0. 1. 0. 1.
 111 0. 1. 1. 2. 1. 0. 0. 2. 1.
 121 0. 1. 0. 0. 0. 0. 0. 2. 0.
 131 2. 1. 2. 0. 0. 0. 1. 0. 2.
 141 1. 0. 2. 1. 0. 2. 2. 2. 1.
 151 2. 0. 1. 2. 4. 1. 3. 2. 1.
 161 0. 4. 0. 1. 0. 0. 3. 3. 7.
 171 0. 2. 3. 2. 4. 5. 1. 0. 1.
 181 3. 1. 3. 3. 2. 4. 3. 2. 5.
 191 3. 4. 5. 3. 2. 5. 1. 3. 4.
 201 4. 6. 5. 3. 4. 7. 0. 0. 13.
 211 15. 20. 13. 12. 33. 47. 54. 41. 33. 06.
 221 112. 137. 155. 154. 161. 235. 227. 278. 286. 311.
 231 351. 379. 347. 354. 267. 221. 192. 126. 04. 50.
 241 24. 17. 3. 2. 5. 2. 4. 0. 6. 12.
 251 8. 2. 9. 9. 7. 7. 0. 12. 4. 9.
 261 16. 15. 12. 5. 0. 10. 13. 13. 12. 10.
 271 13. 9. 12. 11. 8. 11. 9. 10. 7. 10.
 281 13. 11. 13. 19. 14. 17. 20. 22. 24. 39.
 291 38. 43. 55. 50. 45. 49. 49. 69. 72. 58.
 301 62. 36. 104. 103. 113. 112. 118. 99. 78. 56.
 311 55. 33. 15. 16. 13. 0. 6. 5. 2. 7.
 321 8. 6. 8. 14. 14. 7. 6. 14. 6. 14.
 331 15. 17. 15. 13. 13. 25. 15. 29. 33. 36.
 341 33. 39. 50. 73. 92. 126. 125. 194. 237. 294.
 351 345. 463. 490. 575. 608. 727. 756. 799. 862. 930.
 361 1023. 1151. 1219. 1218. 1179. 1050. 923. 715. 501. 291.
 371 194. 77. 38. 29. 9. 0. 2. 0. 0. 0.
 381 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 391 0. 0. 0. 0. 0. 0. 0. 1. 0. 0.
 401 0. 1. 0. 0. 0. 0. 0. 0. 0. 0.
 411 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 421 0. 0. 1. 1. 1. 2. 0. 1. 0. 1.
 431 0. 0. 0. 0. 0. 0. 0. 1. 0. 0.
 441 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 451 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 461 0. 0. 0. 0. 0. 0. 1. 0. 0. 1.
 471 0. 0. 2. 4. 0. 0. 0. 2. 1. 1.
 481 0. 0. 1. 0. 0. 0. 0. 1. 0. 0.
 491 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

1 LEGEND: RAW = MODELED PEAKS = 1,2,.., ETC

7637.6

4
....4.
.....4
.....4
.4

3
3

2
.2
...2
...2
2

1
.. 1
.....1
.....1....
.....1
.1.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-977 PU
File ID: SD6015.SPC

Counted on: 2/21/90 @14: 0
Detector/Geometry number: 6/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height Initial	Peak height Final	Peak center Initial	Peak center Final	FWHM	Initial	Final	Tau
1	1736.9	1780.2	363.361	363.361	20.000	12.144	10.000	4.559
2	130.3	134.0	305.024	305.024	24.000	9.637	12.000	1.795
3	142.7	39.0	269.397	269.397	12.000	1.817	6.000	3.177
4	2928.9	2976.5	231.448	231.448	20.000	11.741	10.000	4.014
5	24.1	19.7	151.793	151.793	32.000	52.739	16.000	14.027
6	10.3	10.3	24.372	24.372	20.000	10.236	10.000	1.788

PEAK RESULTS

Peak ID	Isotope	AEA Fract.	Peak Centroid Exr.	Peak Centroid Obs.	Diff.	FWHM	Count Rate c/m	d/m	Activity uCi/ea
1	Pu238	0.3661	5.755	5.747	0.009	0.06	36.14	188.04	0.847E-04
2	Am241	0.0378	5.480	5.478	0.002	0.04	3.73	20.23	0.911E-05
3		0.0027		5.314		0.01	0.26	1.33	0.601E-06
4	Pu239	0.5339	5.143	5.140	0.003	0.05	57.33	293.86	0.132E-03
	Pu240		5.144	5.140	0.004				0.132E-03
5	Np237	0.0074	4.781	4.773	0.008	0.24	0.73	4.20	0.193E-05
6	U 238	0.0022	4.200	4.187	0.013	0.05	0.21	1.42	0.638E-06

DETECTOR CALIBRATION
Energy(MEV) = 4.075 + (0.0046)*Channel
Energy range (MeV): 4.075 TO 6.430
Efficiency = 0.1931 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	40053.0	100.000
Smoothed	40051.6	99.997
Composite fit	49340.8	101.015
Residuals	-497.2	-1.018

Analyzed by: -----
DM

Raw Data Dump for AEA Spectrum: SP:SD6045.SPC
 1 0. 0. 0. 0. 0. 0. 3. 4. 5. 4.
 11 2. 3. 2. 6. 6. 4. 2. 5. 3. 5.
 21 4. 7. 5. 8. 3. 0. 1. 3. 4. 1.
 31 0. 0. 1. 0. 0. 1. 0. 0. 1. 0.
 41 0. 1. 0. 0. 1. 2. 0. 0. 1. 0.
 51 2. 1. 1. 1. 2. 0. 0. 0. 0. 0.
 61 1. 0. 3. 2. 0. 1. 0. 1. 2. 1.
 71 1. 2. 0. 0. 0. 1. 0. 0. 0. 1.
 81 0. 2. 1. 0. 0. 0. 2. 1. 1. 0.
 91 1. 2. 1. 0. 0. 0. 1. 2. 2. 0.
 101 2. 0. 0. 1. 2. 2. 1. 2. 0. 0.
 111 2. 3. 1. 3. 1. 2. 2. 5. 0. 0.
 121 0. 0. 1. 0. 1. 4. 2. 4. 1. 5.
 131 3. 5. 2. 3. 4. 5. 5. 6. 5. 9.
 141 13. 8. 3. 9. 12. 15. 8. 9. 15. 12.
 151 15. 13. 14. 16. 7. 6. 2. 6. 9. 10.
 161 4. 8. 8. 6. 7. 5. 5. 3. 6. 5.
 171 11. 8. 2. 6. 9. 7. 11. 11. 9. 9.
 181 10. 13. 15. 15. 13. 14. 5. 19. 12. 16.
 191 17. 18. 15. 17. 27. 29. 23. 36. 30. 30.
 201 47. 64. 61. 71. 65. 111. 129. 127. 154. 182.
 211 210. 223. 291. 346. 359. 450. 407. 592. 653. 735.
 221 854. 960. 1025. 1069. 1213. 1305. 1433. 1572. 1633. 1674.
 231 1565. [1679.] 1494. 1309. 1141. 926. 648. 459. 318. 201.
 241 108. 56. 35. 17. 9. 6. 2. 5. 6. 4.
 251 9. 10. 13. 14. 14. 14. 15. 12. 20. 15.
 261 14. 22. 11. 29. 27. 20. 32. 25. 23. 17.
 271 24. 20. 21. 20. 25. 12. 12. 10. 10. 10.
 281 15. 26. 21. 21. 37. 31. 35. 34. 16. 40.
 291 40. 55. 45. 47. 34. 47. 53. 60. 70. 49.
 301 65. 59. 82. 91. 73. 67. 65. 61. 56. 35.
 311 31. 19. 11. 12. 6. 15. 9. 3. 8. 10.
 321 6. 7. 5. 10. 7. 11. 17. 15. 20. 23.
 331 20. 29. 31. 37. 37. 48. 40. 73. 60. 91.
 341 101. 110. 133. 187. 195. 219. 252. 267. 363. 391.
 351 480. 552. 504. 657. 704. 700. 720. 825. 789. 901.
 361 900. "984. 963. 930. 931. 839. 632. 538. 418. 295.
 371 190. 111. 62. 31. 25. 6. 2. 2. 0. 0.
 381 0. 1. 0. 0. 0. 0. 1. 0. 0. 0.
 391 0. 1. 0. 0. 0. 0. 0. 0. 0. 0.
 401 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 411 0. 0. 0. 0. 0. 0. 0. 1. 0. 0.
 421 0. 0. 0. 0. 0. 0. 1. 0. 1. 0.
 431 0. 0. 1. 0. 0. 0. 0. 0. 0. 1.
 441 0. 0. 1. 0. 0. 0. 0. 0. 0. 0.
 451 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 461 1. 1. 0. 1. 1. 0. 0. 0. 1. 0.
 471 0. 2. 0. 2. 0. 1. 2. 0. 0. 0.
 481 0. 0. 1. 1. 2. 0. 0. 0. 0. 0.
 491 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

SPECTRUM SD6045.SPC
1 LEGEND: RAW = MODELED PEAKS = 1,2,... ETC

10543.3

୧୬୬

55555

.4
... 4
.....4
.....4...
.....4...
.....4
.

3
2
2
.2
.2
.2
.2
.1
.... 1
.....1
.....1..
.....1
.....1
1.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-97B FU
File ID: SD8094.SPC

Counted on: 2/21/90 @14: 0
Detector/Geometry number: 8/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
ID	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	1343.6	1359.3	361.013	361.013	20.000	10.822	10.000	4.263
2	186.1	172.4	307.794	307.794	10.000	16.048	20.000	18.040
3	161.2	28.7	268.155	268.155	12.000	2.000	6.000	0.200
4	3082.0	3069.2	232.090	232.090	20.000	9.978	10.000	4.710
5	287.1	292.8	193.187	193.187	36.000	24.187	18.000	14.002
6	10.0	17.5	154.418	154.418	20.000	6.440	10.000	0.977
7	9.7	8.9	29.763	29.763	24.000	18.175	12.000	4.575

PEAK RESULTS

Peak	AEA	Peak Centroid			Count	Activity			
ID	Isotope	Fract.	Exp.	Obs.	Diff.	FWHM	Rate c/m	d/m	uCi/ea
1	Pu236	0.2758	5.756	5.748	0.008	0.05	26.03	136.06	0.613E-04
2	Am241	0.0608	5.480	5.490	-0.010	0.22	5.74	31.28	0.141E-04
	Pu238		5.499	5.498	0.001				0.184E-04
3		0.0121		5.312		0.01	1.14	5.04	0.264E-05
4	Pu239	0.5690	5.143	5.142	0.001	0.05	53.70	275.11	0.124E-03
	Pu240		5.144	5.142	0.002				0.124E-03
5		0.0744		4.959		0.11	7.02	35.96	0.162E-04
6	Nr237	0.0057	4.781	4.777	0.004	0.03	0.53	3.14	0.142E-05
7	U 238	0.0022	4.200	4.191	0.009	0.09	0.21	1.41	0.633E-06

DETECTOR CALIBRATION
Energy(MEV) = 4.051 + (0.0047)*Channel
Energy range (MeV): 4.051 TO 6.458
Efficiency = 0.1952 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	47266.0	100.000
Smoothed	47264.8	99.997
Composite fit	47187.9	99.835
Residuals	76.9	0.163

Analyzed by: -----
DM

Raw Data Dump for AEA Spectrum: SP:SD0094.SPC

1	0.	0.	0.	0.	0.	0.	3.	3.	2.	3.
11	2.	3.	1.	3.	4.	0.	4.	2.	3.	1.
21	3.	1.	4.	4.	4.	6.	6.	9.	4.	5.
31	4.	2.	4.	8.	2.	0.	1.	2.	0.	1.
41	0.	3.	0.	0.	2.	0.	3.	2.	0.	2.
51	1.	1.	0.	0.	1.	0.	2.	0.	1.	0.
61	1.	1.	0.	4.	1.	1.	1.	1.	0.	2.
71	0.	1.	0.	4.	0.	1.	0.	4.	1.	0.
81	2.	0.	1.	3.	0.	0.	0.	0.	0.	0.
91	0.	0.	4.	1.	3.	2.	0.	0.	0.	3.
101	0.	0.	3.	2.	5.	2.	2.	2.	2.	2.
111	1.	3.	4.	3.	4.	1.	1.	4.	1.	5.
121	1.	4.	3.	5.	4.	1.	2.	5.	3.	5.
131	1.	1.	2.	4.	5.	6.	3.	2.	6.	7.
141	6.	1.	10.	11.	0.	10.	7.	8.	6.	11.
151	13.	11.	10.	14.	13.	8.	9.	9.	7.	4.
161	8.	6.	1.	5.	7.	0.	8.	8.	11.	17.
171	22.	22.	27.	29.	34.	51.	47.	49.	72.	66.
181	99.	105.	122.	127.	147.	151.	173.	160.	188.	179.
191	153.	159.	152.	164.	157.	150.	134.	139.	152.	131.
201	130.	138.	108.	143.	122.	129.	133.	146.	162.	145.
211	171.	173.	194.	241.	253.	268.	317.	425.	440.	523.
221	609.	689.	816.	969.	1066.	1228.	1467.	1590.	1744.	1820.†
231	1811.	1813.	1642.	1478.	1214.	971.	701.	448.	305.	175.
241	123.	52.	26.	26.	11.	11.	10.	8.	13.	6.
251	8.	8.	17.	11.	14.	12.	20.	18.	18.	19.
261	11.	14.	20.	18.	20.	19.	15.	31.	15.	24.
271	14.	19.	8.	13.	14.	11.	7.	13.	10.	14.
281	17.	18.	13.	19.	25.	31.	19.	30.	30.	36.
291	29.	41.	44.	43.	43.	66.	60.	64.	68.	74.
301	93.	76.	106.	107.	120.	94.	117.	108.	80.	80.
311	104.	68.	74.	66.	70.	74.	64.	75.	60.	70.
321	57.	59.	73.	58.	61.	63.	48.	61.	50.	37.
331	71.	70.	53.	62.	50.	62.	70.	55.	93.	67.
341	97.	90.	113.	136.	163.	213.	229.	210.	302.	371.
351	386.	450.	517.	511.	556.	654.	646.	706.	713.	766.
361	770.	771.	641.	545.	430.	322.	233.	159.	95.	48.
371	29.	7.	6.	2.	1.	0.	0.	0.	0.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
401	0.	0.	0.	0.	0.	0.	0.	1.	0.	0.
411	0.	0.	0.	0.	0.	1.	0.	0.	1.	0.
421	0.	0.	1.	0.	0.	0.	0.	0.	0.	0.
431	0.	0.	0.	1.	0.	0.	0.	0.	1.	0.
441	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
451	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
461	0.	0.	0.	2.	0.	0.	0.	0.	0.	0.
471	0.	0.	1.	0.	1.	0.	0.	0.	0.	0.
481	0.	0.	1.	0.	0.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.

SPECTRUM SD8094.SPC

1 LEGEND: RAW = MODELED PEAKS = 1,2,... ETC

10305.1

7
7
7
7

6
6
6
6
6

5
.5
....5.
4....5.
.5....
.....4.
3.....4.
3.....4.
3.....4.
3.....4.
3
3
3

2
.2
...2
..2.
.2.
2..
.1.
....1.
.....1.
.....1
....1

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-1027 SEG,COMP#11
File ID: SD3905.SPC

Counted on: 2/23/90 013: 0
 Detector/Geometry number: 3/ 1
 Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	0.6	8.2	477.905	477.985	16.000	3.741	8.000	1.008
2	1128.4	1147.1	362.320	362.320	24.000	15.712	12.000	6.931
3	159.1	150.8	303.816	303.816	24.000	15.039	12.000	4.365
4	318.1	64.2	265.136	265.136	12.000	5.150	6.000	4.368
5	1427.4	1427.5	231.420	231.420	20.000	14.803	10.000	7.609
6	4.8	4.1	149.091	149.091	40.000	214.793	20.000	19.946

PEAK RESULTS

Peak ID	AEA Isotope	AEA Fract.	Peak Centroid Exp.	Peak Centroid Obs.	Diff.	FWHM	Count Rate c/m	Activity d/m uCi/ea
1		0.0036		5.314		0.04	0.21	1.04 0.167E-03
2	Pu236	0.4184	5.756	5.759	-0.003	0.00	24.04	121.01 0.549E-04
3	Am241	0.0661	5.400	5.470	0.002	0.07	3.80	20.06 0.904E-05
4		0.0131		5.293		0.02	0.75	3.71 0.169E-05
5	Pu239	0.4928	5.143	5.131	0.012	0.07	28.32	140.59 0.633E-04
	Pu240		5.144	5.131	0.013			0.633E-04
6	Np237	0.0060	4.640	4.736	-0.096	1.03	0.34	28.32 0.120E-04
	Np237		4.781	4.736	0.045			0.380E-05

DETECTOR CALIBRATION
 Energy(MEV) = 4.020 + (0.0048)*Channel
 Energy range (MeV): 4.020 TO 6.477
 Efficiency = 0.2014 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	20560.0	100.000
Smoothed	20559.9	100.000
Composite fit	20729.7	100.594
Residuals	-149.8	-0.595

Analyzed by: -----
JA

Raw Data Dump for AEA Spectrum: SP:SD3985.SPC

1	0.	0.	0.	0.	0.	0.	1.	1.	1.
11	1.	1.	2.	1.	0.	1.	0.	0.	1.
21	0.	1.	1.	0.	0.	0.	0.	0.	0.
31	1.	0.	1.	2.	1.	1.	0.	0.	0.
41	1.	0.	1.	1.	0.	1.	3.	0.	2.
51	3.	0.	0.	1.	0.	1.	0.	2.	1.
61	1.	3.	0.	0.	1.	1.	0.	0.	1.
71	0.	0.	0.	2.	2.	1.	1.	0.	1.
81	0.	0.	0.	0.	2.	0.	1.	1.	0.
91	1.	1.	0.	1.	2.	1.	0.	2.	1.
101	1.	0.	2.	1.	3.	1.	0.	0.	1.
111	0.	0.	1.	0.	1.	1.	0.	1.	2.
121	1.	2.	0.	1.	0.	2.	3.	1.	2.
131	1.	3.	1.	2.	4.	3.	1.	2.	1.
141	1.	3.	0.	2.	3.	3.	5.	1.	3.
151	4.	1.	2.	0.	4.	1.	1.	1.	2.
161	2.	4.	2.	2.	1.	3.	3.	3.	1.
171	1.	5.	1.	1.	4.	2.	2.	1.	3.
181	4.	2.	2.	4.	4.	3.	1.	3.	2.
191	3.	4.	5.	9.	5.	5.	5.	4.	15.
201	11.	14.	18.	20.	23.	32.	19.	39.	62.
211	80.	89.	133.	156.	156.	170.	229.	271.	277.
221	409.	441.	406.	562.	611.	715.	703.	780.	829.
231	742.	700.	717.	620.	570.	461.	309.	312.	230.
241	139.	87.	60.	42.	33.	22.	16.	14.	13.
251	12.	11.	19.	16.	16.	12.	21.	16.	23.
261	28.	19.	29.	26.	20.	15.	27.	22.	15.
271	21.	20.	18.	17.	8.	13.	8.	17.	16.
281	11.	19.	23.	31.	26.	26.	31.	27.	36.
291	37.	44.	44.	47.	51.	61.	60.	78.	57.
301	97.	88.	88.	88.	84.	68.	73.	49.	51.
311	36.	28.	27.	17.	15.	9.	5.	3.	2.
321	6.	6.	5.	10.	5.	11.	10.	13.	16.
331	10.	15.	15.	29.	31.	34.	37.	46.	44.
341	56.	97.	85.	112.	120.	141.	177.	219.	244.
351	308.	352.	367.	473.	469.	519.	550.	571.	604.
361	632.	590.	590.	503.	502.	447.	396.	353.	225.
371	170.	99.	71.	55.	32.	13.	10.	8.	2.
381	1.	0.	0.	0.	0.	0.	0.	0.	0.
391	1.	0.	0.	0.	0.	0.	0.	0.	1.
401	0.	0.	0.	0.	0.	0.	0.	0.	0.
411	0.	1.	1.	1.	0.	0.	0.	0.	0.
421	1.	1.	0.	1.	2.	2.	1.	0.	1.
431	0.	0.	0.	3.	0.	0.	1.	0.	1.
441	0.	0.	0.	1.	0.	0.	1.	0.	0.
451	0.	1.	0.	0.	3.	1.	1.	1.	0.
461	1.	5.	4.	3.	2.	2.	4.	5.	1.
471	2.	0.	4.	4.	4.	4.	5.	0.	5.
481	4.	2.	1.	0.	1.	0.	0.	1.	0.
491	0.	0.	1.	0.	0.	0.	0.	0.	0.
511	0.	0.	0.	0.	0.	0.	0.	0.	0.

SPECTRUM SD3985.SPC

1 .LEGEND: RAW = MODELED PEAKS = 1,2,... ETC

5193.1

1
1
1
1
1

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F1028 SEG/COMP/#12
File ID: SD2764.SPC

Counted on: 2/26/90 @16: 0
Detector/Geometry number: 2/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height		Peak center		FWHM		Tau	
	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	17.5	17.8	473.739	473.739	20,000	12.220	10.000	9.236
2	5.1	5.0	428.101	428.101	20,000	11.636	10.000	5.122
3	2086.3	2109.6	361.933	361.933	20,000	11.319	10.000	5.232
4	273.4	275.1	304.347	304.347	20,000	11.433	10.000	3.991
5	213.2	45.0	266.291	266.291	12,000	3.220	6.000	5.095
6	2521.3	2522.6	231.196	231.196	20,000	11.637	10.000	6.630

PEAK RESULTS

Peak ID	Isotope	AEA Fract.	Peak Centroid			Count Rate c/m	d/m	Activity uCi/ea
			Exp.	Obs.	Diff.			
1		0.0034		4.299		0.06	0.31	1.49 0.673E-04
2		0.0010		6.004		0.05	0.09	0.46 0.206E-04
3	Pu236	0.4331	5.756	5.773	-0.017	0.05	38.79	193.20 0.871E-04
	Cm243		5.786	5.773	0.013			0.117E-03
4	Pu238	0.0628	5.499	5.503	-0.004	0.05	5.62	38.12 0.172E-04
	Am241		5.480	5.503	-0.023			0.132E-04
5		0.0044		5.324		0.02	0.39	1.91 0.050E-06
6	Pu239	0.4934	5.143	5.159	-0.016	0.05	44.37	216.66 0.973E-04
	Pu240		5.144	5.159	-0.015			0.976E-04

DETECTOR CALIBRATION
Energy(MEV) = 1.072 + (0.0047)*Channel
Energy range (MeV): 4.072 TO 6.479
Efficiency = 0.2048 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	44011.0	100.000
Smoothed	44010.2	99.990
Composite fit	44707.2	99.947
Residuals	23.0	0.051

Analyzed by: -----
VR

Raw Data Dump for AEA Spectrum: SP:SD2764.SPC

1	0.	0.	0.	0.	0.	1.	0.	0.	1.	0.
11	1.	0.	0.	0.	0.	0.	0.	0.	0.	1.
21	1.	0.	0.	0.	0.	0.	0.	0.	0.	2.
31	0.	0.	1.	0.	1.	1.	0.	0.	0.	0.
41	1.	0.	0.	0.	0.	0.	1.	1.	0.	0.
51	0.	2.	1.	0.	0.	0.	0.	0.	0.	1.
61	1.	3.	1.	1.	1.	0.	0.	1.	1.	0.
71	0.	1.	1.	1.	3.	1.	1.	0.	2.	0.
81	0.	0.	0.	1.	0.	1.	1.	0.	0.	1.
91	1.	1.	1.	1.	2.	0.	0.	2.	0.	0.
101	1.	0.	1.	1.	0.	2.	1.	0.	0.	2.
111	4.	0.	2.	4.	1.	2.	0.	0.	1.	1.
121	1.	2.	2.	3.	1.	1.	2.	2.	3.	1.
131	0.	1.	1.	2.	0.	1.	1.	2.	3.	0.
141	1.	3.	1.	2.	0.	1.	4.	0.	2.	4.
151	0.	1.	2.	1.	2.	0.	2.	6.	0.	3.
161	2.	3.	4.	5.	2.	4.	1.	5.	6.	6.
171	12.	11.	5.	5.	6.	4.	9.	5.	3.	3.
181	3.	4.	13.	9.	7.	10.	8.	5.	7.	10.
191	6.	5.	7.	11.	11.	11.	3.	10.	11.	17.
201	7.	22.	18.	24.	26.	26.	39.	52.	52.	73.
211	82.	114.	116.	168.	235.	273.	323.	412.	444.	493.
221	604.	690.	790.	943.	1023.	1250.	1321.	1308.	1440.	1441.
231	1474.	1388.	1228.	1030.	840.	641.	545.	376.	222.	130.
241	94.	42.	35.	18.	8.	11.	0.	8.	6.	12.
251	14.	11.	15.	4.	10.	17.	7.	19.	17.	13.
261	23.	22.	18.	26.	19.	24.	19.	20.	29.	14.
271	10.	9.	6.	8.	3.	3.	14.	16.	9.	15.
281	20.	18.	21.	25.	29.	26.	36.	43.	43.	62.
291	63.	65.	80.	82.	83.	83.	108.	110.	120.	126.
301	150.	152.	162.	162.	150.	135.	129.	86.	71.	71.
311	44.	27.	18.	19.	13.	15.	12.	6.	5.	9.
321	4.	6.	6.	7.	9.	14.	6.	16.	8.	14.
331	17.	15.	16.	19.	22.	31.	31.	47.	62.	69.
341	77.	95.	120.	160.	195.	256.	294.	365.	427.	475.
351	561.	656.	689.	765.	810.	876.	970.	1076.	1135.	1149.
361	1186.	1204.	1127.	1008.	814.	668.	520.	396.	199.	139.
371	82.	57.	23.	19.	7.	0.	2.	1.	1.	0.
381	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
391	0.	0.	0.	0.	0.	0.	0.	0.	1.	0.
401	1.	0.	0.	0.	1.	0.	0.	0.	1.	0.
411	0.	0.	0.	1.	1.	1.	1.	0.	3.	4.
421	2.	1.	3.	1.	3.	2.	4.	3.	2.	4.
431	1.	1.	2.	0.	0.	2.	0.	0.	0.	0.
441	1.	0.	0.	0.	0.	0.	0.	0.	0.	0.
451	0.	1.	0.	1.	1.	0.	1.	1.	2.	2.
461	2.	4.	3.	1.	5.	7.	10.	6.	6.	13.
471	13.	12.	5.	11.	8.	8.	6.	9.	6.	3.
481	2.	0.	1.	2.	1.	0.	0.	0.	0.	0.
491	0.	0.	0.	0.	0.	0.	0.	0.	0.	0.
511	0.	0.								

SPECTRUM SP2764, SPC

1 LEGEND: -RAW = ... MODELED PEAKS = 1,2,... ETC

9056.B

6
.....6
.....6.
.....
.....6.

卷之三

2
2
2

1
1
1

missed many
outstanding areas
which probably
should have been
filled this year.
(1956)

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	E60044
PROCEDURE/REV	LA-503-156/C-2
TECHNOLOGIST	R. Hale
DATE	Feb. 22, 1990
TEMPERATURE	24 C
STARTING TIME	0900 02-21-90
ENDING TIME	1533 02-22-90
CHEMIST	S. A. Catlow

Americium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Sample Composite 14	F1001
6	Duplicate Sample Composite 14	F1002
7	Sample Composite 14	F1007
8	Duplicate Sample Composite 14	F1008
9	Sample Composite 6	F0923
10	Sample Composite 15	F1025
11	Duplicate Sample Composite 15	F1026

	DESCRIPTION	LAB ID
12	Sample Composite 15	F1031
13	Duplicate Sample Comp. 15	F1032
14	Spike Composite 15	F1033
15	Sample Composite 7	F0983
16	Duplicate Sample Comp. 7	F0984
17	Final LMCS Check Std.	F1034
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	16B43/10 ul			N/A
Spike	16B43/10 ul	F1032/1 ml		N/A

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-975 SEG.COMP#7 AM
File ID: SDJ001.SPC

Counted on: 2/27/90 020: 0
Detector/Geometry number: 3/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak ID	Peak height Initial	Peak height Final	Peak center Initial	Peak center Final	FWHM Initial	FWHM Final	Tau Initial	Tau Final
1	1421.0	1419.0	303.091	303.091	24.000	16.601	12.000	6.741
2	1724.3	1705.6	257.236	257.236	20.000	15.123	10.000	6.115
3	9.0	9.9	110.940	110.940	100.000	2.000	94.000	0.200
4	0.7	0.1	93.205	93.205	12.000	0.200	6.000	0.200

PEAK RESULTS

Peak ID Isotope	AEA Fract.	Peak Centroid Exp.	Peak Centroid Obs.	FWHM Diff.	Count Rate c/m	Activity d/m	Activity uCi/ea
1 Am241	0.4300	5.400	5.475	0.005	31.13	164.41	0.741E-04
2 Am243	0.5640	5.234	5.255	-0.021	40.00	1045.40	0.031E-03
3	0.0052		4.591		0.30	1.00	0.046E-06
4	0.0000		4.468		0.00	0.00	0.100E-08

DETECTOR CALIBRATION
Energy(MEV) = 1.020 + (0.0048)*Channel
Energy range (MeV): 4.020 TO 6.477
Efficiency = 0.2014 CPM/DFM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	37304.0	100.000
Smoothed	37304.0	100.000
Composite fit	36194.4	96.818
Residuals	1189.5	3.182

Analyzed by: -----
VR

1,LEGEND: .RAW = MODELED PEAKS = 1,2,... ETC

6547.0

3
3
3
4
3
3
3

.

.

.

2.

....2

.....2

.....2

.....2.

.....2.

..2.1....

.....1

.....1

.....1

.....1

1.

Raw Data Number for AEA Spectrum: SP:SD3001,SP001

SP:SD3001.SPC

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-976 SEG.COMP#8 AM
File ID: SD0116.SPC

Counted on: 2/27/90 020:0
Detector/Geometry number: 8/1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
ID	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	100.4	102.9	304.971	304.971	20.000	13.033	10.000	3.050
2	1040.5	1030.3	260.517	240.517	20.000	12.010	10.000	3.713
3	4.8	3.3	152.554	152.554	36.000	422.341	10.000	30.603

PEAK RESULTS

Peak	ID	AEA	Peak Centroid			Count	Activity		
	Isotope	Fract.	Exp.	Obs.	Diff.	Rate c/m	d/m	uCi/ea	
1	Pu239	0.0961	5.422	5.480	0.017	0.07	2.45	10.75	0.844E-05
	Am241		5.400	5.400	-0.000				0.647E-05
2	Am243	0.8904	5.234	5.272	-0.038	0.06	22.70	1137.11	0.512E-03
3	Np237	0.0135	4.640	4.764	-0.124	1.99	0.34	31.45	0.143E-04
	Np237		4.781	4.764	0.017				0.903E-06

DETECTOR CALIBRATION
Energy(MEV) = 4.047 + (0.0047)*Channel
Energy range (MeV): 4.047 TO 6.454
Efficiency = 0.1015 CPM/DPM


TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	13240.0	100.000
Smoothed	13240.0	100.000
Composite fit	12740.4	96.287
Residuals	491.5	3.712

Analyzed by: -----
VR

1 LEGEND: RAW = MODELED PEAKS = 1,2,.., ETC

4043.6



Raw Data Dump for ACA Spectrum: SP:SIDC16,SPCC

Hy 711 - 608c

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-977 SEG.COMPT#2 AM
File ID: SD4760.GPC

Counted on: 2/27/90 @20: 0
Detector/Geometry number: 4/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
ID	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	7.6	5.8	349.183	349.183	12.000	22.313	6.000	0.000
2	676.4	662.3	302.574	302.574	24.000	14.510	12.000	5.666
3	3315.0	3282.1	257.449	257.449	20.000	12.839	10.000	5.811
4	0.0	0.1	145.533	145.533	0.000	0.200	0.000	0.200

PEAK RESULTS

Peak	AEA	Peak Centroid				Count	Activity		
ID	Isotope	Fract.	Exp.	Obs.	Diff.	FWHM	Rate c/m	d/m	uCi/ea
1	Ra224	0.0241	5.680	5.705	-0.025	0.10	2.07	9.21	0.415E-05
2	Pu238	0.1758	5.499	5.405	0.014	0.07	13.98	81.07	0.365E-04
	Am241		5.480	5.405	-0.005				0.200E-04
3	Am243	0.7981	5.234	5.273	-0.039	0.06	63.48	2400.58	0.108E-02
4		0.0000		4.747		0.00	0.00	0.00	0.929E-09

DETECTOR CALIBRATION
Energy(MEV) = 4.063 + (0.0047)*Channel
Energy range (MeV): 4.063 TO 6.470
Efficiency = 0.2396 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	40010.0	100.000
Smoothed	40009.0	99.997
Composite fit	39769.8	99.400
Residuals	239.2	0.598

Analyzed by: _____
VR

Raw Data Dump for AEA Spectrum: SP:SD4760.SPC
 1 0. 0. 0. 0. 0. 1. 1. 0. 3. 2.
 11 0. 1. 0. 1. 2. 0. 2. 0. 1. 1.
 21 4. 0. 1. 1. 2. 0. 0. 1. 1. 1.
 31 1. 1. 0. 0. 1. 0. 0. 0. 1. 1.
 41 2. 0. 0. 1. 0. 0. 0. 2. 2. 1.
 51 0. 0. 0. 0. 1. 1. 1. 1. 2. 0.
 61 1. 4. 1. 1. 0. 0. 0. 0. 0. 1.
 71 0. 2. 1. 0. 3. 0. 1. 2. 4. 1.
 81 1. 2. 0. 2. 1. 2. 1. 1. 0. 0.
 91 2. 0. 1. 0. 1. 1. 2. 1. 0. 1.
 101 2. 3. 1. 1. 2. 1. 3. 1. 1. 0.
 111 1. 1. 1. 2. 0. 2. 1. 0. 1. 2.
 121 3. 3. 3. 1. 1. 0. 2. 0. 0. 1.
 131 4. 2. 3. 4. 1. 3. 2. 2. 4. 3.
 141 3. 1. 2. 2. 5. 2. 5. 2. 1. 1.
 151 4. 1. 1. 1. 1. 1. 2. 1. 3. 2.
 161 3. 3. 3. 2. 1. 6. 3. 2. 3. 2.
 171 4. 4. 2. 7. 3. 8. 2. 4. 7. 9.
 181 8. 4. 7. 6. 6. 6. 3. 6. 6. 8.
 191 16. 13. 8. 11. 10. 9. 17. 16. 19. 17.
 201 0. 16. 18. 17. 12. 16. 7. 22. 23. 17.
 211 25. 30. 25. 34. 29. 30. 32. 35. 41. 36.
 221 39. 37. 48. 64. 52. 63. 71. 60. 84. 82.
 231 102. 99. 116. 148. 150. 177. 223. 250. 311. 326.
 241 337. 439. 489. 571. 646. 743. 826. 965. 1155. 1255.
 251 1388. 1533. 1619. 1796. 1815. 1900. 1953. 1814. 1705. 1490.
 261 1201. 951. 725. 534. 398. 284. 224. 171. 166. 113.
 271 110. 121. 97. 68. 61. 52. 50. 37. 41. 43.
 281 42. 53. 49. 52. 69. 72. 81. 106. 127. 124.
 291 144. 188. 175. 209. 267. 279. 313. 357. 359. 306.
 301 400. 379. 378. 370. 284. 254. 212. 175. 142. 120.
 311 91. 76. 56. 44. 36. 26. 14. 22. 11. 7.
 321 6. 4. 3. 0. 0. 0. 1. 1. 1. 0.
 331 3. 0. 1. 0. 2. 2. 0. 1. 1. 0.
 341 0. 3. 1. 4. 3. 4. 4. 4. 2. 3.
 351 4. 1. 3. 1. 1. 1. 2. 1. 1. 3.
 361 0. 0. 0. 2. 2. 1. 1. 1. 0. 1.
 371 0. 0. 0. 1. 0. 0. 0. 0. 0. 0.
 381 0. 0. 0. 0. 0. 1. 0. 0. 0. 0.
 391 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 401 0. 0. 0. 0. 0. 0. 0. 0. 0. 1.
 411 0. 0. 0. 1. 1. 0. 0. 0. 0. 0.
 421 1. 0. 2. 2. 0. 0. 2. 2. 0. 0.
 431 1. 4. 2. 0. 1. 0. 2. 1. 0. 0.
 441 1. 0. 0. 1. 0. 0. 0. 0. 0. 0.
 451 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 461 0. 0. 1. 0. 0. 1. 0. 1. 0. 2.
 471 0. 3. 1. 1. 1. 0. 0. 0. 1. 0.
 481 1. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 491 0. 1. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

F978-6182

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F978 AM
File ID: SD8114.SPC

Counted on: 2/27/90 @10: 0
Detector/Geometry number: 8/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
ID	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	401.1	391.1	304.981	304.981	24.000	13.677	12.000	3.566
2	1545.1	1488.9	259.840	259.840	20.000	13.023	10.000	3.791

PEAK RESULTS

Peak	AEA	Peak Centroid			Count	Activity		
ID Isotope	Fract.	Expt.	Obs.	Diff.	Rate c/m	d/m	uCi/ea	
1 Pu238	0.2168	5.499	5.481	0.018	0.06	7.46	72.43	0.326E-04
Am241		5.480	5.481	-0.001				0.250E-04
2 Am243	0.7832	5.234	5.268	-0.034	0.06	34.19	1712.73	0.772E-03

DETECTOR CALIBRATION
Energy(MEV) = 4.047 + (0.0047)*Channel
Energy range (MeV): 4.047 TO 6.454
Efficiency = 0.1815 CPM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	22400.0	100.000
Smoothed	22399.3	99.997
Composite fit	21829.7	97.454
Residuals	569.6	2.543

Analyzed by: -----
MAX

1 LEGEND: RAW = MODELED PEAKS = 1,2r.., ETC

5802.6

2
2
..2.
.....2....
.....2..
.....2..... 2
.....2.....2
1.....2.....2.
.1.2.....
....1
.....1
.....1
...1

Raw Data Dump for AEA Spectrum: SP:SD8114.SPC
 - 1 0. 0. 0. 0. 0. 0. 2. 1. 0. 1.
 11 0. 0. 3. 0. 2. 1. 1. 0. 1. 0.
 21 0. 0. 0. 1. 0. 2. 0. 0. 1. 0.
 31 1. 1. 0. 1. 1. 3. 1. 0. 1. 1.
 41 2. 0. 0. 1. 0. 0. 3. 0. 0. 1.
 51 0. 0. 0. 2. 1. 1. 2. 2. 1. 2.
 61 1. 1. 2. 0. 0. 1. 1. 1. 1. 1.
 71 1. 3. 2. 0. 1. 0. 0. 0. 2. 0.
 81 2. 1. 1. 1. 0. 1. 0. 1. 2. 1.
 91 1. 1. 2. 0. 1. 2. 1. 1. 0. 2.
 101 0. 1. 1. 0. 0. 0. 1. 1. 0. 3.
 111 0. 1. 0. 3. 0. 1. 1. 1. 0. 2.
 121 2. 0. 0. 0. 1. 0. 1. 0. 1. 2.
 131 1. 1. 3. 2. 2. 2. 1. 4. 0. 0.
 141 1. 2. 2. 0. 3. 1. 2. 2. 1. 2.
 151 2. 3. 0. 3. 3. 0. 2. 0. 1. 2.
 161 3. 3. 0. 2. 0. 1. 2. 1. 2. 0.
 171 1. 3. 0. 2. 2. 1. 1. 3. 0. 1.
 181 0. 3. 1. 3. 5. 1. 2. 1. 4. 4.
 191 1. 1. 1. 0. 2. 3. 5. 2. 3. 4.
 201 3. 5. 6. 6. 2. 5. 6. 11. 5. 7.
 211 11. 18. 9. 25. 30. 31. 31. 29. 47. 71.
 221 60. 70. 81. 90. 126. 123. 155. 123. 159. 162.
 231 158. 157. 168. 163. 161. 156. 146. 151. 170. 175.
 241 203. 220. 201. 224. 256. 291. 320. 338. 369. 430.
 251 455. 572. 622. 648. 749. 769. 858. 914. 953. 877.
 261 778. 698. 619. 519. 397. 281. 190. 163. 125. 110.
 271 103. 101. 88. 88. 62. 67. 67. 55. 47. 55.
 281 42. 43. 45. 46. 31. 42. 50. 52. 57. 80.
 291 92. 88. 99. 106. 87. 146. 155. 148. 164. 182.
 301 194. 219. 250. 256. 211. 207. 199. 158. 149. 89.
 311 71. 73. 58. 44. 23. 20. 16. 11. 5. 13.
 321 4. 1. 1. 1. 0. 1. 0. 2. 0. 1.
 331 0. 1. 1. 0. 1. 0. 0. 1. 0. 1.
 341 0. 0. 1. 1. 0. 2. 2. 2. 0. 0.
 351 4. 2. 2. 1. 4. 0. 0. 2. 3. 1.
 361 0. 1. 1. 1. 1. 1. 1. 3. 1. 0.
 371 2. 0. 1. 2. 0. 0. 0. 1. 0. 1.
 381 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 391 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 401 0. 0. 0. 0. 0. 0. 0. 0. 0. 1.
 411 0. 0. 0. 0. 0. 1. 0. 0. 0. 0.
 421 0. 0. 0. 0. 1. 1. 0. 0. 0. 0.
 431 1. 1. 3. 1. 1. 0. 0. 1. 0. 0.
 441 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 451 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 461 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 471 0. 0. 0. 0. 0. 0. 1. 0. 1. 0.
 481 1. 0. 0. 0. 1. 0. 0. 0. 0. 0.
 491 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 511 0. 0.

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F1033 SEC/COMP#17
File ID: SD5627.SPC

Counted on: 2/26/90 @16: 0
Detector/Geometry number: 5/ 1
Count time: 30000. Sec

PEAK ANALYSIS

Peak	Peak height		Peak center		FWHM		Tau	
ID	Initial	Final	Initial	Final	Initial	Final	Initial	Final
1	2516.1	2505.7	303.215	303.215	20.000	14.473	10.000	4.314
2	3353.5	3365.0	257.501	257.501	20.000	12.250	10.000	3.820
3	0.2	6.4	158.503	158.503	64.000	2.000	32.000	0.200

PEAK RESULTS

Peak	ID	Isotope	AEA	Peak	Centroid	Count	Activity
			Fract.	Exr.	Obs.	Rate c/m	d/m uCi/ea
1	Pu239		0.4422	5.499	5.491	58.60	348.12 0.157E-03
	Am241			5.400	5.491	-0.011	0.120E-03
2			0.5560		5.274	72.69	315.16 0.142E-03
3	Np237		0.0019	4.701	4.011	0.25	1.23 0.553E-04

DETECTOR CALIBRATION
Energy(MEV) = 4.066 + (0.0017)*Channel
Energy range (MeV): 4.066 TO 6.472
Efficiency = 0.2338 CFM/DPM

TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	66771.0	100.000
Smoothed	66770.7	100.000
Composite fit	66260.3	99.247
Residuals	502.3	0.752

Analyzed by: -----
VR

1 LEGEND: RAW = MODELED PEAKS = 1,2,... ETC

11515.6

11515.6

.2
.2
...2
....2
.....2
.....2..
1.....2..
.1.....2..
.1.....2....
2.....1...
.....1
.....1
.....1
.....1
.

Raw Data		Number	for AEA Spectrum:	SP:SIM5627.SPC
1	1	0	0	0
11	11	0	0	0
21	21	1	1	1
31	31	0	1	0
41	41	0	0	0
51	51	0	0	0
61	61	0	0	0
71	71	0	0	0
81	81	0	0	0
91	91	0	0	0
101	101	1	0	1
111	111	1	0	0
121	121	1	0	0
131	131	2	0	0
141	141	2	0	0
151	151	3	0	0
161	161	2	0	0
171	171	6	0	0
181	181	7	0	0
191	191	5	0	0
201	201	24	0	0
211	211	43	0	0
221	221	94	0	0
231	231	24	0	0
241	241	630	0	0
251	251	1303	0	0
261	261	1610	0	0
271	271	1293	0	0
281	281	1063	0	0
291	291	800	0	0
301	301	535	0	0
311	311	412	0	0
321	321	330	0	0
331	331	298	0	0
341	341	212	0	0
351	351	179	0	0
361	361	170	0	0
371	371	203	0	0
381	381	210	0	0
391	391	310	0	0
401	401	379	0	0
411	411	347	0	0
421	421	363	0	0
431	431	420	0	0
441	441	457	0	0
451	451	479	0	0
461	461	540	0	0
471	471	610	0	0
481	481	1248	0	0
491	491	1301	0	0
511	511	1565	0	0

GENERAL ALPHA ENERGY ANALYSIS
Rev. 1.10

DATA REDUCTION REPORT

SAMPLE
F-1034 SEC.COMPFIC A
File ID: SD2739.SPC

Counted on: 2/27/90 @20: 0
Detector/Geometry number: 2/ 1
Count time: 30000. Sec.

PEAK ANALYSIS

Peak		Peak height		Peak center		FWHM		Tau	
ID		Initial	Final	Initial	Final	Initial	Final	Initial	Final
1		430.1	405.0	300.091	300.091	20.000	15.848	10.000	5.297
2		003.7	049.9	255.143	255.143	20.000	14.350	10.000	2.509

PEAK RESULTS

Peak		AEA	Peak Centroid		Count		Activite		
ID	Isotope	Fract.	Exp.	Obs.	Diff.	Rate c/m	d/m	uCi/ea	
1	Pu238	0.3733	5.499	5.402	0.017	0.07	15.75	95.72	0.431E-04
	Am241			5.400	5.402	-0.002			0.320E-04
2	Am243	0.6267	5.231	5.247	-0.016	0.07	26.43	1051.70	0.474E-03

DETECTOR CALIBRATION
Energy(MEV) = 4.068 + (0.0047)*Channel
Energy range (MeV): 4.068 TO 6.475
Efficiency = 0.2205 CPM/DPM


TOTAL COUNT DATA:

Item	Total	% Recovery
Raw spectrum	20909.0	100.000
Smoothed	20909.0	100.000
Composite fit	21091.0	100.484
Residuals	-102.0	-0.166

Analyzed by: -----
VR

1 LEGEND: "RAW" MODELED PEAKS = 1,2,..., ETC.

3300,6



Raw Data Dump for AEA Spectrum: SP:SD2769.SPC
 1 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 11 0. 1. 1. 0. 0. 1. 0. 1. 1. 1.
 21 0. 0. 0. 0. 0. 0. 0. 0. 1. 1.
 31 0. 1. 0. 0. 1. 0. 0. 0. 0. 0.
 41 0. 0. 1. 3. 1. 0. 0. 1. 0. 0.
 51 1. 0. 1. 0. 0. 0. 0. 0. 1. 0.
 61 0. 0. 3. 0. 3. 1. 0. 0. 1. 1.
 71 0. 1. 0. 3. 1. 0. 0. 1. 1. 1.
 81 1. 2. 2. 0. 0. 0. 0. 2. 1. 1.
 91 0. 3. 1. 0. 2. 0. 2. 2. 1. 0.
 101 1. 0. 0. 0. 1. 2. 0. 2. 0. 3.
 111 0. 0. 0. 0. 1. 1. 0. 2. 1. 0.
 121 2. 0. 2. 2. 0. 3. 1. 3. 2. 1.
 131 1. 2. 1. 1. 2. 0. 3. 2. 1. 0.
 141 1. 5. 5. 1. 2. 1. 4. 3. 1. 1.
 151 3. 3. 3. 4. 0. 5. 0. 2. 6. 0.
 161 6. 3. 6. 1. 1. 6. 5. 5. 5. 5.
 171 6. 0. 5. 7. 4. 6. 13. 6. 2. 10.
 181 6. 9. 8. 2. 9. 9. 9. 12. 5. 9.
 191 9. 5. 13. 20. 9. 10. 9. 19. 16. 14.
 201 19. 12. 27. 20. 32. 27. 34. 29. 39. 55.
 211 45. 49. 71. 62. 64. 71. 73. 110. 78. 130.
 221 108. 177. 145. 150. 175. 152. 197. 207. 204. 204.
 231 197. 198. 100. 191. 165. 172. 179. 152. 166. 182.
 241 145. 209. 224. 234. 270. 310. 320. 353. 329. 131.
 251 444. 500. 409. 497. 541. 460. 421. 425. 325. 285.
 261 211. 164. 140. 119. 71. 61. 58. 47. 45. 61.
 271 56. 53. 36. 45. 30. 51. 50. 62. 57. 60.
 281 62. 67. 90. 113. 132. 127. 142. 161. 186. 196.
 291 197. 263. 259. 209. 300. 335. 355. 300. 400. 377.
 301 353. 349. 326. 331. 237. 215. 164. 134. 95. 93.
 311 65. 51. 46. 24. 26. 18. 15. 5. 3. 2.
 321 1. 1. 0. 0. 0. 1. 0. 0. 1. 0.
 331 0. 1. 0. 0. 1. 0. 0. 1. 0. 0.
 341 0. 2. 1. 0. 0. 1. 0. 1. 0. 1.
 351 1. 1. 1. 1. 0. 1. 0. 0. 1. 2.
 361 0. 1. 0. 1. 0. 1. 2. 0. 0. 0.
 371 0. 0. 0. 0. 0. 1. 0. 0. 0. 0.
 381 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 391 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 401 0. 0. 0. 0. 0. 0. 0. 0. 0. 1.
 411 0. 0. 0. 0. 0. 0. 0. 0. 0. 1.
 421 0. 0. 0. 0. 0. 0. 0. 0. 0. 1.
 431 0. 1. 0. 0. 0. 1. 0. 0. 0. 0.
 441 1. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 451 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.
 461 0. 0. 0. 0. 0. 0. 0. 0. 1. 0.
 471 0. 0. 0. 0. 0. 0. 0. 1. 1. 0.
 481 2. 0. 0. 0. 1. 1. 0. 0. 0. 1.
 491 0. 0. 0. 0. 0. 1. 0. 0. 0. 0.
 511 0. 0. 0. 0. 0. 0. 0. 0. 0. 0.

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	Tennelec
PROCEDURE/REV	LA-933-141/G-1
TECHNOLOGIST	R. D. Hale
DATE	March 12, 1990
TEMPERATURE	23 C
STARTING TIME	1000
ENDING TIME	1700
CHEMIST	S. A. Catlow

Neptunium Analysis
Fusion Dissolution

Mount Volume = 500 uL

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0897
2	Reagent Blank	F0898
3	Sample Composite 5	F0899
4	Duplicate Sample Composite 5	F0900
5	Sample Composite 6	F0923
6	Duplicate Sample Composite 6	F0924
7	Sample Composite 8	F0947
8	Duplicate Sample Composite 8	F0948
9	Sample Composite 7	F0977
10	Duplicate Sample Composite 7	F0978
11	Spike Composite 7	F0979

	DESCRIPTION	LAB ID
12	Final LMCS Check Std.	F0980
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQT.VOL.	FINAL VOL. OF STD.
LMCS Check Std	148B33/100 uL			N/A
Spike	148B33/100 uL	F0947/250 uL		N/A

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	WA77930
PROCEDURE/REV	LA-438-101/C-2
TECHNOLOGIST	S. Lai
DATE	March 06, 1990
TEMPERATURE	24 C
STARTING TIME	0800
ENDING TIME	1500
CHEMIST	S. A. Catlow

Technetium Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Spike Composite 7	F0979
6	Final LMCS Check Std.	F0980
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY Book # & ALIQUOT VOL.	SECOND Book # & ALIQUOT VOL.	THIRD Bk# & ALQT.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	68B39/250 ul			20 ml
Spike	68B39/250 ul	F0977/1.0 ml		20 ml

Single Shell Tank Calibration Record

ANALYTE: TC 99

PROCEDURE: LA-508-121

REVISION: A-0

INSTRUMENT: Liquid Scintillation Counter

PROPERTY NUMBER: WA77390

TECHNOLOGIST: R. A. Jones

PAYROLL NUMBER: 65801

DATE: September 02, 1988

CALIBRATION STANDARD ID: Packard 6008502 #2

ANALYTE CONCENTRATION: See attached calibration sheets.

TYPE OF CALIBRATION: Quench Curve

COMMENTS: Quench Curve

請支持香港 TEC，參與我們的行動，一起為人權而鬥爭！
請支持我們，為我們的運動，投上一票！
支持我們的運動，支持我們的行動，支持我們的未來！
支持我們的運動，支持我們的行動，支持我們的未來！

聯合國的RECLINK，已經對中國大陸的黑市進行了調查，發現中國大陸的黑市上，有許多中國人被拐賣到東南亞、日本、韓國等地。

• 100 • 100 • 100 • 100 • 100 • 100 • 100 • 100 • 100 • 100 •

THEORY OF THE DYNAMIC EQUILIBRIUM

第十一章 算法设计与分析

ESTUDIOS SOCIOLÓGICOS DE LA
CULTURA CUENCA DIVULGACIÓN INSTITUCIONAL NÚMERO 482-2011

THE MUSICAL FORMS OF THE TUNES
IN THE LITURGY OF THE GREEK CHURCH
AND THEIR DIFFERENCE FROM THOSE OF THE
ROMAN RITE AND OF THE CATHOLIC CHURCH.
BY
CHARLES A. WILSON,
RECTOR OF THE SEMINARY OF THE SOCIETY OF JESUS,
IN THE UNIVERSITY OF TORONTO.

WILLIAM H. T. TIGLIETTI, BOSTONIAN, OF THE FIRM OF TIGLIETTI & CO., BOSTON, MASS.

PER	TEMP.	PER	TEMP.
2.3, 3.7	2.1, 3.2	2.2, 3.7	2.1, 3.2
1.96, 3	2.1, 3.2	1.97, 3	2.1, 3.2
1.97, 3	2.1, 3.2	1.97, 3	2.1, 3.2
1.97, 3	2.1, 3.2	1.97, 3	2.1, 3.2

ELASTIC STAMPS FOR DETERMINING
ADDITIONAL REACTION COEFFICIENTS
AND REACTOR COEFFICIENTS

REPEATED MEASURES ANALYSIS
REPEATED TIME (10-1200) DAY (1-4)
SAMPLE REPEATS (0-10)
CYCLE REPEATS (1-5)
MEAN OUTLIERS (0-10)
INTERACTION (NO/YES) DIF (0-1)

THE EFFECTS OF CHANGING THE NUMBER OF CHANNELS ON THE PERFORMANCE OF A CHANNEL EQUALIZER

17. *On the History of the English People*, by Edward Gibbon, M.A., F.R.S., &c., &c., &c.

DATA PROTECTION ACT REGULATIONS - 1000000000

THE BOSTONIAN

（三）在本办法施行前，已经取得《医疗机构执业许可证》的中医诊所，应当自本办法施行之日起六个月内向所在地县级人民政府中医药主管部门申请换发《医疗机构执业许可证》，逾期不申请换发的，由县级人民政府中医药主管部门依法处理。

SARAH L. HARRIS

ANSWERING QUESTIONS ON THE PAPER

¹³ See, e.g., *U.S. v. Gandy*, 415 U.S. 853, 863 (1974) ("[T]he First Amendment protects the right to receive as well as to speak."); *see also* *Wickliffe v. U.S.*, 352 U.S. 241, 248 (1957).

© 2014 Kluwer

ESTATE PLANNING: HOW TO HAVE ENOUGH MONEY FOR YOUR CHILDREN

从以上数据可以看出， L_1 和 L_2 在所有指标上都表现得更好，而 L_3 在大部分指标上表现不如 L_1 和 L_2 。

175
1960-1961

F975

	DATE	TIME	TYPE	END TIME	END DATE	PERIOD	TIME
F976	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F976+	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F977	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F977+	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F978	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F978+	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
INTERVALS FOR DAY							
F979	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F979+	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F980	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00
F980+	1970-01-01	00:00:00	DATA	00:00:00	1970-01-01	00:00:00	00:00:00

Analytical Batch

LAB SEGMENT SERIAL #: F0971

CUSTOMER ID: 000007

INSTRUMENT	N/A
PROCEDURE/REV	LA-378-103/A-2
TECHNOLOGIST	M. Myers
DATE	June 21, 1990
TEMPERATURE	21 C
STARTING TIME	0800
ENDING TIME	1530
CHEMIST	S. A. Catlow

Iodine 129 Analysis
Fusion Dissolution

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std.	F0975
2	Reagent Blank	F0976
3	Sample Composite 7	F0977
4	Duplicate Sample Composite 7	F0978
5	Spike Composite 7	F0979
6	Final LMCS Check Std.	F0980
7		
8		
9		
10		
11		

	DESCRIPTION	LAB ID
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY BOOK # & ALIQUOT VOL.	SECOND BOOK # & ALIQUOT VOL.	THIRD BK# & ALQ.T.VOL.	FINAL VOL. OF STD.
LMCS Check Std.	38B46/1.0 ml			N/A
Spike	38B46/1.0 ml	F0977/1.0 ml		N/A

Single Shell Tank Calibration Record

ANALYTE: I-129

PROCEDURE: LA-508-152

REVISION: A-1

INSTRUMENT: TN-4500

PROPERTY NUMBER: WA45242

TECHNOLOGIST: R. A. Jones

PAYROLL NUMBER: 65801

DATE: January 09, 1989

CALIBRATION STANDARD ID: 45B40A & B

ANALYTE CONCENTRATION: Se^{75} = 4.06 uci, SB^{125} = 4.67 uci, I^{129} = 57.8 uci

TYPE OF CALIBRATION: Efficiency

COMMENTS: T zero = June 06, 1988

1. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
2. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
3. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
4. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
5. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
6. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
7. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
8. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*
9. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*

10. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*

11. *Leucostoma* *flavum* (L.) Pers.
Benth. *Sp. Pl.*

Category	Definition	Example
1. Geometric Properties	Properties related to shape, size, and position.	Area, Perimeter, Volume, Congruence, Similarity, Parallelism, Perpendicularity.
2. Algebraic Properties	Properties involving numbers, variables, and operations.	Equations, Inequalities, Functions, Sequences, Series, Matrices.
3. Statistical Properties	Properties related to data analysis, probability, and distributions.	Mean, Median, Mode, Standard Deviation, Correlation, Regression.
4. Calculus Properties	Properties related to rates of change, accumulation, and optimization.	Differentiation, Integration, Derivatives, Antiderivatives, Limits.
5. Trigonometric Properties	Properties related to angles, ratios, and relationships between sides of triangles.	Sine, Cosine, Tangent, Pythagorean Theorem, Law of Sines, Law of Cosines.
6. Number Theory Properties	Properties related to integers, divisibility, prime numbers, and modular arithmetic.	Prime Factorization, GCD, LCM, Modular Arithmetic, Fermat's Little Theorem.
7. Geometry Properties	Properties related to geometric shapes, their properties, and relationships.	Euclidean Geometry, Non-Euclidean Geometry, Fractal Geometry, Geometric Transformations.
8. Probability Properties	Properties related to chance, likelihood, and statistical outcomes.	Probability Distributions, Bayes' Theorem, Conditional Probability, Expected Value.
9. Calculus Properties	Properties related to rates of change, accumulation, and optimization.	Differentiation, Integration, Derivatives, Antiderivatives, Limits.
10. Number Theory Properties	Properties related to integers, divisibility, prime numbers, and modular arithmetic.	Prime Factorization, GCD, LCM, Modular Arithmetic, Fermat's Little Theorem.

mc121. I80Tdrf FILE

#	Isotope	Half-life	#%	Value	Calc,Limit
				Energie	Acc,Int.(%)
1	I 129	1.600000 b	---	100	
		39.2		7.50	
2	Br 82	1.390000 b	---	100	
		55.0		15.90	
3	Lu 243	1.700000 b	---	100	
		74.7		56.00	
4	Sr 126	1000.00 b	---	100	
		174.2		5.00	
5	Se 75	110.77 b	---	100	
		135.0		55.00	
		191.1		17.30	

Maximum Energie Error for Isotope Ident. detection = 1.5 keV

All values are corrected for decay.

Comments--?

*
* G A M M A S P E C T R U M A N A L Y S I S *
*

CANBERRA SPECTRAN-F V2.06 SOFTWARE

10-SEP-90 09:58:58

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 4.0
DETECTOR NUMBER: 6 / GEOMETRY NUMBER: 1
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 95.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD6172

ANALYZED BY: 69549

SAMPLE DESCRIPTION: F975-6585

GEOMETRY DESCRIPTION: I-129/CULTURE TUBE

SAMPLE SIZE: 1.0000E+00 EA / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL129

COLLECT STARTED ON 22-JUN-90 AT 19:46:42

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3003. SECONDS

DEAD TIME: 0.10 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 21-JUN-90

EFFICIENCY CALIBRATION PERFORMED 18-JUN-90

10-SEP-9009:58:58

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	148.56	29.57	1.56	745.	10155.	2.5	
2C	169.27	33.71	1.56	527.	2200.	4.9	CE-144
3C	198.30	39.51	1.52	209.	1413.	6.6	I-129,BI-212, CE-144

ERROR QUOTATION AT 1.96 SIGMA
PEAK CONFIDENCE LEVEL AT 95.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0024
BACKGROUND DESCRIPTION: BKG
BACKGROUND COLLECT STARTED ON 5-JUN-90 AT 13:00:00
BACKGROUND LIVE TIME: 3000. SECONDS
BACKGROUND WAS INSIGNIFICANT

10-SEP-9009:58:58

SAMPLE: F975-6585

DATA COLLECTED ON 22-JUN-90 AT 19:46:42

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/EA			ENERGY COMPARISON	
	MEASURED	ERROR	DECAY CORRECTED	ERROR	(KEV) EXPECT
AM-241	LLD<1.83E-06		LLD<1.83E-06		59.54
AM-243	LLD<9.16E-07		LLD<9.16E-07		74.67
I-129	3.26E-04	+2.16E-05	3.26E-04	+2.16E-05	39.60 -0.09
SB-125	LLD<1.97E-05		LLD<1.97E-05		176.33
SE-75	LLD<1.44E-06		LLD<1.44E-06		136.00
SN-113	LLD<3.44E-06		LLD<3.44E-06		391.67
TOTAL	3.26E-04	+2.16E-05	3.26E-04	+2.16E-05	

E BAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 5.77E-03 UC/EA

TOTAL MEASURED ACTIVITY = 3.26E-04 (+-2.16E-05) UC/EA

% TECH. SPEC. = 5.65 (+-0.37)

ERROR QUOTATION AT 1.96 SIGMA

LLD CONFIDENCE LEVEL AT 95.0%

P E A K S N O T U S E D I N A N A L Y S I S

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
148.56	29.57	10155.	2.5	1.42E+01
169.27	33.71	2200.	4.9	2.08E+00

*
* G A M M A S P E C T R U M A N A L Y S I S *
*

CANBERRA SPECTRAN-F V2.06 SOFTWARE

10-SEP-90 10:06:25

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 4.0
DETECTOR NUMBER: 6 / GEOMETRY NUMBER: 1
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 95.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED
LLD CALCULATION PERFORMED
MEASURED ENERGY DIFFERENCES LISTED
MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD6173
ANALYZED BY: 69549

SAMPLE DESCRIPTION: F976-6385
GEOMETRY DESCRIPTION: I-129/CULTURE TUBE
SAMPLE SIZE: 1.0000E+00 EA / CONVERSION FACTOR: 1.0000E+00
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL129

COLLECT STARTED ON 22-JUN-90 AT 21:34:04

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3003. SECONDS
DEAD TIME: 0.10 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 21-JUN-90
EFFICIENCY CALIBRATION PERFORMED 18-JUN-90

10-SEP-90 10:06:25

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
----	---------------------	---------------	-------------	-------------------	--------------------	------------	----------

ERROR QUOTATION AT 1.96 SIGMA
PEAK CONFIDENCE LEVEL AT 95.0%

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0024
BACKGROUND DESCRIPTION: BKG
BACKGROUND COLLECT STARTED ON 5-JUN-90 AT 13:00:00
BACKGROUND LIVE TIME: 3000. SECONDS
BACKGROUND WAS INSIGNIFICANT

10-SEP-9010:06:25

SAMPLE: F976-6385

DATA COLLECTED ON 22-JUN-90 AT 21:34:04

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/EA			ENERGY COMPARISON	
	MEASURED	ERROR	DECAY CORRECTED	ERROR	(KEV) EXPECT
AM-241	LLD<1.89E-06		LLD<1.89E-06		59.54
AM-243	LLD<9.16E-07		LLD<9.16E-07		74.67
I-129	LLD<1.82E-05		LLD<1.82E-05		39.60
SB-125	LLD<1.95E-05		LLD<1.95E-05		176.33
SE-75	LLD<1.53E-06		LLD<1.53E-06		136.00
SN-113	LLD<2.50E-06		LLD<2.50E-06		391.67
TOTAL	0.00E-01	+ -0.00E-01	0.00E-01	+ -0.00E-01	

ERROR QUOTATION AT 1.96 SIGMA

LLD CONFIDENCE LEVEL AT 95.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS

*
*
* G A M M A S P E C T R U M A N A L Y S I S * * * * * * * * * * * * * * *
*
* *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

10-SEP-90 10:09:16

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 4.0
DETECTOR NUMBER: 6 / GEOMETRY NUMBER: 1
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 95.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.96 SIGMA UNCERTAINTY

ENVIRONMENTAL BACKGROUND SUBTRACTED

LLD CALCULATION PERFORMED

MEASURED ENERGY DIFFERENCES LISTED

MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD6174

ANALYZED BY: 69549

SAMPLE DESCRIPTION: F977-6085

GEOMETRY DESCRIPTION: I-129/CULTURE TUBE

SAMPLE SIZE: 1.0000E+00 EA / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL129

COLLECT STARTED ON 22-JUN-90 AT 22:45:07

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3002. SECONDS

DEAD TIME: 0.07 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 21-JUN-90

EFFICIENCY CALIBRATION PERFORMED 18-JUN-90

10-SEP-90 10:09:16

P E A K A N A L Y S I S

PK CHANNEL	CENTROID KEV	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
---------------	-----------------	---------------	-------------	-------------------	--------------------	------------	----------

ERROR QUOTATION AT 1.96 SIGMA
PEAK CONFIDENCE LEVEL AT 95.0%

BACKGROUND SUBTRACTION PERFORMED USING FILE BK0024

BACKGROUND DESCRIPTION: BKG

BACKGROUND COLLECT STARTED ON 5-JUN-90 AT 13:00:00

BACKGROUND LIVE TIME: 3000. SECONDS

BACKGROUND WAS INSIGNIFICANT

10-SEP-9010:09:16

SAMPLE: F977-6085

DATA COLLECTED ON 22-JUN-90 AT 22:45:07

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE	ACTIVITY CONCENTRATION IN uCi/EA			ENERGY COMPARISON	
	MEASURED	ERROR	DECAY CORRECTED	ERROR	(KEV) EXPECT
AM-241	LLD<1.95E-06		LLD<1.95E-06		59.54
AM-243	LLD<9.98E-07		LLD<9.98E-07		74.67
I-129	LLD<1.55E-05		LLD<1.55E-05		39.60
SB-125	LLD<1.80E-05		LLD<1.80E-05		176.33
SE-75	LLD<1.44E-06		LLD<1.44E-06		136.00
SN-113	LLD<4.32E-06		LLD<4.32E-06		391.67
TOTAL	0.00E-01	+ -0.00E-01	0.00E-01	+ -0.00E-01	

ERROR QUOTATION AT 1.96 SIGMA

LLD CONFIDENCE LEVEL AT 95.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS