



EBERLINE SERVICES

0059109

December 10, 2002

Ms. Joan Kessner
Bechtel Hanford Inc.
3350 George Washington Way
Richland, WA 99352
MSIN: H0-25

Reference: P.O. #630
Eberline Services R2-11-117-7407, SDG H1990

Dear Ms. Kessner:

Enclosed is the data report for two other solid samples designated under SAF No. B00-055 received at Eberline Services on November 22, 2002. The samples were analyzed according to the accompanying chain-of-custody document.

Please call if you have any questions concerning this report.

Sincerely,


Melissa Mannion

Melissa C. Mannion
Program Manager

MCM

Enclosure: Data Package

RECEIVED
APR 28 2003
EDMC



Analytical Services
2030 Wright Avenue
P.O. Box 4040
Richmond, California 94804-0040
(510) 235-2633 Fax (510) 235-0438
Toll Free (800) 841-5487
www.eberlineservices.com

1.0 GENERAL

Bechtel Hanford Inc. (BHI) Sample Delivery Group H1990 was composed of two other solid samples designated under SAF No. B00-055 with a Project Designation of: 100-NR-1 TSD Sites R.A. Sampling – Other Solid.

The samples were received as stated on the Chain-of-Custody document. Any discrepancies are noted on the Eberline Services Sample Receipt Checklist. The results were transmitted to BHI via e-Fax on December 10, 2002.

2.0 ANALYSIS NOTES

2.1 Gross Alpha and Gross Beta Analyses

The LCS and method blank were not scaled to the nominal aliquot. No problems were encountered during the course of the analyses.

2.2 Total Strontium Analyses

The LCS and method blank were not scaled to the nominal aliquot. No problems were encountered during the course of the analyses.

2.4 Isotopic Plutonium Analyses

The LCS and method blank were not scaled to the nominal aliquot. No problems were encountered during the course of the analyses.

2.5 Americium-241 Analyses

The LCS and method blank were not scaled to the nominal aliquot. No problems were encountered during the course of the analyses.

2.6 Gamma Spectroscopy Analyses

No problems were encountered during the course of the analyses.

Case Narrative Certification Statement

"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."

Melini Mannion
Melissa C. Mannion
Program Manager

12/10/02
Date

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

Client Hanford
Contract No. 630
Case no SDG_H1990

S U M M A R Y D A T A S E C T I O N

T A B L E O F C O N T E N T S				
About this section	.	.	.	1
Sample Summaries	.	.	.	3
Prep Batch Summary	.	.	.	5
Work Summary	.	.	.	6
Method Blanks	.	.	.	8
Lab Control Samples	.	.	.	9
Duplicates	.	.	.	10
Data Sheets	.	.	.	11
Method Summaries	.	.	.	13
Report Guides	.	.	.	19
End of Section	.	.	.	33

Melina Mannion
Prepared by

Melina Mannion
Reviewed by

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-TOC
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H1990

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford
Contract No. 630
Case no SDG_H1990

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

SAMPLE SUMMARY

SDG 7407

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Case no SDG_H1990

CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	LAB SAMPLE ID	SAF NO	CHAIN OF CUSTODY	COLLECTED
J008P8	116-N-1 Crib Inlet Pipe.	SOLID		R211117-01	B00-055	B00-055-015	11/15/02 11:00
J009K8	116-N-1 Crib Inlet Pipe.	SOLID		R211117-02	B00-055	B00-055-015	11/15/02 11:10
Method Blank		SOLID		R211117-04	B00-055		
Lab Control Sample		SOLID		R211117-03	B00-055		
Duplicate (R211117-02)	116-N-1 Crib Inlet Pipe.	SOLID		R211117-05	B00-055		11/15/02 11:10

SAMPLE SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CS

Version 3.06

Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

QC SUMMARY

SDG 7407

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Case no SDG H1990

QC BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL	LAB SAMPLE ID	DEPARTMENT SAMPLE ID
7407	800-055-015	J008P8	SOLID	100.0	7.27 g		11/22/02	7	R211117-01	7407-001
		J009K8	SOLID	100.0	16.39 g		11/22/02	7	R211117-02	7407-002
		Method Blank	SOLID						R211117-04	7407-004
		Lab Control Sample	SOLID						R211117-03	7407-003
		Duplicate (R211117-02)	SOLID	100.0	16.39 g		11/22/02	7	R211117-05	7407-005

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-QS

Version 3.06

Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407

Contact Melissa C. Mannion

PREP BATCH SUMMARY

Client Hanford

Contract No. 630

Case no SDG H1990

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED				QUALI-		
			BATCH	2σ %	CLIENT	MORE	RE	BLANK		LCS	DUP/ORIG
Alpha Spectroscopy											
AM	SOLID	Americium 241 in Soil	7052-123	5.0	2			1	1	1/1	
PU	SOLID	Plutonium, Isotopic in Solids	7052-123	5.0	2			1	1	1/1	
Beta Counting											
SR	SOLID	Total Strontium in Soil	7052-123	10.0	2			1	1	1/1	
Gas Proportional Counting											
93A	SOLID	Gross Alpha in Soil	7052-123	20.0	2			1	1	1/1	
93B	SOLID	Gross Beta in Soil	7052-123	15.0	2			1	1	1/1	
Gamma Spectroscopy											
GAM	SOLID	Gamma Scan	7052-123	15.0	2			1	1	1/1	

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.

Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

PREP BATCH SUMMARY

Page 1

SUMMARY DATA SECTION

Page 5

Lab id EBRLNE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-PBS
 Version 3.06
 Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Case no SDG H1990

WORK SUMMARY

CLIENT SAMPLE ID		LAB SAMPLE ID									
LOCATION	MATRIX	COLLECTED	PLANCHET	TEST	SUF-	ANALYZED	REVIEWED	BY	METHOD		
CUSTODY	SAF No	RECEIVED			FIX						
J008P8		R211117-01	7407-001	93A/93		12/04/02	12/10/02	MCM	Gross Alpha in Soil		
116-N-1 Crib Inlet Pipe.	SOLID	11/15/02	7407-001	93B/93		12/04/02	12/10/02	MCM	Gross Beta in Soil		
800-055-015	800-055	11/22/02	7407-001	AM		12/09/02	12/10/02	MCM	Americium 241 in Soil		
			7407-001	GAM		12/09/02	12/10/02	MCM	Gamma Scan		
			7407-001	PU		12/09/02	12/10/02	MCM	Plutonium, Isotopic in Solids		
			7407-001	SR		12/04/02	12/10/02	MCM	Total Strontium in Soil		
J009K8		R211117-02	7407-002	93A/93		12/04/02	12/10/02	MCM	Gross Alpha in Soil		
116-N-1 Crib Inlet Pipe.	SOLID	11/15/02	7407-002	93B/93		12/04/02	12/10/02	MCM	Gross Beta in Soil		
800-055-015	800-055	11/22/02	7407-002	AM		12/09/02	12/10/02	MCM	Americium 241 in Soil		
			7407-002	GAM		12/09/02	12/10/02	MCM	Gamma Scan		
			7407-002	PU		12/09/02	12/10/02	MCM	Plutonium, Isotopic in Solids		
			7407-002	SR		12/04/02	12/10/02	MCM	Total Strontium in Soil		
Method Blank		R211117-04	7407-004	93A/93		12/04/02	12/10/02	MCM	Gross Alpha in Soil		
	SOLID		7407-004	93B/93		12/04/02	12/10/02	MCM	Gross Beta in Soil		
	800-055		7407-004	AM		12/09/02	12/10/02	MCM	Americium 241 in Soil		
			7407-004	GAM		12/09/02	12/10/02	MCM	Gamma Scan		
			7407-004	PU		12/09/02	12/10/02	MCM	Plutonium, Isotopic in Solids		
			7407-004	SR		12/04/02	12/10/02	MCM	Total Strontium in Soil		
Lab Control Sample		R211117-03	7407-003	93A/93		12/04/02	12/10/02	MCM	Gross Alpha in Soil		
	SOLID		7407-003	93B/93		12/04/02	12/10/02	MCM	Gross Beta in Soil		
	800-055		7407-003	AM		12/09/02	12/10/02	MCM	Americium 241 in Soil		
			7407-003	GAM		12/09/02	12/10/02	MCM	Gamma Scan		
			7407-003	PU		12/09/02	12/10/02	MCM	Plutonium, Isotopic in Solids		
			7407-003	SR		12/04/02	12/10/02	MCM	Total Strontium in Soil		
Duplicate (R211117-02)		R211117-05	7407-005	93A/93		12/06/02	12/10/02	MCM	Gross Alpha in Soil		
116-N-1 Crib Inlet Pipe.	SOLID	11/15/02	7407-005	93B/93		12/04/02	12/10/02	MCM	Gross Beta in Soil		
	800-055	11/22/02	7407-005	AM		12/09/02	12/10/02	MCM	Americium 241 in Soil		
			7407-005	GAM		12/09/02	12/10/02	MCM	Gamma Scan		
			7407-005	PU		12/09/02	12/10/02	MCM	Plutonium, Isotopic in Solids		
			7407-005	SR		12/04/02	12/10/02	MCM	Total Strontium in Soil		

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CWS

Version 3.06

Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407

Contact Melissa C. Mannion

WORK SUMMARY, cont.

Client Hanford

Contract No. 630

Case no SDG H1990

COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP	SPIKE	TOTAL
93A/93	B00-055	Gross Alpha in Soil	900.0_ALPHABETA_GPC	2			1	1	1		5
93B/93	B00-055	Gross Beta in Soil	900.0_ALPHABETA_GPC	2			1	1	1		5
AM	B00-055	Americium 241 in Soil	AMCMISO_IE_PLATE_AEA	2			1	1	1		5
GAM	B00-055	Gamma Scan	GAMMA_GS	2			1	1	1		5
PU	B00-055	Plutonium, Isotopic in Solids	PUISO_PLATE_AEA	2			1	1	1		5
SR	B00-055	Total Strontium in Soil	SRTOT_SEP_PRECIP_GPC	2			1	1	1		5
TOTALS				12			6	6	6		30

WORK SUMMARY

Page 2

SUMMARY DATA SECTION

Page 7

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CWS

Version 3.06

Report date 12/10/02

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H1990

R211117-04

Method Blank

METHOD BLANK

SDG <u>7407</u>	Client/Case no <u>Hanford</u>	SDG <u>H1990</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R211117-04</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7407-004</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>B00-055</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Gross Alpha	12587-46-1	0.097	0.22	0.39	10	U	93A
Gross Beta	12587-47-2	0.240	0.40	0.65	15	U	93B
Total Strontium	SR-RAD	-0.020	0.17	0.35	1.0	U	SR
Plutonium 238	13981-16-3	0	0.028	0.11	1.0	U	PU
Plutonium 239/240	PU-239/240	0.014	0.057	0.11	1.0	U	PU
Americium 241	14596-10-2	0.032	0.063	0.081	1.0	U	AM
Potassium 40	13966-00-2	U		7.9		U	GAM
Cobalt 60	10198-40-0	U		<u>0.64</u>	0.050	U	GAM
Cesium 137	10045-97-3	U		<u>0.52</u>	0.10	U	GAM
Radium 226	13982-63-3	U		0.98		U	GAM
Radium 228	15262-20-1	U		2.2		U	GAM
Europium 152	14683-23-9	U		<u>1.1</u>	0.10	U	GAM
Europium 154	15585-10-1	U		<u>2.0</u>	0.10	U	GAM
Europium 155	14391-16-3	U		<u>0.86</u>	0.10	U	GAM
Thorium 228	14274-82-9	U		0.59		U	GAM
Thorium 232	TH-232	U		2.2		U	GAM
Uranium 235	15117-96-1	U		1.4		U	GAM
Uranium 238	U-238	U		74		U	GAM
Americium 241	14596-10-2	U		0.98		U	GAM

100-NR-1 TSD Sites R.A. Smpl.-Other

QC-BLANK 43253

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

R211117-03

Lab Control Sample

LAB CONTROL SAMPLE

SDG <u>7407</u>	Client/Case no <u>Hanford</u>	SDG <u>H1990</u>
Contact <u>Melissa C. Mannion</u>	Contract <u>No. 630</u>	
Lab sample id <u>R211117-03</u>	Client sample id <u>Lab Control Sample</u>	
Dept sample id <u>7407-003</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>800-055</u>	

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	2σ ERR pCi/g	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Gross Alpha	23.2	1.5	0.36	10		93A	20.0	0.80	116	63-137	70-130
Gross Beta	21.5	1.1	0.78	15		93B	21.3	0.85	101	75-125	70-130
Total Strontium	23.8	1.2	0.37	1.0		SR	21.3	0.85	112	80-120	80-120
Plutonium 238	12.4	1.3	0.13	1.0		PU	12.2	0.49	102	81-119	80-120
Plutonium 239/240	14.0	1.5	0.13	1.0		PU	13.2	0.53	106	80-120	80-120
Americium 241	10.1	1.2	0.15	1.0		AM	9.53	0.38	106	79-121	80-120
Cobalt 60	33.0	1.6	<u>0.83</u>	0.050		GAM	32.0	1.3	103	75-125	80-120
Cesium 137	44.4	1.5	<u>0.96</u>	0.10		GAM	41.3	1.7	108	74-126	80-120

100-NR-1 TSD Sites R.A. Smpl.-Other

QC-LCS 43252

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>12/10/02</u>

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

R211117-05

J009K8

DUPLICATE

SDG <u>7407</u>		Client/Case no <u>Hanford</u> SDG <u>H1990</u>	
Contact <u>Melissa C. Mannion</u>		Contract <u>No. 630</u>	
DUPLICATE		ORIGINAL	
Lab sample id <u>R211117-05</u>	Lab sample id <u>R211117-02</u>	Client sample id <u>J009K8</u>	
Dept sample id <u>7407-005</u>	Dept sample id <u>7407-002</u>	Location/Matrix <u>116-N-1 Crib Inlet Pipe. SOLID</u>	
	Received <u>11/22/02</u>	Collected/Weight <u>11/15/02 11:10 16.39 g</u>	
% solids <u>100.0</u>	% solids <u>100.0</u>	Custody/SAF No <u>800-055-015 800-055</u>	

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD %	3σ TOT	PROT LIMIT
Gross Alpha	794	86	<u>26</u>	10		93A	966	95	<u>35</u>		20	48	
Gross Beta	26800	340	<u>64</u>	15		93B	27800	350	<u>66</u>		4	32	
Total Strontium	4460	140	<u>34</u>	1.0		SR	4530	150	<u>39</u>		2	22	
Plutonium 238	73.0	21	<u>11</u>	1.0		PU	81.1	27	<u>14</u>		11	67	
Plutonium 239/240	492	65	<u>11</u>	1.0		PU	457	71	<u>14</u>		7	32	
Americium 241	245	37	<u>8.7</u>	1.0		AM	246	45	<u>13</u>		0	37	
Potassium 40	U		210		U	GAM	U		220	U	-		
Cobalt 60	38600	120	<u>71</u>	0.050		GAM	38700	120	<u>72</u>		0	32	
Cesium 137	5840	62	<u>59</u>	0.10		GAM	5530	54	<u>54</u>		5	32	
Radium 226	U		60		U	GAM	U		61	U	-		
Radium 228	U		220		U	GAM	U		230	U	-		
Europium 152	U		<u>71</u>	0.10	U	GAM	U		<u>71</u>	U	-		
Europium 154	U		<u>91</u>	0.10	U	GAM	U		<u>110</u>	U	-		
Europium 155	U		<u>38</u>	0.10	U	GAM	U		<u>39</u>	U	-		
Thorium 228	U		28		U	GAM	U		28	U	-		
Thorium 232	U		220		U	GAM	U		230	U	-		
Uranium 235	U		63		U	GAM	U		64	U	-		
Uranium 238	U		6700		U	GAM	U		6800	U	-		
Americium 241	U		840		U	GAM	U		790	U	-		

100-NR-1 TSD Sites R.A. Smpl.-Other

QC-DUP#2 43254

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

R211117-01

J008P8

DATA SHEET

SDG <u>7407</u>	Client/Case no <u>Hanford</u>	SDG <u>H1990</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R211117-01</u>	Client sample id <u>J008P8</u>	
Dept sample id <u>7407-001</u>	Location/Matrix <u>116-N-1 Crib Inlet Pipe. SOLID</u>	
Received <u>11/22/02</u>	Collected/Weight <u>11/15/02 11:00 7.27 g</u>	
% solids <u>100.0</u>	Custody/SAF No <u>B00-055-015 B00-055</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Gross Alpha	12587-46-1	8810	620	<u>150</u>	10		93A
Gross Beta	12587-47-2	19700	690	<u>270</u>	15		93B
Total Strontium	SR-RAD	4650	320	<u>160</u>	1.0		SR
Plutonium 238	13981-16-3	741	140	<u>53</u>	1.0		PU
Plutonium 239/240	PU-239/240	4620	440	<u>42</u>	1.0		PU
Americium 241	14596-10-2	2680	400	<u>75</u>	1.0		AM
Potassium 40	13966-00-2	U		130		U	GAM
Cobalt 60	10198-40-0	13400	70	<u>34</u>	0.050		GAM
Cesium 137	10045-97-3	2020	32	<u>32</u>	0.10		GAM
Radium 226	13982-63-3	U		37		U	GAM
Radium 228	15262-20-1	U		140		U	GAM
Europium 152	14683-23-9	37.8	29	<u>43</u>	0.10	U	GAM
Europium 154	15585-10-1	531	62	<u>70</u>	0.10		GAM
Europium 155	14391-16-3	166	24	<u>31</u>	0.10		GAM
Thorium 228	14274-82-9	U		17		U	GAM
Thorium 232	TH-232	U		140		U	GAM
Uranium 235	15117-96-1	U		40		U	GAM
Uranium 238	U-238	U		4100		U	GAM
Americium 241	14596-10-2	U		5100		U	GAM

100-NR-1 TSD Sites R.A. Smpl.-Other

DATA SHEETS

Page 1

SUMMARY DATA SECTION

Page 11

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>12/10/02</u>

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

R211117-02

J009K8

D A T A S H E E T

SDG <u>7407</u>	Client/Case no <u>Hanford</u>	SDG <u>H1990</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R211117-02</u>	Client sample id <u>J009K8</u>	
Dept sample id <u>7407-002</u>	Location/Matrix <u>116-N-1 Crib Inlet Pipe. SOLID</u>	
Received <u>11/22/02</u>	Collected/Weight <u>11/15/02 11:10</u> <u>16.39 g</u>	
% solids <u>100.0</u>	Custody/SAF No <u>B00-055-015</u> <u>B00-055</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Gross Alpha	12587-46-1	966	95	<u>35</u>	10		93A
Gross Beta	12587-47-2	27800	350	<u>66</u>	15		93B
Total Strontium	SR-RAD	4530	150	<u>39</u>	1.0		SR
Plutonium 238	13981-16-3	81.1	27	<u>14</u>	1.0		PU
Plutonium 239/240	PU-239/240	457	71	<u>14</u>	1.0		PU
Americium 241	14596-10-2	246	45	<u>13</u>	1.0		AM
Potassium 40	13966-00-2	U		220		U	GAM
Cobalt 60	10198-40-0	38700	120	<u>72</u>	0.050		GAM
Cesium 137	10045-97-3	5530	54	<u>54</u>	0.10		GAM
Radium 226	13982-63-3	U		61		U	GAM
Radium 228	15262-20-1	U		230		U	GAM
Europium 152	14683-23-9	U		<u>71</u>	0.10	U	GAM
Europium 154	15585-10-1	U		<u>110</u>	0.10	U	GAM
Europium 155	14391-16-3	U		<u>39</u>	0.10	U	GAM
Thorium 228	14274-82-9	U		28		U	GAM
Thorium 232	TH-232	U		230		U	GAM
Uranium 235	15117-96-1	U		64		U	GAM
Uranium 238	U-238	U		6800		U	GAM
Americium 241	14596-10-2	U		790		U	GAM

100-NR-1 TSD Sites R.A. Smpl.-Other

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>12/10/02</u>

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

Test AM Matrix SOLID

SDG 7407

Contact Melissa C. Mannion

METHOD SUMMARY

AMERICIUM 241 IN SOIL

ALPHA SPECTROSCOPY

Client Hanford

Contract No. 630

Contract SDG H1990

RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	Americium 241
------------------	------------------	-------------	-------------	------------------

Preparation batch 7052-123

J008P8	R211117-01	7407-001	2680
J009K8	R211117-02	7407-002	246
BLK (QC ID=43253)	R211117-04	7407-004	U
LCS (QC ID=43252)	R211117-03	7407-003	ok
Duplicate (R211117-02)	R211117-05	7407-005	ok

Nominal values and limits from method RDLs (pCi/g) 1.0

100-NR-1 TSD Sites R.A. Smpl.-Other

METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	------------------	-------------	-------------	--------------	-----------	-------------	---------------	------------	----------	--------------	-------------	--------------	--------------	-------------------	------	----------

Preparation batch 7052-123 2σ prep error 5.0 % Reference Lab Notebook 7052 pg. 123

J008P8	R211117-01	75	0.0020	41	177	24	12/09/02	12/09	SS-043
J009K8	R211117-02	13	0.0100	46	177	24	12/09/02	12/09	SS-044
BLK (QC ID=43253)	R211117-04	0.081	1.00	77	176	12/09/02	12/09	SS-048	
LCS (QC ID=43252)	R211117-03	0.15	1.00	42	175	12/09/02	12/09	SS-047	
Duplicate (R211117-02) (QC ID=43254)	R211117-05	8.7	0.0100	80	176	24	12/09/02	12/09	SS-049

Nominal values and limits from method 1.0 1.00 20-105 100 100 180

PROCEDURES	REFERENCE	AMCMISO_IE_PLATE_AEA
CP-071	Soil Dissolution, > 1.0g Aliquot, rev 2	
CP-963	Americium and Curium in Water and Dissolved Samples by Extraction Chromatography, rev 3	
CP-008	Heavy Element Electroplating, rev 7	

AVERAGES ± 2 SD	MDA	19	±	63
FOR 5 SAMPLES	YIELD	57	±	39

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 13

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-CMS

Version 3.06

Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

Test PU Matrix SOLID
SDG 7407
Contact Melissa C. Mannion

METHOD SUMMARY

PLUTONIUM, ISOTOPIC IN SOLIDS
ALPHA SPECTROSCOPY

Client Hanford
Contract No. 630
Contract SDG H1990

RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	Plutonium 238	Plutonium 239/240
------------------	------------------	-------------	-------------	------------------	----------------------

Preparation batch 7052-123

J008P8	R211117-01	7407-001	741	4620
J009K8	R211117-02	7407-002	81.1	457
BLK (QC ID=43253)	R211117-04	7407-004	U	U
LCS (QC ID=43252)	R211117-03	7407-003	ok	ok
Duplicate (R211117-02)	R211117-05	7407-005	ok	ok

Nominal values and limits from method RDLs (pCi/g) 1.0 1.0
100-NR-1 TSD Sites R.A. Smpl.-Other

METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	MAX MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	------------------	-------------	-------------	------------------	-----------	-------------	---------------	------------	----------	--------------	-------------	--------------	--------------	-------------------	------	----------

Preparation batch 7052-123 2σ prep error 5.0 % Reference Lab Notebook 7052 pg. 123

J008P8	R211117-01	53	0.0020	65	208	24	12/09/02	12/09	SS-033
J009K8	R211117-02	14	0.0100	71	119	24	12/09/02	12/09	SS-042
BLK (QC ID=43253)	R211117-04	0.11	1.00	64	176	12/09/02	12/09	SS-050	
LCS (QC ID=43252)	R211117-03	0.13	1.00	74	120	12/09/02	12/09	SS-024	
Duplicate (R211117-02) (QC ID=43254)	R211117-05	11	0.0100	63	172	24	12/09/02	12/09	SS-058

Nominal values and limits from method 1.0 1.00 20-105 100 100 180

PROCEDURES	REFERENCE	PUISO_PLATE_AEA
CP-070	Soil Dissolution, < 1.0g Aliquot, rev 5	
CP-941	Plutonium in Water and Dissolved Samples by Extraction Chromatography, rev 1	
CP-008	Heavy Element Electroplating, rev 7	

AVERAGES ± 2 SD	MDA	16	±	44
FOR 5 SAMPLES	YIELD	67	±	10

METHOD SUMMARIES

Page 2

SUMMARY DATA SECTION

Page 14

Lab id	EBRLNE
Protocol	Hanford
Version	Ver 1.0
Form	DVD-CMS
Version	3.06
Report date	12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

Test SR Matrix SOLID
SDG 7407
Contact Melissa C. Mannion

METHOD SUMMARY

TOTAL STRONTIUM IN SOIL
BETA COUNTING

Client Hanford
Contract No. 630
Contract SDG H1990

RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	Total Strontium
------------------	------------------	-------------	-------------	--------------------

Preparation batch 7052-123

J008P8	R211117-01	7407-001	4650
J009K8	R211117-02	7407-002	4530
BLK (QC ID=43253)	R211117-04	7407-004	U
LCS (QC ID=43252)	R211117-03	7407-003	ok
Duplicate (R211117-02)	R211117-05	7407-005	ok

Nominal values and limits from method RDLs (pCi/g) 1.0
100-NR-1 TSD Sites R.A. Smpl.-Other

METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- YZED	DETECTOR
------------------	------------------	-------------	-------------	--------------	-----------	-------------	---------------	------------	----------	--------------	-------------	--------------	--------------	---------------	----------

Preparation batch 7052-123 2σ prep error 10.0 % Reference Lab Notebook 7052 pg. 123

J008P8	R211117-01	160	0.0020	55	100	19	12/04/02	12/04	GRB-218
J009K8	R211117-02	39	0.0100	81	100	19	12/04/02	12/04	GRB-206
BLK (QC ID=43253)	R211117-04	0.35	1.00	73	100	12/04/02	12/04	GRB-229	
LCS (QC ID=43252)	R211117-03	0.37	1.00	74	57	12/04/02	12/04	GRB-230	
Duplicate (R211117-02)	R211117-05	34	0.0100	83	100	19	12/04/02	12/04	GRB-221
(QC ID=43254)									

Nominal values and limits from method 1.0 1.00 30-105 100 180

PROCEDURES	REFERENCE	SRTOT_SEP_PRECIP_GPC
CP-070	Soil Dissolution, < 1.0g Aliquot, rev 5	
CP-502	Strontium in Solids, rev 6	

AVERAGES ± 2 SD	MDA <u>47</u> ± <u>130</u>
FOR 5 SAMPLES	YIELD <u>73</u> ± <u>22</u>

METHOD SUMMARIES

Page 3

SUMMARY DATA SECTION

Page 15

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-CMS</u>
Version <u>3.06</u>
Report date <u>12/10/02</u>

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

Test 93A Matrix SOLID
SDG 7407
Contact Melissa C. Mannion

METHOD SUMMARY

GROSS ALPHA IN SOIL
GAS PROPORTIONAL COUNTING

Client Hanford
Contract No. 630
Contract SDG H1990

RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- PLANCHET	Gross Alpha
------------------	------------------	-----------------	------------------	-------------

Preparation batch 7052-123

J008P8	R211117-01	93	7407-001	8810
J009K8	R211117-02	93	7407-002	966
BLK (QC ID=43253)	R211117-04	93	7407-004	U
LCS (QC ID=43252)	R211117-03	93	7407-003	ok
Duplicate (R211117-02)	R211117-05	93	7407-005	ok

Nominal values and limits from method RDLs (pCi/g) 10
100-NR-1 TSD Sites R.A. Smpl.-Other

METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST FIX	SUF- pCi/g	MDA	ALIQ g	PREP FAC	DILU- TION	RESID mg	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	------------------	-----------------	---------------	-----	-----------	-------------	---------------	-------------	----------	--------------	-------------	--------------	--------------	-------------------	------	----------

Preparation batch 7052-123 2σ prep error 20.0 % Reference Lab Notebook 7052 pg. 123

J008P8	R211117-01	93	<u>150</u>	<u>0.0020</u>				<u>2</u>	100			19	12/04/02	12/04	GRB-114
J009K8	R211117-02	93	<u>35</u>	<u>0.0100</u>				9	100			19	12/04/02	12/04	GRB-115
BLK (QC ID=43253)	R211117-04	93	0.39	1.00				21	100				12/04/02	12/04	GRB-115
LCS (QC ID=43252)	R211117-03	93	0.36	1.00				20	100				12/04/02	12/04	GRB-114
Duplicate (R211117-02) (QC ID=43254)	R211117-05	93	<u>26</u>	<u>0.0100</u>				9	100			21	12/04/02	12/06	GRB-114

Nominal values and limits from method 10 1.00 5-250 100 180

PROCEDURES REFERENCE 900.0_ALPHABETA_GPC
CP-070 Soil Dissolution, < 1.0g Aliquot, rev 5
CP-125 Gross Alpha and Beta in Dissolved Solids, rev 3

AVERAGES ± 2 SD MDA 42 ± 120
FOR 5 SAMPLES RESIDUE 12 ± 16

METHOD SUMMARIES

Page 4

SUMMARY DATA SECTION

Page 16

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-CMS
Version 3.06
Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

Test 93B Matrix SOLID
SDG 7407
Contact Melissa C. Mannion

METHOD SUMMARY

GROSS BETA IN SOIL
GAS PROPORTIONAL COUNTING

Client Hanford
Contract No. 630
Contract SDG H1990

RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	PLANCHET	Gross Beta
------------------	------------------	-------------	-------------	----------	------------

Preparation batch 7052-123

J008P8	R211117-01	93		7407-001	19700
J009K8	R211117-02	93		7407-002	27800
BLK (QC ID=43253)	R211117-04	93		7407-004	U
LCS (QC ID=43252)	R211117-03	93		7407-003	ok
Duplicate (R211117-02)	R211117-05	93		7407-005	ok

Nominal values and limits from method RDLs (pCi/g) 15
100-NR-1 TSD Sites R.A. Smpl.-Other

METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW TEST	SUF- FIX	MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	RESID mg	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- YZED	DETECTOR
------------------	------------------	-------------	-------------	--------------	-----------	-------------	---------------	-------------	----------	--------------	-------------	--------------	--------------	---------------	----------

Preparation batch 7052-123 2σ prep error 15.0 % Reference Lab Notebook 7052 pg. 123

J008P8	R211117-01	93		<u>270</u>	<u>0.0020</u>			<u>2</u>	100				19	12/04/02	12/04	GRB-109
J009K8	R211117-02	93		<u>66</u>	<u>0.0100</u>			9	100				19	12/04/02	12/04	GRB-105
BLK (QC ID=43253)	R211117-04	93		0.65	1.00			21	100					12/04/02	12/04	GRB-115
LCS (QC ID=43252)	R211117-03	93		0.78	1.00			20	100					12/04/02	12/04	GRB-114
Duplicate (R211117-02) (QC ID=43254)	R211117-05	93		<u>64</u>	<u>0.0100</u>			9	100				19	12/04/02	12/04	GRB-115

Nominal values and limits from method 15 1.00 5-250 100 180

PROCEDURES REFERENCE 900.0_ALPHABETA_GPC
CP-070 Soil Dissolution, < 1.0g Aliquot, rev 5
CP-125 Gross Alpha and Beta in Dissolved Solids, rev 3

AVERAGES ± 2 SD MDA 80 ± 220
FOR 5 SAMPLES RESIDUE 12 ± 16

METHOD SUMMARIES

Page 5

SUMMARY DATA SECTION

Page 17

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-CMS
Version 3.06
Report date 12/10/02

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H1990

Test GAM Matrix SOLID
SDG 7407
Contact Melissa C. Mannion

METHOD SUMMARY

GAMMA SCAN
GAMMA SPECTROSCOPY

Client Hanford
Contract No. 630
Contract SDG H1990

RESULTS

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUF- TEST FIX	PLANCHET	Cobalt 60	Cesium 137
------------------	------------------	----------------------	----------	-----------	------------

Preparation batch 7052-123

J008P8	R211117-01	7407-001	13400	2020
J009K8	R211117-02	7407-002	38700	5530
BLK (QC ID=43253)	R211117-04	7407-004	U	U
LCS (QC ID=43252)	R211117-03	7407-003	ok	ok
Duplicate (R211117-02)	R211117-05	7407-005	ok	ok

Nominal values and limits from method RDLs (pCi/g) 0.050 0.10
100-NR-1 TSD Sites R.A. SmpL.-Other

METHOD PERFORMANCE

CLIENT SAMPLE ID	LAB SAMPLE ID	RAW SUF- TEST FIX	MDA pCi/g	ALIQ g	PREP FAC	DILU- TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
------------------	------------------	----------------------	--------------	-----------	-------------	---------------	------------	----------	--------------	-------------	--------------	--------------	-------------------	------	----------

Preparation batch 7052-123 2σ prep error 15.0 % Reference Lab Notebook 7052 pg. 123

J008P8	R211117-01	<u>200</u>	5.66	121	24	12/05/02	12/09	SP,03,00
J009K8	R211117-02	<u>350</u>	7.20	101	24	12/05/02	12/09	SP,03,00
BLK (QC ID=43253)	R211117-04	<u>3.8</u>	5.66	160		12/05/02	12/09	SP,04,00
LCS (QC ID=43252)	R211117-03	<u>0.83</u>	5.66	614		12/05/02	12/09	SP,03,00
Duplicate (R211117-02) (QC ID=43254)	R211117-05	<u>320</u>	7.20	105	24	12/05/02	12/09	SP,03,00

Nominal values and limits from method 0.050 5.66 100 180

PROCEDURES REFERENCE GAMMA_GS
CP-100 Ge(Li) Preparation for Commercial Samples, rev 5

AVERAGES ± 2 SD MDA 170 ± 330
FOR 5 SAMPLES YIELD _____ ± _____

METHOD SUMMARIES

Page 6

SUMMARY DATA SECTION

Page 18

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-CMS
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H1990

SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- * LAB SAMPLE ID is the lab's primary identification for a sample.
- * DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- * CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- * QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- * All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 19

Lab id EBERLINE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG_H1990

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- * The preparation batches are shown in the same order as the Method Summary Reports are printed.
- * Only analyses of planchets relevant to the SDG are included.
- * Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- * The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 20

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG_H1990

WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- * TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- * SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- * The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- * PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- * For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- * The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

REPORT GUIDES

Page 3

SUMMARY DATA SECTION

Page 21

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H1990

DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- * TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- * The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- * ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- * A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- * When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

- U The RESULT is less than the MDA (Minimum Detectable Activity).

REPORT GUIDES

Page 4

SUMMARY DATA SECTION

Page 22

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 630
Case no SDG H1990

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
 - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
 - H Similar to 'L' except the recovery was high.
 - P The RESULT is 'preliminary'.
 - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
 - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- * An MDA is underlined if it is bigger than its RDL.

REPORT GUIDES

Page 5

SUMMARY DATA SECTION

Page 23

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford
Contract No. 630
Case no SDG H1990

DATA SHEET

- * An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- * A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- * When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

REPORT GUIDES

Page 6

SUMMARY DATA SECTION

Page 24

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H1990

LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- * An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- * The first, computed limits for the recovery reflect:
 1. The error of RESULT, including that introduced by rounding the result prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
 2. The error of ADDED.
 3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- * The second limits are protocol defined upper and lower QC limits for the recovery.
- * The recovery is underlined if it is outside either of these ranges.

REPORT GUIDES

Page 7

SUMMARY DATA SECTION

Page 25

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG_H1990

DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- * The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- * The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

REPORT GUIDES

Page 8

SUMMARY DATA SECTION

Page 26

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford
Contract No. 630
Case no SDG H1990

DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- * The RPD is underlined if it is greater than either limit.
- * If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- * The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

REPORT GUIDES

Page 9

SUMMARY DATA SECTION

Page 27

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H1990

MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- * The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- * The second limits are protocol defined upper and lower QC limits

REPORT GUIDES

Page 10

SUMMARY DATA SECTION

Page 28

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 630
Case no SDG H1990

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- * The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 29

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG_H1990

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- * Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- * The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- * If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- * Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- * Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

REPORT GUIDES

Page 12

SUMMARY DATA SECTION

Page 30

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 630
Case no SDG H1990

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- * Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- * If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- * Aliquots are underlined if less than the nominal value specified for the method.
- * Preparation factors are underlined if greater than the nominal value specified for the method.
- * Dilution factors are underlined if greater than the nominal value specified for the method.
- * Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- * Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- * Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

REPORT GUIDES

Page 13

SUMMARY DATA SECTION

Page 31

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 630
Case no SDG H1990

METHOD SUMMARY

- * Count times are underlined if less than the nominal value specified for the method.
- * Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- * Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- * Days Held are underlined if greater than the holding time specified in the protocol.
- * Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1÷3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

REPORT GUIDES

Page 14

SUMMARY DATA SECTION

Page 32

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H1990

SDG 7407
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford
Contract No. 630
Case no SDG_H1990

METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

REPORT GUIDES

Page 15

SUMMARY DATA SECTION

Page 33

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 12/10/02

Bechtel Hanford Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST				B00-055-015		Page 1 of 1													
Collector R B Kerkow		Company Contact R B Kerkow		Telephone No. 373-9123		Project Coordinator TRENT, SJ		Price Code 7K Data Turnaround													
Project Designation 100-NR-1 TSD Sites R. A. Sampling - Other Solid		Sampling Location 116-N-1 Crib Inlet pipelines (36" and 12") H1990 (7401)		SAF No. B00-055		Air Quality <input type="checkbox"/>		15 DAYS													
Ice Chest No. ERC-01-025		Field Logbook No. EL-1524-2		COA R1301N2600		Method of Shipment FED EX															
Shipped To TMA/RECRA RK 11-15-02		Offsite Property No. RSR # 106977		Bill of Lading/Air Bill No.																	
POSSIBLE SAMPLE HAZARDS/REMARKS Potentially Radioactive RADIOACTIVE Special Handling and/or Storage None				Preservation	None																
				Type of Container	Marinelli VIAL	RK 11-15-02															
				No. of Container(s)	1																
				Volume	500mL 20 ML	RK 11-15-02															
SAMPLE ANALYSIS				See item (I) in Special Instructions.																	
Sample No.		Matrix *		Sample Date		Sample Time															
J008P8		OTHER SOLID		11-15-02		1100		X									J008P7	36"			
J009K8		OTHER SOLID		11-15-02		1110		X									J009K7	12"			
CHAIN OF POSSESSION				SPECIAL INSTRUCTIONS				Matrix * S=Soil SE=Sediment SO=Solid SL=Sludge W=Water O=Oil A=Air DS=Drum Solids DL=Drum Liquids T=Tissue W=Wipe L=Liquid V=Vegetation X=Other													
Relinquished By/Removed From		Date/Time		Sign/Print Names		Date/Time								Lab COA: R1301N2F00 (1) Gross Alpha; Gross Beta; Gamma Spectroscopy (Cesium-137, Cobalt-60, Europium-152, Europium-154, Europium-155); Gamma Spec - Add-on (Americium-241); Isotopic Plutonium; Americium-241; Strontium-89,90 - Total Sr; Nickel-63; Tritium-3 RK 11-15-02 DELETE							
3728 REF 1A		11/15/02		REF 1A RB Kerkow		11/15/02															
Relinquished By/Removed From		Date/Time		Received By/Stored In		Date/Time															
3728 REF 1A		11/21/02 0700		Dennis St. John		11/21/02 0700															
Relinquished By/Removed From		Date/Time		Received By/Stored In		Date/Time															
Dennis St. John		11/21/02 0700		FED EX		11/21/02 0700															
Relinquished By/Removed From		Date/Time		Received By/Stored In		Date/Time															
Fed Express		11/22/02		Ando Nanno		11/22/02 10:00															
Relinquished By/Removed From		Date/Time		Received By/Stored In		Date/Time															
11/22/02		11/22/02		11/22/02 10:30		11/22/02 10:30															
Relinquished By/Removed From		Date/Time		Received By/Stored In		Date/Time															
LABORATORY SECTION		Received By		Title				Date/Time													
FINAL SAMPLE DISPOSITION		Disposal Method		Disposed By				Date/Time													

EBERLINE SERVICES
ANALYTICAL SERVICES GROUP

Richmond, CA Laboratory

SAMPLE RECEIPT CHECKLIST

SAMPLE RECEIPT			
Client:	<u>Wen - Hanford Beckfel</u>	Date/Time received	<u>11/22/02</u>
CoC No.	<u>B00-055-015</u>		
Container I.D. No.	<u>ERC-01-025</u>	Requested TAT (Days)	<u>15</u> ^{Days} P.O. Received Yes [] No []
INSPECTION			
1.	Custody seals on shipping container intact?	Yes [<input checked="" type="checkbox"/>]	No [] N/A []
2.	Custody seals on shipping container dated & signed?	Yes [<input checked="" type="checkbox"/>]	No [] N/A []
3.	Custody seals on sample containers intact?	Yes [<input checked="" type="checkbox"/>]	No [] N/A []
4.	Custody seals on sample containers dated & signed?	Yes [<input checked="" type="checkbox"/>]	No [] N/A []
5.	Packing material is:	Wet []	Dry [<input checked="" type="checkbox"/>]
6.	Number of samples in shipping container:	<u>2</u>	
7.	Number of containers per sample:	<u>1</u> (Or see CoC _____)	
8.	Paperwork agrees with samples?	Yes [<input checked="" type="checkbox"/>]	No []
9.	Samples have: Tape [] Hazard labels [] Rad labels [] Appropriate sample labels [<input checked="" type="checkbox"/>]		
10.	Samples are: In good condition [<input checked="" type="checkbox"/>] Leaking [] Broken Container [] Missing []		
11.	Describe any anomalies: _____		
13.	Was P.M. notified of any anomalies?	Yes []	No [] Date <u>11/22/02</u>
14.	Received by	<u>[Signature]</u>	Date: _____ Time: <u>10:00</u>

Customer Sample No.	cpm	mr/hr	wipe	Customer Sample No.	cpm	mr/hr	wipe

Ion Chamber Ser. No. _____	Calibration date _____
Alpha meter Ser. No. _____	Calibration date _____
Survey Meter Ser. No. _____	Calibration date _____