

# START

A-7900-013-2784

0041212

## ENGINEERING CHANGE NOTICE

1. ECN **613664**Page 1 of 2Proj.  
ECN

|   |   |  |   |
|---|---|--|---|
| 2. ECN Category<br>(mark one)<br><br>Supplemental<br>Direct Revision <input checked="" type="checkbox"/><br>Change ECN <input type="checkbox"/><br>Temporary <input type="checkbox"/><br>Standby <input type="checkbox"/><br>Supersedure <input type="checkbox"/><br>Cancel/Void <input type="checkbox"/> | 3. Originator's Name, Organization, MSIN,<br>and Telephone No.<br><br>A.D. Rice, Characterization<br>Plans and Reports, T6-06, 373-<br>5878 | 3a. USQ Required?<br><input type="checkbox"/> Yes <input checked="" type="checkbox"/> No | 4. Date<br>05/15/95   |
|   | 5. Project Title/No./Work Order No.<br><br>Tank 241-AX-102, Auger Samples<br>95-AUG-006 and 95-AUG-007                                      | 6. Bldg./Sys./Fac. No.<br>N/A  | 7. Approval Designator<br>Q   |
|   | 8. Document Numbers Changed by this ECN<br>(includes sheet no. and rev.)<br><br>WHC-SD-WM-DP-100, Rev. D                                    | 9. Related ECN No(s).<br>N/A   | 10. Related PO No.<br>N/A   |
| 11a. Modification Work<br><br>[ ] Yes (fill out Blk.<br>11b)<br>[X] No (NA Blks. 11b,<br>11c, 11d)  | 11b. Work Package<br>No.<br>N/A   | 11c. Modification Work Complete<br>N/A<br><br>Cog. Engineer Signature & Date             | 11d. Restored to Original Condition<br>(Temp. or Standby ECN only)<br>N/A<br><br>Cog. Engineer Signature & Date |

## 12. Description of Change

This ECN is being generated in order to update/add additional information to the existing document.



## 13a. Justification (mark one)

Criteria Change  Design Improvement  Environmental  Facility Deactivation   
As-Found  Facilitate Const  Const. Error/Omission  Design Error/Omission

## 13b. Justification Details

This ECN will complete the documentation process for this document.

## 14. Distribution (include name, MSIN, and no. of copies)

See Attached Distribution Sheet

## RELEASE STAMP

OFFICIAL RELEASE  
BY WHC  
DATE MAY 17 1995  
55 *Stas S*

## ENGINEERING CHANGE NOTICE

Page 2 of 2

1. ECN (use no. from pg. 1)

ECN-613664

| 15. Design Verification Required | 16. Cost Impact    |        |                    | 17. Schedule Impact (days) |                   |     |
|----------------------------------|--------------------|--------|--------------------|----------------------------|-------------------|-----|
|                                  | ENGINEERING        |        | CONSTRUCTION       |                            |                   |     |
| [ ] Yes                          | Additional Savings | [ ] \$ | Additional Savings | [ ] \$                     | Improvement Delay | [ ] |
| [X] No                           |                    |        |                    |                            |                   |     |

18. Change Impact Review: Indicate the related documents (other than the engineering documents identified on Side 1) that will be affected by the change described in Block 12. Enter the affected document number in Block 19.

|                                |     |                                  |     |                               |     |
|--------------------------------|-----|----------------------------------|-----|-------------------------------|-----|
| SDD/DD                         | [ ] | Seismic/Stress Analysis          | [ ] | Tank Calibration Manual       | [ ] |
| Functional Design Criteria     | [ ] | Stress/Design Report             | [ ] | Health Physics Procedure      | [ ] |
| Operating Specification        | [ ] | Interface Control Drawing        | [ ] | Spares Multiple Unit Listing  | [ ] |
| Criticality Specification      | [ ] | Calibration Procedure            | [ ] | Test Procedures/Specification | [ ] |
| Conceptual Design Report       | [ ] | Installation Procedure           | [ ] | Component Index               | [ ] |
| Equipment Spec.                | [ ] | Maintenance Procedure            | [ ] | ASME Coded Item               | [ ] |
| Const. Spec.                   | [ ] | Engineering Procedure            | [ ] | Human Factor Consideration    | [ ] |
| Procurement Spec.              | [ ] | Operating Instruction            | [ ] | Computer Software             | [ ] |
| Vendor Information             | [ ] | Operating Procedure              | [ ] | Electric Circuit Schedule     | [ ] |
| OM Manual                      | [ ] | Operational Safety Requirement   | [ ] | ICRS Procedure                | [ ] |
| FSAR/SAR                       | [ ] | IEFD Drawing                     | [ ] | Process Control Manual/Plan   | [ ] |
| Safety Equipment List          | [ ] | Cell Arrangement Drawing         | [ ] | Process Flow Chart            | [ ] |
| Radiation Work Permit          | [ ] | Essential Material Specification | [ ] | Purchase Requisition          | [ ] |
| Environmental Impact Statement | [ ] | Fac. Proc. Samp. Schedule        | [ ] | Tickler File                  | [ ] |
| Environmental Report           | [ ] | Inspection Plan                  | [ ] |                               | [ ] |
| Environmental Permit           | [ ] | Inventory Adjustment Request     | [ ] |                               | [ ] |

19. Other Affected Documents: (NOTE: Documents listed below will not be revised by this ECN.) Signatures below indicate that the signing organization has been notified of other affected documents listed below.

| Document Number/Revision | Document Number/Revision | Document Number Revision |
|--------------------------|--------------------------|--------------------------|
| N/A                      |                          |                          |

## 20. Approvals

|                                   | Signature | Date    | Signature | Date |
|-----------------------------------|-----------|---------|-----------|------|
| <u>OPERATIONS AND ENGINEERING</u> |           |         |           |      |
| Cog. Eng. A.D. Rice               |           | 5-15-95 | PE        |      |
| Cog. Mgr. J.G. Kristofzski        |           | 5-13-95 | QA        |      |
| QA E. W. Miller                   |           | 5-16-95 | Safety    |      |
| Safety                            |           |         | Design    |      |
| Environ.                          |           |         | Environ.  |      |
| Other                             |           |         | Other     |      |
|                                   |           |         |           |      |
|                                   |           |         |           |      |
|                                   |           |         |           |      |

DEPARTMENT OF ENERGY

Signature or a Control Number that tracks the Approval Signature

ADDITIONAL

100-116-2785

| SUPPORTING DOCUMENT   |   | 1. Total Pages   146 |
|---|---|----------------------|
| 2. Title<br>90-Day Final Report for Tank 241-AX-102, Auger Samples 95-AUG-006 and 95-AUG-007  | 3. Number<br>WHC-SD-WM-DP-100   | 4. Rev No.<br>0-A    |
| 5. Key Words<br>90-Day, 90-Day Report, Tank 241-AX-102, Tank AX-102, AX-102, Auger Samples, 95-AUG-006, 95-AUG-007                                | 6. Author<br>Name: Andrew D. Rice<br><br>Signature |                      |
| 7. Abstract<br>N/A  | Organization/Charge Code 75310/MDR21  |                      |
| 8. RELEASE STAMP  |   |                      |
| <div style="border: 1px solid black; padding: 5px; text-align: center;">OFFICIAL RELEASE<br/>BY WHC<br/>DATE MAY 17 1995<br/>55 <i>Stas</i></div> |   |                      |

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

## **RECORD OF REVISION**

(1) Document Number  
WHC-SD-WM-DP-100

Page A

(2) Title

90-Final Report for Tank 241-AX-102, Auger Samples 95-AUG-006 and 95-AUG-007

**CHANGE CONTROL RECORD**

**THIS PAGE INTENTIONALLY  
LEFT BLANK**



Westinghouse  
Hanford Company

P.O. Box 1970 Richland, WA 99352

100-000000000000000000000000000000

WHC-SD-WM-DP-100, REV. 0A

**ANALYTICAL SERVICES**

**90-DAY FINAL REPORT FOR  
TANK 241-AX-102, AUGERS 95-AUG-006 AND 95-AUG-007.**

Date Printed: MAY 15, 1995

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

WHC-SD-WM-DP-100, REV. 0A

TABLE OF CONTENTS

|  |     |
|--|-----|
| Narrative . . . . .                                    | 1   |
| Sample Data Summary . . . . .                          | 3   |
| Chain of Custody Forms . . . . .                       | 6   |
| Logbook . . . . .                                      | 9   |
| Sample Analyses Results . . . . .                      | 20  |
| Extrusion Worklist # 619 . . . . .                     | 22  |
| Extrusion Worklist # 620 . . . . .                     | 23  |
| Extrusion Worklist # 639 . . . . .                     | 24  |
| Fusion Worklist # 648 . . . . .                        | 25  |
| Water Leach Worklist # 1131 . . . . .                  | 26  |
| Total Organic/Total Inorganic Worklist # 764 . . . . . | 27  |
| Total Organic/Total Inorganic Worklist # 881 . . . . . | 50  |
| Hydroxide Worklist # 1272 . . . . .                    | 67  |
| Cyanide Worklist # 1361 . . . . .                      | 73  |
| Ion Chromatograph Worklist # 1191 . . . . .            | 82  |
| Total Apha/Total Beta Worklist # 672 . . . . .         | 95  |
| Total Apha/Total Beta Worklist # 693 . . . . .         | 105 |
| Total Apha/Total Beta Worklist # 745 . . . . .         | 115 |

This Document consists of pages 1 through 116, plus page 2.1 and page 21 was intentionally left blank.

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

144-2789

WHC-SD-WM-DP-100, REV. 0A

**NARRATIVE**

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

~~CONFIDENTIAL~~

WHC-SD-WM-DP-100, REV. 0A

90-DAY FINAL REPORT FOR TANK 241-AX-102, AUGERS 95-AUG-006 AND 95-AUG-007.

Summary

This is the final report for tank AX-102, augers 95-AUG-006 and 95-AUG-007. It contains the primary results called for in the organic DQO, and the required secondary analyses for auger 95-AUG-007. There was insufficient sample to perform secondary analyses on Auger 95-AUG-006, which contained only 2 grams of sample at extrusion. Samples from both augers (S95T000203/206) exceeded the notification limit for Total Organic Carbon (TOC). Notification was made on 3/31/95. DSC and TGA results, which were previously reported in reference (2) below, have been included in the attached analytical summary tables to assist in data interpretation.

As the final report, the following is also included: the extrusion logbook, chains of custody, sample preparation data, and the raw data for all analyses other than DSC and TGA, which has been provided in reference (2) below.

Sample Receipt and Extrusion

A narrative which details sample receipt and extrusion is contained in reference (2) below.

Analytical Results

Total Organic Carbon (TOC)

The TOC analysis was performed using procedure LA-342-100 Rev A-0. The coulometer solution turned foggy on the first run and spike recoveries were high, apparently due to method byproduct interferences. A rerun was performed with modifications intended to remove the interferences. The reanalysis did not solve the problem, however, as indicated by further high spike recoveries. The TCP precision criteria of 10% RPD was not met by either sample, quite possibly due to the interferences mentioned above. The TCP accuracy criteria was met. Results for the 95-AUG-006 sample (S95T000203) averaged 5.73 E+04 ug/g, and the 95-AUG-007 sample (S95T000206) averaged 5.58 E+04 ug/g. Both exceeded the notification limit of 3.00 E+04 ug/g, for which notification was made on 3/31/95. These results are higher than the TOC values determined in 1988, although assumptions about density could account for much of this difference.

Hydroxide (OH)

Hydroxide analysis was required because the energy equivalent of the TOC assay for sample S95T000206 was greater than 125% of the DSC value. The OH analysis was performed using procedure LA-211-102 Rev B-1. No analytical problems were noted. No free hydroxide above the detection limit was observed in the 95-AUG-007 sample (S95T000593). All TCP quality control criteria were met.

WHC-SD-WM-DP-100, REV. 0A

Ion Chromatography (IC)

Ion Chromatography for nitrate and nitrite was required because the energy equivalent of the TOC assay for sample S95T000206 was greater than 125% of the DSC value. The IC analysis for nitrite and nitrate was performed using LA-533-105 Rev C-2. The TCP precision and accuracy criteria were met. The spike recovery for nitrate was low due to high concentration of nitrate in the sample. Additional dilution would correct this problem, but the precision of the nitrite value would suffer. The 95-AUG-007 sample (S95T000593) averaged 4.07 E+04 ug/g nitrite, and 1.72 E+05 ug/g nitrate.

Cyanide (CN)

Cyanide analysis was required because DSC results for this sample exceeded the notification limit. Analysis was performed using LA-695-102 Rev C-0. No analytical problems were noted. The TCP accuracy criteria was exceeded, but all other criteria were met. No analytical problems were noted. The 95-AUG-007 sample (S95T000206) averaged 26.2 ug/g CN.

- References:
- (1) WHC-SD-WM-TP-227, Rev. 1, "Tank 241-AX-102 Tank Characterization Plan", dated January 24, 1995, Westinghouse Hanford Company, Richland, WA 99352
  - (2) WHC-SD-WM-DP-100, Rev. 0, "45-Day Safety Screen Results for Tank 241-AX-102, Augers 95-AUG-006 and 95-AUG-007", dated April 17, 1995, Westinghouse Hanford Company, Richland, WA 99352

106-079

**WHC-SD-WM-DP-100, REV. 0A**

**SAMPLE DATA SUMMARY**

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

90 DAY REPORT FOR AUGERS 95-AUG-006 AND 95-AUG-007  
AX-102

CORE NUMBER: n/a  
SEGMENT #: 95-AUG-006

SEGMENT PORTION: W Whole Segment

| Sample#    | R | A# | Analyte                      | Unit         | Action Limits |          | Standard % | Blank | Result   | Duplicate | Average  | RPD % | Spk Rec % | Det Limit | Count Err% |
|------------|---|----|------------------------------|--------------|---------------|----------|------------|-------|----------|-----------|----------|-------|-----------|-----------|------------|
|            |   |    |                              |              | Lower         | Upper    |            |       |          |           |          |       |           |           |            |
| S95T000203 |   |    | % Water by TGA using Mettler | %            | 100.00        | 101.000  | 97.26      | n/a   | 29.57    | 28.01     | 28.79    | 5.42  | n/a       | n/a       | n/a        |
| S95T000203 |   |    | DSC Exotherm Dry Calculated  | Joules/g Dry | -1.000        | 481.000  | n/a        | n/a   | 494.0    | 488       | 491.0    | 1.22  | n/a       | n/a       | n/a        |
| S95T000203 |   |    | DSC Exotherm using Mettler   | Joules/g     | None          | None     | 98.42      | n/a   | 352.1    | 347.8     | 350.0    | 1.23  | n/a       | n/a       | n/a        |
| S95T000203 |   |    | TOC by Persulfate/Coulometry | ug/g         | -1.000        | 30000.00 | 90.33      | 31.80 | 6.12e+04 | 5.34e4    | 5.73e+04 | 13.6  | 196.0     | 80.00     | n/a        |

=> Limit violated  
=====  
=> Selected Limit

WHC-SD-WM-DF-100, REV. 0-A

90 DAY REPORT FOR AUGERS 95-AUG-006 AND 95-AUG-007  
AX-102

CORE NUMBER: n/a  
SEGMENT #: 95-AUG-007

SEGMENT PORTION: W Whole Segment

| Sample#    | R | A# | Analyte                       | Unit         | Action Limits |          | Standard % | Blank   | Result   | Duplicate | Average  | RPD % | Spk Rec % | Det Limit | Count | Err% |
|------------|---|----|-------------------------------|--------------|---------------|----------|------------|---------|----------|-----------|----------|-------|-----------|-----------|-------|------|
|            |   |    |                               |              | Lower         | Upper    |            |         |          |           |          |       |           |           |       |      |
| S95T000206 |   |    | % Water by TGA using Mettler  | %            | 97.000        | 101.000  | 97.26      | n/a     | 31.12    | 33.30     | 32.21    | 6.77  | n/a       | n/a       | n/a   | n/a  |
| S95T000206 |   |    | DSC Exotherm Dry Calculated   | Joules/g Dry | -1.000        | 101.000  | n/a        | n/a     | 416.0    | 487       | 451.5    | 15.7  | n/a       | n/a       | n/a   | n/a  |
| S95T000206 |   |    | DSC Exotherm using Mettler    | Joules/g     | None          | None     | 98.42      | n/a     | 282.3    | 330.3     | 306.3    | 15.7  | n/a       | n/a       | n/a   | n/a  |
| S95T000206 |   |    | Cyanide by Microdist. & Spec. | ug/g         | -1.000        | 100.000  | 121.3      | 1.200   | 26.80    | 25.7      | 26.25    | 4.19  | 103.0     | 3.100     | n/a   | n/a  |
| S95T000206 |   |    | TOC by Persulfate/Coulometry  | ug/g         | -1.000        | 3000.000 | 90.33      | 31.80   | 6.35e+04 | 4.81e4    | 5.58e+04 | 27.6  | n/a       | 80.00     | n/a   | n/a  |
| S95T000593 | W |    | OH- by Pot. Titration         | ug/g         | None          | None     | 100.2      | n/a     | < 1.66e3 | <1.66e3   | n/a      | n/a   | n/a       | 1.66e+03  | n/a   | n/a  |
| S95T000593 | W |    | Nitrite by IC - Dionex 4000i  | ug/g         | None          | None     | 99.62      | <3050.0 | 4.01e+04 | 4.13e4    | 4.07e+04 | 2.95  | 87.80     | 3.05e+03  | n/a   | n/a  |
| S95T000593 | W |    | Nitrate by IC - Dionex 4000i  | ug/g         | None          | None     | 100.9      | <3810.0 | 1.72e+05 | 1.72e5    | 1.72e+05 | 0.00  | 48.40     | 3.81e+03  | n/a   | n/a  |

=> Limit violated  
=> Selected Limit

S

WHC-SD-WM-DP-100, REV. 0-A

100-7795

**WHC-SD-WM-DP-100, REV. 0A**

**CHAIN OF CUSTODY FORMS**

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

**COPY**

*B2-13-75*  
**CHAIN-OF-CUSTODY RECORD FOR AUGER SAMPLING**

(1) Shipment Number 95-AUG-6 (2) Sample Number 95-AUG-6 (3) Supervisor Tom Sickels  
 (4) Tank AX-102 (5) Riser 3A (6) Cask Serial Number SN-25-6

|                         |   |   |   |
|-------------------------|---|---|---|
| Radiation Survey Data:  | (7) FIELD   | (31) LABORATORY                                       | (8) Shipment Description                              |
| Over Top Dose Rate      | <u>&lt; 5 mR/hr @ 2'</u>                            | <u>&lt; 0.5 mR/hr</u>                                 | A. Work Package Number<br><u>E5-94-701 10</u>         |
| Side Dose Rate          | <u>7 mR/hr @ 2'</u>                                 | <u>7 mR/hr</u>  | B. Cask Seal Number<br><u>3755</u>                    |
| Bottom Dose Rate        | <u>2 mR/hr @ 2'</u>                                 | <u>2 mR/hr</u>  | C. Date and Time Sample                               |
| Smearable Contamination | <u>&lt; 20 dpm/10cm<sup>2</sup></u><br>(Alpha)      | <u>&lt; 200 dpm/10cm<sup>2</sup></u><br>(Alpha)       | Removed from Tank<br><u>2/10/95 1301 hrs</u>          |
|                         | <u>&lt; 10 dpm/10cm<sup>2</sup></u><br>(Beta-Gamma) | <u>&lt; 1000 dpm/10cm<sup>2</sup></u><br>(Beta-Gamma) | D. Expected Liquid Content<br><u>10%</u>              |
| RCT*                    | <u>R. J. Sickels</u><br>(Signature)                 | <u>M. E. Paus</u><br>(Signature)                      | E. Expected Solid Content<br><u>90%</u>               |
|                         |   |   | F. Dose Rate Through Drill String<br><u>200 mR/hr</u> |
|                         |   |   | G. Expected Sample Length<br><u>10%</u>               |

(9) INFORMATION (Include statement of laboratory tests to be performed.)

|                     |                          |
|---------------------|--------------------------|
| (10) Field Comments | (32) Laboratory Comments |
|---------------------|--------------------------|

|   |   |   |   |                      |
|---|---|---|---|----------------------|
| (11) Point of Origin<br><u>341-AP 102</u>                       | (12) Destination<br><u>2225 Labs</u>                        | (13) Sender Name (Sign and PRINT)<br><u>James Sickels</u> | (14) Date/Time<br><u>2/13/95 11:00 AM</u> | (15) Sender Comments |
| (17) Relinquished By (Sign and PRINT)<br><u>James Sickels</u>   | (18) Received By (Sign and PRINT)<br><u>Charles E. Paus</u> | (19) Date/Time<br><u>2-13-95 11:30</u>                    | (20) Receiver Comments                    |                      |
| (21) Relinquished By (Sign and PRINT)<br><u>Charles E. Paus</u> | (22) Received By (Sign and PRINT)<br><u>N. Liapides</u>     | (23) Date/Time<br><u>2-13-95 12:10</u>                    | (24) Receiver Comments                    |                      |
| (25) Relinquished By (Sign and PRINT)                           | (26) Received By (Sign and PRINT)                           | (27) Date/Time  | (28) Receiver Comments                    |                      |

|   |   |   |  |   |
|---|---|---|--|---|
| (16) Seal Intact Upon Release?<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | (29) Seal Intact Upon Receipt?<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | (30) Seal Data Consistent with this Record?   |  |   |
|   |   | Shipment No.<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | Cask Seal No.<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | Sample No.<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |

**COPY**

CHAIN-OF-CUSTODY RECORD FOR AUGER SAMPLING

(1) Shipment Number 241-AX-102 (2) Sample Number 95-AUG-7 (3) Supervisor Tim Sickels  
 (4) Tank 9E (5) Riser 9E (6) Cask Serial Number C1054

|                         |  |  |                                   |
|-------------------------|--|--|-----------------------------------|
| Radiation Survey Data:  | (7) FIELD  | (31) LABORATORY  | (8) Shipment Description          |
| Over Top Dose Rate      | < 0.5 mR/hr  | < 0.5 mR/hr  | ES-94-00701/                      |
| Side Dose Rate          | 11 mR/hr   | 10 mR/hr   | 1070                              |
| Bottom Dose Rate        | < 0.5 mR/hr  | 0.5 mR/hr  |                                   |
| Smearable Contamination | < 20 $\mu$ g/10cm <sup>2</sup><br>(Alpha)<br>$\leq 1 K \text{dpm}/100 \text{cm}^2$<br>(Beta-Gamma) | < 20 dpm<br>(Alpha)<br>$\leq 1 K \text{dpm}/100 \text{cm}^2$<br>(Beta-Gamma) | 2-14-95 12:15 pm                  |
| RCT*                    | <u>Rhonda</u><br>(Signature)   | <u>S. Wink</u><br>(Signature)  | 10%                               |
|                         |  |  | 90%                               |
|                         |  |  | F. Dose Rate Through Drill String |
|                         |  |  | 1 R/hr                            |
|                         |  |  | G. Expected Sample Length         |
|                         |  |  | 10"                               |

(9) INFORMATION (Include statement of laboratory tests to be performed.)

00

WHC-SD-WM-DP-100, REV. 0-A

|                     |  |                          |  |  |
|---------------------|--|--------------------------|--|--|
| (10) Field Comments |  | (32) Laboratory Comments |  |  |
|---------------------|--|--------------------------|--|--|

|  |  |   |                                  |   |
|--|--|---|----------------------------------|---|
| (11) Point of Origin<br><u>241-AX-102</u>                                    | (12) Destination<br><u>222s Lab</u>                                      | (13) Sender Name (Sign and PRINT)<br><u>JAMES SICKELS</u>           | (14) Date/Time<br><u>2-15-95</u> | (15) Sender Comments  |
| (17) Relinquished By (Sign and PRINT)<br><u>JAMES SICKELS</u>                | (18) Received By (Sign and PRINT)<br><u>Chase E. Byrd &amp; CO. BYRD</u> | (19) Date/Time<br><u>2-15-95</u>                                    | (20) Receiver Comments           |   |
| (21) Relinquished By (Sign and PRINT)<br><u>Chase E. Byrd &amp; CO. BYRD</u> | (22) Received By (Sign and PRINT)<br><u>James Sickels</u>                | (23) Date/Time<br><u>02-15-95</u>                                   | (24) Receiver Comments           |   |
| (25) Relinquished By (Sign and PRINT)  | (26) Received By (Sign and PRINT)  | (27) Date/Time  | (28) Receiver Comments           |   |
| (16) Seal Intact Upon Release?   |  | (29) Seal Intact Upon Receipt?                                      |                                  |   |
| <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No          |  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |                                  |   |
|  |  | Shipment No.<br><u>2410 # AD-241-02</u>                             | Cask Seal No.<br><u>1054</u>     | Sample No.<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |

**WHC-SD-WM-DP-100, REV. 0A**

**LOGBOOK**

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

A4-18  
WHC-SD-WM-DP-100, REV. 0-A

| NOTEBOOK/LOGBOOK UNCLASSIFIED COVERSHEET  |  |                            |                                 |
|---|--|----------------------------|---------------------------------|
| <b>SECTION I</b><br><br><b>RECORD COPY</b><br><b>NOT FOR CIRCULATION</b><br><b>OCT 07 1994</b><br><b>RECEIVED WHC BCS</b><br><b>DOCUMENT CONTROL</b>  | Notebook No. <u>WHC-N-1064 1</u>   |                            |                                 |
|   | Date of Issue<br><u>10-7-94</u>  | Copy<br><u>#1</u>          |                                 |
|   | Title<br><u>241-AX-102</u>   |                            |                                 |
|   |  |                            |                                 |
| Author<br><u>Richard K Fuller</u>   | If continued from another notebook<br>give the notebook number   |                            |                                 |
| <p>This is a Controlled Notebook. The assigned custodian is responsible for this book. When the book is completed, contact your Records Management Specialist for a Retention Schedule. Complete Section II of this form and return the Notebook to Unclassified Document Control, A4-18.</p> |  |                            |                                 |
| Responsible Custodian<br><u>R.K. Fuller</u>   | Payroll No.<br><u>67528</u>  | MSIN<br><u>T6:31</u>       | Date Assigned<br><u>10-7-94</u> |
|   |  |                            |                                 |
|   |  |                            |                                 |
|   |  |                            |                                 |
| <b>SECTION II</b>   | Complete this section prior to returning notebook to Unclassified Document Control, A4-18  |                            |                                 |
| Abstract:   | (Give brief description of notebook contents)  |                            |                                 |
|   |  |                            |                                 |
|   |  |                            |                                 |
| Period Covered:   | (Inclusive dates - Month/Day/Year)   |                            |                                 |
| Certification Statement:  | This notebook does <input type="checkbox"/> does not <input type="checkbox"/> contain any Quality Assurance Record Material (as described in Section 9.0 of WHC-CM-3-5) and has been verified to be a complete and legible record. |                            |                                 |
| Custodian's Signature and Date  |  |                            |                                 |
| Retention Schedule:   | Specialist Concurrence Name  | Custodian's Manager's Name |                                 |

BD-6001-258 (10/93)

17-2

17-3

6-9

10-13

## CHAIN-OF-CUSTODY RECORD FOR AUGER SAMPLING

3-13-75  
 (1) Shipment Number 93-AUG-1 (2) Sample Number 95-AUG-6 (3) Supervisor T. Sackets  
 (4) Tank AX-102 (5) Riser SA (6) Cask Serial Number SN-25-6

## Radiation Survey Data:

Over Top Dose Rate < 5 MR/hr  
 Side Dose Rate 7 MR/hr  
 Bottom Dose Rate 2 MR/hr  
 Smearable Contamination < 20 cpm/10cm<sup>2</sup>  
 (Alpha) < 10 cpm/10cm<sup>2</sup>  
 (Beta-Gamma) < 10 cpm/10cm<sup>2</sup>

RCT: D. J. Amstutz  
 (Signature)

**COPY**

## (29) Seal Intact Upon Receipt?

 Yes No Yes No

## Shipment No.

 Yes No

## Cask Seal No.

 Yes No

## Sample No.

 Yes No

## (30) Seal Data Consistent with this Record?

|  |   |                          |
|--|---|--------------------------|
| (7) FIELD  | (31) LABORATORY                                       | (8) Shipment Description |
| <u>&lt; 5 MR/hr</u>  | <u>&lt; 0.5 mR/hr</u>                                 | <u>E-102-701</u>         |
| <u>7 MR/hr</u>   | <u>7 mR/hr</u>  | <u>3755</u>              |
| <u>2 MR/hr</u>   | <u>2 mR/hr</u>  |                          |
| <u>&lt; 20 cpm/10cm<sup>2</sup></u><br>(Alpha)                           | <u>&lt; 20 cpm/10cm<sup>2</sup></u><br>(Beta-Gamma)   |                          |
| <u>&lt; 10 cpm/10cm<sup>2</sup></u><br>(Beta-Gamma)                      | <u>&lt; 1000 cpm/10cm<sup>2</sup></u><br>(Beta-Gamma) |                          |
| RCT: <u>D. J. Amstutz</u><br>(Signature)                                 | RCT: <u>D. J. Amstutz</u><br>(Signature)              |                          |
| (9) INFORMATION (Include statement of laboratory tests to be performed.) |   |                          |
| <p><b>COPY</b></p> <p><i>M. A. Smith</i></p> <p><i>M. A. Smith</i></p>   |   |                          |
| (10) Field Comments  |   | (32) Laboratory Comments |
|  |   |                          |

|   |   |  |   |                      |
|---|---|--|---|----------------------|
| (11) Point of Origin<br><u>241-AP 102</u>                       | (12) Destination<br><u>2225 Labs</u>                        | (13) Sender Name (Sign and PRINT)<br><u>T. Sackets</u> | (14) Date/Time<br><u>2-13-95 11:05 AM</u> | (15) Sender Comments |
| (17) Relinquished By (Sign and PRINT)<br><u>Charla E. Tyrod</u> | (18) Received By (Sign and PRINT)<br><u>Charla E. Tyrod</u> | (19) Date/Time<br><u>2-13-95 11:32</u>                 | (20) Receiver Comments                    | <i>M. A. Smith</i>   |
| (21) Relinquished By (Sign and PRINT)<br><u>Charla E. Tyrod</u> | (22) Received By (Sign and PRINT)<br><u>Charla E. Tyrod</u> | (23) Date/Time<br><u>12:10</u><br><u>2-13-95</u>       | (24) Receiver Comments                    | <i>M. A. Smith</i>   |
| (25) Relinquished By (Sign and PRINT)<br><u>Charla E. Tyrod</u> | (26) Received By (Sign and PRINT)<br><u>Charla E. Tyrod</u> | (27) Date/Time   | (28) Receiver Comments                    | <i>M. A. Smith</i>   |

## (16) Seal Intact Upon Release?

 Yes No

## (29) Seal Intact Upon Receipt?

 Yes No

## (30) Seal Data Consistent with this Record?

## Shipment No.

 Yes No

## Cask Seal No.

 Yes No

## Sample No.

 Yes No

TCF-WM 30-WM-TP-227  
Sample #: 95-AUG-6  
Log book #: WHC-N-1064

work list # 619

Video Tape #4 Title AX-Farm

Hasselblad camera also was used Photo used = 8<sup>#</sup> Frame number

Balance check 20gm = 19.99g 500gm = 499.98gm

Hot Cell Temperature 78.8° Humidity 20%

\* There were NO liner liquid present.

\* description of solids: Dark Brown, very thin coating,  
like a film covering.

\* Sub sample description:

Vial # 6496

Size : 20ml

Final wt: 29.677g

Initial wt: 27.70

Net wt: 1.977

Collected material

Dark Brown, thin layer

Sludge, was taking from

flute 2-9.

Word perfect directory = (C:\Wf Data\WK Plans\AX-102 AUG INF)

Word perfect file = AX-102 AUG INF.

Lab core number = S95T000158

AX102\AX102AUG INF  
AX-102 A&B  
Farm

\* Sampler Efficiency: Auger

Volume of ABB 03/01/95

\* Estimated Auger percent recovery ≈ 25%

MARCH 27, 1975



RECAP: SAMPLE / JTHC INFORMATION

| JAN# / VIAL#   | MATERIAL (Type & Sub.) | MASS (GRAMS) |
|----------------|------------------------|--------------|
| C496 (Densize) | Solid                  | 1.97 grams   |

WHC-SD-WM-DP-100, REV. 0-A

AX102 95 AUG-006 P1SER 3A  
PHOTOGRAPH

MARCH 01, 95



### CHAIN-OF-CUSTODY RECORD FOR AUGER SAMPLING

(1) Shipment Number 241-AX-102 (2) Sample Number 95-AUG-7 (3) Supervisor Tim Sickels  
 (4) Tank 9E (5) Riser C 1054 (6) Cask Serial Number C 1054

Radiation Survey Data:

|                         |   |   |
|-------------------------|---|---|
| Over Top Dose Rate      | <u>&lt; 0.5 mR/hr</u>   | (7) FIELD   |
| Side Dose Rate          | <u>14 mR/hr</u>   | (31) LABORATORY   |
| Bottom Dose Rate        | <u>0.5 mR/hr</u>  | <u>5.05 mR/hr</u>   |
| Smearable Contamination | <u>20 pCi/100 cm<sup>2</sup></u><br>(Alpha)<br><u>1.1K dpm/100 cm<sup>2</sup></u><br>(Beta-Gamma) | <u>10 mR/hr</u><br><u>0.5 mR/hr</u><br><u>2.0 dpm</u><br>(Alpha)<br><u>1.1 Kdpm</u><br>(Beta-Gamma) |
| RCT*                    | <u>Planned</u><br>(Signature)   | RCT*  |

|                                   |                |
|-----------------------------------|----------------|
| (8) Shipment Description          |                |
| A. Work Package Number            | <u>ES-74</u>   |
| B. Cask Seal Number               | <u>1070</u>    |
| C. Date and Time Sample           | <u>2-14-95</u> |
| D. Expected Liquid Content        | <u>10%</u>     |
| E. Expected Solid Content         | <u>70%</u>     |
| F. Dose Rate Through Drill String | <u>1 R/h</u>   |
| G. Expected Sample Length         | <u>10"</u>     |

(9) INFORMATION (Include statement of laboratory tests to be performed.)

(10) Field Comments

(32) Laboratory Comments

|   |  |   |                                  |                      |
|---|--|---|----------------------------------|----------------------|
| (11) Point of Origin<br><u>241-AX-102</u>                             | (12) Destination<br><u>2225 Lab</u>                                | (13) Sender Name (Sign and PRINT)<br><u>JAMES SICKELS</u> | (14) Date/Time<br><u>2-15-95</u> | (15) Sender Comments |
| (17) Relinquished By (Sign and PRINT)<br><u>JAMES SICKELS</u>         | (18) Received By (Sign and PRINT)<br><u>Chase Edward GED BYRD</u>  | (19) Date/Time<br><u>2-15-95</u>                          | (20) Receiver Comments           |                      |
| (21) Relinquished By (Sign and PRINT)<br><u>Chase Edward GED BYRD</u> | (22) Received By (Sign and PRINT)<br><u>James Cobb Sandra Cobb</u> | (23) Date/Time<br><u>02-15-95</u>                         | (24) Receiver Comments           |                      |
| (25) Relinquished By (Sign and PRINT)                                 | (26) Received By (Sign and PRINT)                                  | (27) Date/Time  | (28) Receiver Comments           |                      |

|   |   |   |
|---|---|---|
| (16) Seal Intact Upon Release?<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | (29) Seal Intact Upon Receipt?<br><input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | (30) Seal Data Consistent with this Record?<br>Shipment No. <u>241-AX-102</u> Cask Seal No. <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No<br>Sample No. <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No |
|---|---|---|

March 01, 1995

SET 1-E 100 ml  
6.08 liter monitor  
1.000 ml. sample  
VIDEO TAPE: #1, FIX TAC

HASSELBLAD CAMERA: FRAME #1

BALANCE CHECK 20 grams = 19.99 grams 500 grams = 499.98 grams

Hot Cell Temp: 79°F % Humidity: 20%

LABCURE SAMPLE NUMBER: S95T000173

## EXTRUSION INFORMATION:

## \* DRAINABLE LIQUIDS

JAR NUMBER: 6407 # (40ml vial size)  
 Final wt 27.153 grams  
 Initial wt 25.050 grams  
 Net wt 2.07 grams

Liquid <sup>200</sup> is dark brown in color, turbid, collected  
approximately 2 mls; No organic layer present.

## \* Solids:

JAR NUMBER: 6559 (125ml JAR size)  
 Final wt 162.37 grams  
 Initial wt 127.92 grams  
 Net wt 34.45 grams

- Solid material was medium brown in color, moist  
resembled sludge.
- Collected material from Filter 2 thru 9.

## RECOVERY:

\* Estimated Auger percent recovery is 10%, based  
on a 10 inch expected sample length.

100-111-PEW(-4)

March 01, 1995

100-111-PEW(-4)

Initial weight (g) 162.26 (grams)

Final weight (g) 26.75 grams

Total weight 134.45 grams

NOTE: Without time removing the sleeve from the  
Ridge Guard spool in the groove stem  
made it difficult to remove the sleeve.

3-3-95

AX-102 95-AVG-007 Riser 9E

6559

125 mL

6522

20 mL



Initial wt.: 162.24 g  
Final wt.: 153.64 g  
Net wt.: 8.60 g

Initial wt.: 26.99  
Final wt.: 33.97  
Net wt.: 6.98

Vial # 6522 transferred to lab for TIC/TOC, OSC/TGA analysis.

AX102 95AUG-007 RISER 9E  
PHOTOGRAPH

March 8/95



WHC-SD-WM-DP-100, REV. 0A

SAMPLE ANALYSES RESULTS

**WHC-SD-WM-DP-100, REV. 0A**

**THIS PAGE WAS INTENTIONALLY LEFT BLANK**

Analyst: EC Instrument: BA000 Method: LO-160-103 A-7

Worklist Comment: AX-102 95-AUG-6 Riser 3A Extrusion

| Seg | Type      | Sample#    | Rep AlTest | Matrix   | Actual | Found  | DL                    | Unit |
|-----|-----------|------------|------------|----------|--------|--------|-----------------------|------|
| 1   | INSTCHK01 |            | EXTRUD01   | SOLID    | 20.00  | 19.99  | N/A                   |      |
| 2   | INSTCHK02 |            | EXTRUD01   | SOLID    | 500.00 | 499.98 | N/A                   |      |
| 3   | SAMPLE    | S95T000158 | 0          | DLIQVOL1 | SOLID  | N/A    | 0                     | mL   |
| 4   | SAMPLE    | S95T000158 | 0          | DLIQWT01 | SOLID  | N/A    | 0                     | g    |
| 5   | SAMPLE    | S95T000158 | 0          | EST.G/ML | SOLID  | N/A    | 0                     | g/mL |
| 6   | SAMPLE    | S95T000158 | 0          | EXTRUD01 | SOLID  | N/A    | Complete              |      |
| 7   | SAMPLE    | S95T000158 | 0          | LLIQWT01 | SOLID  | N/A    | 0                     | g    |
| 8   | SAMPLE    | S95T000158 | 0          | NOTEBOOK | SOLID  | N/A    | WHC-N-1064            |      |
| 9   | SAMPLE    | S95T000158 | 0          | SLDVOL01 | SOLID  | N/A    | 1.3<br>0-AB 4-3.45 mL | mL   |
| 10  | SAMPLE    | S95T000158 | 0          | SLDWT-01 | SOLID  | N/A    | 1.97                  | g    |
| 11  | SAMPLE    | S95T000158 | 0          | ORGVOL01 | SOLID  | N/A    | 0                     | mL   |

Final page for worklist # 619

R.H.  
\_\_\_\_\_  
Analyst Signature

ED  
\_\_\_\_\_  
Reviewed by: John B. Bay

3-1-95  
Date  
3-2-95  
3-3-95

Data Entry Comments:

22

Units shown for QC (SPK) may not reflect the actual units.

Page: 1

4/16/95

Analyst: SC Instrument: BA000 Method: LO-160-103 A-7

Worklist Comment: AX-102 95-AUG-7 Riser 9E Extrusion

| Seg | Type      | Sample#    | Rep AtTest | Matrix   | Actual | Found  | DL         | Unit |
|-----|-----------|------------|------------|----------|--------|--------|------------|------|
| 1   | INSTCHK01 |            | EXTRUD01   | SOLID    | 2000   | 19.99  | N/A        |      |
| 2   | INSTCHK02 |            | EXTRUD01   | SOLID    | 500.00 | 499.98 | N/A        |      |
| 3   | SAMPLE    | S95T000173 | 0          | DLIQVOL1 | SOLID  | N/A    | <5         | mL   |
| 4   | SAMPLE    | S95T000173 | 0          | DLIJWT01 | SOLID  | N/A    | 2.1        | g    |
| 5   | SAMPLE    | S95T000173 | 0          | EST.G/ML | SOLID  | N/A    | 1.1        | g/mL |
| 6   | SAMPLE    | S95T000173 | 0          | EXTRUD01 | SOLID  | N/A    | complete   |      |
| 7   | SAMPLE    | S95T000173 | 0          | LLIJWT01 | SOLID  | N/A    | 0          | g    |
| 8   | SAMPLE    | S95T000173 | 0          | NOTEBOOK | SOLID  | N/A    | WHC-N-1064 |      |
| 9   | SAMPLE    | S95T000173 | 0          | SLDVOLO1 | SOLID  | N/A    | 31.0       | mL   |
| 10  | SAMPLE    | S95T000173 | 0          | SLDWT-01 | SOLID  | N/A    | 34.45      | g    |
| 11  | SAMPLE    | S95T000173 | 0          | ORGVOL01 | SOLID  | N/A    | 0          | mL   |

Final page for worklist # 620



Analyst Signature

3-2-95

Date



3-3-95

Data Entry Comments:

---



---



---

## LABCORE Data Entry Template for Worklist# 639

Analyst: EC Instrument: BA000 Book # \_\_\_\_\_

Method: LO-160-103 Rev/Mod A-7

Worklist Comment: AX-102 Auger #6 and #7 Homogenization

| GROUP    | PROJECT | S TYPE      | SAMPLE#      | R A -----TEST----- | MATRIX | ACTUAL     | FOUND         | DL         | UNIT |
|----------|---------|-------------|--------------|--------------------|--------|------------|---------------|------------|------|
|          |         | 1 INSTCHK01 |              | EXTRUD01           | SOLID  | <u>20</u>  | <u>20.00</u>  | <u>N/A</u> |      |
|          |         | 2 INSTCHK02 |              | EXTRUD01           | SOLID  | <u>500</u> | <u>499.99</u> | <u>N/A</u> |      |
| 95000014 | AX-102  | 3 SAMPLE    | S95T000203 0 | HOMGNZ01           | SOLID  | <u>N/A</u> | <u>1.97</u>   |            |      |
| 95000015 | AX-102  | 4 SAMPLE    | S95T000205 0 | HOMGNZ01           | SOLID  | <u>N/A</u> | <u>6.98</u>   |            |      |

Final page for worklist # 639

EC 3-3-95  
Analyst Signature Date

Analyst Signature Date

S95T000203 - AX-102 95-AUG-006 SAMPLE V6496

S95T000205 - AX-102 95-AUG-007 SAMPLE V6559 → 6522

Reviewed by John B. Sung March 3, 95

Data Entry Comments:

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## LABCORE Data Entry Template for Worklist# 648

Analyst: MCJ Instrument: FUS01 AL11066 Book # \_\_\_\_\_Method: LA-549-141 Rev/Mod C-2

Worklist Comment: AX-102 FUSION DIGEST - 203---&gt;204, 206---&gt;208

50mrad/hr on sample  
w/Buster 3-6-95

| GROUP    | PROJECT | S TYPE      | SAMPLE#    | R A | TEST | MATRIX   | ACTUAL | FOUND         | DL            | UNIT    |
|----------|---------|-------------|------------|-----|------|----------|--------|---------------|---------------|---------|
|          |         | 1 BLNK-PREP |            |     |      | FUSION01 | SOLID  | <u>250</u>    | <u>250</u>    | N/A g/L |
| 95000014 | AX-102  | 2 SAMPLE    | S95T000204 | O F |      | FUSION01 | SOLID  | <u>N/A</u>    | <u>0.4280</u> | g/L     |
| 95000014 | AX-102  | 3 DUP       | S95T000204 | O F |      | FUSION01 | SOLID  | <u>0.4280</u> | <u>0.4560</u> | N/A g/L |
| 95000015 | AX-102  | 4 SAMPLE    | S95T000208 | O F |      | FUSION01 | SOLID  | <u>N/A</u>    | <u>0.4720</u> | g/L     |
| 95000015 | AX-102  | 5 DUP       | S95T000208 | O F |      | FUSION01 | SOLID  | <u>0.4720</u> | <u>0.4880</u> | N/A g/L |

## Final page for worklist # 648

Mike Jones 3-6-95  
 Analyst Signature Date  
 20ml HCl

$$204 \text{ smp} \frac{.107g}{.250L} = .428g/L$$

$$204 \text{ Dup} \frac{.114g}{.250L} = .456g/L$$

$$208 \text{ smp} \frac{.118g}{.250L} = .472g/L$$

$$208 \text{ Dup} \frac{.122g}{.250L} = .488g/L$$

Data Entry Comments:

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## LABCORE Data Entry Template for Worklist# 1131

Analyst: LMH2 Instrument: H2O01 AL11066 Book # N/A  
 Method: LA-504-101 Rev/Mod A-4 C-O

Worklist Comment: AX-102 WATER - 206- > 593

| GROUP    | PROJECT | S TYPE          | SAMPLE#    | R A | TEST | MATRIX   | ACTUAL | FOUND           | DL              | UNIT       |
|----------|---------|-----------------|------------|-----|------|----------|--------|-----------------|-----------------|------------|
|          |         | 1 BLNK-PREP     |            |     |      | H2ODIG01 | SOLID  | <u>50mL</u>     | <u>50mL</u>     | <u>N/A</u> |
|          |         | 50 mL Tot. Vol. |            |     |      |          |        |                 |                 | g/L        |
| 95000015 | AX-102  | 2 SAMPLE        | S95T000593 | 0 W |      | H2ODIG01 | SOLID  | <u>N/A</u>      | <u>10.7640g</u> | <u>N/A</u> |
| 0.5382   | → 50 mL |                 |            |     |      |          |        |                 |                 | g/L        |
| 95000015 | AX-102  | 3 DUP           | S95T000593 | 0 W |      | H2ODIG01 | SOLID  | <u>10.7640g</u> | <u>10.7020g</u> | <u>N/A</u> |
| 0.5351   | → 50 mL |                 |            |     |      |          |        |                 |                 | g/L        |

Final page for worklist # 1131

Jean Marie Gifford 04/19/95  
 Analyst Signature Date

Jean Marie Gifford 4/20/95  
 Analyst Signature Date

Data Entry Comments:

Samples dose Rate of 2mR/hr by  
Sig Yandoe (SMTK) 04/19/95  
Bethrand Griffin II 4-20-95

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## LABCORE Data Entry Template for Worklist# 764

Analyst: KRM Instrument: TIC01 Book # 15N12E  
10N12F

Method: LA-342-100 Rev/Mod A-O

Worklist Comment: TICTOC KRM AX-102

| GROUP    | PROJECT | S TYPE   | SAMPLE#      | R A -----TEST----- | MATRIX | ACTUAL                    | FOUND                     | DL           | UNIT |
|----------|---------|----------|--------------|--------------------|--------|---------------------------|---------------------------|--------------|------|
|          |         | 1 BLNK   |              | @TICTOC1 TIC-02    | SOLID  | <u>1</u>                  | <u>6.2</u>                | N/A          | ug/g |
|          |         | 1 BLNK   |              | @TICTOC1 TOC-02    | SOLID  | <u>1</u>                  | <u>36.7</u>               | N/A          | ug/g |
|          |         | 2 STD    |              | @TICTOC1 TIC-02    | SOLID  | <u>6.00E<sup>-2</sup></u> | <u>5.75E<sup>-2</sup></u> | N/A          | ug/g |
|          |         | 2 STD    |              | @TICTOC1 TOC-02    | SOLID  | <u>3.00E<sup>-3</sup></u> | <u>2.76E<sup>-3</sup></u> | N/A          | ug/g |
| 95000014 | AX-102  | 3 SAMPLE | S95T000203 0 | @TICTOC1 TIC-02    | SOLID  | <u>N/A</u>                | <u>1.93E<sup>-4</sup></u> | <u>5.0e0</u> | ug/g |
| 95000014 | AX-102  | 3 SAMPLE | S95T000203 0 | @TICTOC1 TOC-02    | SOLID  | <u>N/A</u>                | <u>4.94E<sup>-4</sup></u> | <u>8.0e1</u> | ug/g |
| 95000014 | AX-102  | 4 DUP    | S95T000203 0 | @TICTOC1 TIC-02    | SOLID  | <u>1.93E<sup>-4</sup></u> | <u>1.58E<sup>-4</sup></u> | N/A          | ug/g |
| 95000014 | AX-102  | 4 DUP    | S95T000203 0 | @TICTOC1 TOC-02    | SOLID  | <u>4.94E<sup>-4</sup></u> | <u>4.93E<sup>-4</sup></u> | N/A          | ug/g |
| 95000014 | AX-102  | 5 SPK    | S95T000203 0 | @TICTOC1 TIC-02    | SOLID  | <u>100</u>                | <u>129</u>                | N/A          | ug/g |
| 95000014 | AX-102  | 5 SPK    | S95T000203 0 | @TICTOC1 TOC-02    | SOLID  | <u>100</u>                | <u>161</u>                | N/A          | ug/g |
| 95000015 | AX-102  | 6 SAMPLE | S95T000206 0 | @TICTOC1 TIC-02    | SOLID  | <u>N/A</u>                | <u>1.57E<sup>-4</sup></u> | <u>5.0e0</u> | ug/g |
| 95000015 | AX-102  | 6 SAMPLE | S95T000206 0 | @TICTOC1 TOC-02    | SOLID  | <u>N/A</u>                | <u>5.75E<sup>-4</sup></u> | <u>8.0e1</u> | ug/g |
| 95000015 | AX-102  | 7 DUP    | S95T000206 0 | @TICTOC1 TIC-02    | SOLID  | <u>1.57E<sup>-4</sup></u> | <u>1.44E<sup>-4</sup></u> | N/A          | ug/g |
| 95000015 | AX-102  | 7 DUP    | S95T000206 0 | @TICTOC1 TOC-02    | SOLID  | <u>5.75E<sup>-4</sup></u> | <u>5.93E<sup>-4</sup></u> | N/A          | ug/g |

Final page for worklist # 764

 Analyst Signature

Date 3-22-95

 Analyst Signature

Date 3-29-95

Data Entry Comments:

COULOMETER SOLN TURNED FOGGY, INDICATING A

SAMPLE INCOMPATABILITY WITH THIS METHOD. REANALYSIS WILL  
BE PERFORMED WITH ADDITIONAL SCRUBBERS SUPPLIED.

QC 3-31-95

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number,  
R = Replicate Number, A = Aliquot Code.

## TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT

TICTOC REV 2.0

&lt;&lt;&lt; BLANK ANALYSIS &gt;&gt;&gt;

Sample: BLK

Date: 03/22/95

Time: 00:29:41

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # = BLK  
 Blank Value = N/A

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.20       | 0.00            |
| 2             | 1.01          | 0.50       | 60.00           |
| 3             | 1.51          | 0.80       | 37.50           |
| 4             | 2.00          | 1.30       | 38.46           |
| 5             | 2.50          | 1.60       | 18.75           |
| 6             | 3.00          | 1.80       | 11.11           |
| 7             | 3.50          | 2.10       | 14.29           |
| 8             | 4.00          | 2.40       | 12.50           |
| 9             | 4.50          | 2.60       | 7.69            |
| 10            | 5.00          | 3.00       | 13.33           |
| 11            | 5.50          | 3.20       | 6.25            |
| 12            | 6.00          | 3.40       | 5.88            |
| 13            | 6.50          | 3.70       | 8.11            |
| 14            | 7.00          | 4.00       | 7.50            |
| 15            | 7.50          | 4.30       | 6.98            |
| 16            | 8.00          | 4.50       | 4.44            |
| 17            | 8.50          | 4.80       | 6.25            |
| 18            | 9.00          | 5.10       | 5.88            |
| 19            | 9.50          | 5.40       | 5.56            |
| 20            | 10.00         | 5.70       | 5.26            |
| 21            | 10.50         | 5.90       | 3.39            |
| 22            | 11.00         | 6.20       | 4.84            |

SIGNATURE BELOW REPRESENTS CHEMICAL TECHNOLOGIST/CHEMIST THAT  
 COMPLETED/VERIFIED THE CALIBRATION/ANALYSIS ON PAGES 28 TO 49.

BLANK VALUE = 6.2 micrograms carbon

BLANK FACTOR = 6.2 / 10.99883 =

+5.6E-01 ug/min Carbon

Sample Run By:

KR MONTEITH

3-22-95

00000

WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0  
<<< BLANK ANALYSIS >>>

Sample: BLK

Date: 03/22/95

Time: 00:41:41

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # = BLK  
Blank Value = N/A

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time == | Coulometer == | % Difference == |
|---------------|------------------|---------------|-----------------|
| 1             | 0.51             | 1.10          | 0.00            |
| 2             | 1.01             | 7.60          | 85.53           |
| 3             | 1.50             | 16.50         | 53.94           |
| 4             | 2.00             | 21.00         | 21.43           |
| 5             | 2.50             | 23.20         | 9.48            |
| 6             | 3.00             | 24.50         | 5.31            |
| 7             | 3.50             | 25.70         | 4.67            |
| 8             | 4.00             | 26.80         | 4.10            |
| 9             | 4.50             | 28.10         | 4.63            |
| 10            | 5.00             | 29.30         | 4.10            |
| 11            | 5.50             | 30.00         | 2.33            |
| 12            | 6.00             | 31.80         | 5.66            |
| 13            | 6.50             | 31.80         | 0.00            |
| 14            | 7.00             | 32.50         | 2.15            |
| 15            | 7.50             | 33.00         | 1.52            |
| 16            | 8.00             | 33.60         | 1.79            |
| 17            | 8.50             | 34.20         | 1.75            |
| 18            | 9.00             | 34.70         | 1.44            |
| 19            | 9.50             | 35.20         | 1.42            |
| 20            | 10.00            | 35.70         | 1.40            |
| 21            | 10.50            | 36.30         | 1.65            |
| 22            | 11.00            | 36.70         | 1.09            |

BLANK VALUE = 36.7 micrograms carbon

BLANK FACTOR = 36.7 / 10.997 = +3.34E+00 ug/min Carbon

<<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

## WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: STD

Date: 03/22/95

Time: 00:53:40

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 1.70       | 0.00            |
| 2             | 1.01          | 88.00      | 98.07           |
| 3             | 1.50          | 253.00     | 65.22           |
| 4             | 2.00          | 403.10     | 37.24           |
| 5             | 2.50          | 495.30     | 18.61           |
| 6             | 3.00          | 541.00     | 8.45            |
| 7             | 3.50          | 558.80     | 3.19            |
| 8             | 4.00          | 565.50     | 1.18            |
| 9             | 4.50          | 568.50     | 0.53            |
| 10            | 5.00          | 570.10     | 0.28            |
| 11            | 5.50          | 571.30     | 0.21            |
| 12            | 6.00          | 572.40     | 0.19            |
| 13            | 6.50          | 574.40     | 0.35            |
| 14            | 7.00          | 575.80     | 0.24            |
| 15            | 7.50          | 576.90     | 0.19            |
| 16            | 8.00          | 577.70     | 0.14            |
| 17            | 8.50          | 578.40     | 0.12            |
| 18            | 9.00          | 579.10     | 0.12            |
| 19            | 9.50          | 579.70     | 0.10            |
| 20            | 10.00         | 580.20     | 0.09            |
| 21            | 10.50         | 580.60     | 0.07            |
| 22            | 11.00         | 581.20     | 0.10            |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

( 581.2 - 6.159906 ) (1) / ~~12~~ =  
 ( 581.2 - 6.159906 ) (1) / (1) (12) =

~~5.75E-2~~ <sup>5.75E-2</sup> ~~+5.750E+02~~ <sup>Mar 22-95</sup> g/L Carbon  
~~+4.792E+01~~ Molar Carbon

Sample Run By:

KR MONTEITH

00000

30

1 mc - 15N12E

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: STD

Date: 03/22/95

Time: 01:58:51

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

== Reading ===== Analysis Time ===== Coulometer ===== % Difference ==

| 1  | 0.51  | 13.00  | 0.00  |
|----|-------|--------|-------|
| 2  | 1.01  | 214.20 | 93.93 |
| 3  | 1.51  | 534.10 | 59.90 |
| 4  | 2.01  | 664.60 | 19.64 |
| 5  | 2.51  | 697.60 | 4.73  |
| 6  | 3.01  | 707.70 | 1.43  |
| 7  | 3.50  | 711.80 | 0.58  |
| 8  | 4.00  | 713.90 | 0.29  |
| 9  | 4.50  | 715.90 | 0.28  |
| 10 | 5.00  | 717.50 | 0.22  |
| 11 | 5.50  | 718.90 | 0.19  |
| 12 | 6.00  | 720.00 | 0.15  |
| 13 | 6.50  | 721.00 | 0.14  |
| 14 | 7.00  | 721.90 | 0.12  |
| 15 | 7.50  | 722.90 | 0.14  |
| 16 | 8.00  | 723.60 | 0.10  |
| 17 | 8.50  | 724.50 | 0.12  |
| 18 | 9.00  | 725.20 | 0.10  |
| 19 | 9.50  | 725.80 | 0.08  |
| 20 | 10.00 | 726.40 | 0.08  |
| 21 | 10.50 | 727.10 | 0.10  |
| 22 | 11.00 | 727.70 | 0.08  |

## USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 727.7 - 36.74224 ) (1) / <sup>(250)</sup> <sub>11</sub> = <sup>2.76 ± 0</sup>  
 ( 727.7 - 36.74224 ) (1) / (1) (12) = <sup>+6.910E+02</sup><sub>3.22-65</sub> g/L Carbon  
 +5.758E+01 Molar Carbon

<<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

## WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/22/95

Time: 02:24:13

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 3.40       | 0.00            |
| 2             | 1.01          | 54.50      | 93.76           |
| 3             | 1.50          | 286.70     | 80.99           |
| 4             | 2.00          | 492.40     | 41.77           |
| 5             | 2.50          | 628.90     | 21.70           |
| 6             | 3.00          | 697.70     | 9.86            |
| 7             | 3.50          | 729.80     | 4.40            |
| 8             | 4.00          | 743.00     | 1.78            |
| 9             | 4.50          | 748.50     | 0.73            |
| 10            | 5.00          | 751.70     | 0.43            |
| 11            | 5.50          | 753.70     | 0.27            |
| 12            | 6.00          | 755.20     | 0.20            |
| 13            | 6.50          | 756.90     | 0.22            |
| 14            | 7.00          | 757.70     | 0.11            |
| 15            | 7.50          | 758.70     | 0.13            |
| 16            | 8.00          | 759.60     | 0.12            |
| 17            | 8.50          | 760.60     | 0.13            |
| 18            | 9.00          | 761.10     | 0.07            |
| 19            | 9.50          | 761.80     | 0.09            |
| 20            | 10.00         | 762.50     | 0.09            |
| 21            | 10.50         | 763.10     | 0.08            |
| 22            | 11.00         | 763.60     | 0.07            |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

|                                     |                         |
|-------------------------------------|-------------------------|
| ( 763.6 - 6.160376 ) (1)/(1) =      | +7.574E+02 g/L Carbon   |
| ( 763.6 - 6.160376 ) (1)/(1) (12) = | +6.312E+01 Molar Carbon |

Sample Run By:

KR MONTEITH

00000

.05722

32

JNFO

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/22/95

Time: 02:36:35

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 8.30       | 0.00            |
| 2             | 1.01          | 252.60     | 96.71           |
| 3             | 1.51          | 702.10     | 64.02           |
| 4             | 2.00          | 1433.40    | 51.02           |
| 5             | 2.50          | 2180.00    | 34.25           |
| 6             | 3.00          | 2431.40    | 10.34           |
| 7             | 3.50          | 2521.50    | 3.57            |
| 8             | 4.00          | 2574.50    | 2.06            |
| 9             | 4.50          | 2606.70    | 1.24            |
| 10            | 5.00          | 2629.00    | 0.85            |
| 11            | 5.50          | 2645.60    | 0.63            |
| 12            | 6.00          | 2658.30    | 0.48            |
| 13            | 6.50          | 2669.50    | 0.42            |
| 14            | 7.00          | 2678.40    | 0.33            |
| 15            | 7.50          | 2685.40    | 0.26            |
| 16            | 8.00          | 2692.00    | 0.25            |
| 17            | 8.50          | 2697.30    | 0.20            |
| 18            | 9.00          | 2701.70    | 0.16            |
| 19            | 9.50          | 2705.40    | 0.14            |
| 20            | 10.00         | 2708.90    | 0.13            |
| 21            | 10.50         | 2711.30    | 0.09            |
| 22            | 11.00         | 2713.50    | 0.08            |

## USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 2713.5 - 36.73944 )(1)/(1) = +2.6768E+03 g/L Carbon  
 ( 2713.5 - 36.73944 )(1)/(1)(12) = +2.2306E+02 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

.0572

33

INFO

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/22/95

Time: 02:48:31

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | == % Difference == |
|---------------|---------------|------------|--------------------|
| 1             | 0.51          | 1.70       | 0.00               |
| 2             | 1.01          | 25.40      | 93.31              |
| 3             | 1.51          | 99.90      | 74.57              |
| 4             | 2.00          | 164.20     | 39.16              |
| 5             | 2.50          | 205.60     | 20.14              |
| 6             | 3.00          | 225.20     | 8.70               |
| 7             | 3.50          | 235.00     | 4.17               |
| 8             | 4.00          | 240.50     | 2.29               |
| 9             | 4.50          | 244.20     | 1.52               |
| 10            | 5.00          | 247.70     | 1.41               |
| 11            | 5.50          | 253.50     | 2.29               |
| 12            | 6.00          | 261.20     | 2.95               |
| 13            | 6.50          | 269.20     | 2.97               |
| 14            | 7.00          | 276.60     | 2.68               |
| 15            | 7.50          | 283.00     | 2.26               |
| 16            | 8.00          | 289.00     | 2.08               |
| 17            | 8.50          | 293.60     | 1.57               |
| 18            | 9.00          | 297.70     | 1.38               |
| 19            | 9.50          | 301.20     | 1.16               |
| 20            | 10.00         | 304.40     | 1.05               |
| 21            | 10.50         | 307.20     | 0.91               |
| 22            | 11.00         | 309.80     | 0.84               |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

|                                       |                         |
|---------------------------------------|-------------------------|
| ( 309.8 - 6.160376 ) (1) / (1) =      | +3.036E+02 g/L Carbon   |
| ( 309.8 - 6.160376 ) (1) / (1) (12) = | +2.530E+01 Molar Carbon |

Sample Run By:

KR MONTEITH

00000

.01579

34

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/22/95

Time: 03:00:39

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading | ==== Analysis Time | ===== Coulometer | ===== % Difference == |
|------------|--------------------|------------------|-----------------------|
| 1          | 0.51               | 2.50             | 0.00                  |
| 2          | 1.01               | 54.10            | 95.38                 |
| 3          | 1.50               | 114.80           | 52.87                 |
| 4          | 2.00               | 162.10           | 29.18                 |
| 5          | 2.50               | 205.40           | 21.08                 |
| 6          | 3.00               | 237.60           | 13.55                 |
| 7          | 3.50               | 254.20           | 6.53                  |
| 8          | 4.00               | 410.70           | 38.11                 |
| 9          | 4.50               | 612.50           | 32.95                 |
| 10         | 5.00               | 696.60           | 12.07                 |
| 11         | 5.50               | 737.90           | 5.60                  |
| 12         | 6.00               | 758.00           | 2.65                  |
| 13         | 6.50               | 771.00           | 1.69                  |
| 14         | 7.00               | 779.90           | 1.14                  |
| 15         | 7.50               | 787.10           | 0.91                  |
| 16         | 8.00               | 792.80           | 0.72                  |
| 17         | 8.50               | 797.70           | 0.61                  |
| 18         | 9.00               | 801.80           | 0.51                  |
| 19         | 9.50               | 804.90           | 0.39                  |
| 20         | 10.00              | 807.70           | 0.35                  |
| 21         | 10.50              | 810.10           | 0.30                  |
| 22         | 11.00              | 812.10           | 0.25                  |

## USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 812.1 - 36.73613 ) (1)/(1) = +7.754E+02 g/L Carbon  
 ( 812.1 - 36.73613 ) (1)/(1)(12) = +6.461E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

35

.01572

## WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/22/95

Time: 03:19:38

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | == % Difference == |
|---------------|---------------|------------|--------------------|
| 1             | 0.51          | 0.40       | 0.00               |
| 2             | 1.01          | 14.50      | 97.24              |
| 3             | 1.51          | 66.70      | 78.26              |
| 4             | 2.00          | 119.40     | 44.14              |
| 5             | 2.50          | 155.20     | 23.07              |
| 6             | 3.00          | 173.70     | 10.65              |
| 7             | 3.50          | 181.30     | 4.19               |
| 8             | 4.00          | 184.70     | 1.84               |
| 9             | 4.50          | 186.30     | 0.86               |
| 10            | 5.00          | 187.60     | 0.69               |
| 11            | 5.50          | 189.30     | 0.90               |
| 12            | 6.00          | 191.50     | 1.15               |
| 13            | 6.50          | 194.80     | 1.69               |
| 14            | 7.00          | 197.80     | 1.52               |
| 15            | 7.50          | 201.20     | 1.69               |
| 16            | 8.00          | 203.70     | 1.23               |
| 17            | 8.50          | 206.20     | 1.21               |
| 18            | 9.00          | 208.30     | 1.01               |
| 19            | 9.50          | 210.20     | 0.90               |
| 20            | 10.00         | 211.90     | 0.80               |
| 21            | 10.50         | 213.40     | 0.70               |
| 22            | 11.00         | 214.60     | 0.56               |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

( 214.6 - 6.158787 ) (1) / (1) = +2.084E+02 g/L Carbon  
 ( 214.6 - 6.158787 ) (1) / (1) (12) = +1.737E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/22/95

Time: 03:31:41

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading | ==== Analysis Time | ===== Coulometer | ==== % Difference == |
|------------|--------------------|------------------|----------------------|
| 1          | 0.51               | 0.50             | 0.00                 |
| 2          | 1.01               | 56.90            | 99.12                |
| 3          | 1.51               | 149.60           | 61.97                |
| 4          | 2.00               | 363.10           | 58.80                |
| 5          | 2.50               | 525.30           | 30.88                |
| 6          | 3.00               | 590.80           | 11.09                |
| 7          | 3.50               | 620.40           | 4.77                 |
| 8          | 4.00               | 636.10           | 2.47                 |
| 9          | 4.50               | 646.20           | 1.56                 |
| 10         | 5.00               | 653.30           | 1.09                 |
| 11         | 5.50               | 659.20           | 0.90                 |
| 12         | 6.00               | 664.10           | 0.74                 |
| 13         | 6.50               | 668.20           | 0.61                 |
| 14         | 7.00               | 671.80           | 0.54                 |
| 15         | 7.50               | 674.50           | 0.40                 |
| 16         | 8.00               | 677.50           | 0.44                 |
| 17         | 8.50               | 679.80           | 0.34                 |
| 18         | 9.00               | 682.10           | 0.34                 |
| 19         | 9.50               | 684.00           | 0.28                 |
| 20         | 10.00              | 685.30           | 0.19                 |
| 21         | 10.50              | 686.60           | 0.19                 |
| 22         | 11.00              | 687.80           | 0.17                 |

## USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 687.8 - 36.74224 ) (1)/(1) = +6.511E+02 g/L Carbon  
 ( 687.8 - 36.74224 ) (1)/(1) (12) = +5.425E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

37

.0132g

100-16-0003  
WHC-SD-WM-DP-100, REV. 0-ATIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203 + SPK

Date: 03/22/95

Time: 03:44:34

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.80       | 0.00            |
| 2             | 1.01          | 23.20      | 96.55           |
| 3             | 1.51          | 126.30     | 81.63           |
| 4             | 2.01          | 225.30     | 43.94           |
| 5             | 2.51          | 292.20     | 22.90           |
| 6             | 3.01          | 327.90     | 10.89           |
| 7             | 3.51          | 343.20     | 4.46            |
| 8             | 4.01          | 349.80     | 1.89            |
| 9             | 4.50          | 353.20     | 0.96            |
| 10            | 5.00          | 355.50     | 0.65            |
| 11            | 5.50          | 357.70     | 0.62            |
| 12            | 6.00          | 359.40     | 0.47            |
| 13            | 6.50          | 361.30     | 0.53            |
| 14            | 7.00          | 363.10     | 0.50            |
| 15            | 7.50          | 364.90     | 0.49            |
| 16            | 8.00          | 366.70     | 0.49            |
| 17            | 8.50          | 368.60     | 0.52            |
| 18            | 9.00          | 371.10     | 0.67            |
| 19            | 9.50          | 373.50     | 0.64            |
| 20            | 10.00         | 376.00     | 0.66            |
| 21            | 10.50         | 378.60     | 0.69            |
| 22            | 11.50         | 383.30     | 1.23            |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

$$(383.3 - 6.440752) / (1) = +3.769E+02 \text{ g/L Carbon}$$
$$(383.3 - 6.440752) / (1) (12) = +3.140E+01 \text{ Molar Carbon}$$

Sample Run By:

KR MONTEITH

00000

$$\frac{383.3 - (193.0 \times .0095) - 6.2}{100 \times .250} = 129\%$$

38

$$.0095 + .250 = 15N12 E$$

*3-22-95*  
*ENFO* *3-22-95*  
*ONLY*

**WHC-SD-WM-DP-100, REV. 0-A**  
 TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
 TICTOC REV 2.0

Sample: 203 + SPK

Date: 03/22/95

Time: 04:54:20

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 2.20       | 0.00            |
| 2             | 1.00          | 72.00      | 96.94           |
| 3             | 1.50          | 182.00     | 60.44           |
| 4             | 2.00          | 281.90     | 35.44           |
| 5             | 2.50          | 374.60     | 24.75           |
| 6             | 3.00          | 433.90     | 13.67           |
| 7             | 3.50          | 501.30     | 13.45           |
| 8             | 4.00          | 734.30     | 31.73           |
| 9             | 4.50          | 855.00     | 14.12           |
| 10            | 5.00          | 906.90     | 5.72            |
| 11            | 5.50          | 932.40     | 2.73            |
| 12            | 6.00          | 946.30     | 1.47            |
| 13            | 6.50          | 955.50     | 0.96            |
| 14            | 7.00          | 963.00     | 0.78            |
| 15            | 7.50          | 968.60     | 0.58            |
| 16            | 8.00          | 973.30     | 0.48            |
| 17            | 8.50          | 977.30     | 0.41            |
| 18            | 9.00          | 980.60     | 0.34            |
| 19            | 9.50          | 983.70     | 0.32            |
| 20            | 10.00         | 986.20     | 0.25            |
| 21            | 10.50         | 988.40     | 0.22            |
| 22            | 11.00         | 990.10     | 0.17            |

USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

SAMPLE RESULTS:

( 990.1 - 36.74224 ) (1)/(1) = +9.534E+02 g/L Carbon  
 ( 990.1 - 36.74224 ) (1)/(1)(12) = +7.945E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

39

990 - (49,400 X .0095) - 36.7

.0095 + .100 10N12 F

3000 X 0.100

= 1617

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203 + SPK

Date: 03/22/95

Time: 05:07:55

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.30       | 0.00            |
| 2             | 1.00          | 24.10      | 98.76           |
| 3             | 1.50          | 119.40     | 79.82           |
| 4             | 2.00          | 213.80     | 44.15           |
| 5             | 2.50          | 281.90     | 24.16           |
| 6             | 3.00          | 323.60     | 12.89           |
| 7             | 3.50          | 344.90     | 6.18            |
| 8             | 4.00          | 354.30     | 2.65            |
| 9             | 4.50          | 357.90     | 1.01            |
| 10            | 5.00          | 360.00     | 0.58            |
| 11            | 5.50          | 361.10     | 0.30            |
| 12            | 6.00          | 362.10     | 0.28            |
| 13            | 6.50          | 362.90     | 0.22            |
| 14            | 7.00          | 363.50     | 0.17            |
| 15            | 7.50          | 364.00     | 0.14            |
| 16            | 8.00          | 364.50     | 0.14            |
| 17            | 8.50          | 365.10     | 0.16            |
| 18            | 9.00          | 365.50     | 0.11            |
| 19            | 9.50          | 365.80     | 0.08            |
| 20            | 10.00         | 366.20     | 0.11            |
| 21            | 10.50         | 366.60     | 0.11            |
| 22            | 11.00         | 367.00     | 0.11            |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

|                                   |                         |
|-----------------------------------|-------------------------|
| ( 367 - 6.160359 ) (1)/(1) =      | +3.608E+02 g/L Carbon   |
| ( 367 - 6.160359 ) (1)/(1) (12) = | +3.007E+01 Molar Carbon |

Sample Run By:

KR MONTEITH

00000

40

.0089g +/- 250mg 15N12F

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203 + SPK

Date: 03/22/95

Time: 05:20:01

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 1.40       | 0.00            |
| 2             | 1.01          | 84.40      | 98.34           |
| 3             | 1.50          | 191.40     | 55.90           |
| 4             | 2.00          | 304.30     | 37.10           |
| 5             | 2.50          | 380.70     | 20.07           |
| 6             | 3.00          | 547.00     | 30.40           |
| 7             | 3.50          | 817.60     | 33.10           |
| 8             | 4.00          | 933.00     | 12.37           |
| 9             | 4.50          | 984.40     | 5.22            |
| 10            | 5.00          | 1010.00    | 2.53            |
| 11            | 5.50          | 1024.10    | 1.38            |
| 12            | 6.00          | 1033.60    | 0.92            |
| 13            | 6.50          | 1041.00    | 0.71            |
| 14            | 7.00          | 1046.70    | 0.54            |
| 15            | 7.50          | 1051.50    | 0.46            |
| 16            | 8.00          | 1055.90    | 0.42            |
| 17            | 8.50          | 1059.50    | 0.34            |
| 18            | 9.00          | 1062.90    | 0.32            |
| 19            | 9.50          | 1065.80    | 0.27            |
| 20            | 10.00         | 1068.20    | 0.22            |
| 21            | 10.50         | 1070.40    | 0.21            |
| 22            | 11.00         | 1072.50    | 0.20            |

## USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 1072.5 - 36.73939 ) (1)/(1) = +1.0358E+03 g/L Carbon  
 ( 1072.5 - 36.73939 ) (1)/(1)(12) = +8.6313E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

41

.00892 + .100 m 10N12 F

11/16/92  
WHC-SD-WM-DP-100, REV. 0-ATIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/22/95

Time: 05:31:56

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 1.70       | 0.00            |
| 2             | 1.00          | 74.60      | 97.72           |
| 3             | 1.50          | 248.90     | 70.03           |
| 4             | 2.00          | 370.00     | 32.73           |
| 5             | 2.50          | 445.50     | 16.95           |
| 6             | 3.00          | 485.80     | 8.30            |
| 7             | 3.50          | 502.60     | 3.34            |
| 8             | 4.00          | 508.80     | 1.22            |
| 9             | 4.50          | 511.90     | 0.61            |
| 10            | 5.00          | 514.20     | 0.45            |
| 11            | 5.50          | 516.10     | 0.37            |
| 12            | 6.00          | 517.70     | 0.31            |
| 13            | 6.50          | 519.20     | 0.29            |
| 14            | 7.00          | 520.50     | 0.25            |
| 15            | 7.50          | 521.70     | 0.23            |
| 16            | 8.00          | 522.90     | 0.23            |
| 17            | 8.50          | 524.00     | 0.21            |
| 18            | 9.00          | 525.10     | 0.21            |
| 19            | 9.50          | 526.40     | 0.25            |
| 20            | 10.00         | 527.40     | 0.19            |
| 21            | 10.50         | 528.40     | 0.19            |
| 22            | 11.00         | 529.20     | 0.15            |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

( 529.2 - 6.160359 ) (1)/(1) = +5.230E+02 g/L Carbon  
( 529.2 - 6.160359 ) (1)/(1)(12) = +4.359E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

.03632

42

INFO

WHC-SD-WM-DP-100, REV. 0-A  
TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/22/95

Time: 05:44:05

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer == | % Difference == |
|---------------|---------------|---------------|-----------------|
| 1             | 0.51          | 0.90          | 0.00            |
| 2             | 1.01          | 142.40        | 99.37           |
| 3             | 1.51          | 325.00        | 56.18           |
| 4             | 2.00          | 451.70        | 28.05           |
| 5             | 2.50          | 541.60        | 16.60           |
| 6             | 3.00          | 624.00        | 13.21           |
| 7             | 3.50          | 1071.40       | 41.76           |
| 8             | 4.00          | 1380.90       | 22.41           |
| 9             | 4.50          | 1497.20       | 7.77            |
| 10            | 5.00          | 1556.10       | 3.79            |
| 11            | 5.50          | 1590.60       | 2.17            |
| 12            | 6.00          | 1611.30       | 1.28            |
| 13            | 6.50          | 1626.00       | 0.90            |
| 14            | 7.00          | 1637.50       | 0.70            |
| 15            | 7.50          | 1646.80       | 0.56            |
| 16            | 8.00          | 1655.00       | 0.50            |
| 17            | 8.50          | 1661.70       | 0.40            |
| 18            | 9.00          | 1667.60       | 0.35            |
| 19            | 9.50          | 1672.70       | 0.30            |
| 20            | 10.00         | 1677.00       | 0.26            |
| 21            | 10.50         | 1680.70       | 0.22            |
| 22            | 11.00         | 1684.00       | 0.20            |

USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon  
BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

SAMPLE RESULTS:

( 1684 - 36.73949 ) (1)/(1) = +1.6473E+03 g/L Carbon  
( 1684 - 36.73949 ) (1)/(1)(12) = +1.3727E+02 Molar Carbon  
<<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By: KR MONTEITH 00000

-03632

43

XNFO

## WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/22/95

Time: 05:56:41

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer == | % Difference == |
|---------------|---------------|---------------|-----------------|
| 1             | 0.51          | 2.40          | 0.00            |
| 2             | 1.01          | 45.80         | 94.76           |
| 3             | 1.51          | 145.30        | 68.48           |
| 4             | 2.00          | 214.70        | 32.32           |
| 5             | 2.50          | 257.50        | 16.62           |
| 6             | 3.00          | 279.80        | 7.97            |
| 7             | 3.50          | 289.50        | 3.35            |
| 8             | 4.00          | 293.80        | 1.46            |
| 9             | 4.50          | 296.00        | 0.74            |
| 10            | 5.00          | 297.80        | 0.60            |
| 11            | 5.50          | 299.10        | 0.43            |
| 12            | 6.00          | 300.10        | 0.33            |
| 13            | 6.50          | 301.30        | 0.40            |
| 14            | 7.00          | 302.20        | 0.30            |
| 15            | 7.50          | 303.20        | 0.33            |
| 16            | 8.00          | 304.00        | 0.26            |
| 17            | 8.50          | 304.90        | 0.30            |
| 18            | 9.00          | 305.60        | 0.23            |
| 19            | 9.50          | 306.30        | 0.23            |
| 20            | 10.00         | 307.00        | 0.23            |
| 21            | 10.50         | 307.70        | 0.23            |
| 22            | 11.00         | 308.40        | 0.23            |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

|                                    |                         |
|------------------------------------|-------------------------|
| ( 308.4 - 6.15935 ) (1)/(1) =      | +3.022E+02 g/L Carbon   |
| ( 308.4 - 6.15935 ) (1)/(1) (12) = | +2.519E+01 Molar Carbon |

Sample Run By:

KR MONTEITH

00000

01929

44

WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/22/95

Time: 06:08:37

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

|    | Analysis | Time    | Coulometer | % Difference |
|----|----------|---------|------------|--------------|
| 1  | 0.51     | 1.00    |            | 0.00         |
| 2  | 1.01     | 78.90   |            | 98.73        |
| 3  | 1.51     | 168.90  |            | 53.29        |
| 4  | 2.01     | 231.60  |            | 27.07        |
| 5  | 2.50     | 286.00  |            | 19.02        |
| 6  | 3.00     | 334.60  |            | 14.52        |
| 7  | 3.50     | 381.90  |            | 12.39        |
| 8  | 4.00     | 439.20  |            | 13.05        |
| 9  | 4.50     | 475.70  |            | 7.67         |
| 10 | 5.00     | 518.00  |            | 8.17         |
| 11 | 5.50     | 745.40  |            | 30.51        |
| 12 | 6.00     | 928.60  |            | 19.73        |
| 13 | 6.50     | 1010.60 |            | 8.11         |
| 14 | 7.00     | 1054.90 |            | 4.20         |
| 15 | 7.50     | 1080.70 |            | 2.39         |
| 16 | 8.00     | 1096.50 |            | 1.44         |
| 17 | 8.50     | 1108.00 |            | 1.04         |
| 18 | 9.00     | 1117.00 |            | 0.81         |
| 19 | 9.50     | 1124.80 |            | 0.69         |
| 20 | 10.00    | 1130.80 |            | 0.53         |
| 21 | 10.50    | 1136.00 |            | 0.46         |
| 22 | 11.00    | 1140.10 |            | 0.36         |

### USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 1140.1 - 36.73613 ) (1)/(1) = +1.1034E+03 g/L Carbon  
 ( 1140.1 - 36.73613 ) (1)/(1) (12) = +9.1947E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!!!>>>

Sample Run By:

KR MONTEITH

00000

-01929

45

## WHC-SD-WM-DR-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/22/95

Time: 06:20:42

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

|    | Reading | Analysis Time | Coulometer | % Difference |
|----|---------|---------------|------------|--------------|
| 1  | 0.51    | 2.80          |            | 0.00         |
| 2  | 1.01    | 36.70         |            | 92.37        |
| 3  | 1.50    | 120.00        |            | 69.42        |
| 4  | 2.00    | 183.30        |            | 34.53        |
| 5  | 2.50    | 221.90        |            | 17.40        |
| 6  | 3.00    | 241.90        |            | 8.27         |
| 7  | 3.50    | 251.60        |            | 3.86         |
| 8  | 4.00    | 257.40        |            | 2.25         |
| 9  | 4.50    | 262.20        |            | 1.83         |
| 10 | 5.00    | 267.70        |            | 2.05         |
| 11 | 5.50    | 272.80        |            | 1.87         |
| 12 | 6.00    | 276.40        |            | 1.30         |
| 13 | 6.50    | 279.70        |            | 1.18         |
| 14 | 7.00    | 283.70        |            | 1.41         |
| 15 | 7.50    | 288.00        |            | 1.49         |
| 16 | 8.00    | 291.10        |            | 1.06         |
| 17 | 8.50    | 294.30        |            | 1.09         |
| 18 | 9.00    | 296.50        |            | 0.74         |
| 19 | 9.50    | 297.90        |            | 0.47         |
| 20 | 10.00   | 299.40        |            | 0.50         |
| 21 | 10.50   | 300.70        |            | 0.43         |
| 22 | 11.00   | 302.10        |            | 0.46         |

## USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon  
 BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

## SAMPLE RESULTS:

( 302.1 - 6.159829 )(1)/(1) = +2.959E+02 g/L Carbon  
 ( 302.1 - 6.159829 )(1)/(1)(12) = +2.466E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

.01802

46

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/22/95

Time: 06:32:34

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 2.10       | 0.00            |
| 2             | 1.01          | 93.70      | 97.76           |
| 3             | 1.50          | 188.70     | 50.34           |
| 4             | 2.00          | 260.30     | 27.51           |
| 5             | 2.50          | 321.70     | 19.09           |
| 6             | 3.00          | 386.90     | 16.85           |
| 7             | 3.50          | 455.60     | 15.08           |
| 8             | 4.00          | 499.90     | 8.86            |
| 9             | 4.50          | 686.70     | 27.20           |
| 10            | 5.00          | 879.40     | 21.91           |
| 11            | 5.50          | 962.90     | 8.67            |
| 12            | 6.00          | 1008.70    | 4.54            |
| 13            | 6.50          | 1034.80    | 2.52            |
| 14            | 7.00          | 1051.70    | 1.61            |
| 15            | 7.50          | 1063.90    | 1.15            |
| 16            | 8.00          | 1073.30    | 0.88            |
| 17            | 8.50          | 1080.90    | 0.70            |
| 18            | 9.00          | 1087.40    | 0.60            |
| 19            | 9.50          | 1092.70    | 0.49            |
| 20            | 10.00         | 1097.00    | 0.39            |
| 21            | 10.50         | 1101.10    | 0.37            |
| 22            | 11.00         | 1104.40    | 0.30            |

## USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

## SAMPLE RESULTS:

( 1104.4 - 36.72991 ) (1)/(1) = +1.0677E+03 g/L Carbon  
 ( 1104.4 - 36.72991 ) (1)/(1)(12) = +8.8973E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By: KR MONTEITH 00000

.01802

47

2010-06-2015  
WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: R BLK

Date: 03/22/95

Time: 07:15:06

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .56 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 1.40       | 0.00            |
| 2             | 1.01          | 2.80       | 50.00           |
| 3             | 1.51          | 4.10       | 31.71           |
| 4             | 2.00          | 5.30       | 22.64           |
| 5             | 2.50          | 6.40       | 17.19           |
| 6             | 3.00          | 7.70       | 16.88           |
| 7             | 3.50          | 8.70       | 11.49           |
| 8             | 4.00          | 9.90       | 12.12           |
| 9             | 4.50          | 11.00      | 10.00           |
| 10            | 5.00          | 12.20      | 9.84            |
| 11            | 5.50          | 13.20      | 7.58            |
| 12            | 6.00          | 14.20      | 7.04            |
| 13            | 6.50          | 15.30      | 7.19            |
| 14            | 7.00          | 16.30      | 6.13            |
| 15            | 7.50          | 17.40      | 6.32            |
| 16            | 8.00          | 18.50      | 5.95            |
| 17            | 8.50          | 19.60      | 5.61            |
| 18            | 9.00          | 20.50      | 4.39            |
| 19            | 9.50          | 21.50      | 4.65            |
| 20            | 10.00         | 22.40      | 4.02            |
| 21            | 10.50         | 23.50      | 4.68            |
| 22            | 11.00         | 24.40      | 3.69            |

USER INPUT BLANK VALUE

BLANK VALUE = 6.158321 micrograms carbon

BLANK FACTOR = 6.158321 / 10.997 = +5.6E-01 ug/min Carbon

SAMPLE RESULTS:

( 24.4 - 6.160393 ) (1)/(1) = +1.82E+01 g/L Carbon  
( 24.4 - 6.160393 ) (1)/(1) (12) = +1.52E+00 Molar Carbon

Sample Run By:

KR MONTEITH

00000

07772

48

**WHC-SD-WM-DP-100, REV. 0-A**  
TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: R BLK

Date: 03/22/95

Time: 11:27:10

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = 3.34 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time == | Coulometer == | % Difference == |
|---------------|------------------|---------------|-----------------|
| 1             | 0.51             | 1.00          | 0.00            |
| 2             | 1.01             | 6.40          | 84.38           |
| 3             | 1.50             | 18.00         | 64.44           |
| 4             | 2.00             | 27.00         | 33.33           |
| 5             | 2.51             | 35.50         | 23.94           |
| 6             | 3.01             | 43.10         | 17.63           |
| 7             | 3.51             | 49.70         | 13.28           |
| 8             | 4.00             | 55.90         | 11.09           |
| 9             | 4.50             | 60.50         | 7.60            |
| 10            | 5.00             | 64.60         | 6.35            |
| 11            | 5.50             | 67.70         | 4.58            |
| 12            | 6.00             | 70.40         | 3.84            |
| 13            | 6.50             | 72.70         | 3.16            |
| 14            | 7.00             | 74.70         | 2.68            |
| 15            | 7.50             | 76.70         | 2.61            |
| 16            | 8.00             | 78.20         | 1.92            |
| 17            | 8.50             | 79.50         | 1.64            |
| 18            | 9.00             | 80.90         | 1.73            |
| 19            | 9.50             | 82.10         | 1.46            |
| 20            | 10.00            | 83.20         | 1.32            |
| 21            | 10.50            | 84.20         | 1.19            |
| 22            | 11.00            | 85.10         | 1.06            |

USER INPUT BLANK VALUE

BLANK VALUE = 36.72998 micrograms carbon

BLANK FACTOR = 36.72998 / 10.997 = +3.3E+00 ug/min Carbon

SAMPLE RESULTS:

|  |           |              |
|--|-----------|--------------|
| ( 85.1 - 36.74826 ) (1)/(1) =                              | +4.84E+01 | g/L Carbon   |
| ( 85.1 - 36.74826 ) (1)/(1)(12) =                          | +4.03E+00 | Molar Carbon |
| <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>> |           |              |

Sample Run By:

KR MONTEITH

00000

## LABCORE Data Entry Template for Worklist# 881

Analyst: KRM

Instrument: TOC01

Book # 15N12 E TIC  
3/29/95 10N12 G TIC  
10N12 GMethod: LA-342-100 Rev/Mod A-O

Worklist Comment: AX-102 TICTOC -- RERUN

| GROUP    | PROJECT | S TYPE   | SAMPLE#      | R A -----TEST----- | MATRIX | ACTUAL        | FOUND                      | DL                               | UNIT                         |
|----------|---------|----------|--------------|--------------------|--------|---------------|----------------------------|----------------------------------|------------------------------|
|          |         | 1 BLNK   |              | @TICTOC1 TIC-02    | SOLID  | <u>1</u>      | <u>4.4</u><br><u>5.7</u>   | <u>gwB 3/29/95</u><br><u>N/A</u> | <u>ug</u> <u>gwB 3/29/95</u> |
|          |         | 1 BLNK   |              | @TICTOC1 TOC-02    | SOLID  | <u>1</u>      | <u>31.8</u><br><u>20.2</u> | <u>gwB 3/29/95</u><br><u>N/A</u> | <u>ug</u> <u>gwB 3/29/95</u> |
|          |         | 2 STD    |              | @TICTOC1 TIC-02    | SOLID  | <u>6.00e2</u> | <u>5.73e2</u>              | <u>N/A</u>                       | <u>ug/g</u>                  |
|          |         | 2 STD    |              | @TICTOC1 TOC-02    | SOLID  | <u>3.00e3</u> | <u>2.71e3</u>              | <u>N/A</u>                       | <u>ug/g</u>                  |
| 95000014 | AX-102  | 3 SAMPLE | S95T000203 0 | @TICTOC1 TIC-02    | SOLID  | <u>N/A</u>    | <u>1.68e4</u>              | <u>5.0e0</u>                     | <u>ug/g</u>                  |
| 95000014 | AX-102  | 3 SAMPLE | S95T000203 0 | @TICTOC1 TOC-02    | SOLID  | <u>N/A</u>    | <u>6.12e4</u>              | <u>8.0e1</u>                     | <u>ug/g</u>                  |
| 95000014 | AX-102  | 4 DUP    | S95T000203 0 | @TICTOC1 TIC-02    | SOLID  | <u>1.68e4</u> | <u>1.63e4</u>              | <u>N/A</u>                       | <u>ug/g</u>                  |
| 95000014 | AX-102  | 4 DUP    | S95T000203 0 | @TICTOC1 TOC-02    | SOLID  | <u>6.12e4</u> | <u>5.34e4</u>              | <u>N/A</u>                       | <u>ug/g</u>                  |
| 95000014 | AX-102  | 5 SPK    | S95T000203 0 | @TICTOC1 TIC-02    | SOLID  | <u>100</u>    | <u>164</u>                 | <u>N/A</u>                       | <u>90 gwB 3/29/95</u>        |
| 95000014 | AX-102  | 5 SPK    | S95T000203 0 | @TICTOC1 TOC-02    | SOLID  | <u>100</u>    | <u>196</u>                 | <u>N/A</u>                       | <u>90 gwB 3/29/95</u>        |
| 95000015 | AX-102  | 6 SAMPLE | S95T000206 0 | @TICTOC1 TIC-02    | SOLID  | <u>N/A</u>    | <u>1.87e4</u>              | <u>5.0e0</u>                     | <u>ug/g</u>                  |
| 95000015 | AX-102  | 6 SAMPLE | S95T000206 0 | @TICTOC1 TOC-02    | SOLID  | <u>N/A</u>    | <u>6.35e4</u>              | <u>8.0e1</u>                     | <u>ug/g</u>                  |
| 95000015 | AX-102  | 7 DUP    | S95T000206 0 | @TICTOC1 TIC-02    | SOLID  | <u>1.87e4</u> | <u>1.53e4</u>              | <u>N/A</u>                       | <u>ug/g</u>                  |
| 95000015 | AX-102  | 7 DUP    | S95T000206 0 | @TICTOC1 TOC-02    | SOLID  | <u>6.35e4</u> | <u>4.81e4</u>              | <u>N/A</u>                       | <u>ug/g</u>                  |

Final page for worklist # 881


 3-30-95

Analyst Signature Date

Analyst Signature Date



 3-30-95

Reviewed by Schneider 3/30/95

Data Entry Comments:

rerun of above batch. Amended procedure to scrub for suspected method byproduct interferences. Spikes indicate inability to eliminate interference (method incompatibility)

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.


 3/30/95

## WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
 TICTOC REV 2.0  
 <<< BLANK ANALYSIS >>>

Sample: BLK

Date: 03/24/95

Time: 00:26:18

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # = BLK  
 Blank Value = N/A

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.20       | 0.00            |
| 2             | 1.01          | 0.50       | 60.00           |
| 3             | 1.51          | 0.70       | 28.57           |
| 4             | 2.01          | 1.00       | 30.00           |
| 5             | 2.51          | 1.20       | 16.67           |
| 6             | 3.01          | 1.50       | 20.00           |
| 7             | 3.51          | 1.70       | 11.76           |
| 8             | 4.00          | 1.90       | 10.53           |
| 9             | 4.50          | 2.10       | 9.52            |
| 10            | 5.00          | 2.30       | 8.70            |
| 11            | 5.50          | 2.50       | 8.00            |
| 12            | 6.00          | 2.70       | 7.41            |
| 13            | 6.50          | 2.80       | 3.57            |
| 14            | 7.00          | 3.00       | 6.67            |
| 15            | 7.50          | 3.20       | 6.25            |
| 16            | 8.00          | 3.30       | 3.03            |
| 17            | 8.50          | 3.50       | 5.71            |
| 18            | 9.00          | 3.70       | 5.41            |
| 19            | 9.50          | 3.90       | 5.13            |
| 20            | 10.00         | 4.00       | 2.50            |
| 21            | 10.50         | 4.20       | 4.76            |
| 22            | 11.00         | 4.40       | 4.55            |

SIGNATURE BELOW REPRESENTS CHEMICAL TECHNOLOGIST/CHEMIST THAT  
 COMPLETED/VERIFIED THE CALIBRATION/ANALYSIS ON PAGES 61 TO 66.

BLANK VALUE = 4.4 micrograms carbon  
 BLANK FACTOR = 4.4 / 11.0015 =

+4.0E-01 ug/min Carbon

Sample Run By:

KR MONTEITH

3-24-95

00000

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
 TICTOC REV 2.0  
 <<< BLANK ANALYSIS >>>

Sample: BLK

Date: 03/24/95

Time: 01:56:08

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # = BLK  
 Blank Value = N/A

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.00       | 0.00            |
| 2             | 1.01          | 0.80       | 100.00          |
| 3             | 1.50          | 4.60       | 82.61           |
| 4             | 2.00          | 8.20       | 43.90           |
| 5             | 2.50          | 13.00      | 36.92           |
| 6             | 3.00          | 15.50      | 16.13           |
| 7             | 3.50          | 17.60      | 11.93           |
| 8             | 4.00          | 18.70      | 5.88            |
| 9             | 4.50          | 20.60      | 9.22            |
| 10            | 5.00          | 22.10      | 6.79            |
| 11            | 5.50          | 23.90      | 7.53            |
| 12            | 6.00          | 25.30      | 5.53            |
| 13            | 6.50          | 26.10      | 3.07            |
| 14            | 7.00          | 27.10      | 3.69            |
| 15            | 7.50          | 27.90      | 2.87            |
| 16            | 8.00          | 28.80      | 3.12            |
| 17            | 8.50          | 29.40      | 2.04            |
| 18            | 9.00          | 29.90      | 1.67            |
| 19            | 9.50          | 30.40      | 1.64            |
| 20            | 10.00         | 30.90      | 1.62            |
| 21            | 10.50         | 31.40      | 1.59            |
| 22            | 11.00         | 31.80      | 1.26            |

BLANK VALUE = 31.8 micrograms carbon

BLANK FACTOR = 31.8 / 11.00066 = +2.89E+00 ug/min Carbon

&lt;&lt;&lt; WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!&gt;&gt;&gt;

Sample Run By:

KR MONTEITH

00000

## WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: STD

Date: 03/24/95

Time: 02:17:20

Sample Size = 1000 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time == | Coulometer == | % Difference == |
|---------------|------------------|---------------|-----------------|
| 1             | 0.51             | 52.30         | 0.00            |
| 2             | 1.01             | 219.30        | 76.15           |
| 3             | 1.51             | 370.20        | 40.76           |
| 4             | 2.01             | 465.70        | 20.51           |
| 5             | 2.50             | 520.10        | 10.46           |
| 6             | 3.00             | 547.70        | 5.04            |
| 7             | 3.50             | 561.20        | 2.41            |
| 8             | 4.00             | 566.40        | 0.92            |
| 9             | 4.50             | 568.40        | 0.35            |
| 10            | 5.00             | 569.90        | 0.26            |
| 11            | 5.50             | 570.60        | 0.12            |
| 12            | 6.00             | 571.40        | 0.14            |
| 13            | 6.50             | 571.90        | 0.09            |
| 14            | 7.00             | 573.10        | 0.21            |
| 15            | 7.50             | 574.30        | 0.21            |
| 16            | 8.00             | 575.10        | 0.14            |
| 17            | 8.50             | 575.50        | 0.07            |
| 18            | 9.00             | 576.00        | 0.09            |
| 19            | 9.50             | 576.30        | 0.05            |
| 20            | 10.00            | 576.60        | 0.05            |
| 21            | 10.50            | 576.80        | 0.03            |
| 22            | 11.00            | 577.10        | 0.05            |

## USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

## SAMPLE RESULTS:

$$(577.1 - 4.399533) (1) / (1000) = +5.727E-01 \text{ g/L Carbon}$$

$$(577.1 - 4.399533) (1) / (1000) (12) = +4.773E-02 \text{ Molar Carbon}$$

Sample Run By:

KR MONTEITH

00000

1 ml - 15N12F 53

## WHC-SD-WM-DP-100, REV. 0-7

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: STD

Date: 03/24/95

Time: 02:31:51

Sample Size = 300 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 2.89 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.00       | 0.00            |
| 2             | 1.01          | 10.90      | 100.00          |
| 3             | 1.50          | 178.60     | 93.90           |
| 4             | 2.00          | 563.60     | 68.31           |
| 5             | 2.50          | 756.90     | 25.54           |
| 6             | 3.00          | 807.80     | 6.30            |
| 7             | 3.50          | 824.30     | 2.00            |
| 8             | 4.00          | 830.00     | 0.69            |
| 9             | 4.50          | 832.80     | 0.34            |
| 10            | 5.00          | 834.80     | 0.24            |
| 11            | 5.50          | 836.30     | 0.18            |
| 12            | 6.00          | 837.70     | 0.17            |
| 13            | 6.50          | 838.70     | 0.12            |
| 14            | 7.00          | 839.70     | 0.12            |
| 15            | 7.50          | 840.50     | 0.10            |
| 16            | 8.00          | 841.20     | 0.08            |
| 17            | 8.50          | 842.00     | 0.10            |
| 18            | 9.00          | 842.50     | 0.06            |
| 19            | 9.50          | 843.00     | 0.06            |
| 20            | 10.00         | 843.50     | 0.06            |
| 21            | 10.50         | 843.90     | 0.05            |
| 22            | 11.00         | 844.40     | 0.06            |

## USER INPUT BLANK VALUE

BLANK VALUE = 31.79191 micrograms carbon

BLANK FACTOR = 31.79191 / 11.00066 = +2.9E+00 ug/min Carbon

## SAMPLE RESULTS:

( 844.4 - 31.78661 ) (1) / (300) = +2.709E+00 g/L Carbon  
 ( 844.4 - 31.78661 ) (1) / (300) (12) = +2.257E-01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

300uL 10N12G 54

WHC-SD-WM-DP-100, REV. 0-A

TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/24/95

Time: 02:54:21

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.20       | 0.00            |
| 2             | 1.01          | 3.30       | 93.94           |
| 3             | 1.50          | 51.80      | 93.63           |
| 4             | 2.00          | 120.00     | 56.83           |
| 5             | 2.50          | 173.70     | 30.92           |
| 6             | 3.00          | 208.10     | 16.53           |
| 7             | 3.50          | 225.30     | 7.63            |
| 8             | 4.00          | 233.00     | 3.30            |
| 9             | 4.50          | 237.10     | 1.73            |
| 10            | 5.00          | 239.80     | 1.13            |
| 11            | 5.50          | 241.10     | 0.54            |
| 12            | 6.00          | 242.10     | 0.41            |
| 13            | 6.50          | 242.90     | 0.33            |
| 14            | 7.00          | 243.70     | 0.33            |
| 15            | 7.50          | 244.30     | 0.25            |
| 16            | 8.00          | 244.90     | 0.24            |
| 17            | 8.50          | 245.40     | 0.20            |
| 18            | 9.00          | 246.00     | 0.24            |
| 19            | 9.50          | 246.50     | 0.20            |
| 20            | 10.00         | 247.30     | 0.32            |
| 21            | 10.50         | 248.50     | 0.48            |
| 22            | 11.00         | 249.70     | 0.48            |

USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

SAMPLE RESULTS:

( 249.7 - 4.400604 ) (1)/(1) = +2.453E+02 g/L Carbon  
( 249.7 - 4.400604 ) (1)/(1) (12) = +2.044E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

.0146g

55

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203

Date: 03/24/95

Time: 03:07:01

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 2.98 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| Reading | Analysis Time | Coulometer | % Difference |
|---------|---------------|------------|--------------|
| 1       | 0.51          | 2.10       | 0.00         |
| 2       | 1.01          | 28.30      | 92.58        |
| 3       | 1.50          | 121.10     | 76.63        |
| 4       | 2.00          | 219.90     | 44.93        |
| 5       | 2.50          | 468.80     | 53.09        |
| 6       | 3.00          | 680.20     | 31.08        |
| 7       | 3.50          | 777.50     | 12.51        |
| 8       | 4.00          | 824.30     | 5.68         |
| 9       | 4.50          | 849.10     | 2.92         |
| 10      | 5.00          | 865.40     | 1.88         |
| 11      | 5.50          | 876.80     | 1.30         |
| 12      | 6.00          | 885.90     | 1.03         |
| 13      | 6.50          | 893.60     | 0.86         |
| 14      | 7.00          | 900.20     | 0.73         |
| 15      | 7.50          | 905.40     | 0.57         |
| 16      | 8.00          | 910.20     | 0.53         |
| 17      | 8.50          | 913.20     | 0.33         |
| 18      | 9.00          | 916.90     | 0.40         |
| 19      | 9.50          | 920.00     | 0.34         |
| 20      | 10.00         | 922.60     | 0.28         |
| 21      | 10.50         | 924.40     | 0.19         |
| 22      | 11.00         | 927.00     | 0.28         |

## USER INPUT BLANK VALUE

BLANK VALUE = 32.78197 micrograms carbon

BLANK FACTOR = 32.78197 / 11.00066 = +3.0E+00 ug/min Carbon

## SAMPLE RESULTS:

( 927 - 32.78196 ) (1)/(1) = +8.942E+02 g/L Carbon  
 ( 927 - 32.78196 ) (1)/(1) (12) = +7.452E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

01462

56

# WHC-SD-WM-DP-100, REV. 0-A

## TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT TICTOC REV 2.0

Sample: 203

Date: 03/24/95

Time: 03:19:17

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 1.60       | 0.00            |
| 2             | 1.01          | 6.20       | 74.19           |
| 3             | 1.50          | 56.40      | 89.01           |
| 4             | 2.00          | 121.90     | 53.73           |
| 5             | 2.50          | 171.40     | 28.88           |
| 6             | 3.00          | 201.60     | 14.98           |
| 7             | 3.50          | 215.80     | 6.58            |
| 8             | 4.00          | 221.90     | 2.75            |
| 9             | 4.50          | 225.00     | 1.38            |
| 10            | 5.00          | 226.50     | 0.66            |
| 11            | 5.50          | 228.20     | 0.74            |
| 12            | 6.00          | 229.00     | 0.35            |
| 13            | 6.50          | 230.10     | 0.48            |
| 14            | 7.00          | 230.80     | 0.30            |
| 15            | 7.50          | 231.60     | 0.35            |
| 16            | 8.00          | 232.30     | 0.30            |
| 17            | 8.50          | 233.00     | 0.30            |
| 18            | 9.00          | 233.50     | 0.21            |
| 19            | 9.50          | 234.00     | 0.21            |
| 20            | 10.00         | 234.50     | 0.21            |
| 21            | 10.50         | 235.10     | 0.26            |
| 22            | 11.00         | 235.50     | 0.17            |

### USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

### SAMPLE RESULTS:

( 235.5 - 4.399194 ) (1) / (1) = +2.311E+02 g/L Carbon  
( 235.5 - 4.399194 ) (1) / (1) (12) = +1.926E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

.0142

57

Sample: 203

Date: 03/24/95

Time: 03:31:48

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = 2.98 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer == | % Difference == |
|---------------|---------------|---------------|-----------------|
| 1             | 0.51          | 0.10          | 0.00            |
| 2             | 1.01          | 21.10         | 99.53           |
| 3             | 1.50          | 136.10        | 84.50           |
| 4             | 2.00          | 368.70        | 63.09           |
| 5             | 2.50          | 567.90        | 35.08           |
| 6             | 3.00          | 655.90        | 13.42           |
| 7             | 3.50          | 698.10        | 6.04            |
| 8             | 4.00          | 720.30        | 3.08            |
| 9             | 4.50          | 734.70        | 1.96            |
| 10            | 5.00          | 744.80        | 1.36            |
| 11            | 5.50          | 752.00        | 0.96            |
| 12            | 6.00          | 758.60        | 0.87            |
| 13            | 6.50          | 764.30        | 0.75            |
| 14            | 7.00          | 769.30        | 0.65            |
| 15            | 7.50          | 773.60        | 0.56            |
| 16            | 8.00          | 776.90        | 0.42            |
| 17            | 8.50          | 780.10        | 0.41            |
| 18            | 9.00          | 782.80        | 0.34            |
| 19            | 9.50          | 785.50        | 0.34            |
| 20            | 10.00         | 787.20        | 0.22            |
| 21            | 10.50         | 789.40        | 0.28            |
| 22            | 11.00         | 791.10        | 0.21            |

## USER INPUT BLANK VALUE

BLANK VALUE = 32.78197 micrograms carbon

BLANK FACTOR = 32.78197 / 11.00066 = +3.0E+00 ug/min Carbon

## SAMPLE RESULTS:

( 791.1 - 32.782 ) (1)/(1) = +7.583E+02 g/L Carbon  
( 791.1 - 32.782 ) (1)/(1) (12) = +6.319E+01 Molar Carbon  
<<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

**WHC-SD-WM-DP-100, REV. 0-A**  
**TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT**  
**TICTOC REV 2.0**

Sample: 203 + SPK

Date: 03/24/95

Time: 03:43:58

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading | ==== Analysis Time | ===== Coulometer | ==== % Difference == |
|------------|--------------------|------------------|----------------------|
| 1          | 0.51               | 1.20             | 0.00                 |
| 2          | 1.01               | 10.20            | 88.24                |
| 3          | 1.51               | 86.50            | 88.21                |
| 4          | 2.01               | 179.80           | 51.89                |
| 5          | 2.51               | 264.90           | 32.13                |
| 6          | 3.01               | 330.30           | 19.80                |
| 7          | 3.51               | 374.20           | 11.73                |
| 8          | 4.01               | 400.80           | 6.64                 |
| 9          | 4.50               | 414.60           | 3.33                 |
| 10         | 5.00               | 421.80           | 1.71                 |
| 11         | 5.50               | 426.20           | 1.03                 |
| 12         | 6.00               | 428.60           | 0.56                 |
| 13         | 6.50               | 430.30           | 0.40                 |
| 14         | 7.00               | 431.60           | 0.30                 |
| 15         | 7.50               | 432.60           | 0.23                 |
| 16         | 8.00               | 433.60           | 0.23                 |
| 17         | 8.50               | 434.60           | 0.23                 |
| 18         | 9.00               | 435.20           | 0.14                 |
| 19         | 9.50               | 435.90           | 0.16                 |
| 20         | 10.00              | 436.60           | 0.16                 |
| 21         | 10.50              | 437.20           | 0.14                 |
| 22         | 11.00              | 437.90           | 0.16                 |

USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

SAMPLE RESULTS:

( 437.9 - 4.401001 ) (1) / (1) = +4.335E+02 g/L Carbon  
 ( 437.9 - 4.401001 ) (1) / (1) (12) = +3.612E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

59

437.9 - (16800 \* .0112) - 4.4 \* 100%  
600 \* .250  
 = 164%

.0112g + .250ml 15N12E

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 203 + SPK

Date: 03/24/95

Time: 03:56:19

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 2.98 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.30       | 0.00            |
| 2             | 1.01          | 24.10      | 98.76           |
| 3             | 1.51          | 213.80     | 88.73           |
| 4             | 2.01          | 628.20     | 65.97           |
| 5             | 2.51          | 949.40     | 33.83           |
| 6             | 3.01          | 1096.50    | 13.42           |
| 7             | 3.51          | 1162.10    | 5.64            |
| 8             | 4.01          | 1199.00    | 3.08            |
| 9             | 4.50          | 1221.00    | 1.80            |
| 10            | 5.00          | 1235.40    | 1.17            |
| 11            | 5.50          | 1247.80    | 0.99            |
| 12            | 6.00          | 1257.40    | 0.76            |
| 13            | 6.50          | 1265.30    | 0.62            |
| 14            | 7.00          | 1271.70    | 0.50            |
| 15            | 7.50          | 1277.80    | 0.48            |
| 16            | 8.00          | 1283.70    | 0.46            |
| 17            | 8.50          | 1288.10    | 0.34            |
| 18            | 9.00          | 1292.30    | 0.33            |
| 19            | 9.50          | 1296.40    | 0.32            |
| 20            | 10.00         | 1299.80    | 0.26            |
| 21            | 10.50         | 1303.10    | 0.25            |
| 22            | 11.00         | 1306.00    | 0.22            |

## USER INPUT BLANK VALUE

BLANK VALUE = 32.78197 micrograms carbon

BLANK FACTOR = 32.78197 / 11.00066 = +3.0E+00 ug/min Carbon

## SAMPLE RESULTS:

|                                  |                          |
|----------------------------------|--------------------------|
| ( 1306 - 32.785 ) (1)/(1) =      | +1.2732E+03 g/L Carbon   |
| ( 1306 - 32.785 ) (1)/(1) (12) = | +1.0610E+02 Molar Carbon |

<<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

60

1306 - (61,200 x 0.0112) - 31.0  
3,000 x 0.100  
 = 196%

-0.012g + -0.012g + -100 mc 10N12G  
 jmb  
 3/26/95

# WHC-SD-WM-DP-100, REV. 0-A

## TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT TICTOC REV 2.0

Sample: 206

Date: 03/24/95

Time: 05:47:08

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 0.00       | 0.00            |
| 2             | 1.01          | 0.00       | 0.00            |
| 3             | 1.50          | 48.20      | 100.00          |
| 4             | 2.00          | 122.00     | 60.49           |
| 5             | 2.50          | 175.90     | 30.64           |
| 6             | 3.00          | 212.40     | 17.18           |
| 7             | 3.50          | 233.30     | 8.96            |
| 8             | 4.00          | 243.90     | 4.35            |
| 9             | 4.50          | 248.40     | 1.81            |
| 10            | 5.00          | 251.70     | 1.31            |
| 11            | 5.50          | 253.20     | 0.59            |
| 12            | 6.00          | 254.10     | 0.35            |
| 13            | 6.50          | 255.00     | 0.35            |
| 14            | 7.00          | 255.70     | 0.27            |
| 15            | 7.50          | 256.30     | 0.23            |
| 16            | 8.00          | 256.90     | 0.23            |
| 17            | 8.50          | 257.40     | 0.19            |
| 18            | 9.00          | 257.80     | 0.16            |
| 19            | 9.50          | 258.20     | 0.15            |
| 20            | 10.00         | 258.60     | 0.15            |
| 21            | 10.50         | 259.00     | 0.15            |
| 22            | 11.00         | 259.30     | 0.12            |

### USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

### SAMPLE RESULTS:

( 259.3 - 4.398804 )(1)/(1) = +2.549E+02 g/L Carbon  
( 259.3 - 4.398804 )(1)/(1)(12) = +2.124E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

. 0136g

61

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/24/95

Time: 05:59:15

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 2.98 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

| == Reading | ==== Analysis Time | ===== Coulometer | ==== % Difference == |
|------------|--------------------|------------------|----------------------|
| 1          | 0.51               | 0.00             | 0.00                 |
| 2          | 1.01               | 60.90            | 100.00               |
| 3          | 1.51               | 287.50           | 78.82                |
| 4          | 2.01               | 529.40           | 45.69                |
| 5          | 2.51               | 675.70           | 21.65                |
| 6          | 3.01               | 747.40           | 9.59                 |
| 7          | 3.51               | 789.80           | 5.37                 |
| 8          | 4.00               | 812.80           | 2.83                 |
| 9          | 4.50               | 827.50           | 1.78                 |
| 10         | 5.00               | 838.00           | 1.25                 |
| 11         | 5.50               | 845.60           | 0.90                 |
| 12         | 6.00               | 851.60           | 0.70                 |
| 13         | 6.50               | 856.70           | 0.60                 |
| 14         | 7.00               | 860.80           | 0.48                 |
| 15         | 7.50               | 864.90           | 0.47                 |
| 16         | 8.00               | 869.00           | 0.47                 |
| 17         | 8.50               | 873.20           | 0.48                 |
| 18         | 9.00               | 877.40           | 0.48                 |
| 19         | 9.50               | 881.80           | 0.50                 |
| 20         | 10.00              | 886.80           | 0.56                 |
| 21         | 10.50              | 891.80           | 0.56                 |
| 22         | 11.00              | 896.70           | 0.55                 |

## USER INPUT BLANK VALUE

BLANK VALUE = 32.78197 micrograms carbon

BLANK FACTOR = 32.78197 / 11.00066 = +3.0E+00 ug/min Carbon

## SAMPLE RESULTS:

( 896.7 - 32.78446 ) (1)/(1) = +8.639E+02 g/L Carbon  
 ( 896.7 - 32.78446 ) (1)/(1)(12) = +7.199E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

62

.01362

**WHC-SD-WM-DP-100, REV. 0-A**  
TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/24/95

Time: 06:12:01

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading == | Analysis Time | Coulometer | % Difference == |
|---------------|---------------|------------|-----------------|
| 1             | 0.51          | 4.60       | 0.00            |
| 2             | 1.01          | 36.50      | 87.40           |
| 3             | 1.51          | 101.20     | 63.93           |
| 4             | 2.00          | 140.10     | 27.77           |
| 5             | 2.50          | 161.00     | 12.98           |
| 6             | 3.00          | 171.20     | 5.96            |
| 7             | 3.50          | 174.70     | 2.00            |
| 8             | 4.00          | 176.90     | 1.24            |
| 9             | 4.50          | 178.30     | 0.79            |
| 10            | 5.00          | 179.30     | 0.56            |
| 11            | 5.50          | 179.90     | 0.33            |
| 12            | 6.00          | 180.60     | 0.39            |
| 13            | 6.50          | 181.20     | 0.33            |
| 14            | 7.00          | 181.60     | 0.22            |
| 15            | 7.50          | 182.10     | 0.27            |
| 16            | 8.00          | 182.50     | 0.22            |
| 17            | 8.50          | 182.90     | 0.22            |
| 18            | 9.00          | 183.40     | 0.27            |
| 19            | 9.50          | 183.70     | 0.16            |
| 20            | 10.00         | 184.00     | 0.16            |
| 21            | 10.50         | 184.50     | 0.27            |
| 22            | 11.00         | 184.70     | 0.11            |

USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

SAMPLE RESULTS:

( 184.7 - 4.400659 ) (1)/(1) = +1.803E+02 g/L Carbon  
( 184.7 - 4.400659 ) (1)/(1) (12) = +1.502E+01 Molar Carbon

Sample Run By:

KR MONTEITH

00000

.0182

63

## WHC-SD-WM-DP-100, REV. 0-A

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: 206

Date: 03/24/95

Time: 06:30:42

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 2.98 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

|    | Reading | Analysis Time | Coulometer | % Difference |
|----|---------|---------------|------------|--------------|
| 1  | 0.51    | 1.80          | 0.00       |              |
| 2  | 1.01    | 92.60         | 98.06      |              |
| 3  | 1.50    | 247.80        | 62.63      |              |
| 4  | 2.00    | 368.60        | 32.77      |              |
| 5  | 2.50    | 430.80        | 14.44      |              |
| 6  | 3.00    | 470.50        | 8.44       |              |
| 7  | 3.50    | 497.50        | 5.43       |              |
| 8  | 4.00    | 516.90        | 3.75       |              |
| 9  | 4.50    | 531.10        | 2.67       |              |
| 10 | 5.00    | 541.90        | 1.99       |              |
| 11 | 5.50    | 550.30        | 1.53       |              |
| 12 | 6.00    | 557.10        | 1.22       |              |
| 13 | 6.50    | 563.40        | 1.12       |              |
| 14 | 7.00    | 568.10        | 0.83       |              |
| 15 | 7.50    | 572.20        | 0.72       |              |
| 16 | 8.00    | 576.80        | 0.80       |              |
| 17 | 8.50    | 582.00        | 0.89       |              |
| 18 | 9.00    | 590.90        | 1.51       |              |
| 19 | 9.50    | 594.50        | 0.61       |              |
| 20 | 10.00   | 596.50        | 0.34       |              |
| 21 | 10.50   | 598.40        | 0.32       |              |
| 22 | 11.00   | 599.90        | 0.25       |              |

## USER INPUT BLANK VALUE

BLANK VALUE = 32.78197 micrograms carbon

BLANK FACTOR = 32.78197 / 11.00066 = +3.0E+00 ug/min Carbon

## SAMPLE RESULTS:

( 599.9 - 32.782 ) (1)/(1) = +5.671E+02 g/L Carbon  
 ( 599.9 - 32.782 ) (1)/(1)(12) = +4.726E+01 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

.01182

64

**WHC-SD-WM-DP-100, REV. 0 -A**  
TIC- TOTAL INORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: R BLK

Date: 03/24/95

Time: 05:20:28

Sample Size = 1 uL  
Dil Factor = 1  
Blank ID # =  
Blank Value = .4 ug/minute C

Analyst : KR MONTEITH  
Min Readings = 22  
Max Readings = 22  
% Difference = 10

| == Reading | ==== Analysis Time | ==== Coulometer | ==== % Difference == |
|------------|--------------------|-----------------|----------------------|
| 1          | 0.51               | 1.80            | 0.00                 |
| 2          | 1.01               | 2.70            | 33.33                |
| 3          | 1.50               | 3.10            | 12.90                |
| 4          | 2.00               | 3.50            | 11.43                |
| 5          | 2.50               | 3.80            | 7.89                 |
| 6          | 3.00               | 4.10            | 7.32                 |
| 7          | 3.51               | 4.20            | 2.38                 |
| 8          | 4.00               | 4.40            | 4.55                 |
| 9          | 4.50               | 4.50            | 2.22                 |
| 10         | 5.00               | 4.60            | 2.17                 |
| 11         | 5.50               | 4.70            | 2.13                 |
| 12         | 6.00               | 4.90            | 4.08                 |
| 13         | 6.50               | 4.90            | 0.00                 |
| 14         | 7.00               | 5.00            | 2.00                 |
| 15         | 7.50               | 5.10            | 1.96                 |
| 16         | 8.00               | 5.20            | 1.92                 |
| 17         | 8.50               | 5.30            | 1.89                 |
| 18         | 9.00               | 5.40            | 1.85                 |
| 19         | 9.50               | 5.50            | 1.82                 |
| 20         | 10.00              | 5.60            | 1.79                 |
| 21         | 10.50              | 5.70            | 1.75                 |
| 22         | 11.00              | 5.70            | 0.00                 |

USER INPUT BLANK VALUE

BLANK VALUE = 4.400264 micrograms carbon

BLANK FACTOR = 4.400264 / 11.00066 = +4.0E-01 ug/min Carbon

SAMPLE RESULTS:

|                                   |          |              |
|-----------------------------------|----------|--------------|
| ( 5.7 - 4.400257 ) (1)/(1) =      | +1.3E+00 | g/L Carbon   |
| ( 5.7 - 4.400257 ) (1)/(1) (12) = | +1.1E-01 | Molar Carbon |

Sample Run By:

KR MONTEITH

00000

.0733g

65

TOC- TOTAL ORGANIC CARBON ANALYSIS REPORT  
TICTOC REV 2.0

Sample: R BLK

Date: 03/24/95

Time: 05:34:14

Sample Size = 1 uL  
 Dil Factor = 1  
 Blank ID # =  
 Blank Value = 2.98 ug/minute C

Analyst : KR MONTEITH  
 Min Readings = 22  
 Max Readings = 22  
 % Difference = 10

-- Reading ---- Analysis Time ---- Coulometer ---- % Difference ==

|    |       |       |        |
|----|-------|-------|--------|
| 1  | 0.51  | 0.00  | 0.00   |
| 2  | 1.01  | 0.00  | 0.00   |
| 3  | 1.50  | 2.50  | 100.00 |
| 4  | 2.00  | 6.60  | 62.12  |
| 5  | 2.50  | 10.90 | 39.45  |
| 6  | 3.00  | 13.30 | 18.05  |
| 7  | 3.50  | 14.80 | 10.14  |
| 8  | 4.00  | 16.00 | 7.50   |
| 9  | 4.50  | 16.60 | 3.61   |
| 10 | 5.00  | 17.10 | 2.92   |
| 11 | 5.50  | 17.60 | 2.84   |
| 12 | 6.00  | 18.00 | 2.22   |
| 13 | 6.50  | 18.30 | 1.64   |
| 14 | 7.00  | 18.60 | 1.61   |
| 15 | 7.50  | 18.90 | 1.59   |
| 16 | 8.00  | 19.10 | 1.05   |
| 17 | 8.50  | 19.30 | 1.04   |
| 18 | 9.00  | 19.50 | 1.03   |
| 19 | 9.50  | 19.80 | 1.52   |
| 20 | 10.00 | 19.90 | 0.50   |
| 21 | 10.50 | 20.00 | 0.50   |
| 22 | 11.00 | 20.20 | 0.99   |

## USER INPUT BLANK VALUE

BLANK VALUE = 32.78197 micrograms carbon

BLANK FACTOR = 32.78197 / 11.00066 = +3.0E+00 ug/min Carbon

## SAMPLE RESULTS:

( 20.2 - 32.77354 ) (1)/(1) = < 5.00 E-3 g/L Carbon  
 ( 20.2 - 32.77354 ) (1)/(1) (12) = < 4.17 E-4 Molar Carbon  
 <<< WARNING - BLANK VALUE EXCEEDS 1.5 ug/min Carbon!!!!>>>

Sample Run By:

KR MONTEITH

00000

- 07332

66

## LABCORE Data Entry Template for Worklist# 1272

Analyst: RAWInstrument: PH01 WCBook # ZIN8-BMethod: LA-211-102 Rev/Mod B-1

Worklist Comment: AX-102 OH-

| GROUP    | PROJECT | S TYPE   | SAMPLE#                      | R A -----TEST----- | MATRIX | ACTUAL  | FOUND   | DL     | UNIT       | RWS           |
|----------|---------|----------|------------------------------|--------------------|--------|---------|---------|--------|------------|---------------|
|          |         | 1 BLNK   |                              | OH-01              | SOLID  | 1       | <42     | N/A    | ug/g Mg/ML | 5-3-95        |
|          |         | 2 STD    |                              | OH-01              | SOLID  | 9.39e-1 | 9.41e-1 | N/A    | ug/g M     | RWS<br>5-3-95 |
| 95000015 | AX-102  | 3 SAMPLE | S95T000206<br>S95T000593 0 W | OH-01              | SOLID  | N/A     | <1.66e3 | 1.66e3 | ug/g       |               |
| 95000015 | AX-102  | 4 DUP    | S95T000206<br>S95T000593 0 W | OH-01              | SOLID  | <1.66e3 | <1.66e3 | N/A    | ug/g       |               |
|          |         | 5 STD    |                              | OH-01              | SOLID  | 9.39e-1 | 8.97e-1 | N/A    | ug/g       |               |

Final page for worklist # 1272

Ron Nenland Analyst Signature

5-1-95 Date

Lee Jones Analyst Signature

5-3-95 Date

J. Michael 5/3/95

## Data Entry Comments:

This sample was prepared using 0.5022g to 20mL H<sub>2</sub>O.

There is no free hydroxide observed. The sample is suspected to be buffered and the results are &lt; detection limit. RWS 5-2-95

Units shown for QC (SPK &amp; STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|   |   |
|---|---|
| date 95-05-21 time 10:19<br>GET pH 10 # 154<br>ID.#1 .<br>ID.#2 .1994<br>pH(init) 5.84<br>stop volt. reached<br>===== | date 95-05-21 time 10:19<br>GET pH 10 # 151<br>ID.#1 525-8<br>ID.#2 .1994<br>pH(init) 7.69<br>V/m1 pH<br>SF1 .035 5.96<br>stop volt. reached<br>===== |
| date 95-05-21 time 10:19<br>GET pH 10 # 154<br>ID#1 .001/dil .001/dil<br>start V .828 .1<br>5<br>=====                | date 95-05-21 time 10:19<br>GET pH 10 # 151<br>ID#1 .001/dil .001/dil<br>start V .828 .1<br>3<br>=====  |

## OH (AUTO) : LA-211-102 (B-1)

|                 | BLK  |
|-----------------|--|
| Type            | Sample Size (mL) SS 3.000  |
| BLK             | Concentration of HNO3 (Molarity) 0.1994  |
| Work List       | HNO3 Titrant at OH end-point in mL 0.000   |
| 1272            | Dilution Factor DF 1   |
| Test Code       | Concentration of OH in Sample (Molarity) 0.00E+00  |
| OH              | OH in Sample in $\mu\text{g/mL}$ (PPM) 0.00E+00  |
| Matrix          |  |
| Solid           |  |
| Sample #        | Detection Limit = $125\mu\text{g} / \text{SS} * \text{DF}$   |
| Blank           |  |
| Instrument Code | Detection Limit ( $\mu\text{g/mL}$ ) 4.17E+01  |
| Analyst         | OH Molarity = $((\text{mL HNO}_3) * (\text{M HNO}_3)) / \text{Sample Size in mL} * \text{Dilution Factor}$           |
| RA Wendland     |  |
| Date            | OH in $\mu\text{g/mL}$ = $(\text{OH MOLARITY}) * (17.0\text{g/mole}) * ((1000000\mu\text{g/g}) / (1000\text{mL/L}))$ |
| 05/01/95        |  |
| Time            |  |
| 12:00 PM        | Concentration of OH in Sample (Molarity) 0.00E+00  |
|                 | OH in Sample in $\mu\text{g/mL}$ (PPM) <42   |
|                 | The Result is < Detection Limit  |

Data Entry by:

*Ron Schmeidler*

Date: 05/03/95

Approved by:

*JW/BW*

Date: 5/3/95

Form 211102\_1 Rev. 1.0

Page 1 of 1


WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

```

calibration data
date 95-05-01 time 10:16
GDT sh 153
Id.#1 153
Id.#2 153
estimated 11.83
-----+-----+-----+
SFI 1.036 10.18
SFA 1.026 9.56
status volt. recorded
electr. input
=====+=====+=====+

```



**OH (AUTO) : LA-211-102 (B-1)**

| OH (AUTO) : LA-211-102 (B-1) |   | Standard |
|------------------------------|---|----------|
| Type                         | Sample Size (mL) SS   | 0.050    |
| Standard                     | Concentration of HNO3 (Molarity)                                    | 0.1994   |
| WorkList                     | HNO3 Titrant at OH end-point in mL                                  | 0.236    |
| 1272                         | Dilution Factor DF  | 1        |
| Instrument Code              | Concentration of OH in Sample (Molarity)                            | 9.41E-01 |
| OH                           | OH In Sample in µg/mL (PPM)   | 1.60E+04 |
| Matrix                       |   |          |
| Solid                        |   |          |
| Sample                       |   |          |
| Standard                     |   |          |
| Instrument Code              |   |          |
| Analyst                      | OH Molarity =((mL HNO3)*(M HNO3))/Sample Size in mL*Dilution Factor |          |
| RA Wendland                  |   |          |
| Date                         | OH in µg/mL = (OH MOLARITY)*(17.0g/mole)*((1000000µg/g)/(1000mL/L)) |          |
| 05/01/96                     |   |          |
| Time                         | Concentration of OH in Sample (Molarity)                            | 9.41E-01 |
| 12:00 PM                     | OH In Sample in µg/mL (PPM)   | 1.60E+04 |

**Data Entry by:**

R.W. Schroeder

Date: 05/03/95

**Approved by:**

Date: 5/3/95

## WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

Date 95-05-01 time 11:29  
 GET pH 11 # 156  
 -16mV/mV 0.165V/mV  
 start 0.300 mL

----- END -----  
 05/01/95 11:58:50  
 ID 2281  
 0.5022 g  
 + to 20mL H<sub>2</sub>O

Date 95-05-01 time 11:21  
 GET pH 11 # 156  
 ID #1 553  
 ID #2 .1894  
 p-(1+1) 6.81  
 V/mL 1.000 pH  
 EPI .300 6.98  
 manual stop  
 =====

000= 0.01

## OH (AUTO) : LA-211-102 (B-1)

|  | Sample  |
|--|---|
| Type   | Sample Size (mL) SS 3.000   |
| Sample   | Concentration of HNO <sub>3</sub> (Molarity) 0.1994   |
| Work List  | HNO <sub>3</sub> Titrant at OH end-point in mL 0.000  |
| 1272   | Dilution Factor DF 39.8   |
| Test Code  | Concentration of OH In Sample (Molarity) 0.00E+00   |
| OH   | OH In Sample in µg/mL (PPM) 0.00E+00  |
| Matrix   |   |
| Solid  |   |
| Sample#  | Detection Limit = 125µg / SS * DF   |
| S95T000206   |   |
| Instrument Code  | Detection Limit (µg/mL) 1.66E+03  |
| Analyst  | OH Molarity =((mL HNO <sub>3</sub> )*(M HNO <sub>3</sub> ))/Sample Size in mL*Dilution Factor |
| RA Wendland  | OH in µg/mL = (OH MOLARITY)*(17.0g/mole)*((1000000µg/g)/(1000mL/L))                           |
| Date   |   |
| 05/01/95   |   |
| Time   |   |
| 12:00 PM   |   |
|  | Sample  |
| Concentration of OH In Sample (Molarity)                     | 0.00E+00  |
| OH in Sample in <sup>212</sup> µg/mL (PPM) <sub>5/3/95</sub> | <1658   |

The Result is &lt; Detection Limit

|                |              |       |          |
|----------------|--------------|-------|----------|
| Data Entry by: | GW Schreider | Date: | 05/03/95 |
| Approved by:   | GW Schreider | Date: | 5/3/95   |

## WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

date 95-05-01 time 11:28  
 GET pH 7.12 # 157  
 Id.#1 593-3  
 Id.#2 1594  
 shInit  
 WPH 7.12  
 EPI .166 7.12  
 Manual stop  
 ======

date 95-05-01 time 11:29  
 GET pH 7.12 # 157  
 Id.#1 593-3  
 Id.#2 1594  
 shInit  
 WPH 7.12

## OH (AUTO) : LA-211-102 (B-1)


|                 | Duplicate  |
|-----------------|--|
| Type            | Sample Size (mL) SS 3.000  |
| Duplicate       | Concentration of HNO3 (Molarity) 0.1994  |
| Work List       | HNO3 Titrant at OH end-point in mL 0.000   |
| 1272            | Dilution Factor DF 39.8  |
| Test Code       | Concentration of OH in Sample (Molarity) 0.00E+00  |
| OH              | OH in Sample in $\mu\text{g/mL}$ (PPM) 0.00E+00  |
| Matrix          |  |
| Solid           |  |
| Sample#         | Detection Limit = $125\mu\text{g} / \text{SS} * \text{DF}$   |
| S95T000206      |  |
| Instrument Code | Detection Limit ( $\mu\text{g/mL}$ ) 1.66E+03  |
| Analyst         | OH Molarity = $((\text{mL HNO}_3) * (\text{M HNO}_3)) / \text{Sample Size in mL} * \text{Dilution Factor}$           |
| RA Wendland     |  |
| Date            | OH in $\mu\text{g/mL}$ = $(\text{OH MOLARITY}) * (17.0\text{g/mole}) * ((1000000\mu\text{g/g}) / (1000\text{mL/L}))$ |
| 05/01/95        |  |
| Time            | Duplicate  |
| 12:00 PM        | Concentration of OH in Sample (Molarity) 0.00E+00  |
|                 | OH in Sample in $\mu\text{g/mL}$ (PPM) 5/3/95 <1658  |

The Result is &lt; Detection Limit

|                |                 |       |          |
|----------------|-----------------|-------|----------|
| Data Entry by: | R. J. Schreuder | Date: | 05/03/95 |
| Approved by:   | J. M. Baily     | Date: | 5/3/95   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

Date 95-05-01 time 11:34  
 GET pH 12 + 158  
 Id.#1 1  
 Id.#2 .1994  
 pH(init) 11.64  
 Vph1 pH  
 EPI .225 10.13  
 manual atcs  
 =====



Date 95-05-01 time 11:34  
 GET pH 12 + 158  
 .1994.1/1000ml/l/div  
 start 11.642

**OH (AUTO) : LA-211-102 (B-1)**

| Type            | STD   |
|-----------------|---|
| STD             | Sample Size (mL) SS 0.050   |
| WORKSTATION     | Concentration of HNO3 (Molarity) 0.1994                             |
| 1272            | HNO3 Titrant at OH end-point in mL 0.225                            |
| Instrument Code | Dilution Factor DF 1  |
| OH              | Concentration of OH in Sample (Molarity) 8.97E-01                   |
| MATERIAL        | OH in Sample in µg/mL (PPM) 1.53E+04                                |
| Solid           |   |
| Sample Standard | Detection Limit = 125µg / SS * DF                                   |
| Instrument Code | Detection Limit (µg/mL) 2.50E+03                                    |
| Analyst         | OH Molarity =((mL HNO3)*(M HNO3))/Sample Size in mL*Dilution Factor |
| RA Wendland     | OH in µg/mL = (OH MOLARITY)*(17.0g/mole)*((1000000µg/g)/(1000mL/L)) |
| Date            |   |
| 05/01/95        |   |
| Time            |   |
| 12:00 PM        | STD   |
|                 | Concentration of OH in Sample (Molarity) 8.97E-01                   |
|                 | OH in Sample in µg/mL (PPM) 1.53E+04                                |

|                |              |       |          |
|----------------|--------------|-------|----------|
| Data Entry by: | RW Schreider | Date: | 05/03/95 |
| Approved by:   | JMB          | Date: | 5/3/95   |

## LABCORE Data Entry Template for Worklist# 1361

Analyst:

Instrument: SP01 WA93252 Book # 54N8C

Method: LA-695-102 Rev/Mod

Worklist Comment: AX-102 Cyanide

| GROUP    | PROJECT | S TYPE   | SAMPLE#    | R A | TEST  | MATRIX | ACTUAL | FOUND       | DL                     | UNIT |
|----------|---------|----------|------------|-----|-------|--------|--------|-------------|------------------------|------|
|          |         | 1 BLNK   |            |     | CN-01 | SOLID  | 1      | 0.6<br>13.1 | RWS 5-12-95<br>N/A     | ug/g |
|          |         | 2 STD    |            |     | CN-01 | SOLID  | 915    | 1109<br>124 | gws 5-12-95<br>N/A     | ug/g |
| 95000015 | AX-102  | 3 SAMPLE | S95T000206 | 0   | CN-01 | SOLID  | N/A    | 26.8        | 3.1                    | ug/g |
| 95000015 | AX-102  | 4 DUP    | S95T000206 | 0   | CN-01 | SOLID  | 26.8   | 25.7        | N/A                    | ug/g |
| 95000015 | AX-102  | 5 SPK    | S95T000206 | 0   | CN-01 | SOLID  | 100    | 103         | N/A                    | ug/g |
|          |         | 6 BLNK   |            |     | CN-01 | SOLID  | 1      | 23.1        | 1.2 RWS 5-12-95<br>N/A | ug/g |
|          |         | 7 STD    |            |     | CN-01 | SOLID  | 915    | 1110        | N/A                    | ug/g |

Final page for worklist # 1361

  
Analyst Signature

Date

  
Analyst Signature

Date

595T000206 - .4859g into 5ml EDTA/stand solution  
 .250ml of sample dilution used  
 Std D/I = .250ml at 54N8C to Volume 25ml  
 Std amount = .500ml of Std D/I  
 Sp. ke amount = .250ml of Std D/I

Reviewed RW Schmid 5-12-95

.049 Blank  
 .861 Std  
 .157 Sample.  
 .153 Duplicate  
 .497 Spiked  
 .082 Blank  
 .862 Std

Data Entry Comments:

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## WHC-SD-WM-DP-100, REV. 0-A



Cyanide Calibration with EDTA/en and Ammonium Sulfamate

Date: April 18, 1995

Calibrator Standard: 44N8C

Instrument ID: WA93252

Working Standard Concentration: 1026 ppm / 100 d.f. = 10.26 ppm

| Sample | Vol. | Working Std. (ml) | ug CN- | Net Abs. |
|--------|------|-------------------|--------|----------|
| 1      |      | 0                 | 0      | 0        |
| 2      |      | 0.05              | 0.513  | 0.054    |
| 3      |      | 0.2               | 2.05   | 0.358    |
| 4      |      | 0.4               | 4.1    | 0.605    |
| 5      |      | 0.6               | 6.16   | 0.909    |
| 6      |      | 1                 | 10.26  | 1.5      |
| 7      |      | 1.2               | 12.31  | 1.767    |

## Regression Output:

|                     |          |
|---------------------|----------|
| Constant            | 0.014205 |
| Std Err of Y Est    | 0.029141 |
| R Squared           | 0.998507 |
| No. of Observations | 7        |
| Degrees of Freedom  | 5        |
|                     |          |
| X Coefficient(s)    | 0.143914 |
| Std Err of Coef.    | 0.002489 |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |
|--|
|  |
|--|

**CN- DETERMINATION : LA-695-102 (C-0) BLANK, LIQUID, SOLID**

| Type             | SAMPLE   |                 |                 |
|------------------|--|-----------------|-----------------|
| Solid            | Sample Weight in grams (SS) 0.48590  |                 |                 |
| WORKSTATION      | Dissolution Volume (EDTA/en + sample) (DV) 5.00000                                     |                 |                 |
| 1361             | Aliquot Analyzed from Dissolution (A) 4.00000  |                 |                 |
| TEST CODE        | Dilution Factor (DF) 1.000   |                 |                 |
| CN-01            | Absorbance of Blank 0.000  |                 |                 |
|                  | Absorbance of Sample 0.049   |                 |                 |
| Blank            | Y-Intercept Value 0.014205   |                 |                 |
| Sample #         | Slope Value 0.143914   |                 |                 |
|                  | µg of Cyanide 0.242  |                 |                 |
| Instrument Code  | µg CN- /g 6.22E-01   |                 |                 |
| WA93252          |  |                 |                 |
| ANALYST          | µg of Cyanide = [(Absorb. of Sample - Absorb. of Blank) - (Y-Intercept)] / Slope Value |                 |                 |
| J.T. Knight      | µg/g of Cyanide = (µg Cyanide / A) * (DV / SS (g))                                     |                 |                 |
| DATE             |  |                 |                 |
| 05/12/95         | Detection Limit = 1.5µg Cyanide / SS * DF  |                 |                 |
| TIME             | v RESULTS v  |                 |                 |
| Calibration Date | Cyanide Concentration (µg/g)   | <1.5 µg Cyanide | Detection Limit |
| 04/18/95         |  |                 | µg CN- / g      |
|                  |  |                 | 3.09E+00        |

Data Entry by: *D. Miller* Date: 05/12/95  
 Approved by: *R.W. Schmedemann* Date: 05-12-95  
 Form 695102CT Rev. 1.5 Page 1 of 1

PLACE ANALYTICAL CARD IN BOX BELOW-DO NOT WRITE IN SPACE

|  |
|--|
|  |
|--|

## CN- DETERMINATION : LA-695-102 (C-0) SPIKE, STANDARD

| Type             | NA  | STANDARD  |
|------------------|---|-----------|
| Standard         | Standard Aliquot in mL  | 0.250     |
| Working (ml)     | Diluent + Standard Volume                                       | 25.00     |
| 1361             | Diluted Standard in mL to be Analyzed                           | 0.500     |
| Test Code        | True Value CN- Concentration ( $\mu$ g/mL)                      | 915       |
| CN-01            | Absorbance of Blank   | 0.049     |
| Matrix           | Absorbance of Standard  | 0.861     |
| liquid           | Y-Intercept Value   | 0.014205  |
| Sample #         | Slope Value   | 0.143914  |
| 54N8C            | $\mu$ g of CN in Standard                                       | ERR 5.544 |
| Instrument Code  |   |           |
| WA93252          |   |           |
| Analyst          | <i>J.T. Knight</i> -0.6520                                      |           |
| J.T. Knight      |   |           |
| Date             | $\mu$ g of CN-/mL in Standard                                   | ERR 1109  |
| 05/12/95         |   |           |
| (ml)             | Standard % Recovery   | 121.2%    |
| Calibration Date | Slope and Y-Intercept calculated from working curve calibration |           |
| 04/18/95         | Original Sample Calculation from Form 695102C1                  |           |

 $\mu\text{g of CN- in Sample+Spike} = [(\text{Absorbance of Sample+Spike} - \text{Absorbance of Blank}) - (\text{Y-Intercept})] / \text{Slope Value}$  $\mu\text{g/mL of CN-} = \mu\text{g of CN- in Standard} / \text{Diluted Standard} * \text{Dilution Factor}$ 

Dilution Factor = Flask Volume / Standard Aliquot

Standard % Recovery = ( $\mu\text{g of CN-/mL in Standard} / \text{True Value CN- Concentration } (\mu\text{g/mL})$ ) \* 100

|                  |                      |       |          |
|------------------|----------------------|-------|----------|
| Data Entry by:   | <i>J. M. Bell</i>    | Date: | 05/12/95 |
| Approved by:     | <i>B.W. Schaefer</i> | Date: | 5-12-95  |
| Form X2 Rev. 4.0 |                      | Page  | 1 of 1   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |
|--|
|  |
|--|

**CN- DETERMINATION : LA-695-102 (C-0) BLANK, LIQUID, SOLID**

| Type             | SAMPLE   |
|------------------|--|
| Solid            | Sample Weight in grams (SS) 0.48590  |
| Work Log         | Dissolution Volume (EDTA/en + sample) (DV) 5.00000                                     |
| 1361             | Aliquot Analyzed from Dissolution (A) 0.25000  |
| test C-062       | Dilution Factor (DF) 1.000   |
| CN-01            | Absorbance of Blank 0.049  |
| L91312           | Absorbance of Sample 0.157   |
| Solid            | Y-Intercept Value 0.014205   |
| Sample #         | Slope Value 0.143914   |
| S95T000206       | µg of Cyanide 0.652  |
| Instrument Code  | µg CN- /g 2.68E+01   |
| WA93252          |  |
| Analyst          | µg of Cyanide = [(Absorb. of Sample - Absorb. of Blank) - (Y-Intercept)] / Slope Value |
| J.T. Knight      | µg/g of Cyanide = (µg Cyanide / A) * (DV / SS (g))                                     |
| Date             |  |
| 05/12/95         | Detection Limit = 1.5µg Cyanide / SS * DF  |
| Time             | v RESULTS v  |
|                  | Cyanide Concentration (µg/g)   |
| Calibration Date | <1.5 µg Cyanide  |
| 04/18/95         | Detection Limit<br>µg CN- / g<br>3.09E+00  |

|                        |                       |       |          |
|------------------------|-----------------------|-------|----------|
| Data Entry by:         | <i>John Bell</i>      | Date: | 05/12/95 |
| Approved by:           | <i>Bill Schneider</i> | Date: | 5-12-95  |
| Form 695102CJ Rev. 1.5 |                       | Page  | 1 of 1   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |
|--|
|  |
|--|

**CN- DETERMINATION : LA-695-102 (C-0) BLANK, LIQUID, SOLID**

| ITEM                   | SAMPLE   |
|------------------------|--|
| Solid                  | Sample Weight in grams (SS) 0.48590  |
| Wt/ Vol                | Dissolution Volume (EDTA/en + sample) (DV) 5.00000                                     |
| 1361                   | Aliquot Analyzed from Dissolution (A) 0.25000  |
| Test Code              | Dilution Factor (DF) 1.000   |
| CN-01                  | Absorbance of Blank 0.049  |
| Sample                 | Absorbance of Sample 0.153   |
| Solid                  | Y-Intercept Value 0.014205   |
| Sample                 | Slope Value 0.143914   |
| S95T000206dup          | µg of Cyanide 0.624  |
| Instrument Code        | µg CN- / g 2.57E+01  |
| WA93252                |  |
|                        | µg of Cyanide = [(Absorb. of Sample - Absorb. of Blank) - (Y-Intercept)] / Slope Value |
| J.T. Knight            | µg/g of Cyanide = (µg Cyanide / A) * (DV / SS (g))                                     |
| Data                   |  |
| 05/12/95               | Detection Limit = 1.5µg Cyanide / SS * DF  |
| Date                   | v RESULTS v  |
|                        | Cyanide Concentration (µg/g)   |
| <1.0000000000000001    | <1.5 µg Cyanide  |
| 04/18/95               | Detection Limit<br>µg CN- / g<br>3.09E+00  |
| Data Entry by:         | Date: 05/12/95   |
| Approved by:           | Date: 5-12-95  |
| Form 695102C1 Rev. 1.5 | Page 1 of 1  |

PLACE ANALYTICAL CARD IN BOX BELOW-DO NOT WRITE IN SPACE

|  |  |  |
|--|--|--|
|  |  |  |
|--|--|--|

## CN- DETERMINATION : LA-695-102 (C-0) SPIKE, STANDARD

| Type             |   | SPIKE    | NA  |
|------------------|---|----------|-----|
| Spike            | Spike Aliquot in mL   | 0.250    |     |
| Working Dil.     | Diluent + Spike Standard Volume                                 | 25.00    |     |
| 1361             | Diluted Spike Standard in mL                                    | 0.250    |     |
| 1001-0008        | True Value CN- Concentration ( $\mu\text{g/mL}$ )               | 915      |     |
| CN-01            | Absorbance of Blank   | 0.049    |     |
| LMCS             | Absorbance of Sample+Spike                                      | 0.497    |     |
| liquid           | Y-Intercept Value   | 0.014205 |     |
| Sample #         | Slope Value   | 0.143914 |     |
| 54NBC            | $\mu\text{g}$ of CN- in Sample+Spike                            | 3.014    | ERR |
| Instrument ID#   |   |          |     |
| WA93252          |   |          |     |
| Analytical       | Known $\mu\text{g}$ of CN- in Original Sample                   | 0.6520   |     |
| J.T. Knight      |   |          |     |
| Date             | $\mu\text{g}$ of CN- in Spike                                   | 2.2875   |     |
| 05/12/95         |   |          |     |
| (mls)            | Spike % Recovery  | 103.3%   |     |
| Calibration Date | Slope and Y-Intercept calculated from working curve calibration |          |     |
| 04/18/95         | $\mu\text{g}$ of CN- in Sample Calculation from Form 695102C1   |          |     |

$\mu\text{g}$  of CN- in Sample (Corrected) = Known  $\mu\text{g}$  of CN- in Original Sample \* g of Sample in Spike / g Used in Original Sample

$\mu\text{g}$  of CN- in Sample+Spike = [(Absorbance of Sample+Spike - Absorbance of Blank) - (Y-Intercept)] / Slope Value

$\mu\text{g}$  of CN- in Spike = LMCS Value (ppm) / Dilution Factor \* Diluted Spike Standard

Dilution Factor = Spike Dilution Volume / Spike Aliquot

Spike % Recovery = ( $\mu\text{g}$  of CN- in Sample+Spike) - ( $\mu\text{g}$  of CN- in Sample) / ( $\mu\text{g}$  of CN- in Spike) \* 100%

|                  |                    |       |             |
|------------------|--------------------|-------|-------------|
| Data Entry by:   | <i>[Signature]</i> | Date: | 05/12/95    |
| Approved by:     | <i>[Signature]</i> | Date: | 5-12-95     |
| Form X2 Rev. 1.0 |                    |       | Page 1 of 1 |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |
|--|
|  |
|--|

**CN- DETERMINATION : LA-695-102 (C-0) BLANK, LIQUID, SOLID**

| ITEM               | SAMPLE   |                 |                 |
|--------------------|--|-----------------|-----------------|
| Solid              | Sample Weight in grams (SS)      0.48590   |                 |                 |
| Weight Loss        | Dissolution Volume (EDTA/en + sample) (DV)      5.00000                                |                 |                 |
| 1361               | Aliquot Analyzed from Dissolution (A)      4.00000                                     |                 |                 |
| Test Code          | Dilution Factor (DF)      1.000  |                 |                 |
| CN-01              | Absorbance of Blank      0.000   |                 |                 |
| Matrix             | Absorbance of Sample      0.082  |                 |                 |
| Blank              | Y-Intercept Value      0.014205  |                 |                 |
| Sample             | Slope Value      0.143914  |                 |                 |
|                    | µg of Cyanide      0.471   |                 |                 |
| Instrument Control | µg CN-/g      1.21E+00   |                 |                 |
| WA93252            | µg of Cyanide = [(Absorb. of Sample - Absorb. of Blank) - (Y-Intercept)] / Slope Value |                 |                 |
| J.T. Knight        | µg/g of Cyanide = (µg Cyanide / A) * (DV / SS (g))                                     |                 |                 |
| 05/12/95           | Detection Limit = 1.5µg Cyanide / SS * DF  |                 |                 |
|                    | v RESULTS v  |                 |                 |
|                    | Cyanide Concentration (µg/g)   | <1.5 µg Cyanide | Detection Limit |
| 04/18/95           |  |                 | µg CN-/ g       |
|                    |  |                 | 3.09E+00        |

|                        |                       |       |          |
|------------------------|-----------------------|-------|----------|
| Data Entry by:         | <i>John Michael</i>   | Date: | 05/12/95 |
| Approved by:           | <i>P.W. Schroeder</i> | Date: | 5-12-95  |
| Form 695102C1 Rev. 1.5 |                       |       |          |

PLACE ANALYTICAL CARD IN BOX BELOW-DO NOT WRITE IN SPACE

|  |
|--|
|  |
|--|

## CN- DETERMINATION : LA-695-102 (C-0) SPIKE, STANDARD

| ITEM             | NA  | STANDARD  |
|------------------|---|-----------|
| Standard         | Standard Aliquot in mL  | 0.250     |
| Working Dil.     | Diluent + Standard Volume                                       | 25.00     |
| 1361             | Diluted Standard in mL to be Analyzed                           | 0.500     |
| Test Sample      | True Value CN- Concentration ( $\mu\text{g}/\text{mL}$ )        | 915       |
| CN-01            | Absorbance of Blank   | 0.049     |
| MATRIX           | Absorbance of Standard  | 0.862     |
| liquid           | Y-Intercept Value   | 0.014205  |
| Sample #         | Slope Value   | 0.143914  |
| 54N8C            | $\mu\text{g}$ of CN in Standard                                 | ERR 5.551 |
| Instrument ID#   |   |           |
| WA93252          |   |           |
| Analyst          | $y = 0.143914x - 0.014205$                                      |           |
| J.T. Knight      |   |           |
| Date             | $\mu\text{g}$ of CN-/mL in Standard                             | ERR 1110  |
| 05/12/95         |   |           |
| Units            | Standard % Recovery   | 121.3%    |
| Calibration Date | Slope and Y-Intercept calculated from working curve calibration |           |
| 04/18/95         | Original Sample Calculation from Form 695102C1                  |           |

$\mu\text{g}$  of CN- in Sample+Spike =  $[(\text{Absorbance of Sample+Spike} - \text{Absorbance of Blank}) - (\text{Y-Intercept})] / \text{Slope Value}$

$\mu\text{g}/\text{mL}$  of CN- =  $\mu\text{g}$  of CN- in Standard / Diluted Standard \* Dilution Factor

Dilution Factor = Flask Volume / Standard Aliquot

Standard % Recovery =  $(\mu\text{g}$  of CN-/mL in Standard / True Value CN- Concentration ( $\mu\text{g}/\text{mL}$ )) \* 100

|                  |                    |                |
|------------------|--------------------|----------------|
| Data Entry by:   | <i>[Signature]</i> | Date: 05/12/95 |
| Approved by:     | <i>[Signature]</i> | Date: 5-12-95  |
| Form X2 Rev. 1.0 |                    | Page 1 of 1    |

## LABCORE Data Entry Template for Worklist# 1191

Analyst: EE

Instrument: IC01

Book # 82N9-17Method: LA-533-105 Rev/Mod C-2

Worklist Comment: H2O Digest AX-102 IC. JMF

| GROUP    | PROJECT | S TYPE      | SAMPLE#    | R A    | TEST     | MATRIX | ACTUAL     | FOUND        | DL            | UNIT               |
|----------|---------|-------------|------------|--------|----------|--------|------------|--------------|---------------|--------------------|
|          |         | 1 BLNK-PREP |            | aIC-01 | F-02     | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | CL-02    | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | NO2-02   | SOLID  |            | <u>13047</u> | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | BR-02    | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | NO3-02   | SOLID  |            | <u>43808</u> | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | PO4-02   | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | SO4-02   | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 1 BLNK-PREP |            | aIC-01 | OXALATE2 | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | F-02     | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | CL-02    | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | NO2-02   | SOLID  | <u>528</u> | <u>526</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | BR-02    | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | NO3-02   | SOLID  | <u>578</u> | <u>583</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | PO4-02   | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | SO4-02   | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
|          |         | 2 STD       |            | aIC-01 | OXALATE2 | SOLID  | <u>N/A</u> | <u>N/A</u>   | <u>N/A</u>    | ug/g               |
| 95000015 | AX-102  | 3 SAMPLE    | S95T000593 | 0 W    | aIC-01   | NO2-02 | SOLID      | <u>N/A</u>   | <u>4.01E4</u> | <u>3.05E3</u> ug/g |
| 95000015 | AX-102  | 3 SAMPLE    | S95T000593 | 0 W    | aIC-01   | NO3-02 | SOLID      | <u>N/A</u>   | <u>1.72E5</u> | <u>3.81E3</u> ug/g |

S95T000593 10.7640 g/L Dup 10.7020 g/L

Data Entry Comments:

Spike puts NO<sub>3</sub> value very near STD 82N9-A, 100ml - 10ml top of curve, which may explain SPKE 82N917 - 100ml - 5ml spike recovery JMF 5/1/95

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## LABCORE Data Entry Template for Worklist# 1191

| GROUP    | PROJECT | S TYPE | SAMPLE#    | R A | TEST   | MATRIX   | ACTUAL | FOUND  | DL     | UNIT     |
|----------|---------|--------|------------|-----|--------|----------|--------|--------|--------|----------|
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | F-02     | SOLID  | N/A    | N/A    | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | CL-02    | SOLID  | N/A    | 1.72E4 | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | NO2-02   | SOLID  | 4.01E4 | 4.13E4 | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | BR-02    | SOLID  | N/A    | N/A    | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | NO3-02   | SOLID  | 1.72E5 | 1.72E5 | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | PO4-02   | SOLID  | N/A    | N/A    | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | SO4-02   | SOLID  | N/A    | N/A    | N/A ug/g |
| 95000015 | AX-102  | 4 DUP  | S95T000593 | 0 W | AIC-01 | OXALATE2 | SOLID  | N/A    | N/A    | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | CL-02    | SOLID  | N/A    | 1.72E4 | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | F-02     | SOLID  | N/A    | 1.72E4 | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | NO2-02   | SOLID  | 100    | 87.8   | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | BR-02    | SOLID  | N/A    | N/A    | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | NO3-02   | SOLID  | 100    | 48.4   | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | PO4-02   | SOLID  | N/A    | 1.72E4 | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | SO4-02   | SOLID  | N/A    | 1.72E4 | N/A ug/g |
| 95000015 | AX-102  | 5 SPK  | S95T000593 | 0 W | AIC-01 | OXALATE2 | SOLID  | N/A    | N/A    | N/A ug/g |

Final page for worklist # 1191

E.H. Cohn 4-25-94  
 Analyst Signature Date  
CHB 5-2-95

Analyst Signature Date

Jane M. Lye 5/2/95  
 Verified

Data Entry Comments:

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

**WESTINGHOUSE HANFORD COMPANY**  
**222-S LABORATORY**  
**INORGANIC ANALYTICAL BATCH AND SUMMARY SHEET**

## ANION ANALYSIS ON DIONEX

**SAMPLE #:** S95T000593      **ANALYST:** Ed Colvin  
**TEST CODE:** @IC-01      **ANALYSIS DATE:** 04/25/95  
**INSTRUMENT:** Dionex 4000i      **SAMPLE POINT:** AX-102  
**WORK LIST #:** 1191      **SAMPLE PREP:** water digest  
**BATCH ID:**

**NARRATIVE:**

**Analyst Comments:**

**Chemist Comments:**

卷之三

**Form Completed By:**

### Chemist Approach:

Data

*Sher*

Page

~~11/95~~

WHC-SD-WM-DP-100, REV. 0-A

| LAB LEADER INFO             |                |
|-----------------------------|----------------|
| Method:                     | LA-633-105 C-2 |
| Matrix:                     | solid          |
| Test Code:                  | @IC-01         |
| Work List #:                | 1191           |
| Batch #:                    |                |
| Result Units                |                |
| ( $\mu$ g/g or $\mu$ g/mL): | $\mu$ g/g      |
| Spike Book Number:          | 82NBA          |
| Spike Sample #:             | 1              |
| Prepared By:                | Jann Frye      |
| Prepared Date:              | 06/01/95       |
| Chemist:                    | Jann Frye      |
| Analyst:                    | Ed Colvin      |
| Analysis Date:              | 04/25/95       |
| Time Complete:              |                |
| Instrument Code:            | Dionex 4000i   |
| Rerun:                      | 0              |
| Sample Prep:                | water digest   |
| Sample Point:               | AX-102         |
| Sample Type                 |                |
| STANDARD                    | 82NBA          |
| SAMPLE 1                    | S95T000593     |
| DUPLICATE 1                 | S96T000593     |
| SAMPLE 2                    |                |
| DUPLICATE 2                 |                |
| SAMPLE 3                    |                |
| DUPLICATE 3                 |                |
| SAMPLE 4                    |                |
| DUPLICATE 4                 |                |
| SPIKE                       | S95T000593     |
| SPIKE DUPLICATE             |                |

**PRINT**

| TECH INFO                      |          |         |          |           |         |         |         |        |
|--------------------------------|----------|---------|----------|-----------|---------|---------|---------|--------|
| Fluoride                       | Chloride | Nitrite | Nitrate  | Phosphate | Sulfate | Bromide | Oxalate |        |
| Blank Data ( $\mu$ g/mL)       | <0.06    | <0.1    | <.8      | <1        | <.6     | <.8     | <.8     | <.5    |
| Standard Data ( $\mu$ g/mL)    | 62.6     | 78.8    | 526      | 883       | 496     | 618     | 577     | 488    |
| Sample 1 Data ( $\mu$ g/mL)    |          |         | 4.32E+02 | 1.86E+03  |         |         |         |        |
| Sample 1 Dilution Factor       |          |         | 41       | 41        |         |         |         |        |
| Sample 1 Prep DF               | 10.764   | 10.764  | 10.764   | 10.764    | 10.764  | 10.764  | 10.764  | 10.764 |
| Duplicate 1 Data ( $\mu$ g/mL) |          |         | 4.42E+02 | 1.84E+03  |         |         |         |        |
| Duplicate 1 Dilution Factor    |          |         | 41       | 41        |         |         |         |        |
| Duplicate 1 Prep DF            | 10.702   | 10.702  | 10.702   | 10.702    | 10.702  | 10.702  | 10.702  | 10.702 |
| Sample 2 Data ( $\mu$ g/mL)    |          |         |          |           |         |         |         |        |
| Sample 2 Dilution Factor       |          |         |          |           |         |         |         |        |
| Sample 2 Prep DF               |          |         |          |           |         |         |         |        |
| Duplicate 2 Data ( $\mu$ g/mL) |          |         |          |           |         |         |         |        |
| Duplicate 2 Dilution Factor    |          |         |          |           |         |         |         |        |
| Duplicate 2 Prep DF            |          |         |          |           |         |         |         |        |
| Sample 3 Data ( $\mu$ g/mL)    |          |         |          |           |         |         |         |        |
| Sample 3 Dilution Factor       |          |         |          |           |         |         |         |        |
| Sample 3 Prep DF               |          |         |          |           |         |         |         |        |
| Duplicate 3 Data ( $\mu$ g/mL) |          |         |          |           |         |         |         |        |
| Duplicate 3 Dilution Factor    |          |         |          |           |         |         |         |        |
| Duplicate 3 Prep DF            |          |         |          |           |         |         |         |        |
| Sample 4 Data ( $\mu$ g/mL)    |          |         |          |           |         |         |         |        |
| Sample 4 Dilution Factor       |          |         |          |           |         |         |         |        |
| Sample 4 Prep DF               |          |         |          |           |         |         |         |        |
| Duplicate 4 Data ( $\mu$ g/mL) |          |         |          |           |         |         |         |        |
| Duplicate 4 Dilution Factor    |          |         |          |           |         |         |         |        |
| Duplicate 4 Prep DF            |          |         |          |           |         |         |         |        |
| Spike + Sample 1 ( $\mu$ g/mL) |          |         | 6.17E+02 | 1.96E+03  |         |         |         |        |
| Spike + Dup 1 ( $\mu$ g/mL)    |          |         |          |           |         |         |         |        |
| Spike Volume (mL)              |          |         | 1.00E-01 | 1.00E-01  |         |         |         |        |
| Total Volume (mL)              |          |         | 10.25    | 10.25     |         |         |         |        |
| Std. Conc. ( $\mu$ g/mL)       | 58       | 75      | 628      | 578       | 518     | 599     | 572     | 514    |
| Detection Limit                | 0.100    | 0.200   | 1.000    | 1.000     | 1.000   | 1.000   | 1.000   | 1.000  |

$$\text{Spike Recovery} = \frac{[(\text{Spike} + \text{Sample}) - \text{Sample}] * (\text{Total Volume})}{(\text{Spike Vol.}) * (\text{Spike Std.}) * (\text{Sample DF})} * 100\%$$

Note: (For spike recovery when the sample conc. is less than detection limit you do NOT subtract sample conc.)

$$\text{Duplicate Relative \% Difference} = \frac{(\text{Sample} - \text{Duplicate})}{(\text{Sample} + \text{Duplicate}) / 2} * 100\%$$

Less than Values are Calculated from the Detection Limit\*Detection Factor

| RESULTS                  |       |        |          |          |       |        |        |       |
|--------------------------|-------|--------|----------|----------|-------|--------|--------|-------|
| Standard % Recovery      | 93.8% | 105.2% | 99.6%    | 100.8%   | 96.1% | 103.2% | 100.9% | 96.9% |
| Sample 1 in $\mu$ g/g    | <0.00 | <0.00  | 4.01E+04 | 1.72E+05 | <0.00 | <0.00  | <0.00  | <0.00 |
| Duplicate 1 in $\mu$ g/g | <0.00 | <0.00  | 4.13E+04 | 1.72E+05 | <0.00 | <0.00  | <0.00  | <0.00 |
| Duplicate 1 RPD          | N/A   | N/A    | 3.1%     | 0.1%     | N/A   | N/A    | N/A    | N/A   |
| ERR                      | ERR   | ERR    | ERR      | ERR      | ERR   | ERR    | ERR    | ERR   |
| ERR                      | ERR   | ERR    | ERR      | ERR      | ERR   | ERR    | ERR    | ERR   |
| ERR                      | ERR   | ERR    | ERR      | ERR      | ERR   | ERR    | ERR    | ERR   |
| Spike % Recovery         |       |        |          | 87.8%    | 48.4% |        |        |       |

Data Entry by:  
Approved by:

*Jann M. Frye*  
*Jann M. Frye*

Date: 05/01/95

Date: 27/05/95

**WESTINGHOUSE HANFORD COMPANY  
222-S LABORATORY  
INORGANIC ANALYTICAL BATCH AND SUMMARY SHEET  
ANION ANALYSIS ON DIONEX**

|              |              |                |              |
|--------------|--------------|----------------|--------------|
| SAMPLE #:    | S95T000593   | ANALYST:       | Ed Colvin    |
| TEST CODE:   | @IC-01       | ANALYSIS DATE: | 04/25/95     |
| INSTRUMENT:  | Dionex 4000i | SAMPLE POINT:  | AX-102       |
| WORK LIST #: | 1191         | SAMPLE PREP:   | water digest |
| BATCH ID:    |              |                |              |

**NARRATIVE:**

**Analyst Comments:**

**Chemist Comments:**

**Form Completed By:**

**Form Completed By:**

Date: 5/15/13

Date: 2/2/95

WHC-SD-WM-DP-100, REV. 0-A

| LAB LEADER INFO                          |                 |
|--|-----------------|
| Method:                                  | LA-633-106 C-2  |
| Matrix:                                  | solid           |
| Test Code:                               | @IC-01          |
| Work List #:                             | 1191            |
| Batch #:                                 |                 |
| <br>                                     |                 |
| Result Units                             |                 |
| ( $\mu\text{g/g}$ or $\mu\text{g/mL}$ ): | $\mu\text{g/g}$ |
| Spike Book Number:                       | S2N9A           |
| Spike Sample #:                          | 1               |
| <br>                                     |                 |
| Prepared By:                             | Jann Frye       |
| Prepared Date:                           | 06/01/95        |
| Chemist:                                 | Jann Frye       |
| Analyst:                                 | Ed Colvin       |
| Analysis Date:                           | 04/26/95        |
| Time Complete:                           |                 |
| Instrument Code:                         | Dionex 4000     |
| Rerun:                                   | 0               |
| Sample Prep:                             | water digest    |
| Sample Point:                            | AX-102          |
| <br>                                     |                 |
| Sample Type                              |                 |
| STANDARD                                 | S2N9A           |
| SAMPLE 1                                 | S95T000593      |
| DUPLICATE 1                              | S95T000593      |
| SAMPLE 2                                 |                 |
| DUPLICATE 2                              |                 |
| SAMPLE 3                                 |                 |
| DUPLICATE 3                              |                 |
| SAMPLE 4                                 |                 |
| DUPLICATE 4                              |                 |
| SPIKE                                    | S95T000593      |
| SPIKE DUPLICATE                          |                 |

| TECH INFO                             |          |          |          |          |           |         |         |         |
|---------------------------------------|----------|----------|----------|----------|-----------|---------|---------|---------|
|                                       | Fluoride | Chloride | Nitrite  | Nitrate  | Phosphate | Sulfate | Bromide | Oxalate |
| Blank Data ( $\mu\text{g/mL}$ )       | <0.06    | <0.1     | <8       | <1       | <.6       | <.8     | <.8     | <.5     |
| Standard Data ( $\mu\text{g/mL}$ )    | 62.6     | 78.8     | 628      | 583      | 496       | 618     | 677     | 498     |
| Sample 1 Data ( $\mu\text{g/mL}$ )    |          |          | 4.32E+02 | 1.88E+03 |           |         |         |         |
| Sample 1 Dilution Factor              |          |          | 41       | 41       |           |         |         |         |
| Sample 1 Prep DF                      | 10.764   | 10.764   | 10.764   | 10.764   | 10.764    | 10.764  | 10.764  | 10.764  |
| Duplicate 1 Data ( $\mu\text{g/mL}$ ) |          |          | 4.42E+02 | 1.84E+03 |           |         |         |         |
| Duplicate 1 Dilution Factor           |          |          | 41       | 41       |           |         |         |         |
| Duplicate 1 Prep DF                   | 10.702   | 10.702   | 10.702   | 10.702   | 10.702    | 10.702  | 10.702  | 10.702  |
| Sample 2 Data ( $\mu\text{g/mL}$ )    |          |          |          |          |           |         |         |         |
| Sample 2 Dilution Factor              |          |          |          |          |           |         |         |         |
| Sample 2 Prep DF                      |          |          |          |          |           |         |         |         |
| Duplicate 2 Data ( $\mu\text{g/mL}$ ) |          |          |          |          |           |         |         |         |
| Duplicate 2 Dilution Factor           |          |          |          |          |           |         |         |         |
| Duplicate 2 Prep DF                   |          |          |          |          |           |         |         |         |
| Sample 3 Data ( $\mu\text{g/mL}$ )    |          |          |          |          |           |         |         |         |
| Sample 3 Dilution Factor              |          |          |          |          |           |         |         |         |
| Sample 3 Prep DF                      |          |          |          |          |           |         |         |         |
| Duplicate 3 Data ( $\mu\text{g/mL}$ ) |          |          |          |          |           |         |         |         |
| Duplicate 3 Dilution Factor           |          |          |          |          |           |         |         |         |
| Duplicate 3 Prep DF                   |          |          |          |          |           |         |         |         |
| Sample 4 Data ( $\mu\text{g/mL}$ )    |          |          |          |          |           |         |         |         |
| Sample 4 Dilution Factor              |          |          |          |          |           |         |         |         |
| Sample 4 Prep DF                      |          |          |          |          |           |         |         |         |
| Duplicate 4 Data ( $\mu\text{g/mL}$ ) |          |          |          |          |           |         |         |         |
| Duplicate 4 Dilution Factor           |          |          |          |          |           |         |         |         |
| Duplicate 4 Prep DF                   |          |          |          |          |           |         |         |         |
| Spike + Sample 1 ( $\mu\text{g/mL}$ ) |          |          | 8.11E+02 | 1.95E+03 |           |         |         |         |
| Spike + Dup 1 ( $\mu\text{g/mL}$ )    |          |          |          |          |           |         |         |         |
| Spike Volume (mL)                     |          |          | 1.00E-01 | 1.00E-01 |           |         |         |         |
| Total Volume (mL)                     |          |          | 10.25    | 10.25    |           |         |         |         |
| Std. Conc. ( $\mu\text{g/mL}$ )       | 66       | 75       | 628      | 578      | 516       | 598     | 572     | 514     |
| Detection Limit                       | 0.100    | 0.200    | 1.000    | 1.000    | 1.000     | 1.000   | 1.000   | 1.000   |

Spike Recovery =  $((\text{Spike} + \text{Sample}) - \text{Sample}) / (\text{Total Volume}) / ((\text{Spike Vol.}) * (\text{Spike Std.}) * (\text{Sample DF})) * 100\%$

Note: (For spike recovery when the sample conc. is less than detection limit you do NOT subtract sample conc.)

Duplicate Relative % Difference =  $((\text{Sample} - \text{Duplicate}) / ((\text{Sample} + \text{Duplicate}) / 2)) * 100\%$

Less than Values are Calculated from the Detection Limit \* Dilution Factor

| v RESULTS v                    | Fluoride | Chloride | Nitrite  | Nitrate  | Phosphate | Sulfate | Bromide | Oxalate |
|--------------------------------|----------|----------|----------|----------|-----------|---------|---------|---------|
| Standard % Recovery            | 83.9%    | 105.2%   | 89.8%    | 100.8%   | 86.1%     | 103.2%  | 100.8%  | 98.9%   |
| Sample 1 In $\mu\text{g/g}$    | <0.00    | <0.00    | 4.01E+04 | 1.72E+05 | <0.00     | <0.00   | <0.00   | <0.00   |
| Duplicate 1 In $\mu\text{g/g}$ | <0.00    | <0.00    | 4.13E+04 | 1.72E+05 | <0.00     | <0.00   | <0.00   | <0.00   |
| Duplicate 1 RPD                | N/A      | N/A      | 3.1%     | 0.1%     | N/A       | N/A     | N/A     | N/A     |
| ERR                            | ERR      | ERR      | ERR      | ERR      | ERR       | ERR     | ERR     | ERR     |
| ERR                            | ERR      | ERR      | ERR      | ERR      | ERR       | ERR     | ERR     | ERR     |
| ERR                            | ERR      | ERR      | ERR      | ERR      | ERR       | ERR     | ERR     | ERR     |
| Spike % Recovery               |          |          |          |          | 84.8%     | 41.1%   |         |         |

Data Entry by:

Approved by:

*Jann M. Frye*

Date: 05/01/95

Date: 5/3/95

Sample Name: 82N9-A STD  
 Data File : C:\DX\DATA\95042531.D02  
 Method : C:\DX\METHOD\KIT.MET  
 ACI Address: 1 System: 1 Inject#: 2  
 Analyst : *CDL* Column: 4-25-95


Date: 04/25/1995 07:01:56

Detector: CDM-1

| Calibration | Volume | Dilution | Points | Rate | Start | Stop | Area | Reject |
|-------------|--------|----------|--------|------|-------|------|------|--------|
| External    | 1      | 101      | 2700   | 5Hz  | 0.00  | 9.00 |      | 200    |

## \*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk.<br>Num | Ret<br>Time | Component<br>Name | Concentration<br>ug/ml | Height | Area   | Bl.<br>Code | %Delta |
|------------|-------------|-------------------|------------------------|--------|--------|-------------|--------|
| 1          | 0.87        |                   | 0.000                  | 85     | 368    | 2           |        |
| 2          | 1.02        | fluoride          | 52.623                 | 1793   | 8276   | 2           | 2.00   |
| 3          | 1.52        | chloride          | 78.952                 | 1857   | 8522   | 1           | 0.00   |
| 4          | 1.81        | nitrite           | 525.532                | 7775   | 39794  | 1           | -1.09  |
| 5          | 2.67        | bromide           | 577.349                | 4708   | 28105  | 1           | -1.48  |
| 6          | 3.04        | nitrate           | 583.150                | 5372   | 36650  | 1           | -1.62  |
| 7          | 4.51        | phosphate         | 496.258                | 1111   | 13870  | 1           | -0.66  |
| 8          | 5.74        | sulfate           | 617.982                | 4107   | 50238  | 1           | -0.35  |
| 9          | 7.50        | oxalate           | 498.009                | 1775   | 29327  | 1           | -0.27  |
| Totals     |             |                   | 3429.855               | 28582  | 215150 |             |        |

**File: 95042531.D02 Sample: 82N9-A STD**

SIGNATURE ABOVE REPRESENTS CHEMICAL TECHNOLOGIST/CHEMIST THAT  
 COMPLETED/VERIFIED THE CALIBRATION/ANALYSIS ON PAGES 88 TO 94.

**WHC-SD-WM-DP-100, REV. 0-A**

=====

|              |                         |           |                     |
|--------------|-------------------------|-----------|---------------------|
| Sample Name: | INSTR BLANK             | Date:     | 04/25/1995 06:37:38 |
| Data File :  | C:\DX\DATA\95042531.D01 |           |                     |
| Method :     | C:\DX\METHOD\KIT.MET    |           |                     |
| ACI Address: | 1 System: 1 Inject#: 1  |           |                     |
| Analyst :    | Column:                 | Detector: | CDM-1               |


=====

|             |           |           |           |           |           |           |           |           |
|-------------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|-----------|
| Calibration | Volume    | Dilution  | Points    | Rate      | Start     | Stop      | Area      | Reject    |
| - - - - -   | - - - - - | - - - - - | - - - - - | - - - - - | - - - - - | - - - - - | - - - - - | - - - - - |
| External    | 1         | 1         | 2700      | 5Hz       | 0.00      | 9.00      |           | 200       |

\*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk. | Ret Time | Component Name | Concentration<br>ug/ml | Height    | Area      | Bl. Code  | %Delta    |
|-----|----------|----------------|------------------------|-----------|-----------|-----------|-----------|
| Num | Time     | Name           | - - - - -              | - - - - - | - - - - - | - - - - - | - - - - - |
|     |          |                |                        |           |           |           |           |
|     |          | Totals         | 0.000                  | 0         |           | 0         |           |

**File: 95042531.D01 Sample: INSTR BLANK**



Sample Name: SAMPLE BLK  
 Data File : C:\DX\DATA\95042531.D03  
 Method : C:\DX\METHOD\KIT.MET  
 ACI Address: 1 System: 1 Inject#: 3  
 Analyst : Column:

Date: 04/25/1995 07:15:25


Detector: CDM-1

| Calibration | Volume | Dilution | Points | Rate | Start | Stop | Area | Reject |
|-------------|--------|----------|--------|------|-------|------|------|--------|
| External    | 1      | 1        | 2700   | 5Hz  | 0.00  | 9.00 |      | 200    |

\*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk. | Ret Time | Component | Concentration | Height | Area | Bl.  | %Delta |
|-----|----------|-----------|---------------|--------|------|------|--------|
| Num | Time     | Name      | ug/ml         |        |      | Code |        |
| 2   | 1.55     | chloride  | 0.016         | 46     | 218  | 1    | 1.97   |
| 3   | 3.10     | nitrate   | 0.424         | 97     | 612  | 1    | 0.32   |
|     |          |           | Totals        | 0.440  | 143  | 830  |        |

**File: 95042531.D03 Sample: SAMPLE BLK**




|                                     |                           |
|-------------------------------------|---------------------------|
| Sample Name: S95T000593             | Date: 04/25/1995 07:49:18 |
| Data File : C:\DX\DATA\95042531.D06 |                           |
| Method : C:\DX\METHOD\KIT.MET       |                           |
| ACI Address: 1 System: 1 Inject#: 6 | Detector: CDM-1           |
| Analyst :                           | Column:                   |

| Calibration | Volume | Dilution | Points | Rate | Start | Stop | Area | Reject |
|-------------|--------|----------|--------|------|-------|------|------|--------|
| External    | 1      | 41       | 2700   | 5Hz  | 0.00  | 9.00 |      | 200    |

\*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk.<br>Num | Ret<br>Time | Component<br>Name | Concentration<br>ug/ml | Height | Area   | Bl.<br>Code | %Delta |
|------------|-------------|-------------------|------------------------|--------|--------|-------------|--------|
| 1          | 0.88        |                   | 0.000                  | 239    | 1119   | 2           |        |
| 2          | 1.07        | fluoride          | 19.069                 | 2257   | 7353   | 2           | 4.90   |
| 3          | 1.13        |                   | 0.000                  | 2406   | 12139  | 2           |        |
| 4          | 1.52        | chloride          | 10.803                 | 659    | 2882   | 1           | 0.00   |
| 5          | 1.81        | nitrite           | 431.580                | 16647  | 83423  | 1           | -1.09  |
| 6          | 2.94        | nitrate           | 1852.401               | 40258  | 333172 | 1           | -4.85  |
| 7          | 4.17        |                   | 0.000                  | 47     | 490    | 1           |        |
| 8          | 4.53        | phosphate         | 15.435                 | 78     | 828    | 1           | -0.22  |
| 9          | 5.75        | sulfate           | 51.927                 | 788    | 9745   | 1           | -0.17  |
| 10         | 7.49        | oxalate           | 235.622                | 2109   | 34339  | 1           | -0.40  |
| Totals     |             |                   | 2616.836               | 65489  | 485490 |             |        |

**File: 95042531.D06 Sample: S95T000593**



Data Reprocessed On 04/25/1995 08:44:42


```
=====
| Sample Name: S95T000593 DUP           Date: 04/25/1995 08:07:56
| Data File : C:\DX\DATA\95042531.D07
| Method   : C:\DX\METHOD\KIT.MET
| ACI Address: 1 System: 1 Inject#: 7      Detector: CDM-1
| Analyst   : Column:
=====
```

| Calibration | Volume | Dilution | Points | Rate | Start | Stop | Area | Reject |
|-------------|--------|----------|--------|------|-------|------|------|--------|
| External    | 1      | 41       | 2700   | 5Hz  | 0.00  | 9.00 |      | 200    |

\*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk.<br>Num | Ret<br>Time | Component<br>Name | Concentration<br>ug/ml | Height | Area   | Bl. | %Delta<br>Code |
|------------|-------------|-------------------|------------------------|--------|--------|-----|----------------|
| 1          | 0.88        |                   | 0.000                  | 227    | 1028   | 2   |                |
| 2          | 1.07        | fluoride          | 19.936                 | 2329   | 7701   | 2   | 4.90           |
| 3          | 1.13        |                   | 0.000                  | 2460   | 12634  | 2   |                |
| 4          | 1.52        | chloride          | 12.579                 | 763    | 3351   | 1   | 0.00           |
| 5          | 1.81        | nitrite           | 442.499                | 16924  | 85601  | 1   | -1.09          |
| 6          | 2.95        | nitrate           | 1843.990               | 40550  | 331450 | 1   | -4.53          |
| 7          | 4.18        |                   | 0.000                  | 42     | 396    | 1   |                |
| 8          | 4.52        | phosphate         | 16.430                 | 83     | 896    | 1   | -0.44          |
| 9          | 5.75        | sulfate           | 53.210                 | 813    | 10002  | 1   | -0.17          |
| 10         | 7.49        | oxalate           | 250.528                | 2270   | 36576  | 1   | -0.40          |
| Totals     |             |                   | 2639.172               | 66459  | 489637 |     |                |

**File: 95042531.D07 Sample: S95T000593 DUP**



## WHC-SD-WM-DP-100, REV. 0-A

Data Reprocessed On 04/25/1995 08:47:52


```
=====
| Sample Name: S95T000593 + SPIKE           Date: 04/25/1995 08:32:24
| Data File : C:\DX\DATA\95042531.D09
| Method   : C:\DX\METHOD\KIT.MET
| ACI Address: 1 System: 1 Inject#: 9
| Analyst  : ED Cohen Column: Detector: CDM-1
=====
```

| Calibration | Volume | Dilution | Points | Rate | Start | Stop | Area | Reject |
|-------------|--------|----------|--------|------|-------|------|------|--------|
| External    | 1      | 41       | 2700   | 5Hz  | 0.00  | 9.00 |      | 200    |

\*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk. Num | Ret Time | Component Name | Concentration ug/ml | Height | Area   | Bl. Code | %Delta |
|---------|----------|----------------|---------------------|--------|--------|----------|--------|
|         |          |                |                     |        |        |          |        |
| 1       | 0.89     |                | 0.000               | 258    | 1128   | 2        |        |
| 2       | 1.07     | fluoride       | 38.197              | 2967   | 15123  | 2        | 4.90   |
| 3       | 1.15     |                | 0.000               | 2291   | 11483  | 2        |        |
| 4       | 1.54     | chloride       | 39.268              | 2364   | 10454  | 1        | 1.32   |
| 5       | 1.84     | nitrite        | 616.983             | 24400  | 120336 | 1        | 0.55   |
| 6       | 2.68     | bromide        | 227.890             | 4856   | 27283  | 1        | -1.11  |
| 7       | 2.96     | nitrate        | 1964.429            | 43098  | 356339 | 1        | -4.21  |
| 8       | 4.21     |                | 0.000               | 29     | 285    | 1        |        |
| 9       | 4.53     | phosphate      | 205.917             | 1199   | 14188  | 1        | -0.22  |
| 10      | 5.76     | sulfate        | 294.706             | 4885   | 59319  | 1        | 0.00   |
| 11      | 7.48     | oxalate        | 426.462             | 3883   | 63197  | 1        | -0.53  |
|         |          | Totals         | 3813.853            | 90231  | 679134 |          |        |

File: 95042531.D09 Sample: S95T000593 + SPIKE



## WHC-SD-WM-DP-100, REV. D -A

=====
 Sample Name: S95T000593 + SPIKE Date: 04/25/1995 08:20:14  
 Data File : C:\DX\DATA\95042531.D08  
 Method : C:\DX\METHOD\KIT.MET  
 ACI Address: 1 System: 1 Inject#: 8 Detector: CDM-1  
 Analyst : Column:  
=====


Calibration Volume Dilution Points Rate Start Stop Area Reject

External 1 41 2700 5Hz 0.00 9.00 200

\*\*\*\*\* Peak Report: All Peaks \*\*\*\*\*

| Pk. Num | Ret Time | Component Name | Concentration ug/ml | Height | Area   | B1. Code | %Delta |
|---------|----------|----------------|---------------------|--------|--------|----------|--------|
|         |          |                |                     |        |        |          |        |
| 1       | 0.88     |                | 0.000               | 251    | 995    | 2        |        |
| 2       | 1.06     | fluoride       | 39.305              | 2952   | 15578  | 2        | 6.00   |
| 3       | 1.14     |                | 0.000               | 2201   | 10211  | 2        |        |
| 4       | 1.52     | chloride       | 38.842              | 2351   | 10339  | 1        | 0.00   |
| 5       | 1.81     | nitrite        | 610.573             | 23311  | 119062 | 1        | -1.09  |
| 6       | 2.66     | bromide        | 222.571             | 4826   | 26609  | 1        | -1.85  |
| 7       | 2.94     | nitrate        | 1947.209            | 42659  | 352750 | 1        | -4.85  |
| 8       | 4.18     |                | 0.000               | 30     | 274    | 1        |        |
| 9       | 4.51     | phosphate      | 203.926             | 1189   | 14046  | 1        | -0.66  |
| 10      | 5.73     | sulfate        | 290.444             | 4822   | 58434  | 1        | -0.52  |
| 11      | 7.46     | oxalate        | 421.347             | 3840   | 62417  | 1        | -0.80  |
|         |          | Totals         | 3774.218            | 88433  | 670716 |          |        |

File: 95042531.D08 Sample: S95T000593 + SPIKE



**LABCORE Data Entry Template for Worklist# 672**Analyst: HKL Instrument: AB00 15 Book # 91B52Method: LA-508-101 Rev/Mod D-2

Worklist Comment: Determine sample size using Ludlum. Use .100 mL A-SPK. SLF

| GROUP    | PROJECT | S TYPE      | SAMPLE#    | R A -----TEST-----    | MATRIX | ACTUAL | FOUND | DL  | UNIT        |
|----------|---------|-------------|------------|-----------------------|--------|--------|-------|-----|-------------|
|          |         | 1 STD       |            | @ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
|          |         | 1 STD       |            | @ALPHA01 ALPHA01E     | SOLID  |        |       | N/A | % Ct. Error |
|          |         | 2 BLNK-PREP |            | @ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
|          |         | 2 BLNK-PREP |            | @ALPHA01 ALPHA01E     | SOLID  |        |       | N/A | % Ct. Error |
|          |         | 3 BLNK/BKG  |            | @ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
| 95000014 | AX-102  | 4 SAMPLE    | S95T000204 | 0 F @ALPHA01 ALPHA01  | SOLID  | N/A    |       |     | uCi/g       |
| 95000014 | AX-102  | 4 SAMPLE    | S95T000204 | 0 F @ALPHA01 ALPHA01E | SOLID  | N/A    |       |     | % Ct. Error |
| 95000014 | AX-102  | 5 DUP       | S95T000204 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000014 | AX-102  | 5 DUP       | S95T000204 | 0 F @ALPHA01 ALPHA01E | SOLID  |        |       | N/A | % Ct. Error |
| 95000014 | AX-102  | 6 SPK       | S95T000204 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000015 | AX-102  | 7 SAMPLE    | S95T000208 | 0 F @ALPHA01 ALPHA01  | SOLID  | N/A    |       |     | uCi/g       |
| 95000015 | AX-102  | 7 SAMPLE    | S95T000208 | 0 F @ALPHA01 ALPHA01E | SOLID  | N/A    |       |     | % Ct. Error |
| 95000015 | AX-102  | 8 DUP       | S95T000208 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000015 | AX-102  | 8 DUP       | S95T000208 | 0 F @ALPHA01 ALPHA01E | SOLID  |        |       | N/A | % Ct. Error |
| 95000015 | AX-102  | 9 SPK       | S95T000208 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |

Final page for worklist # 672

A. Lewis 3-8-95MT Brown 3-9-95

## Data Entry Comments:

SPK recoveries are out of control/ limit - Batch will be rerun.

MT Brown 3-9-95

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## LABCORE Data Entry Template for Worklist# 672

| GROUP             | PROJECT | S | TYPE | SAMPLE# | R | A | TEST | MATRIX            | ACTUAL | FOUND | DL   | UNIT |
|-------------------|---------|---|------|---------|---|---|------|-------------------|--------|-------|------|------|
| Analyst Signature |         |   | Date |         |   |   |      | Analyst Signature |        |       | Date |      |

1783-101-001

3-9-95

*Data Entry Comments:*

---

---

---

*Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.*

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

## LA-548-101 (A-3) LIQUIDS

| Type            | DETECTOR NUMBER  | STANDARD   | REPLICATE |
|-----------------|--|------------|-----------|
| STANDARD        | DISH SIZE 1, 2, or 5 (MS)  | 15<br>2    | 15<br>2   |
| WORK LIST       | TOTAL COUNTS (TC)  | 3532       | 4294      |
| 672             | COUNT TIME in MINUTES (CT)   | 30         | 30        |
| AT 301 137      | BACKGROUND in cpm (BKG)  | 0.7        | 0.7       |
| AT              | SAMPLE SIZE in mL (SS)   | 10.000     | 10.000    |
| Test Code       | DILUTION FACTOR (DF)   | 1          | 1         |
| @ALPHA-01       | DIGEST DILUTION FACTOR (DDF)   | 1          | 1         |
| Matrix          | EFFICIENCY FACTOR (EFF)  | 0.2380     | 0.2380    |
| LIQUID          | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE   | 117.033    | 142.433   |
| Sample #        | Sample Concentration in $\mu\text{Ci}/\text{L}$  | 2.22E-02   | BOOK#     |
| WORKLIST#672    | Replicate Concentration in $\mu\text{Ci}/\text{L}$   | 2.70E-02   | 91B52     |
| Instrument Code | Average Concentration in $\mu\text{Ci}/\text{L}$   | 2.4554E-02 |           |
| WB26872         |  |            |           |
| Analyte         |  |            |           |
| AKL             | Rs (Sample Count Rate) = $(\text{TC} / \text{CT}) - \text{BKG}$  |            |           |
| Date            | ALPHA TOTAL $\mu\text{Ci}/\text{L}$ = $\text{Rs} * 1000\text{mL/L} * \text{DF} * \text{DDF} / (\text{EFF} * \text{SS} * 2220000\text{dpm}/\mu\text{Ci})$ |            |           |
| 03/08/95        | ALPHA TOTAL $\mu\text{Ci}/\text{mL}$ = ALPHA TOTAL $\mu\text{Ci}/\text{L} / 1000\text{mL/L}$   |            |           |
| Time            | Relative Counting Error = $[(\text{The Square Root of TC + BKG} * \text{CT}) / (\text{TC} - \text{BKG} * \text{CT})] * 1.96 * 100$                       |            |           |
| 01:00 PM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.  |            |           |

## v RESULTS v

|   |          |                                   |
|---|----------|-----------------------------------|
| ALPHA TOTAL in $\mu\text{Ci}/\text{mL}$ (Average) = | 2.46E-05 | DETECTION LEVEL                   |
|   |          |                                   |
| RELATIVE COUNTING ERROR =                           | 3.3%     | 1.52E-07 $\mu\text{Ci}/\text{mL}$ |

|                |                      |       |          |
|----------------|----------------------|-------|----------|
| Data Entry by: | <i>M. J. S.</i>      | Date: | 03/09/95 |
| Approved by:   | <i>J. V. - J. T.</i> | Date: | 3/9/95   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |  |
|--|--|
|  |  |
|--|--|

**AT : LA-508-101 (D-2)****LA-548-101 (A-3)****SOLIDS**

| TYPE            | DETECTOR NUMBER   | BLANK        | REPLICATE     |
|-----------------|---|--------------|---------------|
| BLANK           | DISH SIZE 1, 2 , or 5   | (MS)         | 15 2          |
| WORK UNIT       | TOTAL COUNTS  | (TC)         | 13 15         |
| 672             | COUNT TIME in MINUTES   | (CT)         | 30 30         |
| AT              | BACKGROUND in cpm   | (BKG)        | 0.7 0.7       |
| AT              | SAMPLE SIZE in mL   | (SS)         | 0.050 0.050   |
| Test Code       | DILUTION FACTOR   | (DF)         | 1 1           |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L  | (Dg/L)       | 0.428 0.428   |
| Matrix          | EFFICIENCY FACTOR   | (EFF)        | 0.2380 0.2380 |
| SOLID           | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE  |              | 0.356 0.356   |
| Sample #        | Sample Concentration in $\mu\text{Ci/g}$  | < 3.15E-02   | BOOK#         |
| S95T204         | Replicate Concentration in $\mu\text{Ci/g}$   | < 3.15E-02   |               |
| Instrument Code |   |              |               |
| WB26872         | Maximum Concentration in $\mu\text{Ci/g}$   | < 3.1524E-02 |               |
| Analyt:         |   |              |               |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG  |              |               |
| Date            | ALPHA TOTAL $\mu\text{Ci/g}$ = $Rs * 1000\text{mL/L} * DF / (EFF * SS * Dg/L * 2220000\text{dpm}/\mu\text{Ci})$ |              |               |
| 03/08/95        |   |              |               |
| Time            | Relative Counting Error = $[( (\text{The Square Root of TC + BKG * CT}) / (TC - BKG * CT) )] * 1.96 * 100$      |              |               |
| 01:00 PM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                                 |              |               |

**v RESULTS v**

|                         |                     |   |            |                  |
|-------------------------|---------------------|---|------------|------------------|
| ALPHA TOTAL             | in $\mu\text{Ci/g}$ | (Maximum) =                             | < 3.15E-02 | DETECTION LEVEL  |
|                         |                     | LESS Than Value was Determined from Lc. |            |                  |
| RELATIVE COUNTING ERROR | =                   | 196.0%                                  | 7.11E-02   | $\mu\text{Ci/g}$ |

|                |                    |       |          |
|----------------|--------------------|-------|----------|
| Data Entry by: | <i>[Signature]</i> | Date: | 03/09/95 |
| Approved by:   | <i>[Signature]</i> | Date: | 3/9/95   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

LA-548-101 (A-3)

SOLIDS

| Type            | DETECTOR NUMBER   | SAMPLE     | REPLICATE |
|-----------------|---|------------|-----------|
| SAMPLE          | DISH SIZE 1, 2, or 5  | (MS)       | 15        |
| WORK LIST       | TOTAL COUNTS  | (TC)       | 480       |
| 672             | COUNT TIME in MINUTES   | (CT)       | 30        |
| AT              | BACKGROUND in cpm   | (BKG)      | 0.7       |
| Test Code       | SAMPLE SIZE in mL   | (SS)       | 0.050     |
| @ALPHA-01       | DILUTION FACTOR   | (DF)       | 1         |
| Matrix          | DIGEST GRAMS of SOLIDS/L  | (Dg/L)     | 0.428     |
| SOLID           | EFFICIENCY FACTOR   | (EFF)      | 0.2380    |
| Sample #        | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE  |            | 15.300    |
| S95T204         | Sample Concentration in $\mu\text{Ci/g}$  | 1.35E+00   | BOOK#     |
|                 | Replicate Concentration in $\mu\text{Ci/g}$   | 1.04E+00   |           |
| Instrument Code | Average Concentration in $\mu\text{Ci/g}$   | 1.1984E+00 |           |
| Analyst         | RS (Sample Count Rate) = (TC / CT) - BKG  |            |           |
| AKL             | ALPHA TOTAL $\mu\text{Ci/g}$ = $Rs * 1000\text{mL/L} * DF / (EFF * SS * Dg/L * 2220000\text{dpm}/\mu\text{Ci})$ |            |           |
| Date            |   |            |           |
| 03/08/95        |   |            |           |
| Time            | Relative Counting Error = $[(The\ Square\ Root\ of\ TC + BKG * CT) / (TC - BKG * CT)] * 1.96 * 100$             |            |           |
| 01:00 PM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                                 |            |           |

## v RESULTS v

|                         |                     |             |          |                              |
|-------------------------|---------------------|-------------|----------|------------------------------|
| ALPHA TOTAL             | in $\mu\text{Ci/g}$ | (Average) = | 1.20E+00 | DETECTION LEVEL              |
| RELATIVE COUNTING ERROR | =                   | 11.0%       |          | 7.11E-02<br>$\mu\text{Ci/g}$ |

|                |  |       |          |
|----------------|--|-------|----------|
| Data Entry by: |  | Date: | 03/09/95 |
| Approved by:   |  | Date: | 3/9/95   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

## LA-548-101 (A-3) SOLIDS

| Type             | Detector Number   | Sample     | Replicate |
|------------------|---|------------|-----------|
| DUPLICATE        | DISH SIZE 1, 2, or 5 (MS)   | 15<br>2    | 15<br>2   |
| WORK LIST        | TOTAL COUNTS (TC)   | 554        | 464       |
| 872              | COUNT TIME in MINUTES (CT)  | 30         | 30        |
| AT GATE          | BACKGROUND in cpm (BKG)   | 0.7        | 0.7       |
| AT               | SAMPLE SIZE in mL (SS)  | 0.050      | 0.050     |
| Test Code        | DILUTION FACTOR (DF)  | 1          | 1         |
| @ALPHA-01        | DIGEST GRAMS of SOLIDS/L (Dg/L)   | 0.456      | 0.456     |
| Matrix           | EFFICIENCY FACTOR (EFF)   | 0.2380     | 0.2380    |
| SOLID            | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE  | 17.767     | 14.767    |
| Sample #         | Sample Concentration in $\mu\text{Ci/g}$  | 1.47E+00   | BOOK#     |
| S95T204          | Replicate Concentration in $\mu\text{Ci/g}$   | 1.23E+00   |           |
| Instrument C-100 |   |            |           |
| WB26872          | Average Concentration in $\mu\text{Ci/g}$   | 1.3503E+00 |           |
| Alpha            |   |            |           |
| AKL              | Rs (Sample Count Rate) = (TC / CT) - BKG  |            |           |
| Date             | ALPHA TOTAL $\mu\text{Ci/g}$ = $Rs * 1000\text{mL/L} * DF / (EFF * SS * Dg/L * 2220000\text{dpm}/\mu\text{Ci})$ |            |           |
| 03/08/95         |   |            |           |
| Time             | Relative Counting Error = $[(\text{The Square Root of TC + BKG * CT}) / (\text{TC - BKG * CT})] * 1.96 * 100$   |            |           |
| 01:00 PM         | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                                 |            |           |

## v RESULTS v

|   |          |                  |
|---|----------|------------------|
| ALPHA TOTAL in $\mu\text{Ci/g}$ (Average) = | 1.35E+00 | DETECTION LEVEL  |
|   |          | 6.67E-02         |
| RELATIVE COUNTING ERROR =                   | 9.7%     | $\mu\text{Ci/g}$ |

|                        |                    |       |          |
|------------------------|--------------------|-------|----------|
| Data Entry by:         | <i>[Signature]</i> | Date: | 03/09/95 |
| Approved by:           | <i>[Signature]</i> | Date: | 3/9/95   |
| Form 508101_C Rev. 1.3 |                    | Page  | 1 of 1   |

## WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |  |
|--|--|
|  |  |
|--|--|

**AT : LA-508-101 (D-2)****LA-548-101 (A-3)****SOLIDS**

| Type            | DETECTOR NUMBER   | SPIKE      | REPLICATE |
|-----------------|---|------------|-----------|
| SPIKE           | DISH SIZE 1, 2 , or 5 (MS)  | 15         | 15        |
| Work List       | TOTAL COUNTS (TC)   | 2          | 2         |
| 672             | COUNT TIME in MINUTES (CT)  | 46157      | 37934     |
| AT or TB Y      | BACKGROUND in cpm (BKG)   | 30         | 30        |
| AT              | SAMPLE VOLUME in mL (Spiked Vial) (SS)  | 0.7        | 0.7       |
| Test Code       | SAMPLE DILUTION FACTOR (Spiked Vial) (DF)   | 0.050      | 0.050     |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)   | 1          | 1         |
| Matrix          | SPIKE VOLUME in mL (SVol)   | 0.428      | 0.428     |
| SOLID           | SPIKE DILUTION FACTOR (SDF)   | 0.100      | 0.100     |
| Sample #        | SPIKE VALUE in $\mu\text{Ci}/\text{L}$ (SVal)   | 1          | 1         |
| S95T204         | INSTRUMENT EFFICIENCY FACTOR (EFF)  | 36.378     | 36.378    |
| Instrument Code | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ (S+S)  | 0.238      | 0.238     |
| WB26872         | AVERAGE or MAXIMUM $\mu\text{Ci}/\text{g}$ from FORM C  | 1.36E+02   | 1.12E+02  |
| Analyst         | BOOK#   | 1.1984E+00 | 94B43     |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG  |            |           |
| Date            | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ = Rs * 1000mL/L * DF / (EFF * SS * Dg/L * 2220000dpm/ $\mu\text{Ci}$ )                   |            |           |
| 03/08/95        | PERCENT SPIKE RECOVERY = (((S+S $\mu\text{Ci}/\text{g}$ - SAMPLE $\mu\text{Ci}/\text{g}$ ) * (SDF/SVol)/(DF/SS/Dg/L))/SVal)*100 |            |           |
| Time            |   |            |           |
| 01:00 PM        |   |            |           |

RESULT      AVG. PERCENT SPIKE RECOVERY      =      72.2%

Data Entry by: *[Signature]*  
 Approved by: *[Signature]*  
 Form 508101\_X Rev. 1.3

Date: 09-Mar-95  
 Date: 3/9/95  
 Page 1 of 1

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

AT : LA-508-101 (D-2)

## LA-548-101 (A-3) SOLIDS

| Type            | Detector Number  | Sample     | Replicate |
|-----------------|--|------------|-----------|
| SAMPLE          | DISH SIZE 1, 2, or 5 (MS)  | 15         | 15        |
| NOT LIST        | TOTAL COUNTS (TC)  | 2          | 2         |
| 672             | COUNT TIME in MINUTES (CT)   | 508        | 485       |
| AT 0.013%       | BACKGROUND in cpm (BKG)  | 30         | 30        |
| AT              | SAMPLE SIZE in mL (SS)   | 0.7        | 0.7       |
| Test Code       | DILUTION FACTOR (DF)   | 0.050      | 0.050     |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)  | 1          | 1         |
| Matrix          | EFFICIENCY FACTOR (EFF)  | 0.472      | 0.472     |
| SOLID           | Lc, Rmax, or Rs (SAMPLE RATE) as APPROPRIATE   | 0.2380     | 0.2380    |
| Sample #        | Sample Concentration in $\mu\text{Ci/g}$   | 16.233     | 15.467    |
| S95T208         | Replicate Concentration in $\mu\text{Ci/g}$  | 1.30E+00   | BOOK#     |
| Instrument Code | Average Concentration in $\mu\text{Ci/g}$  | 1.24E+00   |           |
| WB26872         |  | 1.2711E+00 |           |
| Anlyst:         |  |            |           |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG   |            |           |
| Date            | ALPHA TOTAL $\mu\text{Ci/g}$ = Rs * 1000mL/L * DF / ( EFF * SS * Dg/L * 2220000dpm/ $\mu\text{Ci}$ ) |            |           |
| 03/08/95        |  |            |           |
| Time            | Relative Counting Error = [  (The Square Root of TC + BKG * CT) / (TC - BKG * CT)  ] * 1.96 * 100    |            |           |
| 01:00 PM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                      |            |           |

## v RESULTS v

|                         |                     |             |          |                           |
|-------------------------|---------------------|-------------|----------|---------------------------|
| ALPHA TOTAL             | in $\mu\text{Ci/g}$ | (Average) = | 1.27E+00 | DETECTION LEVEL           |
| RELATIVE COUNTING ERROR |                     | =           | 9.5%     | 6.44E-02 $\mu\text{Ci/g}$ |

|                |                 |       |          |
|----------------|-----------------|-------|----------|
| Data Entry by: | <i>M. S. S.</i> | Date: | 03/09/95 |
| Approved by:   | <i>N. R. J.</i> | Date: | 3/9/95   |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |  |
|--|--|
|  |  |
|--|--|

**AT : LA-508-101 (D-2)****LA-548-101 (A-3)****SOLIDS**

| TYPE            | DETECTOR NUMBER   | SAMPLE     | REPLICATE |
|-----------------|---|------------|-----------|
| DUPLICATE       | DISH SIZE 1, 2, or 5 (MS)   | 15         | 15        |
| Work List       | TOTAL COUNTS (TC)   | 2          | 2         |
| 672             | COUNT TIME in MINUTES (CT)  | 451        | 479       |
| AT CODE         | BACKGROUND in cpm (BKG)   | 0.7        | 0.7       |
| AT              | SAMPLE SIZE in mL (SS)  | 0.050      | 0.050     |
| Test Code       | DILUTION FACTOR (DF)  | 1          | 1         |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)   | 0.488      | 0.488     |
| Matrix          | EFFICIENCY FACTOR (EFF)   | 0.2380     | 0.2380    |
| SOLID           | Lc, Rmax, or Rs, (SAMPLE RATE) as APPROPRIATE   | 14.333     | 15.267    |
| Sample #        | Sample Concentration in $\mu\text{Ci/g}$  | 1.11E+00   | BOOK#     |
| S95T208         | Replicate Concentration in $\mu\text{Ci/g}$   | 1.18E+00   |           |
| Instrument Code |   |            |           |
| WB26872         | Average Concentration in $\mu\text{Ci/g}$   | 1.1480E+00 |           |
| Analyist        |   |            |           |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG  |            |           |
| Date            | ALPHA TOTAL $\mu\text{Ci/g}$ = Rs * 1000mL/L * DF / (EFF * SS * Dg/L * 2220000dpm/ $\mu\text{Ci}$ ) |            |           |
| 03/08/95        |   |            |           |
| Time            | Relative Counting Error = [  (The Square Root of TC + BKG * CT) / (TC - BKG * CT)  ] * 1.96 * 100   |            |           |
| 01:00 PM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                     |            |           |

**v RESULTS v**

|                         |                     |             |                           |                 |
|-------------------------|---------------------|-------------|---------------------------|-----------------|
| ALPHA TOTAL             | In $\mu\text{Ci/g}$ | (Average) = | 1.15E+00                  | DETECTION LEVEL |
|                         |                     |             |                           |                 |
| RELATIVE COUNTING ERROR | =                   | 9.9%        | 6.23E-02 $\mu\text{Ci/g}$ |                 |

|                        |            |             |          |
|------------------------|------------|-------------|----------|
| Data Entry by:         | <i>MJS</i> | Date:       | 03/09/95 |
| Approved by:           | <i>JL</i>  | Date:       | 3/9/95   |
| Form 508101_C Rev. 1.3 |            | Page 1 of 1 |          |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

LA-548-101 (A-3)

**SOLIDS**

| Type            | DETECTOR NUMBER  | SPIKE      | REPLICATE |
|-----------------|--|------------|-----------|
| SPIKE           | DISH SIZE 1, 2 , or 5 (MS)   | 15<br>2    | 15<br>2   |
| Work List       | TOTAL COUNTS (TC)  | 40463      | 37761     |
| 672             | COUNT TIME in MINUTES (CT)   | 30         | 30        |
| AT or TB ?      | BACKGROUND in cpm (BKG)  | 0.7        | 0.7       |
| AT              | SAMPLE VOLUME in mL (Spiked Vial) (SS)   | 0.050      | 0.050     |
| Test Code       | SAMPLE DILUTION FACTOR (Spiked Vial) (DF)  | 1          | 1         |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)  | 0.472      | 0.472     |
| Matrix          | SPIKE VOLUME in mL (SVol)  | 0.100      | 0.100     |
| SOLID           | SPIKE DILUTION FACTOR (SDF)  | 1          | 1         |
| Sample #        | SPIKE VALUE in $\mu\text{Ci}/\text{L}$ (SVal)  | 36.378     | 36.378    |
| S95T208         | INSTRUMENT EFFICIENCY FACTOR (EFF)   | 0.238      | 0.238     |
| Instrument Code | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ (S+S)   | 1.08E+02   | 1.01E+02  |
| WB26872         | AVERAGE or MAXIMUM $\mu\text{Ci}/\text{g}$ from FORM C   | 1.2711E+00 |           |
| Analyst         | BOOK#  | 94B43      |           |
| AKL             | Rs (Sample Count Rate) = $(\text{TC} / \text{CT}) - \text{BKG}$  |            |           |
| Date            | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ = $Rs * 1000\text{mL/L} * DF / (\text{EFF} * SS * Dg/L * 2220000\text{dpm}/\mu\text{Ci})$         |            |           |
| 03/08/95        | PERCENT SPIKE RECOVERY = $((S+S \mu\text{Ci}/\text{g} - \text{SAMPLE } \mu\text{Ci}/\text{g}) * ((SDF/SVol)/(DF/SS/Dg/L))) / SVal * 100$ |            |           |
| Time            |  |            |           |
| 01:00 PM        |  |            |           |

RESULT AVG. PERCENT SPIKE RECOVERY = 67.0%

Data Entry by: *M. B. S.*  
 Approved by: *M. B. S.*  
 Form 508101\_X Rev. 1.3

Date: 09-Mar-95

Date: 3/9/95

Page 1 of 1

## LABCORE Data Entry Template for Worklist# 693

Analyst: AKL Instrument: AB00 15 Book # 94B52Method: LA-508-101 Rev/Mod D-2Worklist Comment: AT-Mount .100-10-<sup>100 mL</sup><sub>1 mL</sub>. Use .100 mL A-SPK. Rerun 1. SLF

| GROUP    | PROJECT | S TYPE      | SAMPLE#    | R A -----TEST-----    | MATRIX | ACTUAL | FOUND | DL  | UNIT        |
|----------|---------|-------------|------------|-----------------------|--------|--------|-------|-----|-------------|
|          |         | 1 STD       |            | 2ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
|          |         | 1 STD       |            | 2ALPHA01 ALPHA01E     | SOLID  |        |       | N/A | % Ct. Error |
|          |         | 2 BLNK-PREP |            | 2ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
|          |         | 2 BLNK-PREP |            | 2ALPHA01 ALPHA01E     | SOLID  |        |       | N/A | % Ct. Error |
|          |         | 3 BLNK/BKG  |            | 2ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
| 95000014 | AX-102  | 4 SAMPLE    | S95T000204 | 0 F 2ALPHA01 ALPHA01  | SOLID  | N/A    |       |     | uCi/g       |
| 95000014 | AX-102  | 4 SAMPLE    | S95T000204 | 0 F 2ALPHA01 ALPHA01E | SOLID  | N/A    |       |     | % Ct. Error |
| 95000014 | AX-102  | 5 DUP       | S95T000204 | 0 F 2ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000014 | AX-102  | 5 DUP       | S95T000204 | 0 F 2ALPHA01 ALPHA01E | SOLID  |        |       | N/A | % Ct. Error |
| 95000014 | AX-102  | 6 SPK       | S95T000204 | 0 F 2ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000015 | AX-102  | 7 SAMPLE    | S95T000208 | 0 F 2ALPHA01 ALPHA01  | SOLID  | N/A    |       |     | uCi/g       |
| 95000015 | AX-102  | 7 SAMPLE    | S95T000208 | 0 F 2ALPHA01 ALPHA01E | SOLID  | N/A    |       |     | % Ct. Error |
| 95000015 | AX-102  | 8 DUP       | S95T000208 | 0 F 2ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000015 | AX-102  | 8 DUP       | S95T000208 | 0 F 2ALPHA01 ALPHA01E | SOLID  |        |       | N/A | % Ct. Error |
| 95000015 | AX-102  | 9 SPK       | S95T000208 | 0 F 2ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |

Final page for worklist # 693

Alita LewisMGB - 3-13-95

## Data Entry Comments:

The high sample RPD values are due to the low alpha activity on the mount. The low SPK recoveries are due to dissolved salts on dish. Due to its having a higher count rate (a result of sample size) the original worklist (# 672) data will be reported.

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

## LABCORE Data Entry Template for Worklist# 693

| GROUP             | PROJECT | S    | TYPE | SAMPLE# | R | A | TEST | MATRIX            | ACTUAL | FOUND | DL | UNIT |
|-------------------|---------|------|------|---------|---|---|------|-------------------|--------|-------|----|------|
| Analyst Signature |         | Date |      |         |   |   |      | Analyst Signature |        | Date  |    |      |

M 83,21~~~ 3/13/95

*Data Entry Comments:*

---

---

---

*Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.*

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

LA-548-101 (A-3)

**LIQUIDS**

| Type            | DETECTOR NUMBER  | STANDARD   | REPLICATE |
|-----------------|--|------------|-----------|
| STANDARD        | DISH SIZE 1, 2, or 5 (MS)  | 15         | 15        |
| WORKLIST        | TOTAL COUNTS (TC)  | 2          | 2         |
| 693             | COUNT TIME in MINUTES (CT)   | 3836       | 3576      |
| A1 or 15.7      | BACKGROUND in cpm (BKG)  | 30         | 30        |
| AT              | SAMPLE SIZE in mL (SS)   | 0.4        | 0.4       |
| TEST CODE       | DILUTION FACTOR (DF)   | 10,000     | 10,000    |
| @ALPHA-01       | DIGEST DILUTION FACTOR (DDF)   | 1          | 1         |
| INSTRUMENT      | EFFICIENCY FACTOR (EFF)  | 0.2380     | 0.2380    |
| LIQUID          | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE   | 127.467    | 118.800   |
| Sample          | Sample Concentration in $\mu\text{Ci}/\text{L}$  | 2.41E-02   | BOOK#     |
| WORKLIST#693    | Replicate Concentration in $\mu\text{Ci}/\text{L}$   | 2.25E-02   | 98B52     |
| Instrument Code |  |            |           |
| WB26872         | Average Concentration in $\mu\text{Ci}/\text{L}$   | 2.3305E-02 |           |
| Analyst         |  |            |           |
| AKL             | Rs (Sample Count Rate) = $(\text{TC} / \text{CT}) - \text{BKG}$  |            |           |
| Date            | ALPHA TOTAL $\mu\text{Ci}/\text{L}$ = $\text{Rs} * 1000\text{mL/L} * \text{DF} * \text{DDF} / (\text{EFF} * \text{SS} * 2220000\text{dpm}/\mu\text{Ci})$ |            |           |
| 03/10/95        | ALPHA TOTAL $\mu\text{Ci}/\text{mL}$ = ALPHA TOTAL $\mu\text{Ci}/\text{L} / 1000\text{mL/L}$   |            |           |
| Time            | Relative Counting Error = $[(\text{The Square Root of TC + BKG} * \text{CT}) / (\text{TC} - \text{BKG} * \text{CT})] * 1.96 * 100$                       |            |           |
| 10:00 AM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.  |            |           |

**v RESULTS v**

|   |             |          |                                      |
|---|-------------|----------|--------------------------------------|
| ALPHA TOTAL in $\mu\text{Ci}/\text{mL}$ | (Average) = | 2.33E-05 | DETECTION LEVEL                      |
| RELATIVE COUNTING ERROR                 | =           | 3.3%     | 1.19E-07<br>$\mu\text{Ci}/\text{mL}$ |

Data Entry by: *M.C.B.* -  
 Approved by: *J.S.*

Date: 03/13/95  
 Date: 3/13/95

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

LA-548-101 (A-3)

**SOLIDS**

|                 |   | BLANK  | REPLICATE  |
|-----------------|---|--------|------------|
| TYPE            | DETECTOR NUMBER   | 15     | 15         |
| BLANK           | DISH SIZE 1, 2, or 5  | (MS)   | 2          |
| NOTE #          | TOTAL COUNTS  | (TC)   | 19         |
| 693             | COUNT TIME in MINUTES   | (CT)   | 30         |
| A1081B2         | BACKGROUND in cpm   | (BKG)  | 0.4        |
| AT              | SAMPLE SIZE in mL   | (SS)   | 1.000      |
| Test Card       | DILUTION FACTOR   | (DF)   | 101        |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L  | (Dg/L) | 0.428      |
| MEASURE         | EFFICIENCY FACTOR   | (EFF)  | 0.2380     |
| SOLID           | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE  |        | 0.540      |
| S95T204         | Sample Concentration in $\mu\text{Ci/g}$  | <      | 2.41E-01   |
| S95T204         | Replicate Concentration in $\mu\text{Ci/g}$   | <      | 1.20E-01   |
| Instrument Code |   |        | BOOK#      |
| WB26872         | Maximum Concentration in $\mu\text{Ci/g}$   | <      | 2.4098E-01 |
| Analyist        |   |        |            |
| AKL             | Rs (Sample Count Rate) = $(TC / CT) - BKG$  |        |            |
| Date            | ALPHA TOTAL $\mu\text{Ci/g}$ = $Rs * 1000\text{mL/L} * DF / (EFF * SS * Dg/L * 2220000\text{dpm}/\mu\text{Ci})$ |        |            |
| 03/10/95        |   |        |            |
| Time            | Relative Counting Error = $[(The\ Square\ Root\ of\ TC + BKG * CT) / (TC - BKG * CT)] * 1.96 * 100$             |        |            |
| 10:00 AM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                                 |        |            |

**v RESULTS v**

|   |                        |   |
|---|------------------------|---|
| ALPHA TOTAL in $\mu\text{Ci/g}$           | (Maximum) = < 2.41E-01 | DETECTION LEVEL<br><br>2.81E-01<br>$\mu\text{Ci/g}$ |
| LESS THAN Value was Determined from Rmax. |                        |   |
| RELATIVE COUNTING ERROR = 155.9%          |                        |   |

Data Entry by: *MJS*  
 Approved by: *JL*

Form 508101\_C Rev. 1.3

Date: 03/13/95  
 Date: 3/13/95

Page 1 of 1

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |  |
|--|--|
|  |  |
|--|--|

AT : LA-508-101 (D-2)

**LA-548-101 (A-3) SOLIDS**

| Type            | DETECTOR NUMBER   | SAMPLE     | REPLICATE |
|-----------------|---|------------|-----------|
| <b>SAMPLE</b>   | DISH SIZE 1, 2, or 5 (MS)   | 15         | 15        |
| 693             | TOTAL COUNTS (TC)   | 2          | 2         |
| AT              | COUNT TIME in MINUTES (CT)  | 105        | 114       |
|                 | BACKGROUND in cpm (BKG)   | 30         | 30        |
| AT              | SAMPLE SIZE in mL (SS)  | 0.4        | 0.4       |
|                 | DILUTION FACTOR (DF)  | 1.000      | 1.000     |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)   | 101        | 101       |
|                 | EFFICIENCY FACTOR (EFF)   | 0.428      | 0.428     |
| SOLID           | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE  | 0.2380     | 0.2380    |
| Sample #        | Sample Concentration in $\mu\text{Ci/g}$  | 3.100      | 3.400     |
| S95T204         | Replicate Concentration in $\mu\text{Ci/g}$   | 1.38E+00   | BOOK#     |
| Instrument Code | Average Concentration in $\mu\text{Ci/g}$   | 1.52E+00   |           |
| WB26872         |   | 1.4515E+00 |           |
| Analytical      |   |            |           |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG  |            |           |
| Date            | ALPHA TOTAL $\mu\text{Ci/g}$ = Rs * 1000mL/L * DF / (EFF * SS * Dg/L * 2220000dpm/ $\mu\text{Ci}$ ) |            |           |
| 03/10/95        |   |            |           |
| Time            | Relative Counting Error = [  (The Square Root of TC + BKG * CT) / (TC - BKG * CT)  ] * 1.96 * 100   |            |           |
| 10:00 AM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                     |            |           |

## v RESULTS v

|                           |                     |             |          |                           |
|---------------------------|---------------------|-------------|----------|---------------------------|
| ALPHA TOTAL               | in $\mu\text{Ci/g}$ | (Average) = | 1.45E+00 | DETECTION LEVEL           |
|                           |                     |             |          |                           |
| RELATIVE COUNTING ERROR = |                     | 22.8%       |          | 2.81E-01 $\mu\text{Ci/g}$ |

|                |                      |       |          |
|----------------|----------------------|-------|----------|
| Data Entry by: | <i>M. S. Breyfus</i> | Date: | 03/13/95 |
| Approved by:   | <i>[Signature]</i>   | Date: | 3/13/95  |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |  |
|--|--|
|  |  |
|--|--|

## AT : LA-508-101 (D-2)

## LA-548-101 (A-3) SOLIDS

| ITEM            | DETECTOR NUMBER  | SAMPLE     | REPLICATE |
|-----------------|--|------------|-----------|
| DUPLICATE       | DISH SIZE 1, 2, or 5 (MS)  | 15         | 15        |
| WORK ID#        | TOTAL COUNTS (TC)  | 2          | 2         |
| 693             | COUNT TIME in MINUTES (CT)   | 133        | 139       |
|                 | BACKGROUND in cpm (BKG)  | 30         | 30        |
| AT              | SAMPLE SIZE in mL (SS)   | 0.4        | 0.4       |
|                 | DILUTION FACTOR (DF)   | 1.000      | 1.000     |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)  | 101        | 101       |
| MATRIX          | EFFICIENCY FACTOR (EFF)  | 0.456      | 0.456     |
| SOLID           | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE   | 0.2380     | 0.2380    |
| Sample #        | Sample Concentration in $\mu\text{Ci/g}$   | 4.033      | 4.233     |
| S95T204         | Replicate Concentration in $\mu\text{Ci/g}$  | 1.69E+00   | BOOK#     |
| Instrument Code | Average Concentration in $\mu\text{Ci/g}$  | 1.77E+00   |           |
| WB26872         |  | 1.7327E+00 |           |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG   |            |           |
| 03/10/95        | ALPHA TOTAL $\mu\text{Ci/g}$ = $\text{Rs} * 1000\text{mL/L} * \text{DF} / (\text{EFF} * \text{SS} * \text{Dg/L} * 2220000\text{dpm}/\mu\text{Ci})$ |            |           |
| 10:00 AM        | Relative Counting Error = $[(\text{The Square Root of TC + BKG * CT}) / (\text{TC - BKG * CT})] * 1.96 * 100$                                      |            |           |
|                 | Detection Levels and Less Than Values are determined from Procedure LA-508-002.  |            |           |

## v RESULTS v

|   |          |                  |
|---|----------|------------------|
| ALPHA TOTAL in $\mu\text{Ci/g}$ (Average) = | 1.73E+00 | DETECTION LEVEL  |
|   |          | 2.64E-01         |
| RELATIVE COUNTING ERROR =                   | 19.5%    | $\mu\text{Ci/g}$ |

|                |            |       |          |
|----------------|------------|-------|----------|
| Data Entry by: | <i>MTB</i> | Date: | 03/13/95 |
| Approved by:   | <i>JW</i>  | Date: | 3/13/95  |

## WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

|  |  |
|--|--|
|  |  |
|--|--|

AT : LA-508-101 (D-2)

LA-548-101 (A-3) SOLIDS

| TYPE            | DETECTOR NUMBER   | SPIKE      | REPLICATE |
|-----------------|---|------------|-----------|
| SPIKE           | DISH SIZE 1, 2, or 5 (MS)   | 15         | 15        |
| Work List       | TOTAL COUNTS (TC)   | 2          | 2         |
| 693             | COUNT TIME in MINUTES (CT)  | 56273      | 41599     |
| AT C:TB 7       | BACKGROUND in cpm (BKG)   | 30         | 30        |
| AT              | SAMPLE VOLUME in mL (Spiked Vial) (SS)  | 0.4        | 0.4       |
| Sample Code     | SAMPLE DILUTION FACTOR (Spiked Vial) (DF)   | 1.000      | 1.000     |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)   | 101        | 101       |
| MATRIX          | SPIKE VOLUME in mL (SVol)   | 0.428      | 0.428     |
| SOLID           | SPIKE DILUTION FACTOR (SDF)   | 0.100      | 0.100     |
| Sample #        | SPIKE VALUE in $\mu\text{Ci}/\text{L}$ (SVal)   | 1          | 1         |
| S95T204         | INSTRUMENT EFFICIENCY FACTOR (EFF)  | 36.378     | 36.378    |
| Instrument Code | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ (S+S)  | 0.238      | 0.238     |
| WB26872         | AVERAGE or MAXIMUM $\mu\text{Ci}/\text{g}$ from FORM C  | 8.38E+02   | 6.19E+02  |
| Analyst         | BOOK#   | 1.4515E+00 | 94B43     |
| AKL             | Rs (Sample Count Rate) = $(\text{TC} / \text{CT}) - \text{BKG}$   |            |           |
| Date            | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ = $\text{Rs} * 1000\text{mL/L} * \text{DF} / (\text{EFF} * \text{SS} * \text{Dg/L} * 2220000\text{dpm}/\mu\text{Ci})$                                    |            |           |
| 03/10/95        | PERCENT SPIKE RECOVERY = $((\text{S}+\text{S} \mu\text{Ci}/\text{g} - \text{SAMPLE} \mu\text{Ci}/\text{g}) * ((\text{SDF}/\text{SVol})/(\text{DF}/\text{SS}/\text{Dg/L}))) / \text{SVal} * 100$ |            |           |
| Time            |   |            |           |
| 10:00 AM        |   |            |           |

RESULT AVG. PERCENT SPIKE RECOVERY = 84.7%

|                        |                     |                 |
|------------------------|---------------------|-----------------|
| Data Entry by:         | <i>M. S. Wright</i> | Date: 13-Mar-95 |
| Approved by:           | <i>J. H. Wright</i> | Date: 13-Mar-95 |
| Form 508101_X Rev. 1.3 |                     |                 |

Page 1 of 1

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

## LA-548-101 (A-3) SOLIDS

| Type            | DETECTOR NUMBER  | SAMPLE     | REPLICATE |
|-----------------|--|------------|-----------|
| SAMPLE          | DISH SIZE 1, 2, or 5 (MS)  | 15         | 15        |
| Work List       | TOTAL COUNTS (TC)  | 2          | 2         |
| 693             | COUNT TIME in MINUTES (CT)   | 114        | 116       |
| A or B?         | BACKGROUND in cpm (BKG)  | 30         | 30        |
| AT              | SAMPLE SIZE in mL (SS)   | 0.4        | 0.4       |
| Test Code       | DILUTION FACTOR (DF)   | 1.000      | 1.000     |
| @ALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)  | 101        | 101       |
| Matrix          | EFFICIENCY FACTOR (EFF)  | 0.472      | 0.472     |
| SOLID           | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE   | 0.2380     | 0.2380    |
| Sample          | Sample Concentration in $\mu\text{Ci/g}$   | 3.400      | 3.467     |
| S95T208         | Replicate Concentration in $\mu\text{Ci/g}$  | 1.38E+00   | BOOK#     |
| Instrument Code | Average Concentration in $\mu\text{Ci/g}$  | 1.40E+00   |           |
| WB26872         |  | 1.3905E+00 |           |
| Analyst         | Rs (Sample Count Rate) = (TC / CT) - BKG   |            |           |
| AKL             | ALPHA TOTAL $\mu\text{Ci/g}$ = Rs * 1000mL/L * DF / ( EFF * SS * Dg/L * 2220000dpm/ $\mu\text{Ci}$ ) |            |           |
| Date            |  |            |           |
| 03/10/95        |  |            |           |
| Time            | Relative Counting Error = [  (The Square Root of TC + BKG * CT) / (TC - BKG * CT)  ] * 1.96 * 100    |            |           |
| 10:00 AM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.                      |            |           |

## v RESULTS v

|   |          |                           |
|---|----------|---------------------------|
| ALPHA TOTAL in $\mu\text{Ci/g}$ (Average) = | 1.39E+00 | DETECTION LEVEL           |
|   |          |                           |
| RELATIVE COUNTING ERROR =                   | 21.6%    | 2.55E-01 $\mu\text{Ci/g}$ |

|                |                 |       |          |
|----------------|-----------------|-------|----------|
| Data Entry by: | <i>M. B. S.</i> | Date: | 03/13/95 |
| Approved by:   | <i>J. T. S.</i> | Date: | 3/13/95  |

## WHC-SD-WM-DP-100, REV. 0-A

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER



AT : LA-508-101 (D-2)

LA-548-101 (A-3)

## SOLIDS

| Type            | DETECTOR NUMBER  | SAMPLE     | REPLICATE |
|-----------------|--|------------|-----------|
| DUPLICATE       | DISH SIZE 1, 2, or 5 (MS)  | 15         | 15        |
| 893             | TOTAL COUNTS (TC)  | 2          | 2         |
| AT              | COUNT TIME in MINUTES (CT)   | 98         | 99        |
|                 | BACKGROUND in cpm (BKG)  | 30         | 30        |
|                 | SAMPLE SIZE in mL (SS)   | 0.4        | 0.4       |
|                 | DILUTION FACTOR (DF)   | 1.000      | 1.000     |
| ALPHA-01        | DIGEST GRAMS of SOLIDS/L (Dg/L)  | 0.488      | 0.488     |
|                 | EFFICIENCY FACTOR (EFF)  | 0.2380     | 0.2380    |
| SOLID           | Lc, Rmax, or Rs,(SAMPLE RATE) as APPROPRIATE   | 2.867      | 2.900     |
| SAMPLE          | Sample Concentration in $\mu\text{Ci/g}$   | 1.12E+00   | BOOK#     |
| S95T208         | Replicate Concentration in $\mu\text{Ci/g}$  | 1.14E+00   |           |
| DETECTION LEVEL | Average Concentration in $\mu\text{Ci/g}$  | 1.1294E+00 |           |
| WB26872         | Rs (Sample Count Rate) = (TC / CT) - BKG   |            |           |
| AKL             | ALPHA TOTAL $\mu\text{Ci/g}$ = $\text{Rs} * 1000\text{mL/L} * \text{DF} / (\text{EFF} * \text{SS} * \text{Dg/L} * 2220000\text{dpm}/\mu\text{Ci})$ |            |           |
| Date            |  |            |           |
| 03/10/95        |  |            |           |
| Time            | Relative Counting Error = $[(\text{The Square Root of TC + BKG * CT}) / (\text{TC - BKG * CT})] * 1.96 * 100$                                      |            |           |
| 10:00 AM        | Detection Levels and Less Than Values are determined from Procedure LA-508-002.  |            |           |

## v RESULTS v

|   |          |                  |
|---|----------|------------------|
| ALPHA TOTAL in $\mu\text{Ci/g}$ (Average) = | 1.13E+00 | DETECTION LEVEL  |
|   |          | 2.47E-01         |
| RELATIVE COUNTING ERROR =                   | 23.9%    | $\mu\text{Ci/g}$ |

|                |            |       |          |
|----------------|------------|-------|----------|
| Data Entry by: | <i>MCB</i> | Date: | 03/13/95 |
| Approved by:   | <i>SM</i>  | Date: | 3/13/95  |

PLACE ANALYTICAL CARD IN BOX BELOW OR ATTACH TRAVELER

**AT : LA-508-101 (D-2)****LA-548-101 (A-3)****SOLIDS**

| TYPE            | DETECTOR NUMBER   | SPIKE      | REPLICATE |
|-----------------|---|------------|-----------|
| SPIKE           | DISH SIZE 1, 2, or 5 (MS)   | 15         | 15        |
| TEST CODE       | TOTAL COUNTS (TC)   | 2          | 2         |
| 693             | COUNT TIME in MINUTES (CT)  | 44522      | 41618     |
| AT or TB?       | BACKGROUND in cpm (BKG)   | 30         | 30        |
| AT              | SAMPLE VOLUME in mL (Spiked Vial) (SS)  | 0.4        | 0.4       |
| Test Code       | SAMPLE DILUTION FACTOR (Spiked Vial) (DF)   | 1.000      | 1.000     |
| ZALPHA-01       | DIGEST GRAMS of SOLIDS/L (Dg/L)   | 101        | 101       |
| MATRIX          | SPIKE VOLUME in mL (SVol)   | 0.472      | 0.472     |
| SOLID           | SPIKE DILUTION FACTOR (SDF)   | 0.100      | 0.100     |
| Sample #        | SPIKE VALUE in $\mu\text{Ci}/\text{L}$ (SVal)   | 1          | 1         |
| S95T208         | INSTRUMENT EFFICIENCY FACTOR (EFF)  | 36.378     | 36.378    |
| Instrument Code | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ (S+S)  | 0.238      | 0.238     |
| WB26672         | AVERAGE or MAXIMUM $\mu\text{Ci}/\text{g}$ from FORM C  | 6.01E+02   | 5.62E+02  |
| Analyse         | BOOK#   | 1.3905E+00 | 94B43     |
| AKL             | Rs (Sample Count Rate) = (TC / CT) - BKG  |            |           |
| Date            | SAMPLE + SPIKE $\mu\text{Ci}/\text{g}$ = Rs * 1000mL/L * DF / (EFF * SS * Dg/L * 220000dpm/ $\mu\text{Ci}$ )                      |            |           |
| 03/10/95        | PERCENT SPIKE RECOVERY = (((S+S $\mu\text{Ci}/\text{g}$ - SAMPLE $\mu\text{Ci}/\text{g}$ ) * ((SDF/SVol)/(DF/SS/Dg/L)))/SVal)*100 |            |           |
| Time            |   |            |           |
| 10:00 AM        |   |            |           |

**RESULT AVG. PERCENT SPIKE RECOVERY = 74.5%**

|                        |               |       |           |
|------------------------|---------------|-------|-----------|
| Data Entry by:         | <i>MFB/MH</i> | Date: | 13-Mar-95 |
| Approved by:           | <i>JL</i>     | Date: | 3/13/95   |
| Form 508101_X Rev. 1.3 |               | Page  | 1 of 1    |

## LABCORE Data Entry Template for Worklist# 745

Analyst: AKL Instrument: AB00 15 Book # 91852Method: LA-508-101 Rev/Mod D-2

Worklist Comment: Data re-entry from worklist 672. SLF

| GROUP    | PROJECT | S TYPE      | SAMPLE#    | R A -----TEST-----    | MATRIX | ACTUAL | FOUND | DL  | UNIT        |
|----------|---------|-------------|------------|-----------------------|--------|--------|-------|-----|-------------|
|          |         | 1 STD       |            | @ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
|          |         | 1 STD       |            | @ALPHA01 ALPHA01E     | SOLID  |        |       | N/A | % Ct. Error |
|          |         | 2 BLNK-PREP |            | @ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
|          |         | 2 BLNK-PREP |            | @ALPHA01 ALPHA01E     | SOLID  |        |       | N/A | % Ct. Error |
|          |         | 3 BLNK/BKG  |            | @ALPHA01 ALPHA01      | SOLID  |        |       | N/A | uCi/g       |
| 95000014 | AX-102  | 4 SAMPLE    | S95T000204 | 0 F @ALPHA01 ALPHA01  | SOLID  | N/A    |       |     | uCi/g       |
| 95000014 | AX-102  | 4 SAMPLE    | S95T000204 | 0 F @ALPHA01 ALPHA01E | SOLID  | N/A    |       |     | % Ct. Error |
| 95000014 | AX-102  | 5 DUP       | S95T000204 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000014 | AX-102  | 5 DUP       | S95T000204 | 0 F @ALPHA01 ALPHA01E | SOLID  |        |       | N/A | % Ct. Error |
| 95000014 | AX-102  | 6 SPK       | S95T000204 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000015 | AX-102  | 7 SAMPLE    | S95T000208 | 0 F @ALPHA01 ALPHA01  | SOLID  | N/A    |       |     | uCi/g       |
| 95000015 | AX-102  | 7 SAMPLE    | S95T000208 | 0 F @ALPHA01 ALPHA01E | SOLID  | N/A    |       |     | % Ct. Error |
| 95000015 | AX-102  | 8 DUP       | S95T000208 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |
| 95000015 | AX-102  | 8 DUP       | S95T000208 | 0 F @ALPHA01 ALPHA01E | SOLID  |        |       | N/A | % Ct. Error |
| 95000015 | AX-102  | 9 SPK       | S95T000208 | 0 F @ALPHA01 ALPHA01  | SOLID  |        |       | N/A | uCi/g       |

Final page for worklist # 745

H. Tiff

3-20-95

Fitzgerald

## Data Entry Comments:

Data re-entry From worklist 672 (Per project coordinators instructions).

H. Tiff  
3-20-95

Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.

**LABCORE Data Entry Template for Worklist# 745**

| GROUP             | PROJECT | S TYPE | SAMPLE# | R A -----TEST----- | MATRIX            | ACTUAL | FOUND | DL   | UNIT |
|-------------------|---------|--------|---------|--------------------|-------------------|--------|-------|------|------|
| Analyst Signature |         | Date   |         |                    | Analyst Signature |        |       | Date |      |

*Data Entry Comments:*

---

---

---

*Units shown for QC (SPK & STD) may not reflect the actual units. DL = Detection Limit, S = Worklist Slot Number, R = Replicate Number, A = Aliquot Code.*

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

## DISTRIBUTION SHEET

| To<br>Distribution   | From<br>Characterization Plans and Reports | Page 1 of 2                                |                 |  |
|--|--|--|-----------------|--|
|  |  | Date: 05/15/95                             |                 |  |
| Project Title/Work Order<br>WHC-SD-WM-DP-100, Rev. 0-A, "90-Day Final Report for Tank 241-AX-102, Auger Samples 95-AUG-006 and 95-AUG-007" |  | EDT NO.: EDT-610412<br>ECN NO.: ECN-613644 |                 |  |
| Name   | MSIN                                       | Text With<br>all Attach                    | EDT/ECN<br>ONLY |  |
| <u>Pacific Northwest Laboratory</u>  |  |  |                 |  |
| J. R. Gormsen  | K7-28                                      |  | X               |  |
| S. J. Harris   | K7-22                                      | X  |                 |  |
| K. L. Silvers  | P7-27                                      |  | X               |  |
| <u>U.S. Department of Energy, RL</u>   |  |  |                 |  |
| C. A. Babel  | S7-54                                      | X  |                 |  |
| <u>Westinghouse Hanford Company</u>  |  |  |                 |  |
| J. N. Appel  | G3-21                                      |  | X               |  |
| H. Babad   | S7-30                                      | X  |                 |  |
| R. J. Cash   | S7-15                                      | X  |                 |  |
| J. L. Deichman   | H4-19                                      |  | X               |  |
| G. D. Forehand   | S7-31                                      |  | X               |  |
| C. E. Golberg  | H5-49                                      |  | X               |  |
| V. W. Hall   | H4-21                                      |  | X               |  |
| D. C. Hetzer   | S6-31                                      |  | X               |  |
| L. Jensen  | T6-07                                      | X  |                 |  |
| G. D. Johnson  | S7-15                                      | X  |                 |  |
| N. W. Kirch  | R2-11                                      | X  |                 |  |
| J. G. Kristofzski  | T6-06                                      | X  |                 |  |
| M. J. Kupfer   | H5-49                                      | X  |                 |  |
| E. J. Lipke  | S7-14                                      |  | X               |  |
| N. G. McDuffie   | S7-15                                      | X  |                 |  |
| J. E. Meacham  | S7-15                                      | X  |                 |  |
| P. M. Morant   | H4-25                                      | X  |                 |  |
| A. D. Rice   | T6-06                                      | X  |                 |  |
| B. C. Simpson  | R2-12                                      |  | X               |  |
| D. A. Turner   | S7-15                                      | X  |                 |  |
| J. A. Voogd  | R4-01                                      |  | X               |  |
| Central Files  | L8-04                                      | 2  |                 |  |
| EDMC   | H6-08                                      | X  |                 |  |
| LTIC   | T6-03                                      |  | X               |  |
| OSTI   | L8-07                                      | 2  |                 |  |
| TFIC (Tank Farm Information Center)  | R1-20                                      |  | X               |  |
| TCRC   | R2-12                                      | 2  |                 |  |

**THIS PAGE INTENTIONALLY  
LEFT BLANK**

**DISTRIBUTION SHEET**

| To Distribution  | From Characterization Plans and Reports | Page 2 of 2          |              |
|--|---|----------------------|--------------|
|  |   | Date: 05/15/96       |              |
| Project Title/Work Order   |   | EDT NO.: EDT-610412  |              |
| WHC-SD-WM-DP-100, Rev. 0-A, "90-Day Final Report for Tank 241-AX-102, Auger Samples 95-AUG-006 and 95-AUG-007" |   | ECN NO.: ECN-613644  |              |
| Name   | MSIN                                    | Text With all Attach | EDT/ECN ONLY |

Washington State Department of Ecology

Single-Shell Tank Unit Manager  
 S. E. McKinney  
 P.O. Box 47600  
 Olympia, Washington 98504-7600

X

Environmental Protection Agency

Single-Shell Tank Unit Manager  
 D. R. Einan  
 712 Swift Boulevard, Suite 5  
 Richland, Washington 99352

X

U. S. Department of Energy

Jim Poppiti  
 12800 Middlebrook Rd.  
 Trevion II, EM-36  
 Germantown, MD 20874

X

Los Alamos Technical Associates

A. T. DiCenso  
 750 Swift Boulevard  
 Suite # 4  
 Richland, WA 99352

X

**THIS PAGE INTENTIONALLY  
LEFT BLANK**