



Westinghouse
Hanford Company

P.O. Box 1970 Richland, WA 99352

1793 237
20610



222-S/RCRA ANALYTICAL LABORATORIES

PROJECT: SINGLE-SHELL TANK WASTE
CHARACTERIZATION

TANK: 241-U-110

CORE: 6

SEGMENT: 2 BEST AVAILABLE COPY

CUSTOMER ID. NUMBER: 89-043

REPORT REVISION: 1

DATE PRINTED: AUGUST 30, 1990

TABLE OF CONTENTS

Signature Form.....	ii
Introduction.....	1
Sampling and Custody Data.....	4
Sample Data Summary.....	7
Physical Test Results.....	9
Extrusion of Segment.....	10
Appearance of Solid.....	10
Homogenization.....	10
Single Shell Tank Segment - Subsamples.....	11
VOA Sampling.....	11
Photograph of Tank 241-U-11 Core 6 Segment 2.....	12
Particle Size Analysis.....	13
Undigested Sample Analysis.....	19
Untreated Sample Results Summary.....	20
pH Analysis.....	21
Percent Water.....	22
KOH Fusion Analysis.....	23
Fusion Analysis Results Summary.....	24
Fusion Analysis Results of Laboratory Solutions.....	25
Fusion Dissolution.....	26
Total Alpha and Beta Analysis.....	27
GEA Analysis.....	34
Uranium Analysis.....	74
Water Digestion Test Analysis.....	75
Water Digestion Results Summary.....	76
Water Digestion Results Of Laboratory Solutions.....	77
Water Digestion.....	78
Ion Chromatographic Analysis.....	79
Ion Chromatographic Analysis.....	106
Ion Chromatographic Analysis.....	115
Total Organic Carbon Analysis.....	133
Acid Digestion Test Analysis.....	140
Acid Digestion Data Summary.....	141
Acid Digestion Analysis.....	142
Inductively Coupled Plasma Spectrographic Analysis.....	143
ICP Raw Data Summary.....	145
Appendix A Analytical Analysis Cards	

I have reviewed this report and certify that the package is in compliance with "Quality Assurance Project Plan" - WHC-SD-CP-QAPP-002. I found it to be a true and accurate accounting both technically and for completeness of the laboratory analyses performed on this sample.

Shirley A. Cervantes

Shirley A. Cervantes
Data Coordinator

Date 8/30/90

Cary M. Seidel

Cary M. Seidel
Unit Manager

Date 9/1/90

L.H. Taylor

Larry H. Taylor
Laboratory Q.A. Officer

Date 9-28-90

INTRODUCTION

INTRODUCTION

Westinghouse Hanford Company Analytical Laboratories are supporting the characterization efforts of the single shell tanks. The characterization of tank 241-U-110 was performed under Phase 1A and 1B of the "Waste Characterization Plan for the Hanford Site Single-Shelled Tanks" (WHC-EP-0210).

Tank 241-U-110 has a 500,000 gallon capacity. This tank was construction was completed in 1944. The tank received first cycle waste, REDOX high-level waste, coating waste, and laboratory waste until 1975. Between July 7, 1975 and February 2, 1976, P-10 pumps were installed, and 41,700 gallons of liquid waste were pumped from the tank. Tank 241-U-110 still contains an estimated 195,000 gallons of waste.

The Analytical Laboratories performs all analytical analysis to the specifications of the "Quality Assurance Project Plan", WHC-SD-CP-QAPP-002. In accordance with WHC-SD-CP-QAPP-002 the following laboratory policies are being followed. Spikes are performed on either the undissolved sample, or the sample after dissolution as directed by the chemist. If the spike addition is found to be less than 20% of an analyte concentration, the spike recovery is not reported due to errors introduced by the precision of the sample analysis. The concentration of spike additions will be re-evaluated before the start of phase 1C. Two spiking routines are being used during phase 1A and 1B. For the following analyses, Ion Chromatography, Inductively Coupled Plasma, Mercury Hydride, Total Organic Carbon, and Carbonate analyses the solid sample is spiked independently from the sample digestion. Any non-homogeneity of the sample could adversely affect the spike recoveries. For the radio-isotopic analysis and other analyses not specified above the spikes were performed by spiking an aliquot of sample after digestion.

The laboratory does not report sample results from batch analyses that are questionable. The results from questionable batches are discarded and the analysis is repeated. Sample cards (laboratory travelers) for the repeated analysis are reissued for analysis after they have been stamped "rerun". Laboratory travelers are issued using a computerized routine according to a "sample point". This sample point label (segment-n) on the laboratory travelers and on the GEA analysis reports has no relationship to the sampling activities or the sample identification. All results in this data package relate only to the sample identified as segment 3 from core 5 taken from tank 241-U-110.

The organic analysis of this sample will be performed by Pacific Northwest Laboratories (PNL). Due to instrument and procedure problems, PNL has been unable to separate organics from the normal paraffin hydrocarbon present in the samples. The results from the organic analysis will be provided when available.

Samples analyzed for Total Organic Carbon between November 1, 1989 and February 22, 1990 were not acidified. The results from these analyses include total organic carbon, carbonate, and dissolved carbon dioxide from the air. The validity of these analyses are subject to interpretation. The total organic carbon procedure was corrected and these analyses will be repeated

wherever possible.

All sample results reported here by weight are reported as the "wet weight" of the sample. Some samples did noticeably lose moisture during the process of aliquoting and weighing the sample for digestion. The percent moisture was determined at the earliest opportunity to minimize any errors introduced by the loss of moisture. Drying samples before analysis resulted in radiation exposure increases of about a factor of ten. In order to reduce and control radiation exposure to laboratory personnel, the samples were not dried before aliquouting and digestion. This policy may result in some laboratory results being biased high.

This report is formatted into sections corresponding to the type of dissolutions performed prior to analysis. A brief summary of analytical results is reported, followed by calibration data and an analysis batch report. Any notable observations regarding an analysis are noted on the batch report for that analysis. Copies of laboratory travelers can be found in Appendix A.

SAMPLING and CUSTODY DATA

Lab Segment #
Serial # F0053

9 1 1 2 1 1 7 0 5 7 9

CHAIN-OF-CUSTODY RECORD FOR CORE SAMPLING

(1) Shipment Number 5-023-89 (2) Sample Number 89-043 (3) Supervisor D.C. Hartley
(4) Tank 110 U (5) Riser 17 (6) Segment #2 (7) Cask Serial Number C 1021

Radiation Survey Data:	(8) FIELD	(20) LABORATORY	(9) Shipment Description:
Over Top Dose Rate	<u>1.5 mR/hr</u>	<u>1.5 mR/hr</u>	A. Work Package Number <u>ZW-89-00958-W</u>
Side Dose Rate	<u>2.5 mR/hr</u>	<u>2.5 mR/hr</u>	B. Cask Seal Number <u>For Future Use</u>
Bottom Dose Rate	<u>.75 mR/hr</u>	<u>.75 mR/hr</u>	C. Sampler Number Used <u>#58</u>
Smearable Contamination	<u>1 DET.</u> (alpha)	<u>1 Det</u> (alpha)	D. Date and Time Sampler Unseated <u>11-13-89, 1035</u>
	<u>1 DET.</u> (beta-gamma)	<u>1 Det</u> (beta-gamma)	E. Expected Liquid Content <u>20%</u>
	RPT <u>KMT</u> (Signature)	RPT <u>D. Arnold</u> (Signature)	F. Expected Solid Content <u>80%</u>
			G. Dose Rate Through Drill String <u>70mR/hr</u>
			H. Expected Sample Length <u>19"</u>

(10) INFORMATION (Include statement of laboratory tests to be performed.)

Core #006,

WHC-EP-0210 Waste Characterization Plan for the Sanford
Site Single Shell Tank

*Reference laboratory work request, if available.

Comments:

(11) POINT OF ORIGIN <u>241-U</u> <u>110</u>	(12) SENDER NAME <u>D.C. Hartley</u> SENDER SIGNATURE <u>DCHartley</u>	(13) DATE AND TIME RELEASED <u>11-15-89</u> <u>0920</u>	(14) DESTINATION - <u>222S</u> <u>LABS</u> <u>200West</u>	(16) RECIPIENT NAME <u>C.M. Seidel</u> RECIPIENT SIGNATURE <u>Carry M. Seidel</u>	(17) DATE AND TIME RECEIVED <u>0955</u> <u>11-15-89</u>
(15) Seal Intact Upon Release? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	(18) Seal Intact Upon Receipt? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	(19) Seal Data Consistent with this Record? Shipment No. <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No Sample No. <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No			

**Single Shell Tank Waste Characterization
Summary of Core Sample**

**Phase
I-A**

Tank ID:	241-U-110
Riser ID:	17
Core ID:	006

Date Sampling Initiated:	11-10-89
Date Sampling Completed:	11-14-89

Segment 1	Lab Serial No.	F-0029
	Customer ID. No.	89-042
	Last Segment?	No
Segment 2	Lab Serial No.	F-0053
	Customer ID. No.	89-043
	Last Segment?	No
Segment 3	Lab Serial No.	F-0077
	Customer ID. No.	89-044
	Last Segment?	No
Segment 4	Lab Serial No.	F-0101
	Customer ID. No.	89-045
	Last Segment?	Yes
Segment 5	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 6	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 7	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	

Segment 8	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 9	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 10	Lab Serial No.	
	Customer ID. No..	
	Last Segment?	
Segment 11	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 12	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 13	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	
Segment 14	Lab Serial No.	
	Customer ID. No.	
	Last Segment?	

Remarks: Customer Id. No# 89-042 was received empty.

Interim

SST-1 Rev. B 3/27/90

Prepared by:

Signature

H. S. Rich

Printed Name

Date: 05-15-90

Verified by:

Signature

C. M. Seidel

Printed Name

Date: 05-15-90

Approved by:

Signature

L.H. Taylor

Printed Name

Date: 9-28-90

SAMPLE DATA SUMMARY

SUMMARY DATA REPORT

Tank 241-U-110
 Core 6
 Segment 2
 Customer Id. 89-043

Untreated	Sample	Sample	Duplicate	Sample	Duplicate
		Acid Digestion Results			
pH	11.56	11.76		Aluminum	94285 ug/g
Percent Water	39.50 %	37.60 %		Antimony	579 ug/g
				Barium	74 ug/g
				Beryllium	3 ug/g
				Bismuth	5381 ug/g
				Boron	62 ug/g
				Cadmium	LT ug/g
				Calcium	1098 ug/g
				Chromium	448 ug/g
Total Alpha	2.81 uci/g	2.46 uci/g		Cobalt	79 ug/g
Total Beta	1650 uci/g	1600 uci/g		Copper	97 ug/g
GEA				Europium	8 ug/g
Cs-137	30.1 uci/g	37.0 uci/g		Iron	18001 ug/g
Uranium	14100 ug/g	15000 ug/g		Lanthanum	68 ug/g
				Lead	1344 ug/g
				Lithium	13 ug/g
				Magnesium	8338 ug/g
				Manganese	6755 ug/g
				Mercury	40 ug/g
				Molybdenum	40 ug/g
				Nickel	192 ug/g
				Potassium	LT ug/g
				Samarium	496 ug/g
First Batch Analysis				Selenium	761 ug/g
Fluoride	<1030 ug/g	<971 ug/g		Silver	LT ug/g
Chloride	1620 ug/g	<971 ug/g		Sodium	79677 ug/g
Nitrate	54600 ug/g	44900 ug/g		Strontium	777 ug/g
Sulfate	<10000 ug/g	<9710 ug/g		Sulfur	511 ug/g
Second Batch Analysis				Tantalum	96 ug/g
Phosphate	<10000 ug/g			Thallium	1733 ug/g
Third Batch Analysis				Thorium	476 ug/g
Phosphate		<9710 ug/g		Tin	112 ug/g
Total Organic Carbon	2760 ug/g	2490 ug/g		Titanium	157 ug/g
				Uranium	18706 ug/g
				Vanadium	92 ug/g
				Zinc	735 ug/g
				Zirconium	96 ug/g

LT: Less than instrument detection limit.

3
4
5
6
7
8
9
10
11
12
13
14
15
16

PHYSICAL TEST RESULTS

**Single Shell Tank
Extrusion of Segment -- Physical Tests**

**Phase
I-A**

Lab Segment Serial No.: F0053

Customer ID: 89-043

Analyst: Richard L. Weiss

Date Extruded: 11-15-89

Drainable Liquid

Liquid Submitted for Segment Analysis? -- No

Gross	None	Tare	Net
Serial		Date/Time _____ / _____	Estimated
Specific		Calculated	

Appearance of Liquid:

Dimensions of Segment

Complete Segment Obtained?	No	Length:	5 in.	Calculated Volume:	3.93 cubic in.
Remarks	None				

Appearance of Solid:

The sample was semi-cohesive at the bottom, grading to crumbly at the top. The sample was a uniform brown color.

Penetrometer

Penetrometer	13.8	lbs/sq in	Remarks: None
--------------	------	-----------	---------------

Homogenization

Procedure: T038A-00712 Revision: F	Quantity of Material	102.32	grams
Date Homogenized: 01-03-90	Time Homogenized: 5	Minutes	
Operator: John R. Smith			

Laboratory Notebook Reference

WHC-N-313-4	17
Notebook No.	Page No.

Prepared by:

H. S. Rich
Printed Name

Date: 05-17-90

3/27/90

Verified by:

C. M. Seidel
Printed Name

Date: 05-17-90

Rev. C

Approved by:

L.H. Taylor
Printed Name

Date: 9-28-90

SST-3

10

**Single Shell Tank
Segment -- Subsamples**

**Phase
1A**

Customer ID: 89-043

Lab Segment Serial No. F0053

Volatile Organic Analysis

VOA Sample

Laboratory Serial Number: 89-043-26

Date Sampled: 01-03-90

Particle Size Distribution Analysis

Particle Size Sample

Laboratory Serial Number: F0053

Date Sampled: 01-03-90

Sample analysis performed at 222-S

Homogenized Solids

Undigested Solids Analysis

Laboratory Serial Number for Sample:

F0053

Date Sampled: 01-03-90

Laboratory Serial Number of Duplicate Sample: F0054

Fusion Analysis of Solids

Laboratory Serial Number for Sample:

F0058

Date Sampled: 01-03-90

Laboratory Serial Number of Duplicate Sample: F0059

Laboratory Serial Number of Spiked Sample: N/A

Acid Digestion Analysis of Solids

Laboratory Serial Number for Sample:

F0068

Date Sampled: 01-03-90

Laboratory Serial Number of Duplicate Sample: F0069

Laboratory Serial Number of Spiked Sample: F0118

Water Digestion Analysis of Solids

Laboratory Serial Number for Sample:

F0063

Date Sampled: 01-03-90

Laboratory Serial Number of Duplicate Sample: F0064

Laboratory Serial Number of Spiked Sample: F0065

Laboratory Notebook Reference

WHC-N-313-4

Notebook No.

17

Page No.


Prepared by: Shirley Cervantes
Signature S. A. Cervantes Date: 8-15-90

Verified by: Cathy M. Seidel
Signature C. M. Seidel Date: 8-15-90

Approved by: L.H. Taylor
Signature L. H. Taylor Date: 9-28-90

Rev A
04/24/90

SST-17



9 1 1 2 2 3 0 0 6 1 6

Particle Size Analyzer

PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010
STATISTICS

SAMPLE NAME : SST, B000035, F0053, H2O, SBK

FILE NAME : F0053.001

DATE	:	30/11/1989	ACQ. RANGE	: 0.5-150	COUNTS	: 147242
TIME	:	10:10	ACQ. MODE	: SAMPLE	S.N.F.	: 0.50
CONFIG.	:	1 (0.7 S1)	ACQ. TIME	: 1193 SEC	S.D.U.	: 6657
CELL TYPE	:	MAGNETIC (3)	SAMPLE SIZE	: 4	CONCENTR.	: 3.0E+06 #/ml
SAMPLE TYPE	:	REGULAR	REQ. CONF.	: 95.00%(V)	SOLIDS	: 1.3E-03 %

MEAN Diameter

S.D.

Number, Length	:	1.12 μ m	0.90 μ m
Number, Area	:	1.44 μ m	0.96 μ m
Number, Volume	:	2.02 μ m	1.27 μ m
Length, Area	:	1.85 μ m	1.98 μ m
Length, Volume	:	2.70 μ m	2.15 μ m
Area, Volume	:	3.96 μ m	4.03 μ m
Volume, Moment	:	8.06 μ m	6.71 μ m

MEDIAN Diameter

MODE

CONFIDENCE

Number	:	0.88 μ m	0.75 μ m	100.00%
Area	:	2.99 μ m	5.25 μ m	100.00%
Volume	:	5.76 μ m	5.25 μ m	99.88%

Sample sl. moist, dark brown

Dispersed well in H₂O, nil agglomerationdispersed particles < 150 μ

Particle Size Analyzer

PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010
STATISTICS

SAMPLE NAME : SST,B000035,F0053,H2O,SBK
FILE NAME : F0053.002

DATE	:	30/11/1989	ACQ. RANGE	:	0.5-60	COUNTS	:	21513
TIME	:	10:43	ACQ. MODE	:	SAMPLE	S.N.F.	:	0.96
CONFIG.	:	1 (0.7 S1)	ACQ. TIME	:	87 SEC	S.D.U.	:	6722
CELL TYPE	:	MAGNETIC (3)	SAMPLE SIZE	:	1	CONCENTR.:	:	1.5E+06 #/ml
SAMPLE TYPE	:	REGULAR	REQ. CONF.	:	95.00%(V)	SOLIDS	:	2.8E-05 %

		MEAN Diameter	S.D.
Number, Length	:	0.67 μ m	0.17 μ m
Number, Area	:	0.69 μ m	0.17 μ m
Number, Volume	:	0.71 μ m	0.17 μ m
Length, Area	:	0.71 μ m	0.18 μ m
Length, Volume	:	0.73 μ m	0.18 μ m
Area, Volume	:	0.76 μ m	0.20 μ m
Volume, Moment	:	0.81 μ m	0.20 μ m

		MEDIAN Diameter	MODE	CONFIDENCE
Number	:	0.65 μ m	0.55 μ m	100.00%
Area	:	0.73 μ m	0.70 μ m	100.00%
Volume	:	0.78 μ m	0.70 μ m	100.00%

Brinkmann

Particle Size Analyzer


PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010SAMPLE NAME : SST,B000035,F0053,H2O,SBK
FILE NAME : F0053.002

DATE	: 30/11/1989	ACQ. RANGE	: 0.5-60	COUNTS	: 21513
TIME	: 10:43	ACQ. MODE	: SAMPLE	S.N.F.	: 0.96
CONFIG.	: 1 (0.7 S1)	ACQ. TIME	: 87 SEC	S.D.U.	: 6722
CELL TYPE	: MAGNETIC (3)	SAMPLE SIZE	: 1	CONCENTR.	: 1.5E+06 #/ml
SAMPLE TYPE	: REGULAR	REQ. CONF.	: 95.00%(V)	SOLIDS	: 2.8E-05 %

PROBABILITY NUMBER DENSITY GRAPH

Name: SST,B000035,F0053,H2O,SBX
 $1.5E+06 \text{ #/ml}(100.0\%)$
 Mode at $0.70 \mu\text{m}$
 << SCALE RANGE (μm): ADJUSTED >>

Median : $0.65 \mu\text{m}$
 Mean(nl): $0.67 \mu\text{m}$
 S.D.(nl): $0.17 \mu\text{m}$
 Conf(nl): 100.00 %



SAMPLE NAME : SST,B000035,F0053,H20,SBK
FILE NAME : F0053.002


DATE	: 30/11/1989	ACQ. RANGE	: 0.5-60	COUNTS	: 21513
TIME	: 10:43	ACQ. MODE	: SAMPLE	S.N.F.	: 0.96
CONFIG.	: 1 (0.7 s1)	ACQ. TIME	: 87 SEC	S.D.U.	: 6722
CELL TYPE	: MAGNETIC (3)	SAMPLE SIZE	: 1	CONCENTR.:	1.5E+06 #/ml
SAMPLE TYPE	: REGULAR	REQ. CONF.	: 95.00%(V)	SOLIDS	: 2.8E-05 %

PROBABILITY NUMBER DISTRIBUTION GRAPH

Name: SST,B000035,F0053,H20,SBK
1.5E+06 #/ml(100.0%)

Median : 0.65 μ m
Mean(nl): 0.67 μ m
S.D.(nl): 0.17 μ m
Conf(nl): 100.00 %

<< SCALE RANGE (μ m): ADJUSTED >>



Brinkmann

Particle Size Analyzer

PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010

SAMPLE NAME : SST,B000035,F0053,H2O,SBK

FILE NAME : F0053.001

DATE	:	30/11/1989	ACQ. RANGE	:	0.5-150	COUNTS	:	147242
TIME	:	10:10	ACQ. MODE	:	SAMPLE	S.N.F.	:	0.50
CONFIG.	:	1 (0.7 S1)	ACQ. TIME	:	1193 SEC	S.D.U.	:	6657
CELL TYPE	:	MAGNETIC (3)	SAMPLE SIZE	:	4	CONCENTR.	:	3.0E+06 #/ml
SAMPLE TYPE	:	REGULAR	REQ. CONF.	:	95.00%(V)	SOLIDS	:	1.3E-03 %

PROBABILITY VOLUME DENSITY GRAPH


Name: SST,B000035,F0053,H2O,SBK

Median : 5.76 μ m

1.3E-05 cc/ml(100.0%)

Mean(nv): 2.02 μ mMean(vm): 8.06 μ mMode at 5.25 μ mS.D.(nv): 1.27 μ mS.D.(vm): 6.71 μ m<< SCALE RANGE (μ m): ADJUSTED >>

Conf(vm): 99.88 %




Brinkmann

Particle Size Analyzer

PROCESS CHEMISTRY LABS PARTICLE ANALYSIS
VIA BRINKMANN 2010SAMPLE NAME : SST,B000035,F0053,H2O,SBK
FILE NAME : F0053.001

DATE	: 30/11/1989	ACQ. RANGE	: 0.5-150	COUNTS	: 147242
TIME	: 10:10	ACQ. MODE	: SAMPLE	S.N.F.	: 0.50
CONFIG.	: 1 (0.7 S1)	ACQ. TIME	: 1193 SEC	S.D.U.	: 6657
CELL TYPE	: MAGNETIC (3)	SAMPLE SIZE	: 4	CONCENTR.:	: 9.0E+06 #/ml
SAMPLE TYPE	: REGULAR	REQ. CONF.	: 95.00%(V)	SOLIDS	: 1.3E-03 %

PROBABILITY VOLUME DISTRIBUTION GRAPHName: SST,B000035,F0053,H2O,SBK
1.3E-05 cc/ml(100.0%)Mean(\bar{v}_w): 2.02 μm
S.D.(\bar{v}_w): 1.27 μm Median : 5.76 μm
Mean(\bar{v}_m): 8.06 μm
S.D.(\bar{v}_m): 6.71 μm
Conf(\bar{v}_m): 99.88 %<< SCALE RANGE (μm): ADJUSTED >>

UNDIGESTED SAMPLE ANALYSIS

9 1 1 2 3 6 0 0 6 7 4

20

Single Shell Tank Project

Untreated Sample Results

05-10-90

Tank: 241-U-110

Core: 6

Segment: 2

Customer ID: 89-043

	Check Standard	Blank	Sample	Sample Duplicate	Check Standard
Laboratory ID:	F0056	F0073	F0053	F0054	F0704
pH	100.20%	8.16	11.56	11.76	99.90%

Laboratory ID:	F0052	F0749	F0053	F0054	F0732
%Water	95.00%	6.15E-03	39.50%	37.60%	98.20%

Approved by: H. S. Rich

H. S. Rich Date: 5/10/90

Verified by: Karyn M Seidel

C.M. Seidel Date: 5/10/90

Approved by: J. H. Taylor

J.H. Taylor Date: 9-28-90

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	AL10653
Procedure / Rev	LA-212-103/A-3
Technologist	6C269/M. Franz
Date	1-4-90
Temperature	25.4 C
Starting Time	8:00
Ending Time	14:00
Chemist	R. E. Brandt

pH Analysis of the Solid Sample

Undigested Sample

	Description	Lab. Id.
1	Initial LMCS Check Std.	F0056
2	Blank	F0073
3	Sample 89-043	F0053
4	Duplicate 89-043	F0054
5	Sample 89-082	F0705
6	Duplicate 89-082	F0706
7	Ending LMCS Check Std.	F0704
8		
9		
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Standard	72C11-A/5.0mL			5.0 mL

Prepared by:	<u>Shirley Cervantes</u> Signature	S.A. Cervantes Printed Name	Date: 05/11/90
Verified by:	<u>Cary M Seidel</u> Signature	C.M. Seidel Printed Name	Date: 05/11/90
Approved by:	<u>J. H. Taylor</u> Signature	L.H.Taylor Printed Name	Date: 9/18/90

Interim

4/04/90

Rev. E

SST-102

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	N/A
Procedure / Rev	LA-564-101/D-1
Technologist	6B598/R. A. Hale
Date	1-10-90
Temperature	120 C
Starting Time	11:00 1-9-90
Ending Time	14:00 1-10-90
Chemist	R. E. Brandt

Percent Water

Undigested Sample

	Description	Lab. Id.
1	Initial LMCS Check Std	F0052
2	Blank	F0749
3	Sample 89-043	F0053
4	Duplicate 89-043	F0054
5	Sample 89-082	F0705
6	Duplicate 89-082	F0706
7	Sample 89-083	F0729
8	Duplicate 89-083	F0730
9	Final LMCS Check Std	F0732
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Standard	11C11AH/1 mL			1 mL

Interim
4/04/90
Rev. E
SST-102

Prepared by: H. S. Rich
Signature

H. S. Rich
Printed Name

Date: 05-14-90

Verified by: C. M. Seidel
Signature

C. M. Seidel
Printed Name

Date: 05-14-90

Approved by: L. H. Taylor
Signature

L. H. Taylor
Printed Name

Date: 9-28-90

KOH FUSION ANALYSIS

9 1 1 2 0 6 3 0 4 7 8

Single Shell Tank Project

24

Fusion Analysis

Laboratory Results of Solids
Units Are Sample Wet Weight

Tank: 241-U-110
 Core: 6
 Segment: 2
 Customer ID: 89-043

	Check Standard	Blank	Sample F0058	Sample Duplicate F0059	Spike of Sample	Check Standard
Laboratory ID:						
Fusion Digestion			2.27 g/L	1.68 g/L		
Laboratory ID:	F0057	F0072	F0058	F0059	F0060	F0737
Total Alpha	105.20%	<1.29E-04 uci/L	2.81E+00 uci/g	2.46E+00 uci/g	*	111.80%
Total Beta	99.20%	<3.50E-04 uci/L	1.65E+03 uci/g	1.60E+03 uci/g	*	101.10%
Laboratory ID: GEA	F0057	F0748	F0058	F0059	F0736	F0737
Cs-137	97.80%	<3.50E-01 uci/L	3.09E+01 uci/g	3.70E+01 uci/g	107.50%	97.80%
Laboratory ID: Uranium	F0057	F0748	F0058	F0059	F0060	F0737
	94.90%	<1.03E+03 ug/L	1.41E+04 ug/g	1.48E+04 ug/g	**	113.90%

* Ratio of Standard To Sample Is Insufficient To Calculate Spike Recovery.

** Spike Improperly Prepared.

9 1 1 2 2 5 7 0 6 7 9

25

Single Shell Tank Project

Fusion Analysis

Sample Results on Laboratory Digestion

Tank: 241-U-110
 Core: 6
 Segment: 2
 Customer ID: 89-043

	Check Standard	Blank	Sample	Sample	Spike of Duplicate	Check Sample	Check Standard
Laboratory ID:			F0058		F0059		
Fusion Digestion			2.27	g/L	1.68	g/L	
Laboratory ID:	F0057	F0072	F0058	F0059	F0060	F0737	
Total Alpha	105.20%	<1.29E-04 uci/L	6.38E+00 uci/L	4.13E+00 uci/L	*	111.80%	
Total Beta	99.20%	<3.50E-04 uci/L	3.75E+03 uci/L	2.68E+03 uci/L	*	101.10%	
Laboratory ID:	F0057	F0748	F0058	F0059	F0736	F0737	
GEA							
Cs-137	97.80%	<3.50E-01 uci/L	6.98E+01 uci/L	6.21E+01 uci/L	107.50%	97.80%	
Uranium	94.90%	<1.03E+03 ug/L	3.19E-02 g/L	2.48E-02 g/L	**	113.90%	

* Ratio Of Standard To Sample Insufficient To Calculate Spike Recovery.

** Spike improperly prepared.

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Fusion Dissolution

Instrument	N/A
Procedure / Rev	LA-549-141/A-1
Technologist	6B598/R.D. Hale
Date	1-5-90
Temperature	450 C
Starting Time	10:30
Ending Time	14:30
Chemist	S. A. Catlow

	Description	Lab. Id.
1	Blank	F0748
2	Sample 89-043	F0058
3	Duplicate 89-043	F0059
4	Sample 89-082	F0710
5	Duplicate 89-082	F0711
6	Sample 89-083	F0734
7	Duplicate 89-083	F0735
8		
9		
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
N/A				

Prepared by:	<u>H. S. Rich</u> Signature	H. S. Rich Printed Name	Date: 05-11-90
Verified by:	<u>C. M. Seidel</u> Signature	C. M. Seidel Printed Name	Date: 05-11-90
Approved by:	<u>L. H. Taylor</u> Signature	L. H. Taylor Printed Name	Date: 9-28-90

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WA93415
Procedure / Rev	LA-508-101/C-1
Technologist	6A543/J.A. Hopkins
Date	1-8-90
Temperature	70 F
Starting Time	08:30
Ending Time	13:00
Chemist	S. A. Catlow

Total Alpha and Total Beta
Fusion Dissolution

Samples were prepared in batch, but
counted randomly.

	Description	Lab. Id.
1	Initial Check Standard	F0057
2	Blank	F0072
3	Sample 89-043	F0058
4	Duplicate 89-043	F0059
5	Spike 89-043	F0060
6	Sample 89-082	F0710
7	Duplicate 89-082	F0711
8	Sample 89-083	F0734
9	Duplicate 89-083	F0735
10	Ending Check Standard	F0737
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Standard	83B44/10 mL			10 mL
Spike	83B44/10 mL	Sample/1.0 uL		10.001 mL

Interim

4/04/90

Rev. E

SSST-102
2

Prepared by: H. S. Rich
Signature

H. S. Rich
Printed Name

Date: 05-14-90

Verified by: C. M. Seidel
Signature

C. M. Seidel
Printed Name

Date: 05-14-90

Approved by: L. H. Taylor
Signature

L. H. Taylor
Printed Name

Date: 9-28-90

**Single Shell Tank
Calibration Record**

**Phase
I-A**

Analyte: Am^{241}

Procedure L-508-002

Revision: A-0

Instrument: Detector #18

Property Number: WA93415

Technologist: R. A. Jones

Payroll Number: 65801

Date: 06/28/89

Calibration Standard ID: 36B40A3; 36B40B3, 36B40C3

Analyte Concentration: 61800, 110700, 161400 cpm

Type of Calibration: Efficiency

	Dilution	Concentration	Instrument Reading Units =
1			
2			
3			
4	SEE ATTACHED SHEETS		
5			
6			
7			
8			
9			
10			

Interim

Comments:

Rev. (Draft) 1/18/89

Prepared by:

Signature

H. S. Rich
Printed Name

Date: 05-17-90

Verified by:

Signature

C. M. Seidel
Printed Name

Date: 5/21/90

SST-103

Approved by:

Signature

L.H. Taylor
Printed Name

Date: 9/28/90

CALIBRATION SHEET FOR ALPHA/BETA SYSTEMS: USING PROCEDURE LQ-508-002

DETECTOR No. 18
 RADIONUCLIDE: Am-241 TIME ZERO DATE (HD): 15897
 HALF LIFE: 154497 DATE COUNTED (HD): 16347
 COUNT TIME: 5
 CPM BKG: 0.2 CALIBRATED BY: RA JONES HD O = 09/25/44

STANDARD ID	SIZE	DATE	TIME	COUNTS @ 0 DEG.	COUNTS @ 90 DEG.	COUNTS @ 180 DEG.	COUNTS @ 270 DEG.
36B40A8	1						
36B40B7	1						
36B40C7	1						
36B40A3	2	06/28/80	1542	67207	66768	67025	66645
36B40B3	2	06/28/80	1547	115573	116337	116289	116143
36B40C3	2	06/28/80	1552	162269	162819	162370	161593
36B40A6	5	06/28/80	1558	61627	62404	61970	61272
36B40B6	5	06/28/80	1603	118582	119217	118566	119430
36B40C5	5	06/28/80	1608	164322	165699	166216	166176

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
36B40A8	1"	60570	-0	1.00	-0	-0.0000
36B40B7	1"	109900	-0	1.00	-0	-0.0000
36B40C7	1"	159700	-0	1.00	-0	-0.0000
AVERAGE, 1" =		-0.0000 +/- @95%	0.0000	-97.62 %	ON	06/28/89
STANDARD ID		STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
36B40A3	2"	61800	13382	1.00	13409	0.2170
36B40B3	2"	110700	23217	1.00	23264	0.2102
36B40C3	2"	161400	32452	1.00	32518	0.2015
AVERAGE, 2" =		0.2095 +/- @95%	0.0152	7.27 %	ON	06/28/89
STANDARD ID		STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
36B40A6	5"	59470	12363	1.00	12388	0.2083
36B40B6	5"	109800	23790	1.00	23838	0.2171
36B40C5	5"	160100	33120	1.00	33187	0.2073
AVERAGE, 5" =		0.2109 +/- @95%	0.0106	5.01 %	ON	06/28/89
NEW EFFS FOR DET		18 Am-241	1" =	-0.0000	2" =	0.2095
			5" =	0.2109		

**Single Shell Tank
Calibration Record**

**Phase
I-A**

Analyte: Co^{60}

Procedure LQ-508-002

Revision: A-0

Instrument: Detector #18

Property Number: WA93415

Technologist: R. A. Jones

Payroll Number: 65801

Date: 06/28/89

Calibration Standard ID: 32B40A4, 32B40B3, 32B40C4

Analyte Concentration: 70480, 135100, 202400

Type of Calibration: Efficiency

	Dilution	Concentration	Instrument Reading Units =
1			
2			
3			
4	SEE ATTACHED SHEETS		
5			
6			
7			
8			
9			
10			

Interim

Comments:

Rev. (Draft) 1/18/89

Prepared by: R. A. Jones
Signature

H. S. Rich
Printed Name

Date: 05-17-90

Verified by: C. M. Seidel
Signature

C. M. Seidel
Printed Name

Date: 5/21/90

SST-103

Approved by: L.H. Taylor
Signature

L.H. Taylor
Printed Name

Date: 9/28/90

CALIBRATION SHEET FOR ALPHA/BETA SYSTEMS: USING PROCEDURE LQ-508-002

DETECTOR No. 18
 RADIONUCLIDE: Co-60
 HALF LIFE: 1925
 COUNT TIME: 5
 CPM BKG: 5
 CPM 1" BKG:
 CALIBRATED BY: RA JONES HD 0 = 09/25/44

STANDARD ID	SIZE	DATE	TIME	COUNTS @ 0 DEG.	COUNTS @ 90 DEG.	COUNTS @ 180 DEG.	COUNTS @ 270 DEG.
100B40A2	1						
100B40B1	1						
100B40C1	1						
32B40A4	2	06/28/89	1510	95552	95030	96367	94943
32B40B3	2	06/28/89	1515	179993	179923	180564	179845
32B40C4	2	06/28/89	1521	266251	266109	266791	262848
32B40A5	5	06/28/89	1526	80056	79664	81559	79720
32B40B6	5	06/28/89	1531	159760	162820	161429	163674
32B40C5	5	06/28/89	1536	234482	235955	237348	236432

STANDARD ID	SIZE	STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
100B40A2	1"	67290	0	0.00	0	0.0000
100B40B1	1"	137800	0	0.00	0	0.0000
100B40C1	1"	199700	0	0.00	0	0.0000
AVERAGE, 1" =		0.0000 +/- 0.95%	0.0000	ERR %	ON	06/28/89
STANDARD ID		STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
32B40A4	2"	70480	19090	1.18	22561	0.3201
32B40B3	2"	135100	36011	1.18	42560	0.3150
32B40C4	2"	202400	53095	1.18	62750	0.3100
AVERAGE, 2" =		0.3151 +/- 0.95%	0.0099	3.13 %	ON	06/28/89
STANDARD ID		STD VALUE	AVE CPM	DECAY CORR	DECAY CORR CPM	EFFICIENCY
32B40A5	5"	70160	16045	1.18	18963	0.2703
32B40B6	5"	135700	32379	1.18	38267	0.2820
32B40C5	5"	201900	47206	1.18	55790	0.2763
AVERAGE, 5" =		0.2762 +/- 0.95%	0.0115	4.16 %	ON	06/28/89
NEW EFFS FOR DET		18 Co-60	1" =	0.0000	2" =	0.3151
				5" =		0.2762

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WA38021
Procedure / Rev	LA-548-121/C-2
Technologist	6B598/R.D. Hale
Date	1-10-90
Temperature	24 C
Starting Time	11:00
Ending Time	12:00
Chemist	S. A. Catlow

GEA Analysis
Fusion Dissolution
Samples are prepared in batch, but counted randomly.
Detectors 1,2, and 3

	Description	Lab. Id.
1	Initial Check Standard	F0057
2	Blank	F0748
3	Sample 89-043	F0058
4	Duplicate 89-043	F0059
5	Sample 89-049	F0178
6	Duplicate 89-049	F0179
7	Sample 89-082	F0710
8	Duplicate 89-082	F0711
9	Sample 89-083	F0734
10	Duplicate 89-083	F0735
11	Spike 89-083	F0736

	Description	Lab. Id.
12	Ending Check Standard	F0737
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

	Primary Book	Second Book	Third Book	Final Volume of Standard
Standard Type	No. & Aliquot	No. & Aliquot	No. & Aliquot	
LMCS Check Standard	89B44/500 uL			22 mL
Spike	89B44/500 uL	Sample/500 uL		22 mL

Interim

Rev E 4/04/90

SST-102

Prepared by:	<u>S. A. Catlow</u> Signature	H. S. Rich Printed Name	Date: 05-11-90
Verified by:	<u>C. M. Seidel</u> Signature	C. M. Seidel Printed Name	Date: 05-11-90
Approved by:	<u>L. H. Taylor</u> Signature	L. H. Taylor Printed Name	Date: 9-28-90

**Single Shell Tank
Calibration Record**

**Phase
I-A**

Analyte: Isotope, Mixed Gamma

Procedure	LQ-508-003	Revision:	A-0
Instrument:	GEA Detector #1	Property Number:	401934
Technologist:	JL Anderson	Payroll Number:	61413

Date: 3/2/89

Calibration Standard ID: 56B40 D1

Analyte Concentration: N/A

Type of Calibration: Gamma Energy Analysis (Efficiency)

	Dilution	Concentration	Instrument Reading Units =
1			
2			
3	SEE ATTACHED		
4			
5			
6			
7			
8			
9			
10			

Interim

Comments:

1/18/89

Rev. (Draft)

Prepared by: H. S. Rich
Signature

H. S. Rich
Printed Name

Date: 05/17/90

SST-103

Verified by: C. M. Seidel
Signature

C. M. Seidel
Printed Name

Date: 5/21/90

Approved by: L.H. Taylor
Signature

L.H. Taylor
Printed Name

Date: 9/28/90

DETECTOR: 1
 GEOMETRY CODE: 42
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 14-Feb-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV) EFFICIENCY (COUNTS/GAMMA)

59.536	5.721347E-03
88.032	1.512568E-02
122.0614	2.041958E-02
165.853	1.856472E-02
279.1967	
391.668	1.042777E-02
513.99	7.856059E-03
661.65	6.838966E-03
898.021	5.300244E-03
1173.237	4.218416E-03
1332.501	3.785537E-03
1836.129	2.931033E-03

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -5.343694\text{E+01} \\ & + 2.034704\text{E+01} * \text{LOG(ENERGY)} \\ & + -2.088264\text{E+00} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & 8.372735\text{E+00} \\ & + -7.762489\text{E+00} * \text{LOG(ENERGY)} \\ & + 2.017698\text{E+00} * \text{LOG(ENERGY)}^2 \\ & + -2.447560\text{E-01} * \text{LOG(ENERGY)}^3 \\ & + 1.067720\text{E-02} * \text{LOG(ENERGY)}^4 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 1
 GEOMETRY CODE: 43
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 16-Feb-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV) EFFICIENCY (COUNTS/GAMMA)

59.536	1.397695E-03
88.032	3.641448E-03
122.0614	5.035820E-03
165.853	4.620516E-03
279.1967	
391.668	2.619018E-03
513.99	1.890740E-03
661.65	1.782478E-02
898.021	1.392563E-03
1173.237	1.117189E-03
1332.501	1.007670E-03
1836.129	7.782502E-04

EQUATION 0-165 KEV

$$\text{LOG(EFF)} = -5.354869\text{E+01}$$

+ 1.975356E+01 *LOG(ENERGY)
+ -2.020858E+00 *LOG(ENERGY)^2

EQUATION 165-1836 KEV

LOG(EFF) = 4.001880E+01
+ -2.857555E+01 *LOG(ENERGY)
+ 6.748440E+00 *LOG(ENERGY)^2
+ 7.173093E-01 *LOG(ENERGY)^3
+ 2.821780E-02 *LOG(ENERGY)^4

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

7
6
5
4
3
2
1
9

**Single Shell Tank
Calibration Record**

**Phase
I-A**

Analyte: Mixed Isotope Standards

Procedure LQ-508-003

Revision: A-0

Instrument: GEA Detector #2

Property Number: 401934

Technologist: JL Anderson

Payroll Number: 61413

Date: 9-1-88

Calibration Standard ID: 56B40 D1

Analyte Concentration: N/A

Type of Calibration: Gamma Energy Analysis (Efficiency)

	Dilution	Concentration	Instrument Reading Units =
1			
2			
3	SEE ATTACHED		
4			
5			
6			
7			
8			
9			
10			

Interim

Comments:

Rev.(Draft) 1/18/89

Prepared by:

Signature

H. S. Rich
Printed Name

Date: 05/17/90

Verified by:

Signature

C. M. Seidel
Printed Name

Date: 5/21/90

SST-103

Approved by:

Signature

L.H. Taylor
Printed Name

Date: 9/28/90

DETECTOR: 2
 GEOMETRY CODE: 42
 GEOMETRY DECSRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 21-Oct-88
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	3.417000E-03
88.032	1.090000E-02
122.0614	1.408000E-02
165.853	1.516000E-02
279.1967	9.929000E-03
391.668	7.578000E-03
513.99	5.875000E-03
661.65	4.927000E-03
898.021	3.727000E-03
1173.237	3.085000E-03
1332.501	2.683000E-03
1836.129	2.102000E-03

EQUATION 0-122 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -6.654070\text{E+01} \\ & + 2.583780\text{E+01} * \text{LOG(ENERGY)} \\ & + -2.677550\text{E+00} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 122-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -1.050740\text{E+02} \\ & + 6.428950\text{E+01} * \text{LOG(ENERGY)} \\ & + -1.503170\text{E+01} * \text{LOG(ENERGY)}^2 \\ & + 1.533670\text{E+00} * \text{LOG(ENERGY)}^3 \\ & + -5.838530\text{E-02} * \text{LOG(ENERGY)}^4 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 2
 GEOMETRY CODE: 43
 GEOMETRY DECSRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 28-Sep-88
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	1.476000E-03
88.032	4.721000E-03
122.0614	6.589000E-03
165.853	6.613000E-03
279.1967	4.692000E-03
391.668	3.542000E-03
513.99	2.810000E-03
661.65	2.327000E-03
898.021	1.790000E-03
1173.237	1.437000E-03
1332.501	1.277000E-03
1836.129	9.824000E-04

EQUATION 0-165 KEV

LOG(EFF) = -5.826830E+01
+ 2.165450E+01 *LOG(ENERGY)
+ -2.198930E+00 *LOG(ENERGY)^2

EQUATION 165-1836 KEV

LOG(EFF) = -2.233890E+01
+ 1.174520E+01 *LOG(ENERGY)
+ -2.739550E+00 *LOG(ENERGY)^2
+ 2.655450E-01 *LOG(ENERGY)^3
+ -9.668420E-03 *LOG(ENERGY)^4

**Single Shell Tank
Calibration Record**

**Phase
I-A**

Analyte: Mixed Isotope Standards

Procedure LQ-508-003

Revision: A-0

Instrument: GEA Detector #3

Property Number: WA77228

Technologist: J. L. Anderson

Payroll Number: 61413

Date: 02/07/89

Calibration Standard ID: 56B40 D1

Analyte Concentration: N/A

Type of Calibration: Gamma Energy Analysis (Efficiency)

	Dilution	Concentration	Instrument Reading Units =
1			
2			
3			
4	SEE ATTACHED		
5			
6			
7			
8			
9			
10			

Interim

Comments:

Rev.(Draft) 1/18/89

Prepared by:

Signature

H. S. Rich
Printed Name

Date: 05/17/90

Verified by:

Signature

C. M. Seidel
Printed Name

Date: 5/21/90

SST-103

Approved by:

Signature

L.H. Taylor
Printed Name

Date: 9/26/90

DETECTOR: 3
 GEOMETRY CODE: 41
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 1
 CALIBRATION DATE: 2-Jul-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	2.833765E-02
88.032	2.881764E-02
122.0614	2.756557E-02
165.853	2.270614E-02
279.1967	
391.668	1.285730E-02
513.99	
661.65	7.841011E-03
898.021	5.779292E-03
1173.237	4.773005E-03
1332.501	4.278530E-03
1836.129	3.371238E-03

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -1.113845\text{E+01} \\ & + 3.484260\text{E+00} * \text{LOG(ENERGY)} \\ & + -3.990659\text{E-01} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -2.052334\text{E+01} \\ & + 9.121738\text{E+00} * \text{LOG(ENERGY)} \\ & + -1.553578\text{E+00} * \text{LOG(ENERGY)}^2 \\ & + 8.018036\text{E-02} * \text{LOG(ENERGY)}^3 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 3
 GEOMETRY CODE: 42
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 2
 CALIBRATION DATE: 2-Jul-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	7.455306E-03
88.032	7.462748E-03
122.0614	7.578302E-03
165.853	6.965814E-03
279.1967	
391.668	3.596591E-03
513.99	
661.65	2.318396E-03
898.021	1.824191E-03
1173.237	1.461179E-03
1332.501	1.321243E-03
1836.129	1.011332E-03

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -6.838496\text{E+00} \\ & + 8.819509\text{E-01} * \text{LOG(ENERGY)} \\ & + -9.970528\text{E-02} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & 3.082260\text{E-01} \\ & + -1.410839\text{E+00} * \text{LOG(ENERGY)} \\ & + 1.042898\text{E-01} * \text{LOG(ENERGY)}^2 \\ & + -5.874725\text{E-03} * \text{LOG(ENERGY)}^3 \end{aligned}$$

GEA CALIBRATION RECORD

PROCEDURE LQ-508-003

DETECTOR: 3
 GEOMETRY CODE: 43
 GEOMETRY DESCRIPTION: 22 ML LIQUID, POS 3
 CALIBRATION DATE: 2-Jul-89
 ANALYST(S): J. L. ANDERSON/M. R. DOWELL
 STANDARD ID: 56B40 D1

ENERGY (KEV)	EFFICIENCY (COUNTS/GAMMA)
59.536	2.020462E-03
88.032	1.924344E-03
122.0614	2.027231E-03
165.853	1.712371E-03
279.1967	
391.668	1.056509E-03
513.99	
661.65	7.115743E-04
898.021	5.243928E-04
1173.237	4.551585E-04
1332.501	4.223636E-04
1836.129	3.139091E-04

EQUATION 0-165 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -5.300788\text{E+00} \\ & + -3.550643\text{E-01} * \text{LOG(ENERGY)} \\ & + 3.272635\text{E-02} * \text{LOG(ENERGY)}^2 \end{aligned}$$

EQUATION 165-1836 KEV

$$\begin{aligned} \text{LOG(EFF)} = & -9.815549\text{E+00} \\ & + 2.402920\text{E+00} * \text{LOG(ENERGY)} \\ & + -4.428877\text{E-01} * \text{LOG(ENERGY)}^2 \\ & + 2.059131\text{E-02} * \text{LOG(ENERGY)}^3 \end{aligned}$$

*
* G A M M A S P E C T R U M A N A L Y S I S *
*

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

11-MAY-90 12:34:54

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 1.0
DETECTOR NUMBER: 1 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.00 SIGMA UNCERTAINTY

LLD CALCULATION PERFORMED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD1010
ANALYZED BY: DM

SAMPLE DESCRIPTION: F-57 SEGMENT-6
GEOMETRY DESCRIPTION:
SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 10:17:03

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3006. SECONDS
DEAD TIME: 0.20 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 23-NOV-89
EFFICIENCY CALIBRATION PERFORMED 2-MAR-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1126.99	562.97	1.34	572.	711.	6.7	CS-134, EU-152
2C	1139.12	569.03	1.34	587.	1296.	5.9	CS-134, BI-207
3\$	1209.92	604.42	1.39	552.	8190.	1.4	CS-134
4	1323.77	661.33	1.51	359.	12052.	0.9	CS-137
5C	1592.12	795.49	1.52	316.	5792.	1.6	CS-134
6C	1604.28	801.57	1.52	297.	511.	5.4	CS-134
7	2346.63	1172.87	1.90	201.	5305.	1.4	CO-60
8	2665.19	1332.27	1.92	34.	4790.	1.5	CO-60
9	2730.35	1364.88	1.34	16.	143.	9.5	CS-134
10\$	2798.23	1398.86	1.04	7.	14.	34.0	I-132
11\$	2801.29	1400.39	1.04	10.	35.	21.6	BI-214
12	2921.74	1460.68	1.81	21.	154.	9.4	K-40

` ERROR QUOTATION AT 1.00 SIGMA

` PEAK CONFIDENCE LEVEL AT 85.0%

` - MULTIPLET ANALYSIS CONVERGED NORMALLY

` \$ - MULTIPLET ANALYSIS CONVERGED DUE TO LACK OF CHI-SQ IMPROVEMENT

SAMPLE: F-57 SEGMENT-6

DATA COLLECTED ON 10-JAN-90 AT 10:17:03

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE ACTIVITY CONCENTRATION IN $\mu\text{Ci}/\text{L}$

DECAY

MEASURED ERROR CORRECTED ERROR

AC-228	LLD<7.93E-01		LLD<7.93E-01	
AG-108M	LLD<2.33E-01		LLD<2.33E-01	
AG-110M	LLD<1.04E+00		LLD<1.04E+00	
AM-241	LLD<8.97E-01		LLD<8.97E-01	
AM-243	LLD<2.40E-01		LLD<2.40E-01	
AR-41	LLD<1.37E-01		LLD<1.37E-01	
AU-198	LLD<1.95E-01		LLD<1.95E-01	
BA-133	LLD<2.98E-01		LLD<2.98E-01	
BA-139	LLD<5.98E-01		LLD<5.98E-01	
BA-140	LLD<7.87E-01		LLD<7.87E-01	
BA-141	LLD<5.95E-01		LLD<5.95E-01	
BE-7	LLD<1.99E+00		LLD<1.99E+00	
BI-207	LLD<2.05E-01		LLD<2.05E-01	
BI-212	LLD<2.45E+00		LLD<2.45E+00	
BI-214	LLD<1.07E+00		LLD<1.07E+00	
CD-109	LLD<3.47E+00		LLD<3.47E+00	
CE-139	LLD<1.35E-01		LLD<1.35E-01	
EE-141	LLD<2.07E-01		LLD<2.07E-01	
CEPR144	LLD<1.69E+00		LLD<1.69E+00	
CO-56	LLD<1.93E-01		LLD<1.93E-01	
CO-57	LLD<1.11E-01		LLD<1.11E-01	
CO-58	LLD<1.82E-01		LLD<1.82E-01	
CO-60	2.28E+01	+3.55E-01	2.28E+01	+3.55E-01
CR-51	LLD<1.52E+00		LLD<1.52E+00	
GS-134	2.09E+01	+3.51E-01	2.09E+01	+3.51E-01
CS-136	LLD<1.81E-01		LLD<1.81E-01	
CS-137	3.74E+01	+4.22E-01	3.74E+01	+4.22E-01
CS-138	LLD<1.47E-01		LLD<1.47E-01	
EU-152	LLD<3.74E-01		LLD<3.74E-01	
EU-154	LLD<3.68E-01		LLD<3.68E-01	
EU-155	LLD<4.27E-01		LLD<4.27E-01	
FE-59	LLD<4.36E-01		LLD<4.36E-01	
HF-181	LLD<2.27E-01		LLD<2.27E-01	
HG-203	LLD<1.83E-01		LLD<1.83E-01	
I-131	LLD<2.22E-01		LLD<2.22E-01	
I-132	LLD<2.35E-01		LLD<2.35E-01	
I-133	LLD<2.18E-01		LLD<2.18E-01	
I-134	LLD<2.72E-01		LLD<2.72E-01	
I-135	LLD<4.79E-01		LLD<4.79E-01	
K-40	7.37E+00	+6.95E-01	7.37E+00	+6.95E-01
KR-85	LLD<4.44E+01		LLD<4.44E+01	
KR-85M	LLD<1.30E-01		LLD<1.30E-01	
KR-87	LLD<4.96E-01		LLD<4.96E-01	
KR-89	LLD<7.31E+00		LLD<7.31E+00	
LA-140	LLD<7.82E-02		LLD<7.82E-02	
LA-142	LLD<4.24E-01		LLD<4.24E-01	
MN-54	LLD<1.91E-01		LLD<1.91E-01	

MN-56	LLD<2.17E-01	LLD<2.17E-01
NA-22	LLD<1.18E-01	LLD<1.18E-01
NA-24	LLD<2.05E-01	LLD<2.05E-01
NB-94	LLD<1.66E-01	LLD<1.66E-01
NB-95	LLD<1.61E-01	LLD<1.61E-01
NB-97	LLD<1.27E+00	LLD<1.27E+00
NP-238	LLD<8.45E-01	LLD<8.45E-01
NP-239	LLD<1.05E+00	LLD<1.05E+00
PA-233	LLD<4.49E-01	LLD<4.49E-01
PA-234M	LLD<3.98E+01	LLD<3.98E+01
PB-210	LLD<5.29E+00	LLD<5.29E+00
PB-212	LLD<3.30E-01	LLD<3.30E-01
PB-214	LLD<4.99E-01	LLD<4.99E-01
PO-210	LLD<1.89E+04	LLD<1.89E+04
PO-214	LLD<8.40E+03	LLD<8.40E+03
PO-216	LLD<1.62E+04	LLD<1.62E+04
PU-239	LLD<1.47E+03	LLD<1.47E+03
PU-241	LLD<5.18E+04	LLD<5.18E+04
RA-224	LLD<3.47E+00	LLD<3.47E+00
RA-226	LLD<3.23E+00	LLD<3.23E+00
RB-88	LLD<9.86E-01	LLD<9.86E-01
RB-89	LLD<1.02E+00	LLD<1.02E+00
RN-220	LLD<1.74E+02	LLD<1.74E+02
RU-103	LLD<2.08E-01	LLD<2.08E-01
RURH106	LLD<3.64E+00	LLD<3.64E+00
SB-124	LLD<3.10E-01	LLD<3.10E-01
SB-125	LLD<1.65E+00	LLD<1.65E+00
SC-46	LLD<2.18E-01	LLD<2.18E-01
SE-75	LLD<2.43E-01	LLD<2.43E-01
SN-113	LLD<2.81E-01	LLD<2.81E-01
SR-85	LLD<1.95E-01	LLD<1.95E-01
SR-91	LLD<3.33E-01	LLD<3.33E-01
SR-92	LLD<9.88E-02	LLD<9.88E-02
TA-182	LLD<6.15E-01	LLD<6.15E-01
TC-99M	LLD<1.08E-01	LLD<1.08E-01
TE-123M	LLD<1.24E-01	LLD<1.24E-01
TE-125M	LLD<3.14E+01	LLD<3.14E+01
TE-132	LLD<1.53E-01	LLD<1.53E-01
TH-228	LLD<1.07E+01	LLD<1.07E+01
TL-208	LLD<2.43E-01	LLD<2.43E-01
U-235	LLD<2.15E-01	LLD<2.15E-01
U-237	LLD<6.21E-01	LLD<6.21E-01
W-187	LLD<5.63E-01	LLD<5.63E-01
XE-131M	LLD<5.43E+00	LLD<5.43E+00
XE-133	LLD<3.72E-01	LLD<3.72E-01
XE-133M	LLD<1.35E+00	LLD<1.35E+00
XE-135	LLD<1.58E-01	LLD<1.58E-01
XE-138	LLD<1.20E+00	LLD<1.20E+00
Y-88	LLD<9.35E-02	LLD<9.35E-02
Y-91	LLD<4.36E+01	LLD<4.36E+01
Y-91M	LLD<2.52E-01	LLD<2.52E-01
ZN-65	LLD<4.86E-01	LLD<4.86E-01
ZR-95	LLD<3.24E-01	LLD<3.24E-01
ZR-97	LLD<1.80E-01	LLD<1.80E-01

TOTAL 8.84E+01 +-9.54E-01 8.84E+01 +-9.54E-01

E BAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 1.58E-09 UC/LI

TOTAL MEASURED ACTIVITY = 8.84E+01 (+-9.54E-01) UC/LI

% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.00 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1126.99	562.97	711.	6.7	3.04E+01
1139.12	569.03	1296.	5.9	5.60E+01
1604.28	801.57	511.	5.4	2.93E+01
2730.35	1364.88	143.	9.5	1.28E+01
2798.23	1398.86	14.	34.0	1.24E+00
2801.29	1400.39	35.	21.6	3.18E+00

* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* G A M M A S P E C T R U M A N A L Y S I S *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

11-MAY-90 13:06:27

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.00 SIGMA UNCERTAINTY

LLD CALCULATION PERFORMED

MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3893

ANALYZED BY: DM

SAMPLE DESCRIPTION: F-748 SEGMENT-U

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 1.0000E+00

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 15:04:27

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3002. SECONDS

DEAD TIME: 0.07 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-OCT-89

EFFICIENCY CALIBRATION PERFORMED 31-JUL-89

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	703.58	352.00	1.81	172.	137.	16.0	PB-214
2	1166.52	583.30	1.47	116.	96.	20.1	EU-154, TL-208
3	1218.44	609.25	1.35	85.	168.	11.5	BI-214, RU-103
4	1323.28	661.64	1.59	106.	63.	28.1	CS-137
5	2921.43	1460.81	2.36	14.	639.	4.1	K-40

ERROR QUOTATION AT 1.00 SIGMA
PEAK CONFIDENCE LEVEL AT 85.0%

SAMPLE: F-748 SEGMENT-U

DATA COLLECTED ON 10-JAN-90 AT 15:04:27

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE ACTIVITY CONCENTRATION IN uCi/LI
DECAY

MEASURED ERROR CORRECTED ERROR

AC-228	LLD<4.91E-01		LLD<4.91E-01	
AG-108M	LLD<1.19E-01		LLD<1.19E-01	
AG-110M	LLD<1.85E-01		LLD<1.85E-01	
AM-241	LLD<1.83E-01		LLD<1.83E-01	
AM-243	LLD<1.15E-01		LLD<1.15E-01	
AR-41	LLD<2.44E-01		LLD<2.44E-01	
AU-198	LLD<1.17E-01		LLD<1.17E-01	
BA-133	LLD<1.82E-01		LLD<1.82E-01	
BA-139	LLD<4.46E-01		LLD<4.46E-01	
BA-140	LLD<5.08E-01		LLD<5.08E-01	
BA-141	LLD<4.81E-01		LLD<4.81E-01	
BE-7	LLD<1.05E+00		LLD<1.05E+00	
BI-207	LLD<1.21E-01		LLD<1.21E-01	
BI-212	LLD<2.03E+00		LLD<2.03E+00	
BI-214	1.36E+00	+-1.57E-01	1.36E+00	+-1.57E-01
CD-109	LLD<2.36E+00		LLD<2.36E+00	
CE-139	LLD<1.01E-01		LLD<1.01E-01	
CE-141	LLD<1.80E-01		LLD<1.80E-01	
CEPR144	LLD<1.58E+00		LLD<1.58E+00	
CO-56	LLD<1.40E-01		LLD<1.40E-01	
CO-57	LLD<1.03E-01		LLD<1.03E-01	
CO-58	LLD<1.46E-01		LLD<1.46E-01	
CO-60	LLD<1.62E-01		LLD<1.62E-01	
CR-51	LLD<1.01E+00		LLD<1.01E+00	
CS-134	LLD<1.56E-01		LLD<1.56E-01	
CS-136	LLD<1.31E-01		LLD<1.31E-01	
CS-137	2.88E-01	+-8.10E-02	2.88E-01	+-8.10E-02
CS-138	LLD<3.36E-01		LLD<3.36E-01	
EU-152	LLD<6.62E-01		LLD<6.62E-01	
EU-154	LLD<3.82E-01		LLD<3.82E-01	
EU-155	LLD<3.77E-01		LLD<3.77E-01	
FE-59	LLD<3.13E-01		LLD<3.13E-01	
HF-181	LLD<1.39E-01		LLD<1.39E-01	
HG-203	LLD<1.28E-01		LLD<1.28E-01	
I-131	LLD<1.25E-01		LLD<1.25E-01	
I-132	LLD<1.55E-01		LLD<1.55E-01	
I-133	LLD<1.35E-01		LLD<1.35E-01	
I-134	LLD<2.02E-01		LLD<2.02E-01	
I-135	LLD<6.16E-01		LLD<6.16E-01	
K-40	4.40E+01	+-1.87E+00	4.40E+01	+-1.87E+00
KR-85	LLD<3.55E+01		LLD<3.55E+01	
KR-85M	LLD<1.35E-01		LLD<1.35E-01	
KR-87	LLD<2.80E-01		LLD<2.80E-01	
KR-89	LLD<5.03E+00		LLD<5.03E+00	
LA-140	LLD<1.68E-01		LLD<1.68E-01	
LA-142	LLD<2.98E-01		LLD<2.98E-01	
MN-54	LLD<1.63E-01		LLD<1.63E-01	

MN-56	LLD<1.58E-01	LLD<1.58E-01		
NA-22	LLD<1.61E-01	LLD<1.61E-01		
NA-24	LLD<1.18E-01	LLD<1.18E-01		
NB-94	LLD<1.50E-01	LLD<1.50E-01		
NB-95	LLD<1.49E-01	LLD<1.49E-01		
NB-97	LLD<2.24E-01	LLD<2.24E-01		
NP-238	LLD<5.20E-01	LLD<5.20E-01		
NP-239	LLD<7.21E-01	LLD<7.21E-01		
PA-233	LLD<2.78E-01	LLD<2.78E-01		
PA-234M	LLD<2.48E+01	LLD<2.48E+01		
PB-210	LLD<2.93E+00	LLD<2.93E+00		
PB-212	LLD<2.44E-01	LLD<2.44E-01		
PB-214	LLD<2.88E-01	LLD<2.88E-01		
PO-210	LLD<1.18E+04	LLD<1.18E+04		
PO-214	LLD<1.44E+03	LLD<1.44E+03		
PO-216	LLD<7.22E+03	LLD<7.22E+03		
PU-239	LLD<1.38E+03	LLD<1.38E+03		
PU-241	LLD<4.50E+04	LLD<4.50E+04		
RA-224	LLD<2.73E+00	LLD<2.73E+00		
RA-226	LLD<2.85E+00	LLD<2.85E+00		
RB-88	LLD<1.63E+00	LLD<1.63E+00		
RB-89	LLD<6.80E-01	LLD<6.80E-01		
RN-220	LLD<1.09E+02	LLD<1.09E+02		
RU-103	LLD<1.19E-01	LLD<1.19E-01		
RURH106	LLD<2.75E+00	LLD<2.75E+00		
SB-124	LLD<1.35E-01	LLD<1.35E-01		
SB-125	LLD<1.28E+00	LLD<1.28E+00		
SC-46	LLD<1.70E-01	LLD<1.70E-01		
SE-75	LLD<1.70E-01	LLD<1.70E-01		
SN-113	LLD<1.73E-01	LLD<1.73E-01		
SR-85	LLD<1.56E-01	LLD<1.56E-01		
SR-91	LLD<2.23E-01	LLD<2.23E-01		
SR-92	LLD<2.43E-01	LLD<2.43E-01		
TA-182	LLD<5.63E-01	LLD<5.63E-01		
TC-99M	LLD<9.87E-02	LLD<9.87E-02		
TE-123M	LLD<1.01E-01	LLD<1.01E-01		
TE-125M	LLD<2.98E+01	LLD<2.98E+01		
TE-132	LLD<1.18E-01	LLD<1.18E-01		
TH-228	LLD<6.25E+00	LLD<6.25E+00		
TL-208	4.00E-01	+ -8.07E-02	4.00E-01	+ -8.07E-02
U-235	LLD<1.70E-01	LLD<1.70E-01		
U-237	LLD<4.75E-01	LLD<4.75E-01		
W-187	LLD<4.80E-01	LLD<4.80E-01		
XE-131M	LLD<4.40E+00	LLD<4.40E+00		
XE-133	LLD<2.01E-01	LLD<2.01E-01		
XE-133M	LLD<9.81E-01	LLD<9.81E-01		
XE-135	LLD<1.18E-01	LLD<1.18E-01		
XE-138	LLD<8.70E-01	LLD<8.70E-01		
Y-88	LLD<1.54E-01	LLD<1.54E-01		
Y-91	LLD<6.53E+01	LLD<6.53E+01		
Y-91M	LLD<1.69E-01	LLD<1.69E-01		
ZN-65	LLD<3.86E-01	LLD<3.86E-01		
ZR-95	LLD<2.48E-01	LLD<2.48E-01		
ZR-97	LLD<1.40E-01	LLD<1.40E-01		
<hr/>				
TOTAL	4.61E+01	+ -1.88E+00	4.61E+01	+ -1.88E+00

EBAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 3.89E-13 UC/LI

TOTAL MEASURED ACTIVITY = 4.61E+01 (+-1.88E+00) UC/LI

% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.00 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
703.58	352.00	137.	16.0	1.19E+01

*
* G A M M A S P E C T R U M A N A L Y S I S *
*

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

11-MAY-90 12:44:59

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 2.0
DETECTOR NUMBER: 2 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.00 SIGMA UNCERTAINTY

LLD CALCULATION PERFORMED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD2750
ANALYZED BY: DM

SAMPLE DESCRIPTION: F-58 SEGMENT-7

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-02
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 10:19:59

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3001. SECONDS
DEAD TIME: 0.03 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-MAR-89
EFFICIENCY CALIBRATION PERFORMED 21-OCT-88

222-S COUNTING ROOM

11-MAY-90 12:44:59

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	1324.12	661.67	1.65	48.	1651.	2.5	CS-137
2	2921.28	1460.18	2.24	19.	133.	10.4	K-40

ERROR QUOTATION AT 1.00 SIGMA
PEAK CONFIDENCE LEVEL AT 85.0%

222-S COUNTING ROOM

11-MAY-90 12:44:59

SAMPLE: F-58 SEGMENT-7

DATA COLLECTED ON 10-JAN-90 AT 10:19:59

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

R A D I O N U C L I D E A N A L Y S I S R E P O R T

NUCLIDE ACTIVITY CONCENTRATION IN uCi/LI
 DECAY

MEASURED ERROR CORRECTED ERROR

AC-228	LLD<3.43E+00		LLD<3.43E+00
AG-108M	LLD<1.04E+00		LLD<1.04E+00
AG-110M	LLD<6.02E+00		LLD<6.02E+00
AM-241	LLD<7.19E+00		LLD<7.19E+00
AM-243	LLD<2.12E+00		LLD<2.12E+00
AR-41	LLD<1.07E+00		LLD<1.07E+00
AU-198	LLD<9.34E-01		LLD<9.34E-01
BA-133	LLD<1.41E+00		LLD<1.41E+00
BA-139	LLD<3.54E+00		LLD<3.54E+00
BA-140	LLD<3.68E+00		LLD<3.68E+00
BA-141	LLD<3.24E+00		LLD<3.24E+00
BE-7	LLD<8.97E+00		LLD<8.97E+00
BI-207	LLD<9.40E-01		LLD<9.40E-01
BI-212	LLD<1.40E+01		LLD<1.40E+01
BI-214	LLD<1.94E+00		LLD<1.94E+00
CD-109	LLD<2.59E+01		LLD<2.59E+01
CE-139	LLD<8.00E-01		LLD<8.00E-01
CE-141	LLD<1.38E+00		LLD<1.38E+00
CEPR144	LLD<1.14E+01		LLD<1.14E+01
CO-56	LLD<9.64E-01		LLD<9.64E-01
CO-57	LLD<7.43E-01		LLD<7.43E-01
CO-58	LLD<8.57E-01		LLD<8.57E-01
CO-60	LLD<9.89E-01		LLD<9.89E-01
CR-51	LLD<7.54E+00		LLD<7.54E+00
CS-134	LLD<1.01E+00		LLD<1.01E+00
CS-136	LLD<9.99E-01		LLD<9.99E-01
GS-137	7.13E+01	+-1.87E+00	7.13E+01
CS-138	LLD<2.37E+00		LLD<2.37E+00
EU-152	LLD<4.20E+00		LLD<4.20E+00
EU-154	LLD<2.52E+00		LLD<2.52E+00
EU-155	LLD<3.55E+00		LLD<3.55E+00
FE-59	LLD<2.28E+00		LLD<2.28E+00
HF-181	LLD<1.26E+00		LLD<1.26E+00
HG-203	LLD<8.65E-01		LLD<8.65E-01
I-131	LLD<9.73E-01		LLD<9.73E-01
I-132	LLD<2.67E+00		LLD<2.67E+00
I-133	LLD<9.77E-01		LLD<9.77E-01
I-134	LLD<1.47E+00		LLD<1.47E+00
I-135	LLD<3.21E+00		LLD<3.21E+00
K-40	8.79E+01	+-9.20E+00	8.79E+01
KR-85	LLD<2.76E+02		LLD<2.76E+02
KR-85M	LLD<8.57E-01		LLD<8.57E-01
KR-87	LLD<2.05E+00		LLD<2.05E+00
KR-89	LLD<3.58E+01		LLD<3.58E+01
LA-140	LLD<8.48E-01		LLD<8.48E-01
LA-142	LLD<2.22E+00		LLD<2.22E+00
MN-54	LLD<9.16E-01		LLD<9.16E-01

MN-56	LLD<1.09E+00	LLD<1.09E+00
NA-22	LLD<8.97E-01	LLD<8.97E-01
NA-24	LLD<9.69E-01	LLD<9.69E-01
NB-94	LLD<8.56E-01	LLD<8.56E-01
NB-95	LLD<6.89E-01	LLD<6.89E-01
NB-97	LLD<6.81E+00	LLD<6.81E+00
NP-238	LLD<4.17E+00	LLD<4.17E+00
NP-239	LLD<5.28E+00	LLD<5.28E+00
PA-233	LLD<1.85E+00	LLD<1.85E+00
PA-234M	LLD<1.74E+02	LLD<1.74E+02
PB-210	LLD<2.26E+01	LLD<2.26E+01
PB-212	LLD<1.65E+00	LLD<1.65E+00
PB-214	LLD<2.07E+00	LLD<2.07E+00
PO-210	LLD<7.37E+04	LLD<7.37E+04
PO-214	LLD<8.29E+03	LLD<8.29E+03
PO-216	LLD<4.85E+04	LLD<4.85E+04
PU-239	LLD<1.08E+04	LLD<1.08E+04
PU-241	LLD<3.26E+05	LLD<3.26E+05
RA-224	LLD<1.70E+01	LLD<1.70E+01
RA-226	LLD<1.81E+01	LLD<1.81E+01
RB-88	LLD<6.30E+00	LLD<6.30E+00
RB-89	LLD<4.34E+00	LLD<4.34E+00
RN-220	LLD<7.29E+02	LLD<7.29E+02
RU-103	LLD<9.22E-01	LLD<9.22E-01
RURH106	LLD<1.71E+01	LLD<1.71E+01
SB-124	LLD<9.50E-01	LLD<9.50E-01
SB-125	LLD<9.71E+00	LLD<9.71E+00
SC-46	LLD<1.02E+00	LLD<1.02E+00
SE-75	LLD<1.32E+00	LLD<1.32E+00
SN-113	LLD<1.29E+00	LLD<1.29E+00
SR-85	LLD<1.21E+00	LLD<1.21E+00
SR-91	LLD<1.73E+00	LLD<1.73E+00
SR-92	LLD<1.06E+00	LLD<1.06E+00
TA-182	LLD<2.71E+00	LLD<2.71E+00
TG-99M	LLD<7.61E-01	LLD<7.61E-01
TE-123M	LLD<7.72E-01	LLD<7.72E-01
TE-125M	LLD<2.47E+02	LLD<2.47E+02
TF-132	LLD<7.75E-01	LLD<7.75E-01
TH-228	LLD<8.84E+01	LLD<8.84E+01
TL-208	LLD<9.86E-01	LLD<9.86E-01
U-235	LLD<1.21E+00	LLD<1.21E+00
U-237	LLD<3.29E+00	LLD<3.29E+00
W-187	LLD<3.21E+00	LLD<3.21E+00
XE-131M	LLD<3.43E+01	LLD<3.43E+01
XE-133	LLD<2.88E+00	LLD<2.88E+00
XE-133M	LLD<6.73E+00	LLD<6.73E+00
XE-135	LLD<7.66E-01	LLD<7.66E-01
XE-138	LLD<6.11E+00	LLD<6.11E+00
Y-88	LLD<5.98E-01	LLD<5.98E-01
Y-91	LLD<3.48E+02	LLD<3.48E+02
Y-91M	LLD<1.31E+00	LLD<1.31E+00
ZN-65	LLD<2.99E+00	LLD<2.99E+00
ZR-95	LLD<1.73E+00	LLD<1.73E+00
ZR-97	LLD<8.10E-01	LLD<8.10E-01

TOTAL 1.59E+02 +-9.38E+00 1.59E+02 +-9.38E+00

EBAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 2.58E-08 UC/LI

TOTAL MEASURED ACTIVITY = 1.59E+02 (+-9.38E+00) UC/LI

% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.00 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

ALL DETECTED PEAKS WERE USED IN THE ANALYSIS

6
C
C
C
C
C
C
2
T
-
9

*
* G A M M A S P E C T R U M A N A L Y S I S *
*

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM WESTINGHOUSE HANFORD

11-MAY-90 13:04:17

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 3.0
DETECTOR NUMBER: 3 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.00 SIGMA UNCERTAINTY

LLD CALCULATION PERFORMED

MULTIPLLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD3889

ANALYZED BY: DM

SAMPLE DESCRIPTION: F-59 SEGMENT-8

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-02

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 10:22:54

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3003. SECONDS

DEAD TIME: 0.10 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-OCT-89

EFFICIENCY CALIBRATION PERFORMED 31-JUL-89

222-S COUNTING ROOM WESTINGHOUSE HANFORD

11-MAY-90 13:04:17

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1	703.75	352.09	1.58	220.	124.	19.2	PB-214
2	1218.39	609.22	1.80	124.	142.	14.7	BI-214, RU-103
3	1323.23	661.61	1.60	83.	707.	4.3	CS-137
4	1937.80	968.83	1.31	86.	36.	45.5	SB-124
5	2921.50	1460.85	2.23	32.	583.	4.5	K-40

ERROR QUOTATION AT 1.00 SIGMA
PEAK CONFIDENCE LEVEL AT 85.0%

SAMPLE: F-59 SEGMENT-8

DATA COLLECTED ON 10-JAN-90 AT 10:22:54

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE ACTIVITY CONCENTRATION IN uCi/LI

DECAY

MEASURED ERROR CORRECTED ERROR

AC-228	LLD<1.05E+01		LLD<1.05E+01	
AG-108M	LLD<2.46E+00		LLD<2.46E+00	
AG-110M	LLD<8.01E+00		LLD<8.01E+00	
AM-241	LLD<4.07E+00		LLD<4.07E+00	
AM-243	LLD<2.49E+00		LLD<2.49E+00	
AR-41	LLD<4.39E+00		LLD<4.39E+00	
AU-198	LLD<2.31E+00		LLD<2.31E+00	
BA-133	LLD<3.98E+00		LLD<3.98E+00	
BA-139	LLD<9.66E+00		LLD<9.66E+00	
BA-140	LLD<1.00E+01		LLD<1.00E+01	
BA-141	LLD<9.64E+00		LLD<9.64E+00	
BE-7	LLD<2.52E+01		LLD<2.52E+01	
BI-207	LLD<2.60E+00		LLD<2.60E+00	
BI-212	LLD<4.45E+01		LLD<4.45E+01	
BI-214	2.31E+01	+3.40E+00	2.31E+01	+3.40E+00
CD-109	LLD<4.91E+01		LLD<4.91E+01	
CE-139	LLD<2.19E+00		LLD<2.19E+00	
CE-141	LLD<3.58E+00		LLD<3.58E+00	
CEPR144	LLD<3.32E+01		LLD<3.32E+01	
CO-56	LLD<2.41E+00		LLD<2.41E+00	
CO-57	LLD<2.13E+00		LLD<2.13E+00	
CO-58	LLD<2.90E+00		LLD<2.90E+00	
CO-60	LLD<2.85E+00		LLD<2.85E+00	
CR-51	LLD<2.17E+01		LLD<2.17E+01	
CS-134	LLD<3.35E+00		LLD<3.35E+00	
CS-136	LLD<2.71E+00		LLD<2.71E+00	
CS-137	6.45E+01	+2.81E+00	6.45E+01	+2.81E+00
CS-138	LLD<6.00E+00		LLD<6.00E+00	
EU-152	LLD<1.75E+01		LLD<1.75E+01	
EU-154	LLD<1.15E+01		LLD<1.15E+01	
EU-155	LLD<8.02E+00		LLD<8.02E+00	
FE-59	LLD<6.27E+00		LLD<6.27E+00	
HF-181	LLD<2.98E+00		LLD<2.98E+00	
HG-203	LLD<2.61E+00		LLD<2.61E+00	
I-131	LLD<2.99E+00		LLD<2.99E+00	
I-132	LLD<3.40E+00		LLD<3.40E+00	
I-133	LLD<2.78E+00		LLD<2.78E+00	
I-134	LLD<3.77E+00		LLD<3.77E+00	
I-135	LLD<1.44E+01		LLD<1.44E+01	
K-40	8.03E+02	+3.72E+01	8.03E+02	+3.72E+01
KR-85	LLD<7.14E+02		LLD<7.14E+02	
KR-85M	LLD<2.67E+00		LLD<2.67E+00	
KR-87	LLD<5.66E+00		LLD<5.66E+00	
KR-89	LLD<1.01E+02		LLD<1.01E+02	
LA-140	LLD<3.80E+00		LLD<3.80E+00	
LA-142	LLD<7.31E+00		LLD<7.31E+00	
MN-54	LLD<2.86E+00		LLD<2.86E+00	

MN-56	LLD<2.72E+00	LLD<2.72E+00
NA-22	LLD<4.17E+00	LLD<4.17E+00
NA-24	LLD<3.65E+00	LLD<3.65E+00
NB-94	LLD<2.95E+00	LLD<2.95E+00
NB-95	LLD<2.76E+00	LLD<2.76E+00
NB-97	LLD<9.71E+00	LLD<9.71E+00
NP-238	LLD<1.31E+01	LLD<1.31E+01
NP-239	LLD<1.55E+01	LLD<1.55E+01
PA-233	LLD<5.93E+00	LLD<5.93E+00
PA-234M	LLD<5.61E+02	LLD<5.61E+02
PB-210	LLD<6.39E+01	LLD<6.39E+01
PB-212	LLD<5.22E+00	LLD<5.22E+00
PB-214	LLD<6.54E+00	LLD<6.54E+00
PO-210	LLD<2.25E+05	LLD<2.25E+05
PO-214	LLD<3.11E+04	LLD<3.11E+04
PO-216	LLD<1.48E+05	LLD<1.48E+05
PU-239	LLD<2.89E+04	LLD<2.89E+04
PU-241	LLD<9.67E+05	LLD<9.67E+05
RA-224	LLD<5.76E+01	LLD<5.76E+01
RA-226	LLD<5.82E+01	LLD<5.82E+01
RB-88	LLD<3.25E+01	LLD<3.25E+01
RB-89	LLD<1.30E+01	LLD<1.30E+01
RN-220	LLD<2.58E+03	LLD<2.58E+03
RU-103	LLD<2.58E+00	LLD<2.58E+00
RURH106	LLD<5.34E+01	LLD<5.34E+01
SB-124	LLD<2.76E+00	LLD<2.76E+00
SB-125	LLD<2.63E+01	LLD<2.63E+01
SC-46	LLD<3.74E+00	LLD<3.74E+00
SE-75	LLD<3.52E+00	LLD<3.52E+00
SN-113	LLD<3.38E+00	LLD<3.38E+00
SR-85	LLD<3.13E+00	LLD<3.13E+00
SR-91	LLD<4.31E+00	LLD<4.31E+00
SR-92	LLD<4.24E+00	LLD<4.24E+00
TA-182	LLD<1.11E+01	LLD<1.11E+01
TC-99M	LLD<2.14E+00	LLD<2.14E+00
TE-123M	LLD<2.06E+00	LLD<2.06E+00
TE-125M	LLD<6.33E+02	LLD<6.33E+02
TE-132	LLD<2.42E+00	LLD<2.42E+00
TH-228	LLD<1.33E+02	LLD<1.33E+02
TL-208	LLD<2.78E+00	LLD<2.78E+00
U-235	LLD<3.47E+00	LLD<3.47E+00
U-237	LLD<9.97E+00	LLD<9.97E+00
W-187	LLD<9.45E+00	LLD<9.45E+00
XE-131M	LLD<8.82E+01	LLD<8.82E+01
XE-133	LLD<4.41E+00	LLD<4.41E+00
XE-133M	LLD<2.15E+01	LLD<2.15E+01
XE-135	LLD<2.32E+00	LLD<2.32E+00
XE-138	LLD<1.78E+01	LLD<1.78E+01
Y-88	LLD<3.09E+00	LLD<3.09E+00
Y-91	LLD<1.36E+03	LLD<1.36E+03
Y-91M	LLD<3.26E+00	LLD<3.26E+00
ZN-65	LLD<8.68E+00	LLD<8.68E+00
ZR-95	LLD<4.45E+00	LLD<4.45E+00
ZR-97	LLD<3.02E+00	LLD<3.02E+00

TOTAL 8.91E+02 + -3.74E+01 8.91E+02 + -3.74E+01

EBAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 1.47E-07 UC/LI

TOTAL MEASURED ACTIVITY = 8.91E+02 (+-3.74E+01) UC/LI

% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.00 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
703.75	352.09	124.	19.2	1.08E+01
1937.80	968.83	36.	45.5	7.07E+00

* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* GAMMA SPECTRUM ANALYSIS *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

11-MAY-90 12:52:52

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 1 / ADC UNIT NUMBER: 2.0
DETECTOR NUMBER: 2 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.00 SIGMA UNCERTAINTY
C

LLD CALCULATION PERFORMED
MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD2754
ANALYZED BY: DM

SAMPLE DESCRIPTION: F-736 SEGMENT-I

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01
STANDARD SIZE: 1.0000E+00 EA
ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 14:50:04

COLLECT LIVE TIME: 3000. SECONDS
REAL TIME: 3008. SECONDS
DEAD TIME: 0.27 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 17-MAR-89
EFFICIENCY CALIBRATION PERFORMED 21-OCT-88

222-S COUNTING ROOM

11-MAY-90 12:52:52

SAMPLE: F-736 SEGMENT-I

DATA COLLECTED ON 10-JAN-90 AT 14:50:04

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIONUCLIDE ANALYSIS REPORT

NUCLIDE ACTIVITY CONCENTRATION IN uCi/LI

DECAY

MEASURED ERROR CORRECTED ERROR

AC-228	LLD<1.10E+00		LLD<1.10E+00	
AG-108M	LLD<3.73E-01		LLD<3.73E-01	
AG-110M	LLD<2.36E+00		LLD<2.36E+00	
AM-241	LLD<1.70E+00		LLD<1.70E+00	
AM-243	LLD<4.32E-01		LLD<4.32E-01	
AR-41	LLD<1.66E-01		LLD<1.66E-01	
AU-198	LLD<3.23E-01		LLD<3.23E-01	
BA-133	LLD<4.30E-01		LLD<4.30E-01	
BA-139	LLD<8.82E-01		LLD<8.82E-01	
BA-140	LLD<1.21E+00		LLD<1.21E+00	
BA-141	LLD<8.78E-01		LLD<8.78E-01	
BE-7	LLD<3.18E+00		LLD<3.18E+00	
BI-207	LLD<2.93E-01		LLD<2.93E-01	
BI-212	LLD<3.83E+00		LLD<3.83E+00	
BI-214	LLD<2.03E+00		LLD<2.03E+00	
CD-109	LLD<5.43E+00		LLD<5.43E+00	
CE-139	LLD<2.00E-01		LLD<2.00E-01	
CE-141	LLD<3.21E-01		LLD<3.21E-01	
CEPR144	LLD<2.61E+00		LLD<2.61E+00	
CO-56	LLD<2.63E-01		LLD<2.63E-01	
CO-57	LLD<1.64E-01		LLD<1.64E-01	
CO-58	LLD<2.45E-01		LLD<2.45E-01	
CO-60	2.30E+01	+4.22E-01	2.30E+01	+4.22E-01
CR-51	LLD<2.45E+00		LLD<2.45E+00	
CS-134	2.12E+01	+4.25E-01	2.12E+01	+4.25E-01
CS-136	LLD<2.64E-01		LLD<2.64E-01	
CS-137	1.12E+02	+9.98E-01	1.12E+02	+9.98E-01
CS-138	LLD<2.63E-01		LLD<2.63E-01	
EU-152	LLD<5.79E-01		LLD<5.79E-01	
EU-154	LLD<4.50E-01		LLD<4.50E-01	
EU-155	LLD<7.58E-01		LLD<7.58E-01	
FE-59	LLD<5.98E-01		LLD<5.98E-01	
HF-181	LLD<3.84E-01		LLD<3.84E-01	
HG-203	LLD<2.60E-01		LLD<2.60E-01	
I-131	LLD<3.41E-01		LLD<3.41E-01	
I-132	LLD<1.00E+00		LLD<1.00E+00	
I-133	LLD<3.18E-01		LLD<3.18E-01	
I-134	LLD<3.88E-01		LLD<3.88E-01	
I-135	LLD<6.06E-01		LLD<6.06E-01	
K-40	9.79E+00	+8.99E-01	9.79E+00	+8.99E-01
KR-85	LLD<7.34E+01		LLD<7.34E+01	
KR-85M	LLD<2.05E-01		LLD<2.05E-01	
KR-87	LLD<7.28E-01		LLD<7.28E-01	
KR-89	LLD<1.08E+01		LLD<1.08E+01	
LA-140	LLD<1.16E-01		LLD<1.16E-01	
LA-142	LLD<7.05E-01		LLD<7.05E-01	
MN-54	LLD<2.53E-01		LLD<2.53E-01	

MN-56	LLD<2.96E-01	LLD<2.96E-01
NA-22	LLD<1.60E-01	LLD<1.60E-01
NA-24	LLD<2.21E-01	LLD<2.21E-01
NB-94	LLD<2.31E-01	LLD<2.31E-01
NB-95	LLD<2.43E-01	LLD<2.43E-01
NB-97	LLD<2.67E+00	LLD<2.67E+00
NP-238	LLD<1.13E+00	LLD<1.13E+00
NP-239	LLD<1.56E+00	LLD<1.56E+00
PA-233	LLD<6.32E-01	LLD<6.32E-01
PA-234M	LLD<5.21E+01	LLD<5.21E+01
PB-210	LLD<8.52E+00	LLD<8.52E+00
PB-212	LLD<4.83E-01	LLD<4.83E-01
PB-214	LLD<6.68E-01	LLD<6.68E-01
PO-210	LLD<2.11E+04	LLD<2.11E+04
PO-214	LLD<1.03E+04	LLD<1.03E+04
PO-216	LLD<1.82E+04	LLD<1.82E+04
PU-239	LLD<2.45E+03	LLD<2.45E+03
PU-241	LLD<7.76E+04	LLD<7.76E+04
RA-224	LLD<5.19E+00	LLD<5.19E+00
RA-226	LLD<4.73E+00	LLD<4.73E+00
RB-88	LLD<8.49E-01	LLD<8.49E-01
RB-89	LLD<1.48E+00	LLD<1.48E+00
RN-220	LLD<2.56E+02	LLD<2.56E+02
RU-103	LLD<3.15E-01	LLD<3.15E-01
RURH106	LLD<5.70E+00	LLD<5.70E+00
SB-124	LLD<4.98E-01	LLD<4.98E-01
SB-125	LLD<2.53E+00	LLD<2.53E+00
SC-46	LLD<3.01E-01	LLD<3.01E-01
SE-75	LLD<3.75E-01	LLD<3.75E-01
SN-113	LLD<4.63E-01	LLD<4.63E-01
SR-85	LLD<3.22E-01	LLD<3.22E-01
SR-91	LLD<5.38E-01	LLD<5.38E-01
SR-92	LLD<1.40E-01	LLD<1.40E-01
TA-182	LLD<9.47E-01	LLD<9.47E-01
TC-99M	LLD<1.68E-01	LLD<1.68E-01
TE-123M	LLD<1.90E-01	LLD<1.90E-01
TE-125M	LLD<5.23E+01	LLD<5.23E+01
TE-132	LLD<2.25E-01	LLD<2.25E-01
TH-228	LLD<1.83E+01	LLD<1.83E+01
TL-208	LLD<3.49E-01	LLD<3.49E-01
U-235	LLD<3.14E-01	LLD<3.14E-01
U-237	LLD<9.06E-01	LLD<9.06E-01
W-187	LLD<8.24E-01	LLD<8.24E-01
XE-131M	LLD<8.64E+00	LLD<8.64E+00
XE-133	LLD<6.15E-01	LLD<6.15E-01
XE-133M	LLD<1.96E+00	LLD<1.96E+00
XE-135	LLD<2.43E-01	LLD<2.43E-01
XE-138	LLD<1.72E+00	LLD<1.72E+00
Y-88	LLD<8.05E-02	LLD<8.05E-02
Y-91	LLD<6.86E+01	LLD<6.86E+01
Y-91M	LLD<4.07E-01	LLD<4.07E-01
ZN-65	LLD<7.22E-01	LLD<7.22E-01
ZR-95	LLD<4.39E-01	LLD<4.39E-01
ZR-97	LLD<2.39E-01	LLD<2.39E-01

TOTAL 1.66E+02 +-1.47E+00 1.66E+02 +-1.47E+00

EBAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 2.62E-09 UC/LI

TOTAL MEASURED ACTIVITY = 1.66E+02 (+-1.47E+00) UC/LI

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1127.21	563.24	1.52	700.	591.	7.5	CS-134, EU-152
2C	1139.38	569.32	1.52	668.	1034.	6.2	CS-134, BI-207
3	1210.16	604.70	1.56	734.	6403.	1.4	CS-134
4	1323.98	661.60	1.59	432.	25877.	0.6	CS-137
5C	1592.17	795.68	1.67	303.	4211.	1.9	CS-134
6C	1604.30	801.74	1.67	277.	442.	6.0	CS-134
7	2346.59	1172.85	2.05	243.	3874.	1.7	CO-60
8	2665.06	1332.08	2.03	47.	3509.	1.7	CO-60
9	2730.16	1364.62	1.83	13.	98.	11.9	CS-134
10	2921.64	1460.36	1.96	12.	148.	9.2	K-40

ERROR QUOTATION AT 1.00 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

C - MULTIPLET ANALYSIS CONVERGED NORMALLY

% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.00 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1127.21	563.24	591.	7.5	3.48E+01
1139.38	569.32	1034.	6.2	6.16E+01
1604.30	801.74	442.	6.0	3.54E+01
2730.16	1364.62	98.	11.9	1.21E+01

* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *
* G A M M A S P E C T R U M A N A L Y S I S *
* * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * * *

CANBERRA SPECTRAN-F V2.06 SOFTWARE

222-S COUNTING ROOM

11-MAY-90 12:42:14

A N A L Y S I S P A R A M E T E R S

MCA UNIT NUMBER: 2 / ADC UNIT NUMBER: 1.0
DETECTOR NUMBER: 1 / GEOMETRY NUMBER: 42
SPECTRUM SIZE: 4096 CHANNELS
ORDER OF SMOOTHING FUNCTION: 5
NUMBER OF BACKGROUND CHANNELS: 4 ON EACH SIDE OF PEAK
PEAK CONFIDENCE FACTOR: 85.0%
IDENTIFICATION ENERGY WINDOW: +- 1.50 KEV
ERROR QUOTATION: 1.00 SIGMA UNCERTAINTY

LLD CALCULATION PERFORMED

MULTIPLET ANALYSIS PERFORMED

ANALYSIS OF SPECTRUM SAVED IN DISK FILE: SD1015

ANALYZED BY: DM

SAMPLE DESCRIPTION: F-737 SEGMENT-J

GEOMETRY DESCRIPTION:

SAMPLE SIZE: 1.0000E-03 LI / CONVERSION FACTOR: 5.0000E-01

STANDARD SIZE: 1.0000E+00 EA

ANALYSIS LIBRARY FILE: ANL000

COLLECT STARTED ON 10-JAN-90 AT 14:58:34

COLLECT LIVE TIME: 3000. SECONDS

REAL TIME: 3005. SECONDS

DEAD TIME: 0.17 %

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT

ENERGY CALIBRATION PERFORMED 23-NOV-89

EFFICIENCY CALIBRATION PERFORMED 2-MAR-89

SAMPLE: F-737 SEGMENT-J

DATA COLLECTED ON 10-JAN-90 AT 14:58:34

DECAYED TO 0. DAYS, 0.0000 HOURS BEFORE THE START OF COLLECT.

RADIOMONUCLEIDE ANALYSIS REPORT

NUCLIDE ACTIVITY CONCENTRATION IN uCi/LI

DECAY

MEASURED ERROR CORRECTED ERROR

AC-228	LLD<7.75E-01		LLD<7.75E-01	
AG-108M	LLD<2.20E-01		LLD<2.20E-01	
AG-110M	LLD<1.05E+00		LLD<1.05E+00	
AM-241	LLD<9.43E-01		LLD<9.43E-01	
AM-243	LLD<2.47E-01		LLD<2.47E-01	
AR-41	LLD<1.18E-01		LLD<1.18E-01	
AU-198	LLD<1.98E-01		LLD<1.98E-01	
BA-133	LLD<2.88E-01		LLD<2.88E-01	
BA-139	LLD<5.94E-01		LLD<5.94E-01	
BA-140	LLD<7.56E-01		LLD<7.56E-01	
BA-141	LLD<6.00E-01		LLD<6.00E-01	
BE-7	LLD<2.05E+00		LLD<2.05E+00	
BI-207	LLD<1.90E-01		LLD<1.90E-01	
BI-212	LLD<2.74E+00		LLD<2.74E+00	
BI-214	LLD<1.04E+00		LLD<1.04E+00	
CD-109	LLD<3.49E+00		LLD<3.49E+00	
CE-139	LLD<1.34E-01		LLD<1.34E-01	
CE-141	LLD<2.05E-01		LLD<2.05E-01	
CEPR144	LLD<1.74E+00		LLD<1.74E+00	
CO-56	LLD<1.99E-01		LLD<1.99E-01	
CO-57	LLD<1.09E-01		LLD<1.09E-01	
CO-58	LLD<1.86E-01		LLD<1.86E-01	
CO-60	2.30E+01	+3.57E-01	2.30E+01	+3.57E-01
CR-51	LLD<1.54E+00		LLD<1.54E+00	
CS-134	2.16E+01	+3.44E-01	2.16E+01	+3.44E-01
CS-136	LLD<1.91E-01		LLD<1.91E-01	
CS-137	3.75E+01	+4.21E-01	3.75E+01	+4.21E-01
CS-138	LLD<2.14E-01		LLD<2.14E-01	
EU-152	LLD<2.36E-01		LLD<2.36E-01	
EU-154	LLD<3.72E-01		LLD<3.72E-01	
EU-155	LLD<4.23E-01		LLD<4.23E-01	
FE-59	LLD<4.06E-01		LLD<4.06E-01	
HF-181	LLD<2.26E-01		LLD<2.26E-01	
HG-203	LLD<1.77E-01		LLD<1.77E-01	
I-131	LLD<2.22E-01		LLD<2.22E-01	
I-132	LLD<2.34E-01		LLD<2.34E-01	
I-133	LLD<2.18E-01		LLD<2.18E-01	
I-134	LLD<2.86E-01		LLD<2.86E-01	
I-135	LLD<4.44E-01		LLD<4.44E-01	
K-40	8.73E+00	+6.90E-01	8.73E+00	+6.90E-01
KR-85	LLD<4.50E+01		LLD<4.50E+01	
KR-85M	LLD<1.33E-01		LLD<1.33E-01	
KR-87	LLD<5.10E-01		LLD<5.10E-01	
KR-89	LLD<7.39E+00		LLD<7.39E+00	
LA-140	LLD<7.82E-02		LLD<7.82E-02	
LA-142	LLD<4.32E-01		LLD<4.32E-01	
MN-54	LLD<1.89E-01		LLD<1.89E-01	

MN-56	LLD<2.25E-01	LLD<2.25E-01
NA-22	LLD<1.17E-01	LLD<1.17E-01
NA-24	LLD<2.27E-01	LLD<2.27E-01
NB-94	LLD<1.69E-01	LLD<1.69E-01
NB-95	LLD<1.71E-01	LLD<1.71E-01
NB-97	LLD<1.27E+00	LLD<1.27E+00
NP-238	LLD<8.27E-01	LLD<8.27E-01
NP-239	LLD<1.04E+00	LLD<1.04E+00
PA-233	LLD<4.66E-01	LLD<4.66E-01
PA-234M	LLD<3.93E+01	LLD<3.93E+01
PB-210	LLD<5.27E+00	LLD<5.27E+00
PB-212	LLD<3.32E-01	LLD<3.32E-01
PB-214	LLD<4.96E-01	LLD<4.96E-01
PO-210	LLD<1.97E+04	LLD<1.97E+04
PO-214	LLD<8.46E+03	LLD<8.46E+03
PO-216	LLD<1.68E+04	LLD<1.68E+04
PU-239	LLD<1.49E+03	LLD<1.49E+03
PU-241	LLD<5.23E+04	LLD<5.23E+04
RA-224	LLD<3.62E+00	LLD<3.62E+00
RA-226	LLD<3.19E+00	LLD<3.19E+00
RB-88	LLD<7.19E-01	LLD<7.19E-01
RB-89	LLD<1.00E+00	LLD<1.00E+00
RN-220	LLD<1.68E+02	LLD<1.68E+02
RU-103	LLD<2.06E-01	LLD<2.06E-01
RURH106	LLD<3.61E+00	LLD<3.61E+00
SB-124	LLD<2.98E-01	LLD<2.98E-01
SB-125	LLD<1.66E+00	LLD<1.66E+00
SC-46	LLD<2.12E-01	LLD<2.12E-01
SE-75	LLD<2.39E-01	LLD<2.39E-01
SN-113	LLD<2.89E-01	LLD<2.89E-01
SR-85	LLD<1.97E-01	LLD<1.97E-01
SR-91	LLD<3.63E-01	LLD<3.63E-01
SR-92	LLD<1.06E-01	LLD<1.06E-01
TA-182	LLD<5.93E-01	LLD<5.93E-01
TC-99M	LLD<1.15E-01	LLD<1.15E-01
TE-123M	LLD<1.26E-01	LLD<1.26E-01
TE-125M	LLD<3.23E+01	LLD<3.23E+01
TE-132	LLD<1.55E-01	LLD<1.55E-01
TH-228	LLD<1.05E+01	LLD<1.05E+01
TL-208	LLD<2.56E-01	LLD<2.56E-01
U-235	LLD<2.12E-01	LLD<2.12E-01
U-237	LLD<6.11E-01	LLD<6.11E-01
W-187	LLD<5.64E-01	LLD<5.64E-01
XE-131M	LLD<5.58E+00	LLD<5.58E+00
XE-133	LLD<3.85E-01	LLD<3.85E-01
XE-133M	LLD<1.39E+00	LLD<1.39E+00
XE-135	LLD<1.63E-01	LLD<1.63E-01
XE-138	LLD<1.20E+00	LLD<1.20E+00
Y-88	LLD<6.82E-02	LLD<6.82E-02
Y-91	LLD<4.84E+01	LLD<4.84E+01
Y-91M	LLD<2.75E-01	LLD<2.75E-01
ZN-65	LLD<4.72E-01	LLD<4.72E-01
ZR-95	LLD<3.26E-01	LLD<3.26E-01
ZR-97	LLD<1.74E-01	LLD<1.74E-01
<hr/>		
TOTAL	9.08E+01	+ -9.48E-01
	9.08E+01	+ -9.48E-01

EBAR = ***** MEV/DISINTEGRATION

MAXIMUM PERMISSABLE ACTIVITY = 1.59E-09 UC/LI

TOTAL MEASURED ACTIVITY = 9.08E+01 (+ -9.48E-01) UC/LI

P E A K A N A L Y S I S

PK	CENTROID CHANNEL	ENERGY KEV	FWHM KEV	BACKGND COUNTS	NET AREA COUNTS	ERROR %	NUCLIDES
1C	1126.76	562.85	1.47	621.	701.	5.5	CS-134, EU-152
2C	1139.18	569.06	1.47	557.	1378.	4.6	CS-134, BI-207
3	1209.86	604.39	1.49	629.	8070.	1.2	CS-134
4	1323.69	661.29	1.50	330.	12059.	0.9	CS-137
5C	1592.03	795.44	1.54	278.	5989.	1.5	CS-134
6C	1604.20	801.53	1.54	265.	603.	3.9	CS-134
7C	2336.00	1167.55	1.78	138.	133.	9.2	CS-134
8C	2346.55	1172.83	1.78	127.	5421.	1.5	CO-60
9	2665.02	1332.19	1.84	35.	4837.	1.5	CO-60
10	2729.89	1364.65	2.05	11.	175.	8.1	CS-134
11	2801.24	1400.36	1.63	21.	51.	20.3	BI-214
12	2921.99	1460.80	1.81	9.	182.	7.9	K-40

ERROR QUOTATION AT 1.00 SIGMA
 PEAK CONFIDENCE LEVEL AT 85.0%

M - MULTIPLET ANALYSIS CONVERGED NORMALLY

% TECH. SPEC. = ***** (+-****)

ERROR QUOTATION AT 1.00 SIGMA
LLD CONFIDENCE LEVEL AT 85.0%

PEAKS NOT USED IN ANALYSIS

CENTROID CHANNEL	ENERGY KEV	NET AREA COUNTS	ERROR %	GAMMAS/SEC
1126.76	562.85	701.	5.5	3.00E+01
1139.18	569.06	1378.	4.6	5.95E+01
1604.20	801.53	603.	3.9	3.46E+01
2336.00	1167.55	133.	9.2	1.04E+01
2729.89	1364.65	175.	8.1	1.56E+01
2801.24	1400.36	51.	20.3	4.66E+00

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WA77344
Procedure / Rev	LA-925-106/A-2
Technologist	6C269 M. Franz
Date	1-8-90
Temperature	N/A
Starting Time	10:00
Ending Time	14:30
Chemist	S. A. Catlow

Uranium Analysis

Fusion Dissolution

	Description	Lab. Id.
1	Initial LMCS Check Std	F0057
2	Blank	F0748
3	Sample 89-043	F0058
4	Duplicate 89-043	F0059
5	Spiked 89-043	F0060
6	Sample 89-082	F0710
7	Duplicate 89-082	F0711
8	Sample 89-083	F0734
9	Duplicate 89-083	F0735
10	Final LMCS Check Std	F0737
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

	Primary Book	Second Book	Third Book	Final Volume of Standard
Standard Type	No. & Aliquot	No. & Aliquot	No. & Aliquot	
LMCS Check Standard	58B38/100 uL			5.6 mL
Spike	54B38/100 uL	F0060/100 uL		5.7 mL

Interim

4/04/90

Rev. E

4/04/90

SST-102

Prepared by: Shirley Cervantes S.A. Cervantes Date: 8-28-90
 Signature Printed Name

C. M. Seidel Date: 8-28-90

Verified by: Craig M. Seidel C. M. Seidel Date: 8-28-90
 Signature Printed Name

L-H. Taylor Date: 9-28-90
 Signature Printed Name

WATER DIGESTION TEST ANALYSIS

9 1 1 2 0 0 7 0 7 1 0

76

Single Shell Tank

Water Digestion
Laboratory Results of Solids
Units are Sample Wet Weight

Tank : 241-U-110
 Core: 6
 Segment: 2
 Customer ID: 89-043

Laboratory Segment Serial No.: F0053

	Check Standard	Blank	Sample	Sample Duplicate	Spike of Sample	Check Standard
Laboratory ID Water Digestion			F0063 10.1 g/L	F0064 10.4 g/L	F0065 10.1 g/L	
Laboratory ID:	F0110	F0122	F0063	F0064	F0113	F0066
Ion Chromatograph *						
Fluoride	93.10%	<.10 ppm	<1.00E+03 ug/g	<9.71E+02 ug/g	96.30%	93.10%
Chloride	97.90%	<.15 ppm	1.62E+03 ug/g	<9.71E+02 ug/g	107.20%	96.30%
Nitrate	98.30%	<1.0 ppm	5.46E+04 ug/g	4.49E+04 ug/g	104.40%	105.20%
Sulfate	92.90%	<1.0 ppm	<1.00E+04 ug/g	<9.71E+03 ug/g	101.30%	98.80%
Laboratory ID:	F0110	F0122	F0063	F0064	F0113	F0114
Phosphate	95.90%	<1.0 ppm	<1.00E+04 ug/g	**	103.20%	101.00%
Laboratory ID:	F0426	F0438	F0063	F0064	F0429	F0574
Phosphate	100.80%	<1.0 ppm	***	<9.71E+03 ug/g	105.60%	101.50%
Laboratory ID:	F0062	F0074	F0063	- F0064 -	F0065	F0066
Total Organic Carbon/ Carbonate	98.60%	5.32E+00 ug	2.76E+03 ug/g	2.49E+03 ug/g	87.40%	93.80%

* Instrument Out Of Calibration For Phosphate.

** Not Reported

*** Sample Not Rerun.

9 1 1 2 0 6 0 0 7 1 1

Single Shell Tank Project

Water Digestion
Sample Results on Laboratory Digestion

Tank 241-U-110

Core 6

Segment 2

Customer ID 89-043

			Laboratory Segment Serial No.:			F0053	
	Check Standard	Blank	Sample	Sample Duplicate	Spike of Sample		Check Standard
Laboratory ID: Water Digestion			F0063 10.1 g/L	F0064 10.4 g/L	F0065 10.1 g/L		F0066
Laboratory ID:	F0110	F0122	F0063	F0064	F0113		F0066
Ion Chromatograph *							
Fluoride	93.10%	<0.10 ppm	<10.1 ppm	<10.1 ppm	96.30%		93.10%
Chloride	97.90%	<.15 ppm	1.64E+01 ppm	<10.1 ppm	107.20%		96.30%
Nitrate	98.30%	<1.0 ppm	5.51E+02 ppm	4.67E+02 ppm	104.40%		105.20%
Sulfate	92.90%	<1.0 ppm	<101 ppm	<101 ppm	101.30%		98.90%
Laboratory ID:	F0110	F0122	F0063	F0064	F0113		F0114
Phosphate	95.90%	<1.0 ppm	<101 ppm	**	103.20%		101.00%
Laboratory ID:	F0426	F0438	F0063	F0064	F0429		F0574
Phosphate	100.80%	<1.0 ppm	***	<1.01E+02 ppm	105.60%		101.50%
Laboratory ID:	F0062	F0074	F0063	F0064	F0065		F0066
Total Organic Carbon/ Carbonate	98.60%	5.32E+00 ug	2.79E-02 g/L	2.59E-02 g/L	87.40%		93.80%

* Instrument Out Of Calibration For Phosphate.

** Not Reported.

*** Sample Not Rerun.

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	N/A
Procedure / Rev	LA-504-101/A-2
Technologist	81098/L. Hughes-Standly
Date	1-6-90
Temperature	25 C
Starting Time	11:00 1-5-90
Ending Time	15:00 1-6-90
Chemist	H. S. Rich

Water Digestion

Note: Sample is not spiked prior to digestion. This procedure provides a sample to be spiked later with the appropriate elements.

	Description	Lab. Id.
1	Reagent Blank	F-0074
2	Sample 89-043	F-0063
3	Duplicate 89-043	F-0064
4	Spike 89-043	F-0065
5		
6		
7		
8		
9		
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
N/A				

Interim

Rev E 4/04/90

SST-102

Prepared by:	<u>H. S. Rich</u> Signature	H. S. Rich Printed Name	Date: 05-14-90
Verified by:	<u>C. M. Seidel</u> Signature	C. M. Seidel Printed Name	Date: 05-14-90
Approved by:	<u>L.H. Taylor</u> Signature	L.H. Taylor Printed Name	Date: 9-28-90

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WB24721
Procedure / Rev	LA-533-105/A-3
Technologist	6B107/N.E. Wright
Date	02/16/90
Temperature	24 C
Starting Time	11:30
Ending Time	14:00
Chemist	H. S. Rich

Ion Chromatograph Analysis

Water Digestion

Chromatographs are not calibrated for nitrite.
Peaks are for identification only

*Chromatogram Only

	Description	Lab. Id.
1	Eluent Blank	*
2	Initial LMCS Check Std.	F0110
3	Reagent Blank 89-045	F0122
4	Sample 89-045	F0111
5	Duplicate 89-045	F0112
6	Spike 89-045	F0113
7	Sample 89-043	F0063
8	Duplicate 89-043	F0064
9	Final LMCS Check Std.	F0066
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Std.	6C11HI/10uL			10.1 mL
Spike	35C9-67/300uL	F0113/ 50 uL		5.35 mL

Interim

4/04/90

Rev. E

Prepared by: Shirley Cervantes S. A. Cervantes Date: 06/06/90
Signature Printed Name

Verified by: Cary M. Seidel C.M. Seidel Date: 06/06/90
Signature Printed Name

Approved by: Z.H. Zayk L.H. Taylor Date: 9/28/90
Signature Printed Name

Detector Parameters

Number of Detectors.....	1
Detector 1 Type.....	CDM-1

Report Options

Run Time (minutes).....	11.50
Detector 1 real time plot scale.....	20.00
Print Report.....	Yes
Print Replot.....	Yes
AutoScale Replot to Highest Peak.....	Yes
Print Retention Times on Chromatogram.....	Yes
List Peaks Not Found in this run.....	No
Report Unknowns found in run.....	No
Record Raw Data.....	Yes
Raw Data File Name: c:\WINDOWS\AI400\DATA\90021401.D08	
Record Result Data.....	No

Integration Parameters

Sampling Rate (seconds).....	0.20
Peak Threshold (mV or uS/data pt interval).....	0.400
Starting Peak Width (seconds).....	10.0
Peak Area Reject.....	1000

Integration Timed Events

Time	Description
-----	-----

Calibration Parameters

External or Internal Calibration.....	External
Calibrate by Area or Height.....	Height
Replace Or Average Calibrations.....	Replace
Number Of Levels for Calibration.....	6
Calibration fit type.....	Quadratic
Response Factor for unknown peaks.....	0.0
Default Injection Volume.....	1.0
Default Dilution Factor.....	1.0
Area Reject for Reference Peaks.....	1000
Percent Retention Time Window for Reference Peaks.....	5.0

DIONEX METHOD PARAMETERS - SST.MET

Component # 1 FLUORIDE Retention Time 0.97
 Reference Peak FLUORIDE Window Size 2.00%
 Least Squares Slope = 3.60283E-004
 Least Squares Intercept = 1.37365E-002
 Ka = -4.29870E-009

Level	Amount	Area	Height
1	9.38100E-002	1336	246
2	2.33800E-001	3478	616
3	4.65300E-001	7271	1226
4	9.21500E-001	15622	2625
5	1.80760E+000	37180	5315
6	3.48130E+000	74116	11092

Component # 2 CHLORIDE Retention Time 1.53
 Reference Peak FLUORIDE Window Size 2.50%
 Least Squares Slope = 6.25472E-004
 Least Squares Intercept = -1.74138E-002
 Ka = -1.51561E-008

Level	Amount	Area	Height
1	1.19800E-001	1267	200
2	2.98500E-001	2903	489
3	5.94100E-001	6430	1017
4	1.17650E+000	13713	2088
5	2.30760E+000	28370	4066
6	4.44430E+000	59291	9183

Component # 3 NITRITE Retention Time 1.90
 Reference Peak FLUORIDE Window Size 5.00%
 Least Squares Slope = 8.73497E-004
 Least Squares Intercept = 5.05282E-001
 Ka = 4.08720E-009

Level	Amount	Area	Height
1	1.28940E+000	8214	1202
2	3.21850E+000	20050	2969
3	6.39600E+000	43200	6258
4	1.26667E+001	91140	13081
5	2.48451E+001	181100	25092
6	4.78505E+001	353600	44776

Component # 4 NITRATE Retention Time 3.28
 Reference Peak FLUORIDE Window Size 7.00%
 Least Squares Slope = 1.95501E-003
 Least Squares Intercept = -6.94769E-003
 Ka = 4.87686E-009





Level	Amount	Area	Height
1	9.60100E-001	5253	468
2	2.39300E+000	15077	1234
3	4.76240E+000	30767	2460
4	9.43140E+000	63964	4753
5	1.84992E+001	132213	9250
6	3.56286E+001	274103	17468



Component # 5 PHOSPHATE Retention Time 5.50
 Reference Peak FLUORIDE Window Size 7.00%
 Least Squares Slope = 5.16373E-003
 Least Squares Intercept = 1.15944E-001
 Ka = -7.81115E-008

Level	Amount	Area	Height
1	9.82000E-001	2854	180
2	2.44770E+000	7216	437
3	4.87130E+000	16848	948
4	9.64710E+000	32539	1886
5	1.89223E+001	69406	3876
6	3.64434E+001	142872	8003

Component # 6 SULFATE Retention Time 6.43
 Reference Peak FLUORIDE Window Size 5.00%
 Least Squares Slope = 2.38873E-003
 Least Squares Intercept = 2.12534E-001
 Ka = -1.74248E-008

Level	Amount	Area	Height
1	9.62100E-001	6077	338
2	2.39800E+000	17483	922
3	4.77230E+000	36861	1890
4	9.45100E+000	79004	4005
5	1.85377E+001	163581	8158
6	3.57027E+001	343157	16953





***** AUTOMATIC CALIBRATION UPDATE *****
Method File: C:\WINDOWS\AI400\METHOD\SST.MET
Calibration Level : 1
***** PEAKS NOT FOUND IN THIS RUN *****

Name	Adjusted Ret Time	Reference Peak
NITRITE	1.90	0
NITRATE	3.28	0
Oxalate	9.94	1

COMPONENTS FOUND IN THIS RUN							
COMP	COMPONENT	OLD	MEASURED	NEW	OLD	MEASURED	NEW
NUM	NAME	RET.TIME	RET.TIME	RET.TIME	HEIGHT	HEIGHT	HEIGHT
1	FLUORIDE	0.97	0.98	0.98	2.459e+002	2.459e+002	2.459e+002
2	CHLORIDE	1.53	1.55	1.55	1.998e+002	1.998e+002	1.998e+002
5	PHOSPHATE	5.15	5.40	5.40	1.795e+002	1.795e+002	1.795e+002
6	SULFATE	6.43	6.60	6.60	3.379e+002	3.379e+002	3.379e+002


DATA REPROCESSED ON Sun May 06 14:38:29 1990

Sample Name: AUTOCAL1R	Date: Wed Feb 14 14:51:13 1990
Data File : A:\90021401.D03	
Method : C:\WINDOWS\AI400\METHOD\SST.MET	
Interface : 1 System : 1 Inject#: 3	Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 1

PEAK	RET	PEAK	CONC. in		REF	% DELTA
NUM	TIME	NAME	ug/ml	AREA	BL PEAK	RET TIME
1	0.98	FLUORIDE	9.381e-002	1.336e+003	246	1 0 0.00%
2	1.55	CHLORIDE	1.198e-001	1.267e+003	200	1 0 0.00%
3	3.52		0.000e+000	5.253e+003	468	1
4	5.40	PHOSPHATE	9.820e-001	2.854e+003	180	1 0 0.00%
5	6.60	SULFATE	9.621e-001	6.077e+003	338	1 0 0.00%



***** AUTOMATIC CALIBRATION UPDATE *****
Method File: C:\WINDOWS\AI400\METHOD\SST.MET
Calibration Level : 2
***** PEAKS NOT FOUND IN THIS RUN *****

Name	Adjusted Ret Time	Reference Peak
NITRITE	1.90	0
Oxalate	9.60	1

COMPONENTS FOUND IN THIS RUN							
COMP NUM	COMPONENT NAME	OLD RET. TIME	MEASURED RET. TIME	NEW RET. TIME	OLD HEIGHT	MEASURED HEIGHT	NEW HEIGHT
1	FLUORIDE	0.98	0.97	0.97	6.160e+002	6.160e+002	6.160e+002
2	CHLORIDE	1.55	1.53	1.53	4.890e+002	4.890e+002	4.890e+002
4	NITRATE	3.28	3.48	3.48	1.234e+003	1.234e+003	1.234e+003
5	PHOSPHATE	5.40	5.30	5.30	4.366e+002	4.366e+002	4.366e+002
6	SULFATE	6.60	6.55	6.55	9.218e+002	9.218e+002	9.218e+002

DATA REPROCESSED ON Sun May 06 14:39:14 1990

Sample Name: AUTOCAL2R	Date: Wed Feb 14 15:03:32 1990
Data File : A:\90021401.D04	
Method : C:\WINDOWS\AI400\METHOD\SST.MET	
Interface : 1 System : 1 Inject#: 4	Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3451
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	2.338e-001	3.478e+003	616	1	0 0.00%
2	1.53	CHLORIDE	2.985e-001	2.903e+003	489	1	0 0.00%
3	3.48	NITRATE	2.393e+000	1.508e+004	1234	1	0 0.00%
4	5.30	PHOSPHATE	2.448e+000	7.216e+003	437	1	0 0.00%
5	6.55	SULFATE	2.398e+000	1.748e+004	922	1	0 0.00%

9 1 1 2 3 7 1 0 7 2 2

File: A:\90021401.D04 Sample: AUTOCAL2R

88

1.800

1.550

1.300

1.050

uS

0.800

0.550

0.300

0.050

-0.200

0.00

5.00

10.00

FLUORIDE

CHLORIDE

NITRATE

PHOSPHATE

SULFATE

88

***** AUTOMATIC CALIBRATION UPDATE *****
Method File: C:\WINDOWS\AI400\METHOD\SST.MET
Calibration Level : 3
***** PEAKS NOT FOUND IN THIS RUN *****

Name	Adjusted Ret Time	Reference Peak
NITRITE	1.90	0
Oxalate	9.77	1

***** COMPONENTS FOUND IN THIS RUN *****

COMP NUM	COMPONENT NAME	OLD RET. TIME	MEASURED RET. TIME	NEW RET. TIME	OLD HEIGHT	MEASURED HEIGHT	NEW HEIGHT
1	FLUORIDE	0.97	0.97	0.97	1.226e+003	1.226e+003	1.226e+003
2	CHLORIDE	1.53	1.53	1.53	1.017e+003	1.017e+003	1.017e+003
4	NITRATE	3.48	3.45	3.45	2.460e+003	2.460e+003	2.460e+003
5	PHOSPHATE	5.30	5.32	5.32	9.477e+002	9.477e+002	9.477e+002
6	SULFATE	6.55	6.57	6.57	1.890e+003	1.890e+003	1.890e+003


DATA REPROCESSED ON Sun May 06 14:39:59 1990

Sample Name:	AUTOCAL3R	Date:	Wed Feb 14 15:15:50 1990
Data File :	A:\90021401.D05		
Method :	C:\WINDOWS\AI400\METHOD\SST.MET		
Interface :	1 System : 1 Inject#:	5	Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3451
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	4.653e-001	7.271e+003	1226	1	0 0.00%
2	1.53	CHLORIDE	5.941e-001	6.430e+003	1017	1	0 0.00%
3	3.45	NITRATE	4.762e+000	3.077e+004	2460	1	0 0.00%
4	5.32	PHOSPHATE	4.871e+000	1.685e+004	948	1	0 0.00%
5	6.57	SULFATE	4.772e+000	3.686e+004	1890	1	0 0.00%



***** AUTOMATIC CALIBRATION UPDATE *****
Method File: C:\WINDOWS\AI400\METHOD\SST.MET
Calibration Level : 4
***** PEAKS NOT FOUND IN THIS RUN *****

Name	Adjusted Ret Time	Reference Peak
NITRITE	1.90	0
Oxalate	9.77	1

COMPONENTS FOUND IN THIS RUN							
COMP NUM	COMPONENT NAME	OLD RET. TIME	MEASURED RET. TIME	NEW RET. TIME	OLD HEIGHT	MEASURED HEIGHT	NEW HEIGHT
1	FLUORIDE	0.97	0.97	0.97	2.625e+003	2.625e+003	2.625e+003
2	CHLORIDE	1.53	1.53	1.53	2.088e+003	2.088e+003	2.088e+003
4	NITRATE	3.45	3.40	3.40	4.753e+003	4.753e+003	4.753e+003
5	PHOSPHATE	5.32	5.33	5.33	1.886e+003	1.886e+003	1.886e+003
6	SULFATE	6.57	6.57	6.57	4.005e+003	4.005e+003	4.005e+003

DATA REPROCESSED ON Sun May 06 14:40:45 1990

Sample Name: AUTOCAL4R	Date: Wed Feb 14 15:28:08 1990
Data File : A:\90021401.D06	
Method : C:\WINDOWS\AI400\METHOD\SST.MET	
Interface : 1 System : 1 Inject#: 6 Detector: CDM	


***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3451
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME	
1	0.97	FLUORIDE	9.215e-001	1.562e+004	2625	1	0	0.00%
2	1.53	CHLORIDE	1.177e+000	1.371e+004	2088	1	0	0.00%
3	3.40	NITRATE	9.431e+000	6.396e+004	4753	1	0	0.00%
4	5.33	PHOSPHATE	9.647e+000	3.254e+004	1886	1	0	0.00%
5	6.57	SULFATE	9.451e+000	7.900e+004	4005	1	0	0.00%

9 1 1 2 3 5 7 0 7 2 6

File: A:\90021401.D06 Sample: AUTOCAL4R



***** AUTOMATIC CALIBRATION UPDATE *****

Method File: C:\WINDOWS\AI400\METHOD\SST.MET

Calibration Level : 5

***** PEAKS NOT FOUND IN THIS RUN *****

Name	Adjusted Ret Time	Reference Peak
NITRITE	1.90	0
Oxalate	9.77	1

***** COMPONENTS FOUND IN THIS RUN *****

COMP NUM	COMPONENT NAME	OLD RET.TIME	MEASURED RET.TIME	NEW RET.TIME	OLD HEIGHT	MEASURED HEIGHT	NEW HEIGHT
1	FLUORIDE	0.97	0.97	0.97	5.315e+003	5.315e+003	5.315e+003
2	CHLORIDE	1.53	1.53	1.53	4.066e+003	4.066e+003	4.066e+003
4	NITRATE	3.40	3.37	3.37	9.250e+003	9.250e+003	9.250e+003
5	PHOSPHATE	5.33	5.37	5.37	3.876e+003	3.876e+003	3.876e+003
6	SULFATE	6.57	6.58	6.58	8.158e+003	8.158e+003	8.158e+003

DATA REPROCESSED ON Sun May 06 14:41:30 1990

Sample Name: AUTOCAL5R	Date: Wed Feb 14 15:40:27 1990
Data File : A:\90021401.D07	
Method : C:\WINDOWS\AI400\METHOD\SST.MET	
Interface : 1 System : 1 Inject#: 7 Detector: CDM	

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3451


Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	% DELTA BL PEAK RET TIME
1	0.97	FLUORIDE	1.808e+000	3.718e+004	5315	2 0 0.00%
2	1.53	CHLORIDE	2.308e+000	2.837e+004	4066	2 0 0.00%
3	3.37	NITRATE	1.850e+001	1.322e+005	9250	1 0 0.00%
4	5.37	PHOSPHATE	1.892e+001	6.941e+004	3876	1 0 0.00%
5	6.58	SULFATE	1.854e+001	1.636e+005	8158	1 0 0.00%

9 1 1 2 2 , 0 0 7 2 8

File: A:\90021401.D07 Sample: AUTOCAL5R



***** AUTOMATIC CALIBRATION UPDATE *****
Method File: C:\WINDOWS\AI400\METHOD\SST.MET
Calibration Level : 6
***** PEAKS NOT FOUND IN THIS RUN *****

Name	Adjusted Ret Time	Reference Peak
NITRITE	1.90	0
Oxalate	9.77	1

***** COMPONENTS FOUND IN THIS RUN *****

COMP NUM	COMPONENT NAME	OLD RET.TIME	MEASURED RET.TIME	NEW RET.TIME	OLD HEIGHT	MEASURED HEIGHT	NEW HEIGHT
1	FLUORIDE	0.97	0.97	0.97	1.109e+004	1.109e+004	1.109e+004
2	CHLORIDE	1.53	1.53	1.53	9.183e+003	9.183e+003	9.183e+003
4	NITRATE	3.37	3.28	3.28	1.747e+004	1.747e+004	1.747e+004
5	PHOSPHATE	5.37	5.15	5.15	8.003e+003	8.003e+003	8.003e+003
6	SULFATE	6.58	6.43	6.43	1.695e+004	1.695e+004	1.695e+004

DATA REPROCESSED ON Sun May 06 14:42:15 1990

=====

Sample Name:	AUTOCAL6R	Date:	Wed Feb 14 15:52:46 1990
Data File :	A:\90021401.D08		
Method :	C:\WINDOWS\AI400\METHOD\SST.MET		
Interface :	1	System :	1
		Inject#:	8
		Detector:	CDM


=====

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3451
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	% DELTA BL PEAK	RET TIME	
1	0.97	FLUORIDE	3.481e+000	7.412e+004	11092	2	0	0.00%
2	1.53	CHLORIDE	4.444e+000	5.927e+004	9183	2	0	0.00%
3	3.28	NITRATE	3.563e+001	2.741e+005	17468	1	0	0.00%
4	5.15	PHOSPHATE	3.644e+001	1.429e+005	8003	1	0	0.00%
5	6.43	SULFATE	3.570e+001	3.432e+005	16953	1	0	0.00%

File: A:\90021401.D08 Sample: AUTOCAL6R
9 1 1 2 3 3 0 7 7 0



DIONEX SCHEDULE - A:\90021500.SCH

Inj #	Sample Name	Method Name	Data File	Vol.	Dil.	Int.Std.
1	SETUP	...\\sst	...\\900215001	1	0	
2	BLANK	...\\sst	...\\900215001	1	0	
3	LMCS/6C11HI	...\\sst	...\\900215001	101	0	
4	6294	...\\sst	...\\900215001	1111	0	
5	LMCS/6C11HI	...\\sst	...\\900215001	101	0	
6	LMCS/73C11J	...\\sst	...\\900215001	101	0	
7	122B	...\\sst	...\\900215001	1	0	
8	111	...\\sst	...\\900215001	101	0	
9	112D	...\\sst	...\\900215001	101	0	
10	113S	...\\sst	...\\900215001	101	0	
11	63	...\\sst	...\\900215001	101	0	
12	64D	...\\sst	...\\900215001	101	0	
13	LMCS/6C11HI	...\\sst	...\\900215001	101	0	
14	LMCS/73C11J	...\\sst	...\\900215001	101	0	

DATA REPROCESSED ON Sun May 06 13:51:47 1990

Sample Name: LMCS/6C11HI

Date: Thu Feb 15 12:19:28 1990

Data File : A:\90021500.D05

Method : c:\windows\ai400\method\sst.met

ACI Address: 1 System : 1 Inject#: 5 Detector: CDM

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	% DELTA BL PEAK	RET TIME
1	0.97	FLUORIDE	6.704e+001	1.122e+004	1845	1	0 0.00%
2	1.53	CHLORIDE	8.524e+001	9.110e+003	1426	1	0 0.00%
3	3.40	NITRATE	7.100e+002	4.452e+004	3567	1	0 0.00%
4	5.62	PHOSPHATE	6.809e+002	2.401e+004	1309	1	0 0.00%
5	6.80	SULFATE	6.960e+002	5.899e+004	2855	1	0 5.70%

File: A:\90021500.D05 Sample: LMCS/6C11HI



DATA REPROCESSED ON Sun May 06 13:45:02 1990

=====
Sample Name: BLANK Date: Thu Feb 15 11:42:40 1990
Data File : A:\90021500.D02
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 2 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3451

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	% DELTA BL PEAK	RET TIME
1	2.53		0.000e+000	6.737e+004	1200	1	

File: A:\90021500.D02 Sample: BLANK



DATA REPROCESSED ON Mon May 21 07:24:20 1990

=====
Sample Name: 122B Date: Thu Feb 15 12:44:01 1990
Data File : C:\DX\DATA\90021500.D07
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 7 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	1.53	CHLORIDE	7.990e-002	1.008e+003	156	1	0
3	3.89		0.000e+000	5.763e+004	-1	1	0.00%

File: C:\DX\DATA\90021500.D07 Sample: 122B



DATA REPROCESSED ON Thu May 24 07:45:05 1990


=====
Sample Name: 111 Date: Thu Feb 15 12:56:16 1990
Data File : A:\90021500.D08
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 8 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	HEIGHT	REF BL	% DELTA PEAK	RET TIME
1	0.97	FLUORIDE	1.819e+002	3.635e+004	5295	1	0	0.00%
2	1.87	NITRITE	9.151e+001	3.375e+003	458	1	0	0.00%
3	3.43	NITRATE	2.703e+002	1.737e+004	1368	1	0	0.00%
4	5.57	PHOSPHATE	1.411e+003	5.179e+004	2803	1	0	0.00%
5	6.80	SULFATE	4.313e+001	1.605e+003	90	1	0	5.70%

File: A:\90021500.D08 Sample: 111



Note: Chromatogram included for spike calculation. See batch sheet.

DATA REPROCESSED ON Thu May 24 07:18:55 1990

=====
Sample Name: 113S Date: Thu Feb 15 13:20:49 1990
Data File : A:\90021500.D10
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 10 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3451

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF	% DELTA	BL	PEAK	RET TIME
1	0.97	FLUORIDE	4.069e+002	1.000e+005	13231	2	0	0.00%	
2	1.53	CHLORIDE	3.470e+002	4.432e+004	6565	3	0	0.00%	
3	1.87	NITRITE	9.066e+001	3.394e+003	448	4	0	0.00%	
4	3.27	NITRATE	2.951e+003	2.218e+005	14428	1	0	0.00%	
5	5.47	PHOSPHATE	3.877e+003	1.676e+005	8506	2	0	0.00%	
6	6.72	SULFATE	2.672e+003	2.529e+005	12046	2	0	0.00%	

File: A:\90021500.D10 Sample: 113S



DATA REPROCESSED ON Wed May 09 15:10:24 1990

=====
Sample Name: 63 Date: Thu Feb 15 13:33:07 1990
Data File : A:\90021500.D11
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 11 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	1.53	CHLORIDE	1.642e+001	1.736e+003	290	1	0 0.00%
2	1.87	NITRITE	1.624e+002	9.463e+003	1255	1	0 0.00%
3	3.40	NITRATE	5.510e+002	3.598e+004	2775	1	0 0.00%

File: A:\90021500.D11 Sample: 63



DATA REPROCESSED ON Wed May 09 15:04:39 1990

=====

Sample Name: 64D	Date: Thu Feb 15 13:45:22 1990
Data File : A:\90021500.D12	
Method : c:\windows\ai400\method\sst.met	
ACI Address: 1 System : 1 Inject#: 12 Detector: CDM	

=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3451

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	PEAK	% DELTA RET TIME
2	1.87	NITRITE	1.434e+002	7.697e+003	1042	1	0	0.00%
3	3.42	NITRATE	4.672e+002	3.054e+004	2356	1	0	-0.00%

File: A:\90021500.D12 Sample: 64D



DATA REPROCESSED ON Wed May 09 15:07:23 1990

=====
Sample Name: LMCS/6C11HI Date: Thu Feb 15 13:57:37 1990
Data File : A:\90021500.D13
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 13 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	6.706e+001	1.166e+004	1845	1	0 0.00%
2	1.52	CHLORIDE	8.379e+001	8.963e+003	1402	1	0 0.00%
3	3.32	NITRATE	7.593e+002	4.930e+004	3813	1	0 0.00%
4	5.12	PHOSPHATE	7.649e+002	2.497e+004	1477	1	0 -6.97%
5	6.47	SULFATE	7.410e+002	5.990e+004	3050	1	0 0.00%

File: A:\90021500.D13 Sample: LMCS/6C11HI



Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	AL10653
Procedure / Rev	LA-533-105/A-3
Technologist	6B107/N.E. Wright
Date	02/22/90
Temperature	24 C
Starting Time	12:00
Ending Time	14:40
Chemist	H. S. Rich

Ion Chromatograph Analysis

Water Digestion

Re-Ran For Phosphate Only

*Chromatogram Only

	Description	Lab. Id.
1	Eluent Blank	*
2	Initial LMCS Check Std.	F0110
3	Reagent Blank 89-045	F0122
4	Sample 89-045	F0111
5	Duplicate 89-045	F0112
6	Spike 89-045	F0113
7	Sample 89-043	F0063
8	Duplicate 89-043	F0064
9	Final LMCS Check Std.	F0114
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Interim

Rev E 4/04/90

SST-102

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Std.	6C11HI/100uL			10.10mL
Spike	35C9-67/300uL	F0113/3.02mg		5.3mL

Prepared by:	<u>S. A. Cervantes</u> Signature	S. A. Cervantes Printed Name	Date: 06/06/90
Verified by:	<u>C.M. Seidel</u> Signature	C.M. Seidel Printed Name	Date: 06/06/90
Approved by:	<u>L.H. Taylor</u> Signature	L.H. Taylor Printed Name	Date: 9/28/90

DIONEX SCHEDULE - A:\90022200.SCH

Inj #	Sample Name	Method Name	Data File	Vol.	Dil.	Int.Std.
1	SETUP	...\\sst	...\\900222001	1	0	
2	BLANK	...\\sst	...\\900222001	1	0	
3	LMCS/6C11HI	...\\sst	...\\900222001	101	0	
4	LMCS/73C11J	...\\sst	...\\900222001	101	0	
5	122B	...\\sst	...\\900222001	1	0	
6	111	...\\sst	...\\900222001	101	0	
7	112D	...\\sst	...\\900222001	101	0	
8	113S	...\\sst	...\\900222001	101	0	
9	63	...\\sst	...\\900222001	101	0	
10	64D	...\\sst	...\\900222001	101	0	
11	LMCS/6C11HI	...\\sst	...\\900222001	101	0	
12	LMCS/73C11J	...\\sst	...\\900222001	101	0	

DATA REPROCESSED ON Wed Aug 29 13:45:59 1990

Sample Name: LMCS/73C11J

Date: Thu Feb 22 12:13:15 1990

Data File : A:\90-24263.D04

Method : c:\windows\ai400\method\sst.met

ACI Address: 1 System : 1 Inject#: 4 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes

Number of Data Points = 3451

Area reject = 1000


One Data Point per 0.2 seconds

Amount Injected = 1

Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	6.938e+001	1.095e+004	1912	1	0 0.00%
2	1.52	CHLORIDE	8.285e+001	9.123e+003	1386	2	0 0.00%
3	1.85	NITRITE	6.540e+002	5.051e+004	6629	2	0 0.00%
4	3.37	NITRATE	7.114e+002	4.580e+004	3575	1	0 0.00%
5	5.12	PHOSPHATE	6.922e+002	2.241e+004	1331	1	0 -6.97%
6	6.37	SULFATE	7.285e+002	5.774e+004	2996	1	0 0.00%

File: A:\90-24263.D04 Sample: LMCS/73C11J



DATA REPROCESSED ON Wed Aug 29 13:22:25 1990


=====
Sample Name: 122B Date: Thu Feb 22 12:25:34 1990
Data File : A:\90022200.D05
Method : C:\WINDOWS\AI400\METHOD\SST.MET
ACI Address: 1 System : 1 Inject#: 5 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	% DELTA BL PEAK	RET TIME
1	1.52	CHLORIDE	1.244e-001	1.564e+004	228	1	0 0.00%

File: A:\90022200.D05 Sample: 122B



DATA REPROCESSED ON Wed Aug 29 13:35:02 1990


Sample Name: 111 Date: Thu Feb 22 12:37:50 1990
Data File : A:\90022200.D06
Method : C:\WINDOWS\AI400\METHOD\SST.MET
ACI Address: 1 System : 1 Inject#: 6 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3451
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	2.135e+002	3.996e+004	6302	1	0	0.00%
2	1.85	NITRITE	9.251e+001	3.218e+003	469	1	0	0.00%
3	3.40	NITRATE	2.813e+002	1.800e+004	1423	1	0	0.00%
4	5.08	PHOSPHATE	1.550e+003	5.343e+004	3095	1	0	0.00%

File: A:\90022200.D06 Sample: 111



DATA REPROCESSED ON Wed Aug 29 13:37:02 1990

Sample Name: 113S
Data File : A:\90022200.D08
Method : C:\WINDOWS\AI400\METHOD\SST.MET
ACI Address: 1 System : 1 Inject#: 8

Date: Thu Feb 22 13:02:23 1990

Detector: CDM

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3451

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	4.640e+002	1.078e+005	15623	2	0 0.00%
2	1.52	CHLORIDE	3.794e+002	4.754e+004	7338	3	0 0.00%
3	1.85	NITRITE	9.137e+001	3.247e+003	456	4	0 0.00%
4	3.20	NITRATE	3.645e+003	2.721e+005	17684	1	0 0.00%
5	4.98	PHOSPHATE	4.739e+003	1.959e+005	10839	1	0 0.00%
6	6.28	SULFATE	3.501e+003	3.236e+005	16378	1	0 0.00%

File: A:\90022200.D08 Sample: 113S



DATA REPROCESSED ON Wed Aug 29 13:39:02 1990

=====
Sample Name: 63 Date: Thu Feb 22 13:14:42 1990
Data File : A:\90022200.D09
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 9 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.98	FLUORIDE	9.127e+000	1.366e+003	213	1	0 0.00%
2	1.52	CHLORIDE	1.474e+001	1.473e+003	263	1	0 0.00%
3	1.85	NITRITE	1.640e+002	9.247e+003	1273	1	0 0.00%
4	3.37	NITRATE	5.540e+002	3.478e+004	2790	1	0 0.00%

File: A:\90022200.D09 Sample: 63



DATA REPROCESSED ON Wed Aug 29 13:40:23 1990

=====
Sample Name: 64D Date: Thu Feb 22 13:26:58 1990
Data File : A:\90022200.D10
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 10 Detector: CDM
=====

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3451

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	PEAK	% DELTA RET TIME
1	1.53	CHLORIDE	1.343e+001	1.523e+003	242	2	0	0.00%
2	1.85	NITRITE	1.438e+002	7.613e+003	1046	2	0	0.00%
3	3.37	NITRATE	4.514e+002	2.770e+004	2277	1	0	0.00%
4	5.18	PHOSPHATE	8.670e+001	8.244e+003	144	1	0	-5.76%

File: A:\90022200.D10 Sample: 64D



DATA REPROCESSED ON Wed Aug 29 13:41:58 1990

Sample Name: LMCS/6C11HI
Data File : A:\90022200.D11
Method : C:\WINDOWS\AI400\METHOD\SST.MET
ACI Address: 1 System : 1 Inject#: 11 Detector: CDM

Date: Thu Feb 22 13:39:15 1990

***** EXTERNAL STANDARD REPORT *****


Stop time = 11.50 Minutes Number of Data Points = 3451

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	0.97	FLUORIDE	7.285e+001	1.157e+004	2012	1	0 0.00%
2	1.52	CHLORIDE	8.801e+001	9.378e+003	1474	1	0 0.00%
3	3.33	NITRATE	7.474e+002	4.753e+004	3753	1	0 0.00%
4	5.10	PHOSPHATE	7.289e+002	2.432e+004	1405	1	0 0.00%
5	6.35	SULFATE	7.537e+002	5.982e+004	3105	1	0 0.00%

File: A:\90022200.D11 Sample: LMCS/6C11HI



Analytical Batch

LAB SEGMENT SERIAL #: F0053

CUSTOMER ID: 89-043

INSTRUMENT	Dionex 4000
PROCEDURE/REV	LA-533-105/A-3
TECHNOLOGIST	N. E. Wright
DATE	April 06, 1990
TEMPERATURE	22 C
STARTING TIME	1100
ENDING TIME	1515
CHEMIST	H. S. Rich

Ion Chromatograph Analysis
Water Digestion

	DESCRIPTION	LAB ID
1	Initial LMCS Check Std	F0426
2	Reagent Blank 89-070	F0438
3	Sample 89-070	F0427
4	Duplicate Sample 89-070	F0428
5	Spike Sample 89-070	F0429
6	Sample 89-071	F0451
7	Duplicate Sample 89-071	F0452
8	Sample 89-072	F0475
9	Duplicate Sample 89-072	F0476
10	Sample 89-075	F0547
11	Duplicate Sample 89-075	F0548

	DESCRIPTION	LAB ID
12	Sample 89-076	F0571
13	Duplicate Sample 89-076	F0572
14	Sample Comp 7	F0983
15	Duplicate Sample Comp 7	F0984
16	Duplicate Sample 89-043	F0064
17	Final LMCS Ck Std 89-076	F0574
18		
19		
20		
21		
22		

STANDARD TYPE	PRIMARY Book # & ALIQUOT Vol.	SECOND Book # & ALIQUOT Vol.	THIRD Book # & ALIQUOT Vol.	FINAL Vol. OF STD.
LMCS Check Std	6C11H0/100 uL			10.1 mL
Spike	35C977/300 uL			5.3 mL

Detector Parameters

Number of Detectors.....	1
Detector 1 Type.....	CDM

Report Options

Run Time (minutes).....	11.50
Detector 1 real time plot scale.....	20.00
Print Report.....	Yes
Print Replot.....	Yes
AutoScale Replot to Highest Peak.....	Yes
Print Retention Times on Chromatogram.....	Yes
List Peaks Not Found in this run.....	No
Report Unknowns found in run.....	Yes
Record Raw Data.....	Yes
Raw Data File Name: A:\90040300.D05	
Record Result Data.....	No

Integration Parameters

Sampling Rate (seconds).....	0.20
Peak Threshold (mV or uS/data pt interval).....	0.400
Starting Peak Width (seconds).....	10.0
Peak Area Reject.....	1000

Integration Timed Events

Time	Description
-----	-----

Calibration Parameters

External or Internal Calibration.....	External
Calibrate by Area or Height.....	Height
Replace Or Average Calibrations.....	Replace
Number Of Levels for Calibration.....	6
Calibration fit type.....	Quadratic
Response Factor for unknown peaks.....	0.0
Default Injection Volume.....	1.0
Default Dilution Factor.....	1.0
Area Reject for Reference Peaks.....	1000
Percent Retention Time Window for Reference Peaks.....	5.0

Component # 1 FLUORIDE Retention Time 1.02
 Reference Peak C:\WINDOWS\AI400\METHOD\SST.MET Window Size
 Least Squares Slope = 4.11817E-004
 Least Squares Intercept = -6.11181E-002
 Ka = -3.36922E-010

Level	Amount	Area	Height
1	1.19800E-001	1733	320
2	2.98500E-001	4705	821
3	5.94100E-001	9348	1644
4	1.17650E+000	21998	3547
5	2.30800E+000	37180	5315
6	4.44440E+000	74116	11092

Component # 2 CHLORIDE Retention Time 1.62
 Reference Peak C:\WINDOWS\AI400\METHOD\SST.MET Window Size
 Least Squares Slope = 7.20825E-004
 Least Squares Intercept = -7.89437E-002
 Ka = -1.05413E-008

Level	Amount	Area	Height
1	1.51700E-001	1456	241
2	3.78110E-001	4024	594
3	7.52480E-001	8080	1191
4	1.49020E+000	17215	2702
5	2.92300E+000	28370	4066
6	5.62950E+000	59291	9183

Component # 3 NITRITE Retention Time 1.95
 Reference Peak C:\WINDOWS\AI400\METHOD\SST.MET Window Size
 Least Squares Slope = 6.03697E-004
 Least Squares Intercept = 4.43064E-001
 Ka = 3.82504E-009

Level	Amount	Area	Height
1	1.06990E+000	9937	1360
2	2.66670E+000	25698	3515
3	5.30700E+000	53506	7323
4	1.05099E+001	114215	15244
5	2.06146E+001	218918	28443
6	3.97026E+001	440177	49476

Component # 4 BROMIDE Retention Time 3.00
 Reference Peak FLUORIDE Window Size 5.00%
 Least Squares Slope = 1.66948E-003
 Least Squares Intercept = 2.80223E-001
 Ka = -5.76698E-010

Level	Amount	Area	Height
1	1.00100E+000	0	495
2	2.49500E+000	0	1341
3	4.96500E+000	0	2740
4	9.86850E+000	0	5689
5	1.92877E+001	0	11502
6	3.71471E+001	0	22240

Component # 5 NITRATE Retention Time 3.70
 Reference Peak C:\WINDOWS\AI400\METHOD\SST.MET Window Size
 Least Squares Slope = 2.26506E-003
 Least Squares Intercept = -5.58779E-001
 Ka = 2.11324E-008

Level	Amount	Area	Height
1	1.21960E+000	7363	607
2	3.03970E+000	19564	1518
3	6.04950E+000	39111	2906
4	1.19805E+001	83794	5858
5	2.34991E+001	132213	9250
6	4.52580E+001	274103	17468

Component # 6 PHOSPHATE Retention Time 6.03
 Reference Peak C:\WINDOWS\AI400\METHOD\SST.MET Window Size
 Least Squares Slope = 6.51026E-003
 Least Squares Intercept = -2.98628E-001
 Ka = -1.07878E-007


Level	Amount	Area	Height
1	1.20960E+000	3420	198
2	3.01490E+000	9585	519
3	6.00000E+000	19755	1057
4	1.18824E+001	32539	1886
5	2.33068E+001	69406	3876
6	4.48876E+001	142872	8003

Component # 7 SULFATE Retention Time 7.48
 Reference Peak C:\WINDOWS\AI400\METHOD\SST.MET Window Size
 Least Squares Slope = 3.09635E-003
 Least Squares Intercept = -7.42866E-001
 Ka = -2.82182E-008


Level	Amount	Area	Height
1	1.17560E+000	10745	515
2	2.93030E+000	26326	1236
3	5.83170E+000	50588	2357
4	1.15491E+001	79004	4005
5	2.26530E+001	163581	8158
6	4.36284E+001	343157	16953

Component # 8 Oxalate Retention Time 9.77
 Reference Peak FLUORIDE Window Size 10.00%
 Least Squares Slope = 0.00000E+000
 Least Squares Intercept = 0.00000E+000
 Ka = 0.00000E+000


Level	Amount	Area	Height
1	0.00000E+000	0	0
2	0.00000E+000	0	0
3	0.00000E+000	0	0
4	0.00000E+000	0	0
5	0.00000E+000	0	0
6	0.00000E+000	98993	5848




Component: FLUORIDE
Fit Type: Quadratic
Conc = (-3.369224e-010
(4.118173e-004 * Resp)+






Component: CHLORIDE
Fit Type: Quadratic
Conc = (-1.054134e-008
(7.208249e-004 * Resp)+



Component: NITRITE
Fit Type: Quadratic
Conc = (3.824921e-009 *
(6.037006e-004 * Resp)+



Component: BROMIDE
Fit Type: Quadratic
Conc = (-5.766983e-010
(1.669477e-003 * Resp)+



DATA REPROCESSED ON Mon Jul 02 13:05:05 1990

Sample Name: AUTOCAL1R

Date: Tue Apr 03 10:17:01 1990

Data File : A:\90040300.D03

Method : C:\WINDOWS\AI400\METHOD\SST.MET

CIM Address: 1 System : 1 Cycle#: 3 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes

Number of Data Points = 3451


Area reject = 1000

One Data Point per 0.2 seconds

Amount Injected = 1

Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	PEAK	% DELTA RET TIME
1	1.02	FLUORIDE	1.198e-001	1.733e+003	320	1	0	0.00%
2	1.63	CHLORIDE	1.517e-001	1.456e+003	241	1	0	0.00%
3	3.75	NITRATE	1.220e+000	7.363e+003	607	1	0	0.00%
4	6.07	PHOSPHATE	1.210e+000	3.420e+003	198	1	0	0.00%
5	7.52	SULFATE	1.176e+000	1.075e+004	515	1	0	0.00%



DATA REPROCESSED ON Mon Jul 02 14:37:19 1990

Sample Name: AUTOCAL2R
Data File : A:\90040300.D04
Method : C:\WINDOWS\AI400\METHOD\SST.MET
CIM Address: 1 System : 1 Cycle#: 4

Date: Tue Apr 03 10:29:21 1990

Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes

Number of Data Points = 3451


Area reject = 1000

One Data Point per 0.2 seconds

Amount Injected = 1

Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	HEIGHT	BL	REF PEAK	% DELTA RET TIME
1	1.02	FLUORIDE	2.984e-001	4.705e+003	821	1	0	0.00%
2	1.62	CHLORIDE	3.783e-001	4.024e+003	594	1	0	-1.02%
3	3.73	NITRATE	3.039e+000	1.956e+004	1518	1	0	-0.44%
4	6.02	PHOSPHATE	5.755e+000	9.585e+003	519	1	0	-0.82%
5	7.47	SULFATE	6.145e+000	2.633e+004	1236	1	0	-0.67%



DATA REPROCESSED ON Mon Jul 02 14:37:59 1990

Sample Name: AUTOCAL3R

Date: Tue Apr 03 10:41:41 1990

Data File : A:\90040300.D05

Method : C:\WINDOWS\AI400\METHOD\SST.MET

CIM Address: 1 System : 1 Cycle#: 5 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes

Number of Data Points = 3451


Area reject = 1000

One Data Point per 0.2 seconds

Amount Injected = 1

Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	1.02	FLUORIDE	5.941e-001	9.348e+003	1644	1	0 0.00%
2	1.62	CHLORIDE	7.523e-001	8.080e+003	1191	1	0 -1.02%
3	3.70	NITRATE	6.051e+000	3.911e+004	2906	1	0 -1.33%
4	6.03	PHOSPHATE	8.564e+000	1.976e+004	1057	1	0 -0.55%
5	7.48	SULFATE	8.817e+000	5.059e+004	2357	1	0 -0.44%



Sample Name: AUTOCAL4R
 Data File : A:\90040300.D06
 Method : C:\WINDOWS\AI400\METHOD\SST.MET
 CIM Address: 1 System : 1 Cycle#: 6

Date: Tue Apr 03 10:54:02 1990
 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	HEIGHT	REF	% DELTA
					BL	PEAK	RET TIME
1	1.02	FLUORIDE	1.177e+000	2.200e+004	3547.	1	0 0.00%
2	1.63	CHLORIDE	1.490e+000	1.722e+004	2702	1	0 0.00%
3	3.67	NITRATE	1.198e+001	8.379e+004	5858	1	0 -2.22%
4	6.03	PHOSPHATE	1.460e+001	4.206e+004	2212	1	0 -0.55%
5	7.50	SULFATE	1.496e+001	1.068e+005	4931	1	0 -0.22%

6.47

7

C

C

C

V


us

I

I

-

-0.61



DATA REPROCESSED ON Mon Jul 02 14:39:07 1990

Sample Name: AUTOCAL5R
Data File : A:\90040300.D07
Method : C:\WINDOWS\AI400\METHOD\SST.MET
CIM Address: 1 System : 1 Cycle#: 7

Date: Tue Apr 03 11:06:22 1990

Detector: CDM


***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450

Area reject = 1000 One Data Point per 0.2 seconds

Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	% DELTA PEAK	RET TIME
1	1.02	FLUORIDE	3.050e+000	4.520e+004	7323	1	0	0.00%
2	1.63	CHLORIDE	3.751e+000	3.558e+004	5631	1	0	0.00%
3	3.60	NITRATE	2.869e+001	1.757e+005	11209	1	0	-4.00%
4	6.02	PHOSPHATE	2.675e+001	8.811e+004	4535	1	0	-0.82%
5	7.50	SULFATE	2.728e+001	2.192e+005	10100	1	0	-0.22%



DATA REPROCESSED ON Mon Jul 02 14:39:42 1990

Sample Name: AUTOCAL6R
Data File : A:\90040300.D08
Method : C:\WINDOWS\AI400\METHOD\SST.MET
CIM Address: 1 System : 1 Cycle#: 8

Date: Tue Apr 03 11:18:42 1990

Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes

Number of Data Points = 3451


Area reject = 1000

One Data Point per 0.2 seconds

Amount Injected = 1

Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	PEAK	% DELTA RET TIME
1	1.02	FLUORIDE	5.778e+000	9.886e+004	14697	2	0	0.00%
2	1.63	CHLORIDE	7.060e+000	7.699e+004	11887	2	0	0.00%
3	3.52	NITRATE	5.544e+001	3.641e+005	21314	1	0	-6.22%
4	5.92	PHOSPHATE	5.042e+001	1.851e+005	9060	1	0	-2.47%
5	7.40	SULFATE	5.218e+001	4.591e+005	20537	1	0	-1.55%



DIONEX SCHEDULE - A:\90040500.SCH

Inject	Sample Name	Method Name	Data File	Volume	Dilution	Int Std
1	SETUP	c:\windows\ai	c:\windows\ai	1	1	0
2	BLANK	c:\windows\ai	c:\windows\ai	1	1	0
3	LMCS/6C11-HO	c:\windows\ai	c:\windows\ai	1	101	0
4	438B	c:\windows\ai	c:\windows\ai	1	1	0
5	427	c:\windows\ai	c:\windows\ai	1	101	0
6	428D	c:\windows\ai	c:\windows\ai	1	101	0
7	429S	c:\windows\ai	c:\windows\ai	1	101	0
8	451	c:\windows\ai	c:\windows\ai	1	101	0
9	452D	c:\windows\ai	c:\windows\ai	1	101	0
10	475	c:\windows\ai	c:\windows\ai	1	101	0
11	476D	c:\windows\ai	c:\windows\ai	1	101	0
12	547	c:\windows\ai	c:\windows\ai	1	101	0
13	548D	c:\windows\ai	c:\windows\ai	1	101	0
14	571	c:\windows\ai	c:\windows\ai	1	101	0
15	572D	c:\windows\ai	c:\windows\ai	1	101	0
16	983	c:\windows\ai	c:\windows\ai	1	51	0
17	984D	c:\windows\ai	c:\windows\ai	1	51	0
18	64D	c:\windows\ai	c:\windows\ai	1	101	0
19	LMCS/6C11-HO	c:\windows\ai	c:\windows\ai	1	101	0

data\900-5943.cl

=====


: Sample Name: LMCS/6C11-HO Date: Thu Apr 05 12:09:18 1990
: Data File: c:\windows\ai400\data\900-5963.d03
: Method : c:\windows\ai400\method\sst.met
: CIM Address: 1 System : 1 Cycle#: 3 Detector: CDM

=====

***** EXTERNAL STANDARD REPORT *****

Start Time = 0.00 minutes Stop time = 11.50 Minutes
Number of Data Points = 3450 One Data Point per 0.2 seconds
Dareject = 1000
Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF			% DELTA
					HEIGHT	BL	PEAK RET TIME	
1	1.00	FLUORIDE	5.097e+001	9.542e+003	1452	1	0	-1.64%
2	1.58	CHLORIDE	7.181e+001	7.920e+003	1209	1	0	-3.06%
3	3.52	NITRATE	6.106e+002	3.939e+004	2949	1	0	0.00%
4	5.88	PHOSPHATE	6.038e+002	2.002e+004	1084	1	0	-0.56%
5	7.02	SULFATE	6.268e+002	5.312e+004	2626	1	0	-5.18%




```
: Sample Name: 43BB Date: Thu Apr 05 12:21:34 1990  
: Data File. : c:\windows\ai400\data\900-5963.d04  
: Method : c:\windows\ai400\method\sst.met  
: CIM Address: 1 System : 1 Cycle#: 4 Detector: CDM
```

```
***** EXTERNAL STANDARD REPORT *****
```

Start Time = 0.00 minutes Stop time = 11.50 Minutes
Number of Data Points = 3450 One Data Point per 0.2 seconds
Areareject = 1000
Amount Injected = 1 Dilution factor = 1

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF	% DELTA	BL	PEAK	RET TIME
f	1.60	CHLORIDE	2.017e-001	1.746e+004	266	1	0	-2.04%	



DATA REPROCESSED ON Thu Aug 23 13:17:53 1990


Sample Name: 429S Date: Thu Apr 05 13:58:17 1990
Data File : A:\90040500.D07
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 7 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	1.00	FLUORIDE	3.052e+002	7.634e+004	9685	2	0 0.00%
2	1.58	CHLORIDE	4.348e+002	5.743e+004	8656	3	0 0.00%
3	1.93	NITRITE	1.089e+002	6.323e+003	836	4	0 0.00%
4	3.35	NITRATE	3.839e+003	2.908e+005	17987	1	0 0.00%
5	5.77	PHOSPHATE	3.452e+003	1.356e+005	6762	2	0 0.00%
6	6.93	SULFATE	3.527e+003	3.404e+005	16085	2	0 -6.31%

File: A:\90040500.D07 Sample: 429S



DATA REPROCESSED ON Thu Aug 23 13:35:41 1990


Sample Name: 64D	Date: Thu Apr 05 16:13:19 1990
Data File : A:\90040500.D18	
Method : c:\windows\ai400\method\sst.met	
ACI Address: 1	System : 1 Inject#: 18 Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL	PEAK	% DELTA RET TIME
1	1.03	FLUORIDE	9.202e+000	1.240e+003	167	1	0	0.00%
2	1.37		0.000e+000	1.122e+003	154	1		
3	1.93	NITRITE	1.316e+002	7.996e+003	1079	1	0	0.00%
4	3.57	NITRATE	4.812e+002	2.970e+004	2332	1	0	0.00%
5	6.98	SULFATE	2.971e+001	1.380e+003	86	1	0	-5.63%

File: A:\90040500.D18 Sample: 64D



DATA REPROCESSED ON Thu Aug 23 13:37:04 1990

Sample Name: LMCS/6C11-HO
Data File : A:\90040500.D19
Method : c:\windows\ai400\method\sst.met
ACI Address: 1 System : 1 Inject#: 19

Date: Thu Apr 05 16:25:34 1990


Detector: CDM

***** EXTERNAL STANDARD REPORT *****

Stop time = 11.50 Minutes Number of Data Points = 3450
Area reject = 1000 One Data Point per 0.2 seconds
Amount Injected = 1 Dilution factor = 101

PEAK NUM	RET TIME	PEAK NAME	CONC. in ug/ml	AREA	REF HEIGHT	BL PEAK	% DELTA RET TIME
1	1.00	FLUORIDE	5.094e+001	9.493e+003	1451	1	0 0.00%
2	1.58	CHLORIDE	7.021e+001	7.816e+003	1180	1	0 0.00%
3	3.53	NITRATE	6.154e+002	3.890e+004	2971	1	0 0.00%
4	5.85	PHOSPHATE	6.079e+002	2.009e+004	1091	1	0 0.00%
5	6.95	SULFATE	6.252e+002	5.262e+004	2619	1	0 -6.08%

File: A:\90040500.D19 Sample: LMCS/6C11-HO



Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WB39937
Procedure / Rev	LA-344-105/A-3
Technologist	E. Colvin/80028
Date	1-11-90
Temperature	N/A
Starting Time	0800
Ending Time	1600
Chemist	R. E. Brandt

Total Organic Carbon

Water Digestion

Samples were not acidified before analysis.
Results reported are TOC and carbonate combined.

	Description	Lab. Id.
1	Blank 89-043	F0074
2	Initial LMCS Check Std	F0062
3	Sample 89-043	F0063
4	Duplicate 89-043	F0064
5	Spike 89-043	F0065
6	Final LMCS Check Std	F0066
7		
8		
9		
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Standard	70C11B/200 uL			2.2 mL
Spike	70C11B/200 uL	F0063/200 uL		.4 mL

Interim

Rev. E 4/04/90

SST-102

Prepared by: Shirley Cervantes S. A. Cervantes Date: Aug. 29, 1990
 Signature Printed Name

Verified by: Cary M Seidel C. M. Seidel Date: Sept. 1, 1990
 Signature Printed Name

Approved by: L H Taylor L H Taylor Date: 9/28/90
 Signature Printed Name

COULOMETER ANALYSIS REPORT
TICTOC Rev. 0

Sample: F-74 Date: 01-11-1990 Time: 10:32:43
Blank = N/A Sample Size = 200 Dilution Factor = 1
% Difference = 10 Min Readings = 7 Max Readings = 10

	Reading	Analysis Time	Coulometer	% Difference
1	1.01	0.00	0.00	0.00
2	2.01	1.80	100.00	
3	3.01	4.80	35.71	
4	4.01	5.30	15.15	
5	5.01	4.10	17.51	
6	6.01	4.70	16.33	
7	7.01	5.50	10.71	
8	8.01	6.20	11.29	
9	9.01	6.70	10.14	
10	10.01	7.60	7.21	

BLANK VALUE = 7.6 / 10.00568 = .7595688 ug/minute

COULOMETER ANALYSIS REPORT
TICTOC Rev. 0

Sample: F-62

Date: 01-11-1990 Time: 10:44:12

Blank = .7595688 Sample Size = 200 Dilution Factor = 11
% Difference = 10 Min Readings = 7 Max Readings = 10

== Reading ===== Analysis Time ===== Coulometer ===== % Difference ==
1 1.01 0.00 0.00

2 2.01 42.90 100.00

3 3.01 52.10 17.00

4 4.01 55.50 6.13

5 5.01 57.00 2.00

6 6.01 58.10 1.89

7 7.01 57.10 1.07

$$(57.1 - 5.321386)(11)/(200) = 2.957824 \text{ g/L Carbon}$$

$$(59.1 - 5.321386)(11)/(200)(12) = .2464853 \text{ Molar Carbon}$$

Sample Run By: 8002B_____

COULOMETER ANALYSIS REPORT
TICTOC Rev. 0

Sample: F-63 Date: 01-11-1990 Time: 10:56:06

Blank = .7595688 Sample Size = 200 Dilution Factor = 1
% Difference = 10 Min Readings = 7 Max Readings = 10

== Reading ===== Analysis Time ===== Coulometer ===== % Difference ==
1 1.01 0.00 0.00

2	2.01	5.70	100.00
3	3.01	7.60	22.57
4	4.01	8.50	10.57
5	5.01	9.30	5.00
6	6.01	10.30	7.71
7	7.01	10.40	5.50

O
P
R
C
C
-
2
-
1
6

$$(10.4 - 5.322035)(1)/(200) = 2.788982E-02 \text{ g/L Carbon}$$

$$(10.9 - 5.322035)(1)/(200)(12) = 2.324152E-03 \text{ Molar Carbon}$$

Sample Run By: 80028 _____

COULOMETER ANALYSIS REPORT
TICTOC Rev. 0

Sample: F-04

Date: 01-11-1990 Time: 11:04:51

Blank = .7595688 Sample Size = 200 Dilution Factor = 1
% Difference = 10 Min Readings = 7 Max Readings = 10

== Reading ===== Analysis Time ===== Coulometer ===== % Difference ==
1 1.01 0.00 0.00

2 2.01 5.70 100.00

3 3.01 7.20 20.60

4 4.01 8.20 12.20

5 5.01 7.10 7.87

6 6.01 7.80 7.14

7 7.01 10.50 0.07

$$(10.5 - 5.32134)(1)/(200) = .0258933 \text{ g/L Carbon}$$

$$(10.5 - 5.32134)(1)/(200)(12) = 2.157775E-03 \text{ Molar Carbon}$$

Sample Run By: 80028 _____

COULOMETER ANALYSIS REPORT
TICTOC Rev. 0

Sample: F-65

Date: 01-11-1990 Time: 14:32:38

Blank = .7595688
% Difference = 10

Sample Size = 200 Dilution Factor = 1
Min Readings = 7 Max Readings = 10

== Reading ===== Analysis Time ===== Coulometer ===== % Difference ==
1 1.01 0.00 0.00

2 2.01 133.50 100.00

3 3.01 163.60 18.40

4 4.01 176.20 7.15

5 5.01 181.60 2.77

6 6.01 184.30 1.47

7 7.01 185.80 0.81

$$(185.8 - 5.322035)(1)/(200) = .9023898 \text{ g/L Carbon}$$

$$(185.8 - 5.322035)(1)/(200)(12) = 7.519915E-02 \text{ Molar Carbon}$$

Sample Run By: 80028_____

COULOMETER ANALYSIS REPORT
11CTDC Rev. 0

Sample: F-66

Date: 01-11-1990 Time: 14:41:11

Blank = .7595688
% Difference = 10

Sample Size = 200 Dilution Factor = 11
Min Readings = 7 Max Readings = 10

== Reading ===== Analysis Time ===== Coulometer ===== % Difference ==
1 1.01 0.00 0.00

2 2.01 39.10 100.00

3 3.01 47.70 18.03

4 4.01 51.90 8.09

5 5.01 54.00 3.87

6 6.01 55.40 2.53

7 7.01 56.50 1.70

(56.5 - 5.321432) (11) / (200) = 2.814821 g/L Carbon

(56.5 - 5.321432) (11) / (200) (12) = .2345684 Molar Carbon

Sample Run By: 8002B_____

9 1 1 2 0 3 0 0 7 7 4

ACID DIGESTION TEST ANALYSIS

Data Summary

Date Analyzed:	April 19, 1990	Acid Digested Standard	F1083
Procedure:	LA-505-151/A-0	Reagent Blank	F1084
Analyst:	J. A. White	Sample 89-043	F0068
Digestion	Acid Digestion	Duplicate of 89-043	F0069
Procedure:	LA-505-159/A-0	Spike of 89-043	F1087
		Acid Digested Standard	F1088

	Instrument Starting Standard	Acid Digest. Standard	Reagent BLANK	Wet Weight ug/g	Wet Weight Duplicate ug/g	Spike Recovery %	LMCS ACID Digestion %	Closing LMCS Standard
Aluminum	100.37%		0.07 LT	94285	88959	NOT CALC.	100.63%	100.81%
Antimony	105.91%		-0.01 LT	579	203 LT			102.57%
Barium	104.16%		-0.01 LT	74	38	103.28%	92.28%	102.53%
Beryllium	98.38%		0.00 LT	3	0 LT			97.50%
Bismuth	108.36%	102.12%	-0.01 LT	5381	4709	NOT CALC.		106.64%
Boron	101.73%	94.43%	0.03	62	20 LT	134.81%		99.43%
Cadmium	100.12%	93.46%	0.00 LT	8 LT	-11 LT	89.32%		97.72%
Calcium	106.89%	102.58%	0.09	1098	905	146.72%		105.03%
Chromium	95.51%		-0.03 LT	448	511	235.92%	84.79%	93.30%
Cobalt	97.27%		0.02 LT	79	8 LT	85.08%	86.00%	93.22%
Copper	105.17%	99.09%	-0.01 LT	97	12 LT	100.71%		103.36%
Europium	98.92%		-0.01 LT	8	-16 LT			97.72%
Iron	103.46%		0.03	18001	18129	NOT CALC.	94.41%	101.50%
Lanthanum	94.12%	91.05%	-0.02 LT	68	-20 LT	89.51%		92.92%
Lead	106.64%	99.04%	0.01 LT	1344	3045	93.18%		104.61%
Lithium	106.08%		-0.01 LT	13	-46 LT	91.11%	93.39%	103.61%
Magnesium	104.79%	97.56%	0.02	8338	1444	4138.61%		102.45%
Manganese	102.81%		0.01	6755	6547	NOT CALC.	92.70%	100.65%
Mercury	102.27%		-0.05 LT	40	43			101.94%
Molybdenum	97.14%	93.73%	0.00 LT	40	8 LT	85.72%		97.14%
Nickel	101.54%		-0.01 LT	192	131	98.98%	92.68%	99.05%
Potassium	99.66%	82.65%	-0.53 LT	275 LT	-1543 LT	73.37%		97.22%
Samarium	99.36%		-0.35 LT	496	-1085 LT			96.54%
Selenium	105.01%		-0.06 LT	761	316			104.86%
Silver	107.97%		-0.02 LT	54 LT	-42 LT	53.52%		106.46%
Sodium	102.01%	94.66%	0.06 LT	79677	75641	NOT CALC.		100.05%
Strontium	105.80%	100.02%	0.00 LT	777	756	86.77%		104.01%
Sulfur	106.08%		0.03	511	377			107.95%
Tantalum	96.38%		-0.04 LT	96	-124 LT	27.57%	73.62%	96.12%
Thallium	105.99%		-0.33 LT	1733	-94 LT			106.22%
Thorium	106.38%		-0.18 LT	476	-589 LT			104.74%
Tin	100.85%		0.02 LT	112	53	102.74%	93.54%	98.35%
Titanium	100.86%		0.13	157	113	90.61%	92.17%	101.40%
Uranium	106.74%		-2.40 LT	18706	8238			103.29%
Vanadium	99.32%		-0.02 LT	92	13 LT			100.05%
Zinc	100.91%	93.05%	0.23	735	274	66.80%		98.82%
Zirconium	101.51%		-0.04 LT	96	24 LT	46.04%	93.47%	100.46%

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

Prepared by: J. S. Rich

H. S. Rich Date: May 21, 1990

Verified by: Kary M. Seidel

C. M. Seidel Date: May 21, 1990

Approved by: L. H. Taylor

L. H. Taylor Date: 9/28/90

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

ICP acid digestion of sample 89-043.

Instrument	na
Procedure / Rev	LA-505-159/A-0
Technologist	D. M. Southwick
Date	Jan. 31, 1990
Temperature	na
Starting Time	08:00
Ending Time	14:45
Chemist	S. A. Jones

	Description	Lab. Id.
1	Reagent Blank	F0075
2	Sample 89-043	F0068
3	Duplicate of 89-043	F0069
4	Sample 89-045	F0116
5	Duplicate of 89-045	F0117
6	Spike of F0116	F0118
7		
8		
9		
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

	Primary Book Standard Type	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
	Spike F0118	103C15C/5.0mL	104C15D/5.0mL	F0116/0.5033g
				50.0 mL

Interim

4/04/90

Rev. E

SST-102

Prepared by:	<u>H. S. Rich</u> Signature	H. S. Rich Printed Name	Date: May 22, 1990
Verified by:	<u>C. M. Seidel</u> Signature	C. M. Seidel Printed Name	Date: May 22, 1990
Approved by:	<u>L. H. Taylor</u> Signature	L. H. Taylor Printed Name	Date: 9/28/90

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WB39939
Procedure / Rev	LA-505-151/A-0
Technologist	J. A. White
Date	April 19, 1990
Temperature	70 F
Starting Time	07:47
Ending Time	15:00
Chemist	S. A. Jones

ICP analysis of sample 89-043.
Only data directly related to the analysis of
89-043 will be included in this package.
No inter-element corrections were made on
this data.

	Description	Lab. Id.
1	Initial LMCS Check Std.	na
2	Digested Std. (81C11A)	F1083
3	Reagent Blank	F1084
4	Sample Comp. Core 13	F1085
5	Duplicate Core 13	F1086
6	Spike of F1085	F1087
7	Digested Std. (82C11A)	F1088
8	LMCS Check Std.	na
9	Sample Comp. Core 5	F0899
10	Duplicate Core 5	F0900
11	Acid Blank	na

	Description	Lab. Id.
12	Sample 89-043	F0068
13	Duplicate of 89-043	F0069
14	Sample 89-044	F0092
15	Duplicate of 89-044	F0093
16	LMCS Check Std.	na
17	Sample 89-047	F0140
18	Duplicate of 89-047	F0141
19	Sample 89-048	F0164
20	Duplicate of 89-048	F0165
21	Sample Comp. Core 8	F0959
22	Duplicate of Core 8	F0960

	Primary Book	Second Book	Third Book	Final Volume of Standard
Standard Type	No. & Aliquot	No. & Aliquot	No. & Aliquot	
LMCS Check Std.	78C11J/1.0mL	82B38F/1.0mL	77C11I/1.0mL	11.0 mL
Digested LMCS (1)	81C11A/5.0mL			50.0 mL
Digested LMCS (2)	82C11A/5.0mL			50.0 mL
Spike F1087	34C11CO/5.0mL	34C11CK/5.0mL	F1085/0.5143g	50.0 mL

Interim

4/04/90

Rev E

SST-102

Prepared by:	<u>H. S. Rich</u> Signature	H. S. Rich Printed Name	Date: May 22, 1990
Verified by:	<u>C. M. Seidel</u> Signature	C. M. Seidel Printed Name	Date: May 22, 1990
Approved by:	<u>L. H. Taylor</u> Signature	L. H. Taylor Printed Name	Date: 9/28/90

Analytical Batch

Lab Segment Serial No.: F0053

Customer ID.: 89-043

Instrument	WB39939
Procedure / Rev	LA-505-151/A-0
Technologist	J. A. White
Date	April 19, 1990
Temperature	70 F
Starting Time	07:47
Ending Time	15:00
Chemist	S. A. Jones

ICP analysis of sample 89-043.
 Only data directly related to the analysis of
 89-043 will be included in this package.
 No inter-element corrections were made on
 this data.

	Description	Lab. Id.
1	LMCS Check Std.	na
2	Sample Comp. Core 15	F1037
3	Duplicate of Core 15	F1038
4	Closing LMCS Check Std.	na
5		
6		
7		
8		
9		
10		
11		

	Description	Lab. Id.
12		
13		
14		
15		
16		
17		
18		
19		
20		
21		
22		

Standard Type	Primary Book No. & Aliquot	Second Book No. & Aliquot	Third Book No. & Aliquot	Final Volume of Standard
LMCS Check Std.	78C11J/1.0mL	82B38F/1.0mL	77C11I/1.0mL	11.0 mL
Digested LMCS (1)	81C11A/5.0mL			50.0 mL
Digested LMCS (2)	82C11A/5.0mL			50.0 mL
Spike F1087	34C11CO/5.0mL	34C11CK/5.0mL	F1085/0.5143g	50.0 mL


Interim


4/04/90

Rev E

SST-102

Prepared by:  H. S. Rich Date: May 22, 1990
 Printed Name

Verified by:  C. M. Seidel Date: May 22, 1990
 Printed Name

Approved by:  L. H. Taylor Date: 9/28/90
 Printed Name

ICP Results

Raw Data Summary

Date Analyzed:	April 19, 1990	Acid Digested Standard	F1083
Procedure:	LA-505-151/A-0	Reagent Blank	F1084
Analyst:	J. A. White	Sample 89-043	F0068
Digestion	Acid Digestion	Duplicate of 89-043	F0069
Procedure:	LA-505-159/A-0	Spike of 89-043	F1087
		Acid Digested Standard	F1088

	Instrument Starting Standard %	Acid Digest. LMCS Standard %	Reagent BLANK ppm	Wet Weight Sample ug/g	Wet Weight Sample Duplicate ug/g	Spike Recovery % NOT CALC.	LMCS ACID Digestion %	Closing LMCS Standard %
Aluminum	100.37%		0.07 LT	94285	88959	NOT CALC.	100.63%	100.81%
Antimony	105.91%		-0.01 LT	579	203 LT			102.57%
Arsenic	115.53%		-0.02 LT	113	36 LT			115.75%
Barium	104.16%		-0.01 LT	74	38	103.28%	92.28%	102.53%
Beryllium	98.38%		0.00 LT	3	0 LT			97.50%
Bismuth	108.36%	102.12%	-0.01 LT	5381	4709	NOT CALC.		106.64%
Boron	101.73%	94.43%	0.03	62	20 LT	134.81%		99.43%
Cadmium	100.12%	93.46%	0.00 LT	8 LT	-11 LT	89.32%		97.72%
Calcium	106.89%	102.58%	0.09	1098	905	146.72%		105.03%
Cerium	91.75%		-0.31 LT	439	-906 LT	15.40%	88.66%	88.57%
Chromium	95.51%		-0.03 LT	448	511	235.92%	84.79%	93.30%
Cobalt	97.27%		0.02 LT	79	8 LT	85.08%	86.00%	93.22%
Copper	105.17%	99.09%	-0.01 LT	97	12 LT	100.71%		103.36%
Europium	98.92%		-0.01 LT	8	-16 LT			97.72%
Iron	103.46%		0.03	18001	18129	NOT CALC.	94.41%	101.50%
Lanthanum	94.12%	91.05%	-0.02 LT	68	-20 LT	89.51%		92.92%
Lead	106.64%	99.04%	0.01 LT	1344	3045	93.18%		104.61%
Lithium	106.08%		-0.01 LT	13	-46 LT	91.11%	93.39%	103.61%
Magnesium	104.79%	97.56%	0.02	8338	1444	4138.61%		102.45%
Manganese	102.81%		0.01	6755	6547	NOT CALC.	92.70%	100.65%
Mercury	102.27%		-0.05 LT	40	43			101.94%
Molybdenum	97.14%	93.73%	0.00 LT	40	8 LT	85.72%		97.14%
Neodymium	90.76%		-0.64 LT	-509 LT	-1722 LT	NOT CALC.	77.36%	87.52%
Nickel	101.54%		-0.01 LT	192	131	98.98%	92.68%	99.05%
Phosphorus	115.73%	93.37%	0.11	2788	3519	NOT CALC.		118.51%
Potassium	99.66%	82.65%	-0.53 LT	275 LT	-1543 LT	73.37%		97.22%
Samarium	99.36%		-0.35 LT	496	-1085 LT			96.54%
Selenium	105.01%		-0.06 LT	761	316			104.86%
Silicon	90.40%	75.18%	0.63	3187	2718	-114.70%		90.53%
Silver	107.97%		-0.02 LT	54 LT	-42 LT	53.52%		106.46%
Sodium	102.01%	94.66%	0.06 LT	79677	75641	NOT CALC.		100.05%
Strontium	105.80%	100.02%	0.00 LT	777	756	86.77%		104.01%
Sulfur	106.08%		0.03	511	377			107.95%
Tantalum	96.38%		-0.04 LT	96	-124 LT	27.57%	73.62%	96.12%
Thallium	105.99%		-0.33 LT	1733	-94 LT			106.22%
Thorium	106.38%		-0.18 LT	476	-589 LT			104.74%
Tin	100.85%		0.02 LT	112	53	102.74%	93.54%	98.35%
Titanium	100.86%		0.13	157	113	90.61%	92.17%	101.40%
Tungsten	83.72%		-0.02 LT	163	19 LT			83.88%
Uranium	106.74%		-2.40 LT	18706	8238			103.29%
Vanadium	99.32%		-0.02 LT	92	13 LT			100.05%
Zinc	100.91%	93.05%	0.23	735	274	66.80%		98.82%
Zirconium	101.51%		-0.04 LT	96	24 LT	46.04%	93.47%	100.46%

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

Date Analyzed:	April 19, 1990	Acid Digested Standard	F1083
Procedure:	LA-505-151/A-0	Reagent Blank	F1084
Analyst:	J. A. White	Sample 89-043	F0068
Digestion	Acid Digestion	Duplicate of 89-043	F0069
Procedure:	LA-505-159/A-0	Spike of 89-043	F1087
		Acid Digested Standard	F1088

			Starting LMCS Standard	LMCS Acid Instrument Standard	Acid Digestion Standard	Reagent Blank	Weight Volume Sample
			Instrument Standard	Recovery %	Digestion Standard	Recovery %	Dilution Three ppm
			ppm	%	ppm	ppm	ppm
	SST-1	SST-2	SST-3				
Aluminum			50.18	100.37%			0.07 LT
Antimony	10.59			105.91%			-0.01 LT
Arsenic			57.77	115.53% #			-0.02 LT
Barium	10.42			104.16%			-0.01 LT
Beryllium			9.84	98.38%			0.00 LT
Bismuth		54.29		108.36%	10.21	102.12%	-0.01 LT
Boron	10.17			101.73%	9.44	94.43%	0.03
Cadmium	10.01			100.12%	9.35	93.46%	0.00 LT
Calcium	10.69			106.89%	10.26	102.58%	0.09
Cerium	9.18			91.75%			-0.31 LT
Chromium	9.55			95.51%			-0.03 LT
Cobalt	9.73			97.27%			0.02 LT
Copper	10.52			105.17%	9.91	99.09%	-0.01 LT
Europium		9.89		98.92%			-0.01 LT
Iron	10.35			103.46%			0.03
Lanthanum		47.15		94.12%	9.11	91.05%	-0.02 LT
Lead		53.43		106.64%	9.90	99.04%	0.01 LT
Lithium	10.61			106.08%			-0.01 LT
Magnesium	10.48			104.79%	9.76	97.56%	0.02
Manganese	10.28			102.81%			0.01
Mercury		25.57		102.27%			-0.05 LT
Molybdenum		48.57		97.14%	9.35	93.73%	0.00 LT
Neodymium	9.08			90.76%			-0.64 LT
Nickel	10.15			101.54%			-0.01 LT
Phosphorus		57.86	115.73% #		9.34	93.37%	0.11
Potassium	24.91			99.66%	8.27	82.65%	-0.53 LT
Samarium		9.94		99.36%			-0.35 LT
Selenium		52.51		105.01%			-0.06 LT
Silicon		45.20		90.40%	7.52	75.18%	0.63
Silver		10.80		107.97%	7.42		-0.02 LT
Sodium	25.50			102.01%	9.47	94.66%	0.06 LT
Strontium	10.58			105.80%	10.00	100.02%	0.00 LT
Sulfur		53.04		106.08%			0.03
Tantalum		48.19		96.38%			-0.04 LT
Thallium		53.00		105.99%			-0.33 LT
Thorium		53.29		106.38%			-0.18 LT
Tin	50.43			100.85%			0.02 LT
Titanium		50.43		100.86%			0.13
Tungsten		20.93	83.72% #				-0.02 LT
Uranium		53.48		106.74%			-2.40 LT
Vanadium			9.93	99.32%			-0.02 LT
Zinc	10.09			100.91%	9.31	93.05%	0.23
Zirconium			50.76	101.51%			-0.04 LT
Dilution Factor	1.00	1.00	1.00		10.00		1.00
							1.00

LT: Less Than

NC: Not Calibrated

NOT CALC: Not Calculated

Instrument Standards Outside Control Limits

	Grams/mL		Grams/mL		Grams/mL		
Digestion	#	Digestion	#	Digestion	#		
Sample	Sample	Sample	Sample	Spike of	Spike of	Spike of	
Dilution	Dilution	Duplicate	Duplicate	Duplicate	Dilution	Dilution	
Two	One	Dilution	Dilution	Dilution	Three	Two	
ppm	ppm	ppm	ppm	ppm	ppm	One	
Aluminum	941.15	936.66	858.81	881.73	507.09	473.99	NOT CALC.
Antimony	4.47	5.78	19.36	1.96 LT	13.40	14.24	
Arsenic	-1.03	1.12	1.19	0.35 LT	-0.58	1.02	
Barium	-0.04	0.74	0.76	0.37	10.83	10.57	103.28%
Beryllium	0.01	0.03	0.10	0.00 LT	0.02	0.03	
Bismuth	50.34	53.71	55.28	45.46	160.79	176.36	NOT CALC.
Boron	1.55	0.62	1.01	0.19 LT	14.10	10.25	134.81%
Cadmium	-0.45	0.08 LT	-0.02	-0.11 LT	9.00	10.03	89.32%
Calcium	10.96	8.64	8.74	8.49	20.40	14.91	146.72%
Cerium	-22.21	4.39	9.45	-8.74 LT	-30.01	1.54 LT	15.40%
Chromium	4.48	6.08	2.24	4.93	30.54	19.37	235.92%
Cobalt	2.01	0.78	3.14	0.08 LT	8.30	9.83	85.08%
Copper	-0.45	0.97	1.13	0.12 LT	9.26	10.82	100.71%
Europium	-0.45	0.08	0.14	-0.16 LT	-0.57	0.04 LT	
Iron	179.69	174.84	175.02	174.19	218.35	212.56	NOT CALC.
Lanthanum	-0.91	0.68	2.60	-0.19 LT	7.16	9.85	89.51%
Lead	8.61	13.42	29.40	9.69	17.21	20.87	93.18%
Lithium	-1.06	0.13	0.21	-0.44 LT	9.24	10.65	91.11%
Magnesium	83.23	18.14	13.94	14.37	416.09	37.95	4138.61%
Manganese	67.43	65.54	63.21	62.55	56.88	57.54	NOT CALC.
Mercury	0.77	0.40	0.95	0.41	-2.46	-0.27 LT	
Molybdenum	-0.15	0.40	0.70	0.08 LT	8.93	9.87	85.72%
Neodymium	-66.63	-5.08 LT	-36.44	-16.62 LT	-66.75	0.47 LT	NOT CALC.
Nickel	0.85	1.92	2.11	1.26	9.91	11.36	98.98%
Phosphorus	29.03	27.83	33.98	22.89	116.71	118.22	NOT CALC.
Potassium	-42.76	2.75 LT	-4.95	-14.90 LT	-34.01	9.41	73.37%
Samarium	-26.21	4.95	11.38	-10.47 LT	-36.47	0.62 LT	
Selenium	0.88	7.59	11.16	3.05	7.17	9.37	
Silicon	29.29	31.81	26.09	26.24	42.19	25.60	-114.70%
Silver	-1.23	0.54 LT	0.89	-0.41 LT	4.89	5.71	53.52%
Sodium	795.34	781.86	730.24	721.33	838.67	827.74	NOT CALC.
Strontium	7.76	7.81	7.30	7.11	14.46	14.97	86.77%
Sulfur	11.37	5.11	4.83	3.64	67.98	12.69	
Tantalum	-2.32	0.96	1.96	-1.20 LT	-0.70	3.53	27.57%
Thallium	-8.31	17.30	19.44	-0.91 LT	-18.49	7.30	
Thorium	-14.34	4.75	10.36	-5.69 LT	-19.12	2.21	
Tin	1.06	1.11	1.29	0.51	14.05	10.97	102.74%
Titanium	0.66	1.57	1.68	1.09	9.35	9.90	90.61%
Tungsten	-1.33	1.63	1.71	0.18 LT	-2.06	1.00	
Uranium	-16.63	186.72	184.36	79.53	-175.80	60.96	
Vanadium	0.03	0.92	0.89	0.13 LT	-0.93	0.32 LT	
Zinc	7.34	1.38	2.64	1.24	25.48	13.50	66.80%
Zirconium	-1.71	0.96	2.48	0.24 LT	1.83	5.97	46.04%
Dilution Factor	101.00	21.00	1.00	101.00	21.00	1.00	101.00
							21.00

	Standard LMCS Acid Digestion ppm	Acid Digestion Standard Recovery %		Ending LMCS Standard Recovery %	Spike Standard LMCS ppm added	Spike Standard ID Book #	
			SST-1	SST-2	SST-3		SST-1
Aluminum	10.06	100.63%		50.41	100.81%	10.00	
Antimony			10.26		102.57%		10.00
Arsenic				57.88	115.75% #		
Barium	9.23	92.28%	10.25		102.53%	10.00	10.00
Beryllium				9.75	97.50%		
Bismuth				53.43	106.64%	10.00	
Boron			9.94		99.43%	10.00	10.00
Cadmium			9.77		97.72%	10.00	10.00
Calcium			10.50		105.03%	10.00	10.00
Cerium	8.87	88.66%	8.86		88.57% #	10.00	10.00
Chromium	8.56	84.79%	9.33		93.30%	10.00	10.00
Cobalt	8.60	86.00%	9.32		93.22%	10.00	10.00
Copper			10.34		103.36%	10.00	10.00
Europium				9.77	97.72%		
Iron	9.44	94.41%	10.15		101.50%	10.00	10.00
Lanthanum				46.55	92.92%	10.00	
Lead				52.41	104.61%	10.00	
Lithium	9.34	93.39%	10.36		103.61%	10.00	10.00
Magnesium			10.25		102.45%	10.00	10.00
Manganese	9.27	92.70%	10.07		100.65%	10.00	10.00
Mercury				25.49	101.94%		
Molybdenum				48.57	97.14%	10.00	
Neodymium	7.74	77.36%	8.75		87.52% #	10.00	10.00
Nickel	9.27	92.68%	9.91		99.05%	10.00	10.00
Phosphorus				59.26	118.51% #	10.00	
Potassium			24.31		97.22%	10.00	25.00
Samarium				9.65	96.54%		
Selenium				52.43	104.86%		
Silicon				45.26	90.53%	10.00	
Silver				10.65	106.46%	10.00	
Sodium			25.01		100.05%	10.00	25.00
Strontium			10.40		104.01%	10.00	10.00
Sulfur				53.97	107.95%		
Tantalum	7.33	73.62%		48.06	96.12%	9.95	
Thallium				53.11	106.22%		
Thorium				52.47	104.74%		
Tin	9.35	93.54%	49.18		98.35%	10.00	50.00
Titanium	9.23	92.17%		50.70	101.40%	10.00	
Tungsten				20.97	83.88% #		
Uranium	5.01			51.75	103.29%		
Vanadium				10.01	100.05%		
Zinc			9.88		98.82%	10.00	10.00
Zirconium	9.33	93.47%		50.23	100.46%	9.98	
Dilution Factor	10.00		1.00	1.00	1.00		

		LMCS Standards Values	LMCS Standard IDs Book	ACID DIGESTION STANDARD VALUES	LMCS IDs Book	ACID DIGEST. LMCS
		SST-2	SST-3	ppm #	ppm in Sample	81C11A 82C11A
	Aluminum		50.00		100.00	
	Antimony					
	Arsenic		50.00			
	Barium				100.00	
	Beryllium		10.00			
M	Bismuth	50.10			100.00	
	Boron				100.00	
	Cadmium				100.00	
	Calcium				100.00	
	Cerium				100.00	
	Chromium				100.90	
	Cobalt				100.00	
	Copper				100.00	
	Europium	10.00				
	Iron				100.00	
	Lanthanum	50.10			100.00	
	Lead	50.10			100.00	
	Lithium				100.00	
	Magnesium				100.00	
N	Manganese				100.00	
	Mercury		25.00			
	Molybdenum		50.00		99.80	
	Neodymium				100.00	
	Nickel				100.00	
	Phosphorous		50.00		100.00	
	Potassium				100.00	
	Samarium	10.00				
	Selenium		50.00			
	Silicon		50.00		100.00	
	Silver	10.00				
	Sodium				100.00	
	Strontium				100.00	
	Sulfur		50.00			
	Tantalum		50.00		99.50	
	Thallium		50.00			
	Thorium	50.10				
	Tin				100.00	
	Titanium		50.00		100.10	
	Tungsten		25.00			
	Uranium	50.10				
	Vanadium		10.00			
	Zinc				100.00	
	Zirconium		50.00		99.80	
	Dilution Factor				10.00	

ICP Calibration Report

Procedure: LA-505-151 Revision: A-0
Instrument: WB39939
Technologist: J. A. White
Date: April 19, 1990 Time: 07:47

Calibration Standards for ICP Program "SST"

Element	Standard	Element	Standard
Aluminum	SST-3	Antimony	SST-4
Arsenic	SST-4	Barium	SST-2
Beryllium	SST-2	Bismuth	SST-4
Boron	SST-3	Cadmium	SST-2
Calcium	SST-2	Cerium	SST-5
Chromium	SST-2	Cobalt	SST-2
Copper	SST-2	Europium	SST-5
Iron	SST-2	Lanthanum	SST-5
Lead	SST-4	Lithium	SST-1
Magnesium	SST-2	Manganese	SST-2
Mercury	SST-3	Molybdenum	SST-3
Neodymium	SST-5	Nickel	SST-2
Phosphorous	SST-3	Potassium	SST-1
Samarium	SST-5	Selenium	SST-4
Silicon	SST-3	Silver	SST-2
Sodium	SST-1	Strontium	SST-2
Sulfur	SST-3	Tantalum	SST-3
Thallium	SST-4	Thorium	SST-4
Tin	SST-4	Titanium	SST-3
Tungsten	SST-3	Uranium	SST-4
Vanadium	SST-2	Zinc	SST-2
Zirconium	SST-3		

ICP Standard Formulations

SST-0:

Calibration blank, 1 M ultrex HNO₃.

SST-1:

Stock solutions from AESAR/John Mathey Inc., Seabrook, NH 03874.
Individual element solutions as follows:

Li LiCO₃ 10,000 ppm in 5% HNO₃, Lot# 14394A

K KNO₃ 10,000 ppm in 5% HNO₃, Lot# 14379A

Na NaCO₃ 10,000 ppm in 5% HNO₃, Lot# 14400A

200 mL of standard made by combining 25 mL HCl/HNO₃ mixed acid, 1 mL each single element standards, and water.

SST-2:

Stock solutions from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standards as follows:

SM-10 Li, Na, K, Rb, Cs, Be, Mg, Ca, Sr, & Ba 100 ppm
Lot# 0-119A

SM-20 V, Cr, Mn, Fe, Co, Ni, Cu, Zn, Ag, & Cd 100 ppm
Lot# 0-119B

50 mL of each mixed standard are added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

SST-3:

Stock solutions from AESAR/John Mathey Inc., Seabrook, NH 03874.
Individual element solutions as follows:

Al Al 10,000 ppm in 10% HCl Lot# 9-053A

B H₃BO₃ 10,000 ppm in 1% NH₄OH Lot# 9-335A

Hg Hg 10,000 ppm in 5% HNO₃, Lot# 8-656S

Mo Mo 10,000 ppm in 5% HCl Lot# 9-159T

P P 10,000 ppm in 5% HNO₃ Lot# 9-160A

Si Si 1000 ppm in KOH Lot# 086DM Spex Industries, Edison, NJ

S (NH₄)₂SO₄ in H₂O Lot# 9-231M

Ta TaCl₅ 10,000 ppm in 5% HCl/tr HF Lot# 9-335M

Ti Ti 10,000 ppm in 5% HF Lot# 9-079EE

W W 10,000 ppm in 5% HF/tr HNO₃, Lot# 8-685L

Zr ZrCl₂O 10,100 ppm in 5% HCl Lot# 9-078G

50 mL of each mixed standard are added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

SST-4:

Stock solution from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standard as follows:

SM-50 Ga, In, Tl, Ge, Sn, Pb, As, Sb, Bi, Se, Te, Th, & U 100 ppm Lot# 0-119D

Solution is used directly for calibration.

SST-5:

Stock solution from VHG labs, Inc., 180 Zachary Rd. #5, Manchester, NH 03103. Mixed element standard as follows:

SM-60 Sc, Y, La, Ce, Pr, Nd, Sm, Eu, Gd, Tb, Dy, Ho, Er, Tm, Yb, & Lu 100 ppm Lot# 7-165F

50 mL of SM-60 is added to a 250 mL volumetric flask and diluted to volume with 1 M HNO₃.

6
-
7
0
C
S
C
S
N
-
9

19-Apr-90 07:39:21

Condition	Value	Min	/	Max
VACUUM	= 16.74	7.000	/	50.00
SPTEMP	= 38.70	37.00	/	39.00
MAINS	= 235.8	220.0	/	247.0
-1000V	= -1005	-1010	/	-990
CTEMP	= 23.65	19.00	/	35.00
+5V	= 5.160	4.750	/	5.250
+12V	= 12.14	11.70	/	12.30
-12V	= -12.2	-12.3	/	-11.7
+24V	= 23.16	22.50	/	26.50
-100V	= -100	-101	/	-99.0
+5VSQ	= 5.150	4.750	/	5.250
+15VSQ	= 15.14	14.70	/	15.30
-15VSQ	= -15.2	-15.3	/	-14.7

Position Calibration in Progress

SLIT	PM	ALPHA	BETA	ALPHA	BETA	ALPHA	BETA
POS'N		SLIT	SLIT	LAMBDA1	LAMBDA1	LAMBDA2	LAMBDA2
Previous data :							
INSTR	0.00000	586.483	1.00096	-0.3843	1.00009	-0.0675	0.00000
Current data :							
INSTR	0.00000	587.525	1.00102	0.31641	1.00009	-0.0667	0.00000
START THE PLASMA NOW, PLEASE. 19-Apr-90 07:47:14							

Sample name : SST0
Programme : SST 19-Apr-90 08:12:00

NAME	MV	INT	RSD
AL	2.02	0.96	
SB	0.38	1.41	
AS	1.10	1.16	
BA	4.06	1.19	
BE	0.70	0.99	
BI	3.93	1.41	
B	4.65	1.82	
CD	2.38	1.48	
CA	0.49	0.82	
CH	5.47	1.21	
CR	1.49	3.91	
CO	0.26	0.58	
CU	3.01	1.11	
EU	4.24	1.30	
FE	1.67	1.92	
LA	0.36	0.48	
PB	0.27	0.94	
LI	4.07	0.98	
MG	0.46	0.77	
MN	0.78	0.84	
HG	4.63	0.23	
HO	1.71	0.90	
ND	5.87	0.99	
NI	3.48	1.25	
P	1.28	2.59	
K	3.43	0.69	
SM	5.25	1.20	
SE	1.77	0.54	
SI	3.37	1.05	
AG	15.51	1.25	
NA	5.63	1.34	
SR	3.77	1.02	
S	0.75	1.80	
TA	3.80	1.41	
TL	4.43	1.33	
TH	1.10	1.05	
SN	1.25	3.05	
TI	3.63	1.19	
W	1.38	1.82	
U	5.31	1.19	
VI	4.42	1.18	
ZN	2.42	0.91	
ZR	4.76	1.07	

Sample name : SST1
Programme : SST 19-Apr-90 08:16:04

NAME	MV	INT	RSD
LI	417.24	1.20	
K	13.63	0.90	
NA	60.13	1.10	

Sample name : SST2
Programme : SST 19-Apr-90 08:18:03

NAME	MV	INT	RSD
BA	278.36	0.28	
BE	483.17	0.26	
CD	321.93	0.52	
CA	391.86	0.23	
CR	67.99	2.97	
CO	5.62	0.30	
CU	94.95	0.39	
FE	123.57	0.44	
HG	418.22	0.28	
MN	269.40	0.50	
NI	157.96	0.48	
AG	443.38	0.51	
SK	491.83	0.29	
VI	166.57	0.26	
ZN	614.54	0.39	

Sample name : SST3
 Programme : SST 19-Apr-90 08:20:44

NAME	MV	INT	RSD
AL	21.20	0.57	
B	656.56	0.52	
HG	769.40	0.79	
KO	294.93	0.47	
P	61.18	1.41	
S1	77.63	0.49	
S	40.45	0.07	
TA	124.10	0.63	
TI	435.43	0.60	
W	64.46	0.68	
ZR	152.16	0.53	

Sample name : SST4
 Programme : SST 19-Apr-90 08:22:54

NAME	MV	INT	RSD
SB	7.16	1.20	
AS	122.50	1.01	
BI	102.90	1.08	
PB	4.96	1.03	
SE	51.55	0.68	
TL	43.76	1.40	
TH	13.78	1.01	
SN	237.10	0.91	
U	12.39	0.65	

Sample name : SST5
 Programme : SST 19-Apr-90 08:25:27

NAME	MV	INT	RSD
CE	15.66	0.48	
BU	442.41	0.60	
LA	5.53	0.60	
ND	16.65	0.23	
SM	12.65	0.42	

Programme name : SST Channel name : AL Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients			C3
				C1	C2		
CRV1	1.9228	22.261	-0.527706E+01	0.260724E+01			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	2.0240	0.0000	0.0000	-0.000	-0.000		CRV1
SST3	0	21.201	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : SB1 Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients			C3
				C1	C2		
CRV1	0.3572	7.5166	-0.554354E+01	0.147435E+02			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.3760	0.0000	0.0000	0.0000	0.0000		CRV1
SST4	0	7.1587	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : AS Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients			C3
				C1	C2		
CRV1	1.0472	128.63	-0.908003E+00	0.823710E+00			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.1023	0.0000	0.0000	-0.000	-0.000		CRV1
SST4	0	122.50	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : BA Polynomial type : CC

Curve	Min Int	Max Int	C0	Curve Coefficients			C3
				C1	C2		
CRV1	3.8602	292.37	-0.296277E+00	0.729147E-01			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.0633	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	278.36	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : RE1 Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3
CRV1	0.6697	507.33	-0.292248E-01	0.414536E-01	

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.7050	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	483.17	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : BI Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3
CRV1	3.7316	108.05	-0.396876E+01	0.101038E+01	

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.9280	0.0000	0.0000	0.0000	0.0000		CRV1
SST4	0	102.90	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : B Polynomial type : CC

Curve	Min Int	Max Int	Curve Coefficients		
	C0		C1	C2	C3
CRV1	4.4166	689.39	-0.356566E+00	0.766975E-01	

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.6490	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	656.56	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : CD Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	2.2588	338.03	-0.148813E+00	0.625878E-01				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc % Error Curve								
SST0	0	2.3777	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	321.93	20.000	20.000	20.000	0.0000	0.0000	CRV1
 Programme name : SST Channel name : CA Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	0.4645	411.45	-0.249891E-01	0.511025E-01				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc % Error Curve								
SST0	0	0.4890	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	391.86	20.000	20.000	20.000	0.0000	0.0000	CRV1
 Programme name : SST Channel name : CE Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	5.1981	16.440	-0.107442E+02	0.196361E+01				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc % Error Curve								
SST0	0	5.4717	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST5	0	15.637	20.000	20.000	20.000	-0.000	-0.000	CRV1
 Programme name : SST Channel name : CR Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	1.4123	71.394	-0.447064E+00	0.300716E+00				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc % Error Curve								
SST0	0	1.4867	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	67.995	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : CO Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients		
	C0	C1	C2	C3			
CRV1	0.2492	5.8975	-0.979891E+00	0.373529E+01			

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
	(X)	(Y)	(Y)	(Y)	Conc	Error		
SST0	0	0.2623	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	5.6167	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : CU Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients		
	C0	C1	C2	C3			
CRV1	2.8560	99.693	-0.653979E+00	0.217534E+00			

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
	(X)	(Y)	(Y)	(Y)	Conc	Error		
SST0	0	3.0063	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	94.946	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : EU Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients		
	C0	C1	C2	C3			
CRV1	4.0261	464.53	-0.193441E+00	0.456443E-01			

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
	(X)	(Y)	(Y)	(Y)	Conc	Error		
SST0	0	4.2380	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST5	0	442.41	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : FE Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients		
	C0	C1	C2	C3			
CRV1	1.5878	129.75	-0.274221E+00	0.164073E+00			

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.6713	0.0000	0.0000	-0.000	-0.000		CRV1
SST2	0	123.57	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : LA Polynomial type : CC

Curve	Min Int	Max Int	CO			Curve Coefficients		
			C1	C2	C3			
CRV1	0.3420	5.8083	-0.139220E+01	0.386723E+01				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.3600	0.0000	0.0000	0.0000	0.0000		CRV1
SST5	0	5.5317	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : PB Polynomial type : CC

Curve	Min Int	Max Int	CO			Curve Coefficients		
			C1	C2	C3			
CRV1	0.2530	5.2094	-0.567270E+01	0.212993E+02				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.2663	0.0000	0.0000	-0.000	-0.000		CRV1
SST4	0	4.9613	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : LI Polynomial type : CC

Curve	Min Int	Max Int	CO			Curve Coefficients		
			C1	C2	C3			
CRV1	3.8693	438.10	-0.492900E+00	0.121017E+00				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.0730	0.0000	0.0000	-0.000	-0.000		CRV1
SST1	0	417.24	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : MG Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	0.4326	439.14	-0.217983E-01	0.478733E-01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	0.4553	0.0000	0.0000	-0.000	-0.000	-0.000	CRV1
SST2	0	418.22	20.000	20.000	20.000	-0.000	-0.000	CRV1
Programme name : SST Channel name : MN Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	0.7388	282.87	-0.579004E-01	0.744540E-01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	0.7777	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	269.40	20.000	20.000	20.000	0.0000	0.0000	CRV1
Programme name : SST Channel name : HG Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	4.3982	807.87	-0.302682E+00	0.653788E-01				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	4.6297	0.0000	0.0000	-0.000	-0.000	-0.000	CRV1
SST3	0	769.40	50.000	50.000	50.000	0.0000	0.0000	CRV1
Programme name : SST Channel name : MO Polynomial type : CC								
Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3
CRV1	1.6201	309.67	-0.290791E+00	0.170519E+00				
Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
SST0	0	1.7053	0.0000	0.0000	-0.000	-0.000	-0.000	CRV1
SST3	0	294.92	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : ND Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3

CRV1	5.5790	17.478	-0.109022E+02	0.185644E+01				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
		(X)	(Y)	(Y)	Conc	Error		

SST0	0	5.8727	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST5	0	16.646	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : NI Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3

CRV1	3.3022	165.86	-0.450011E+00	0.129462E+00				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
		(X)	(Y)	(Y)	Conc	Error		

SST0	0	3.4760	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST2	0	157.96	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : P Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3

CRV1	1.2138	64.234	-0.106655E+01	0.834761E+00				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int.	Conc	True	Calc	Conc	% Error	Curve
		(X)	(Y)	(Y)	Conc	Error		

SST0	0	1.2777	0.0000	0.0000	0.0000	0.0000	0.0000	CRV1
SST3	0	61.175	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : K Polynomial type : CC

Curve	Min	Int	Max	Int	Curve Coefficients			
					C0	C1	C2	C3

CRV1	3.2604	14.309	-0.168307E+02	0.490405E+01				
------	--------	--------	---------------	--------------	--	--	--	--

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.4320	0.0000	0.0000	0.0000	0.0000		CRV1
SST1	0	13.628	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : SM Polynomial type : CC

Curve	Min	Int	Max	Int	C0	Curve Coefficients	C1	C2	C3
CRV1	4.9904	14.337	-0.125057E+02	0.238067E+01					

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.2530	0.0000	0.0000	-0.000	-0.000		CRV1
SST5	0	13.654	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : SE Polynomial type : CC

Curve	Min	Int	Max	Int	C0	Curve Coefficients	C1	C2	C3
CRV1	1.6825	54.131	-0.355749E+01	0.200874E+01					

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.7710	0.0000	0.0000	-0.000	-0.000		CRV1
SST4	0	51.553	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : SI Polynomial type : CC

Curve	Min	Int	Max	Int	C0	Curve Coefficients	C1	C2	C3
CRV1	3.2028	81.507	-0.227014E+01	0.673364E+00					

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.3713	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	77.625	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : AG Polynomial type : CC

ICP Calibration April 19, 1990

Curve	Min Int	Max Int	Curve Coefficients					
			C0	C1	C2	C3		
CRV1	14.739	465.55	-0.725194E+00	0.467435E-01				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc Error % Error Curve								
SST0	0	15.514	0.0000	0.0000	-0.000	-0.000		CRV1
SST1	0	443.38	20.000	20.000	20.000	0.0000	0.0000	CRV1
 Programme name : SST Channel name : NA Polynomial type : CC								
Curve	Min Int	Max Int	Curve Coefficients					
			C0	C1	C2	C3		
CRV1	5.3441	63.140	-0.516007E+01	0.917291E+00				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc Error % Error Curve								
SST0	0	5.6253	0.0000	0.0000	0.0000	0.0000		CRV1
SST1	0	60.134	50.000	50.000	50.000	0.0000	0.0000	CRV1
 Programme name : SST Channel name : SK Polynomial type : CC								
Curve	Min Int	Max Int	Curve Coefficients					
			C0	C1	C2	C3		
CRV1	3.5802	516.42	-0.154433E+00	0.409782E-01				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc Error % Error Curve								
SST0	0	3.7687	0.0000	0.0000	0.0000	0.0000		CRV1
SST1	0	491.83	20.000	20.000	20.000	-0.000	-0.000	CRV1
 Programme name : SST Channel name : S Polynomial type : CC								
Curve	Min Int	Max Int	Curve Coefficients					
			C0	C1	C2	C3		
CRV1	0.7166	42.473	-0.950130E+00	0.125956E+01				
 Name Number Int. (X) Conc (Y) True (Y) Calc Conc Conc Error % Error Curve								
SST0	0	0.7543	0.0000	0.0000	0.0000	0.0000		CRV1
SST1	0	40.451	50.000	50.000	50.000	0.0000	0.0000	CRV1

CRV1								
Programme name : SST			Channel name : TA			Polynomial type : CC		
Curve	Min	Int.	Max	Int.	Curve Coefficients			
	C0		C1	C2				C3
CRV1	3.6113	130.30	-0.157996E+01	0.415634E+00				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.8013	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	124.10	50.000	50.000	50.000	-0.000	-0.000	CRV1
CRV1								
CRV1								
Programme name : SST			Channel name : TL2			Polynomial type : CC		
Curve	Min	Int.	Max	Int.	Curve Coefficients			
	C0		C1	C2				C3
CRV1	4.2129	45.944	-0.112779E+02	0.254313E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.4347	0.0000	0.0000	-0.000	-0.000		CRV1
SST4	0	43.756	100.00	100.00	100.00	0.0000	0.0000	CRV1
CRV1								
CRV1								
Programme name : SST			Channel name : TH			Polynomial type : CC		
Curve	Min	Int.	Max	Int.	Curve Coefficients			
	C0		C1	C2				C3
CRV1	1.0418	14.465	-0.864879E+01	0.788644E+01				
Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.0967	0.0000	0.0000	0.0000	0.0000		CRV1
SST4	0	13.777	100.00	100.00	100.00	0.0000	0.0000	CRV1
CRV1								
CRV1								
Programme name : SST			Channel name : SN			Polynomial type : CC		
Curve	Min	Int.	Max	Int.	Curve Coefficients			
	C0		C1	C2				C3
CRV1	1.1919	248.95	-0.531989E+00	0.424008E+00				

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	14.739	465.55	-0.725194E+00	0.467435E-01				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	15.514	0.0000	0.0000	-0.000	-0.000	CRV1	
SST2	0	443.38	20.000	20.000	20.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : NA Polynomial type : CC

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	5.3441	63.140	-0.516007E+01	0.917291E+00				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.6253	0.0000	0.0000	0.0000	0.0000	CRV1	
SST1	0	60.134	50.000	50.000	50.000	0.0000	0.0000	CRV1

Programme name : SST Channel name : SR Polynomial type : CC

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	3.5802	516.42	-0.154433E+00	0.409782E-01				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.7687	0.0000	0.0000	0.0000	0.0000	CRV1	
SST2	0	491.93	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : S Polynomial type : CC

Curve	Min	Int.	Max	Int.	Curve Coefficients			
					C0	C1	C2	C3
CRV1	0.7166	42.473	-0.950130E+00	0.125956E+01				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	0.7543	0.0000	0.0000	0.0000	0.0000	CRV1	
SST2	0	40.451	50.000	50.000	50.000	-0.000	-0.000	CRV1

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.2547	0.0000	0.0000	-0.000	-0.000		CRV1
SST4	0	237.10	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : TI Polynomial type : CC

Curve	Min	Int	Max	Int	C0	C1	C2	C3
-------	-----	-----	-----	-----	----	----	----	----

CRV1	3.4453	457.20	-0.419948E+00	0.115795E+00
------	--------	--------	---------------	--------------

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	3.6267	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	435.43	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : W Polynomial type : CC

Curve	Min	Int	Max	Int	C0	C1	C2	C3
-------	-----	-----	-----	-----	----	----	----	----

CRV1	1.3075	67.678	-0.109096E+01	0.792657E+00
------	--------	--------	---------------	--------------

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	1.3763	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	64.455	50.000	50.000	50.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : U Polynomial type : CC

Curve	Min	Int	Max	Int	C0	C1	C2	C3
-------	-----	-----	-----	-----	----	----	----	----

CRV1	5.0432	13.014	-0.749247E+02	0.141137E+02
------	--------	--------	---------------	--------------

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	5.3087	0.0000	0.0000	0.0000	0.0000		CRV1
SST4	0	12.394	100.00	100.00	100.00	0.0000	0.0000	CRV1

Programme name : SST Channel name : V1 Polynomial type : CC

Curve	Min	Int.	Max	Int.	Curve Coefficients			C3
	C0	C1	C2					
CRV1	4.1949	174.90	-0.544610E+00	0.123336E+00				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.4157	0.0000	0.0000	-0.000	-0.000		CRV1
SST2	0	166.57	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : ZN Polynomial type : CC

Curve	Min	Int.	Max	Int.	Curve Coefficients			C3
	C0	C1	C2					
CRV1	2.2965	645.27	-0.789814E-01	0.326729E-01				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	2.4173	0.0000	0.0000	0.0000	0.0000		CRV1
SST2	0	614.54	20.000	20.000	20.000	-0.000	-0.000	CRV1

Programme name : SST Channel name : ZR Polynomial type : CC

Curve	Min	Int.	Max	Int.	Curve Coefficients			C3
	C0	C1	C2					
CRV1	4.5261	159.77	-0.161619E+01	0.399226E+00				

Name	Number	Int. (X)	Conc (Y)	True (Y)	Calc Conc	Conc Error	% Error	Curve
SST0	0	4.7643	0.0000	0.0000	0.0000	0.0000		CRV1
SST3	0	152.16	50.000	50.000	50.000	-0.000	-0.000	CRV1

ICP Data Report - Acid Blank - (File 1)

Sample name	:	HNO3		
Programme	:	SST		
		19-Apr-90 08:44:13		
NAME	MV	INT	CONCEN	RSD
Al	1.95	-0.199	-21.63	
Sb	0.37	-0.039	-57.28	
As	1.07	-0.031	-35.43	
Ba	3.85	(-0.015	-13.46	
Be	0.69	-0.001	-22.94	
Bi	3.76	-0.167	-9.26	
Br	4.49	-0.013	-14.19	
Cd	2.28	-0.006	-3.54	
Ca	0.48	-0.000	-37.80	
Ce	5.20	-0.534	-14.27	
Cr	1.29	(-0.058	-5.90	
Co	0.26	0.000	*****	
Cu	2.88	-0.028	-14.78	
Eu	4.02	(-0.010	-11.14	
Fe	1.60	-0.012	-22.18	
La	0.35	-0.032	-18.33	
Pb	0.26	-0.043	-144.34	
Li	4.01	-0.007	-68.58	
Mg	0.44	-0.001	-18.92	
Mn	0.75	-0.002	-13.86	
Hg	3.89	(-0.049	-7.27	
Mo	1.64	-0.012	-21.56	
Nd	5.38	(-0.906	-8.91	
Ni	3.33	-0.020	-11.69	
P	1.27	-0.004	-531.46	
K	3.27	-0.775	-14.72	
Sm	4.99	-0.629	-14.98	
Se	1.70	-0.139	-26.84	
Si	3.23	-0.092	-17.41	
Ag	14.76	-0.035	-15.27	
Na	5.35	-0.253	-15.23	
Sr	3.62	-0.006	-14.57	
S	0.72	-0.044	-1.67	
Ta	3.63	-0.073	-14.82	
Tl	4.16	(-0.701	-13.24	
Th	1.05	-0.376	-21.29	
Sn	1.21	-0.018	-20.97	
Ti	3.46	-0.020	-13.00	
W	1.30	(-0.059	-20.24	
U	5.04	-3.735	-13.04	
V	4.16	(-0.031	-11.46	
Zn	2.34	-0.003	-39.44	
Zr	4.59	-0.058	-14.15	

ICP Data Report - LMCS Check Standard 78C11J - (File 2)

Sample name : 78C11J
 Sample code 1 : SST1
 Sample code 2 : DIRECT
 Programme : SST 19-Apr-90 08:48:34

NAME	MV	INT	CONCEN	RSD
Al	2.02	-0.013	-393.95	
Sb	1.08	10.306	1.08	
As	1.17	0.057	24.65	
Ba	143.20	10.145	0.69	
Be	0.72	0.001	30.70	
Bi	3.92	-0.009	-390.64	
B	134.59	9.966	0.37	
Cd	160.15	9.875	0.17	
Ca	204.52	10.427	0.74	
Co	10.07	9.035	0.59	
Cr	32.84	9.427	0.43	
Co	2.89	9.818	0.57	
Cu	50.17	10.260	0.51	
Eu	4.60	0.016	11.83	
Fe	63.21	10.098	0.40	
La	0.37	0.048	20.40	
Pb	0.27	0.028	43.30	
Li	89.66	10.357	0.50	
Hg	214.58	10.251	0.47	
Mn	136.15	10.079	0.34	
Hg	3.95	(-0.044	-7.94	
Ho	1.75	0.008	48.40	
Nd	10.71	8.972	2.24	
Ni	80.53	9.975	0.19	
P	1.35	0.061	36.28	
K	8.43	24.525	0.30	
Sm	5.01	-0.575	-22.70	
Se	3.40	3.272	0.48	
Si	3.31	-0.040	-45.96	
Ag	14.91	-0.028	-26.79	
Na	32.79	24.917	0.33	
Sr	254.70	10.283	0.68	
S	0.91	0.200	8.19	
Ta	3.70	-0.043	-44.43	
Tl	4.39	-0.106	-120.98	
Th	1.09	-0.053	-167.03	
Sn	117.72	49.380	0.22	
Ti	3.49	-0.016	-24.97	
W	1.60	0.175	7.38	
U	5.39	1.077	66.40	
V	4.28	-0.017	-33.23	
Zn	305.53	9.904	0.18	
Zr	4.65	-0.038	-36.27	

18300

ICP Data Report - LMCS Check Standard 82B38F - (File 3)

Sample name : 82B38F
 Sample code 1 : SST2
 Sample code 2 : DIRECT
 Programme : SST 19-Apr-90 08:53:57
 18226

NAME	MV	INT	CONCEN	RSD
Al	3.67	4.283	1.52	
Sb	0.42	0.659	5.63	
As	2.98	1.548	2.05	
Ba	4.30	0.017	14.28	
Be	0.74	0.001	27.77	
Bi	57.46	54.091	0.47	
B	5.40	0.058	3.39	
Cd	2.48	0.007	10.95	
Ca	0.73	0.012	1.25	
Ce	5.75	0.350	14.46	
Cr	1.68	0.058	5.97	
Co	0.28	0.062	6.00	
Cu	4.10	0.238	1.78	
Eu	217.80	9.748	0.28	
Fe	2.08	0.067	27.96	
La	12.43	146.675	0.17	
Pb	2.77	53.326	0.33	
Li	4.43	0.044	19.70	
Hg	0.59	0.006	0.74	
Mn	0.91	0.010	2.54	
Hg	4.56	-0.005	-52.91	
Mo	1.83	0.022	7.87	
Nd	6.12	0.465	22.94	
Ni	3.69	0.027	19.97	
P	1.65	0.308	7.52	
K	3.40	-0.167	-32.75	
Sm	9.47	10.049	0.83	
Se	1.93	0.319	5.03	
Si	4.21	0.563	3.60	
Ag	244.24	10.691	0.28	
Na	5.66	0.036	89.17	
Sr	3.95	0.008	12.55	
S	0.87	0.140	11.23	
Ta	4.22	0.173	9.35	
Tl	6.75	5.881	1.93	
Th	7.80	52.868	0.36	
Sn	1.44	0.080	3.41	
Ti	4.14	0.059	6.67	
W	1.42	0.038	72.86	
U	9.18	54.596	1.19	
V	6.31	0.238	1.69	
Zn	2.69	0.009	9.21	
Zr	5.15	0.132	7.08	

ICP Data Report - LMCS Check Standard 77C11I - (File 4)

Sample name : 77C11I
 Sample code 1 : SST3
 Sample code 2 : DIRECT
 Programme : SST

19-Apr-90 09:02:22

18244

NAME	MV INT	CONCEN	RSD
Al	21.57	50.973	0.24
Sb	0.46	1.263	5.26
As	71.94	58.350	0.32
Ba	4.29	0.017	10.32
Be	244.28	10.097	1.63
Bi	4.89	0.971	1.41
B	5.42	0.059	5.14
Cd	2.61	0.015	11.90
Ca	0.75	0.013	0.67
Ce	5.51	0.073	85.92
Cr	1.50	0.005	95.47
Co	0.29	0.115	6.52
Cu	3.27	0.058	6.13
Eu	4.27	0.002	74.28
Fe	1.95	0.046	3.70
La	0.37	0.027	24.74
Pb	0.28	0.390	8.33
Li	4.13	0.007	40.18
Mg	0.52	0.003	1.60
Mn	1.04	0.019	1.02
Hg	399.37	25.808	0.58
Mo	293.51	49.758	0.43
Nd	5.79	-0.158	-100.24
Ni	7.41	0.510	0.95
P	66.26	154.245	1.07
K	3.40	-0.132	-80.13
Sm	5.31	0.147	53.52
Se	28.39	53.466	0.71
Si	72.02	46.228	0.06
Ag	22.28	0.316	0.94
Na	5.78	0.146	19.94
Sr	3.87	0.004	21.45
S	42.73	152.876	0.82
Ia	122.84	49.478	0.72
Tl	25.50	53.560	0.57
Th	1.22	0.983	4.04
Sn	1.71	0.193	0.76
Ti	447.29	51.373	0.16
W	28.21	21.266	0.47
U	6.19	12.420	1.28
V	86.99	10.184	2.07
Zn	3.56	0.037	2.26
Zr	154.39	50.756	0.11

ICP Data Report - Acid Digested Standard 81C11A - (File 5)

Sample name : F1083
Sample code 1 : 81C11A
Sample code 2 : DIRECT
Sample code 3 : DIGEST
Programme : SST 19-Apr-90 09:07:31

NAME	MV	INT	CONCEN	RSR
Al	2.11	0.228	31.49	
Sb	0.37	-0.049	-180.83	
As	1.44	0.275	9.55	
Ba	3.83	(-0.017	-20.65	
Be	0.70	-0.000	-141.52	
Bi	14.03	10.212	0.64	
B	127.77	9.443	0.82	
Cd	151.70	9.346	1.27	
Ca	201.23	10.258	0.57	
Ce	5.08	(-0.772	-15.81	
Cr	1.89	(-0.030	-21.13	
Co	0.26	-0.012	-51.96	
Cu	48.56	9.909	0.71	
Eu	3.88	(-0.016	-17.94	
Fe	1.84	0.028	23.66	
La	2.71	9.105	0.51	
Pb	0.73	9.904	1.43	
Li	3.82	(-0.031	-22.41	
Mg	204.24	9.756	0.53	
Mn	0.89	0.008	16.27	
Hg	3.96	(-0.043	-19.37	
Mo	56.56	9.354	0.88	
Nd	3.41	(-0.864	-24.79	
Ni	3.28	(-0.025	-31.55	
P	12.46	9.337	3.79	
K	5.12	8.265	0.63	
Sm	4.80	(-1.072	-13.13	
Se	1.70	-0.151	-53.17	
Si	14.54	7.518	6.68	
Ag	174.24	7.419	0.59	
Na	15.94	9.466	0.71	
Sr	247.86	10.002	0.60	
S	0.93	0.222	5.59	
Ta	3.50	(-0.126	-22.37	
Tl	4.00	(-1.116	-14.91	
Ih	1.02	(-0.573	-16.68	
Sn	1.47	0.092	9.79	
Ti	4.84	0.140	3.27	
W	1.52	0.110	21.00	
U	4.90	(-5.829	-16.47	
V	4.04	(-0.046	-11.84	
Zn	287.21	9.305	0.41	
Zr	4.46	(-0.105	-14.92	

ICP Data Report - Reagent Blank - (File 6)

Sample name : F1084
Sample code 1 : REAGEN
Sample code 2 : DIRECT
Sample code 3 : 000013
Programme : SST 19-Apr-90 09:12:39

NAME	MV	INT	CONCEN	RSD
Al	2.05	0.068	59.96	
Sb	0.38	-0.005	-916.63	
As	1.08	-0.022	-50.24	
Ba	3.96	-0.008	-35.37	
Be	0.71	0.000	28.39	
Bi	3.92	-0.006	-797.45	
B	5.08	0.033	2.92	
Cd	2.38	0.000	6376.32	
Ca	2.16	0.085	0.70	
Ce	5.32	-0.306	-35.66	
Cr	1.39	<-0.029	-12.21	
Co	0.27	0.022	34.69	
Cu	2.95	-0.011	-37.31	
Eu	4.09	-0.007	-27.58	
Fe	1.87	0.032	14.36	
La	0.35	-0.022	-50.94	
Pb	0.27	0.014	150.01	
Li	3.99	-0.010	-47.62	
Mg	0.78	0.015	7.20	
Mn	0.92	0.011	4.16	
Hg	3.83	<-0.053	-9.08	
Mo	1.69	-0.003	-74.48	
Nd	5.53	<-0.640	-21.86	
Ni	3.42	-0.008	-60.28	
P	1.41	0.114	12.79	
K	3.32	-0.528	-24.44	
Sm	5.10	-0.354	-30.58	
Se	1.74	-0.064	-26.70	
Si	4.31	0.631	16.43	
Ag	15.13	-0.018	-28.50	
Na	5.69	0.059	76.28	
Sr	3.70	-0.003	-40.42	
S	0.78	0.034	6.50	
Ta	3.72	-0.035	-47.06	
I	4.30	-0.331	-21.52	
Th	1.07	-0.176	-43.95	
Sn	1.29	0.016	107.80	
Ti	4.74	0.129	2.06	
W	1.35	-0.019	-35.11	
U	5.14	-2.399	-29.80	
V	4.29	-0.016	-21.91	
Zn	9.48	0.231	1.22	
Zr	4.66	-0.036	-34.15	

ICP Data Report - Sample F1085 - (File 7)

Sample name : F1085
 Sample code 1 : SAMPLE
 Sample code 2 : 100-10
 Sample code 3 : 000013
 Programme : SST 19-Apr-90 09:17:05

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	4.10	5.418	547.20✓	0.81	
Si	0.39	0.172	17.373	26.19	
As	1.12	0.018	1.858	22.98	
Ba	4.18	0.009	0.869	19.07	
Be	0.74	0.001	0.134✓	6.25	
Bi	5.40	1.487	150.15✓	0.66	
B	4.98	0.025	2.561	3.21	
Cd	2.39	0.001	0.072	49.13	
Ca	1.52	0.053	5.321✓	1.22	
Co	5.59	0.232	23.469✓	27.20	
Cr	1.70	0.064	6.459✓	5.18	
Co	0.27	0.045	4.527	19.24	
Cu	3.08	0.017	1.706	17.32	
Eu	4.31	0.003	0.324	42.80	
Fe	9.83	1.338	135.13✓	0.88	
La	0.37	0.024	2.474	18.23	
Pb	0.28	0.234	23.663	20.99	
Li	4.15	0.009	0.949✓	34.77	
Mg	0.88	0.021	2.071✓	14.02	
Mn	8.02	0.540	54.494✓	1.44	
Hg	4.11	(-0.034	(-3.456	-7.45	
Mo	1.76	0.009	0.878	11.15	
Nd	5.72	-0.292	-29.50	-43.58	
Ni	3.64	0.021	2.105	5.99	
P	2.14	0.719	72.620✓	2.26	
K	3.47	0.186	18.822	42.10	
Sm	5.35	0.236	23.804	30.12	
Se	1.83	0.123	12.444✓	2.49	
Si	4.10	0.494	49.851✓	6.26	
Ag	15.84	0.015	1.525	30.69	
Na	13.44	7.173	724.43✓	0.45	
Sr	3.07	0.053	5.376✓	0.58	
S	0.83	0.100	10.050	22.51	
Ta	3.86	0.025	2.561	59.21	
Tl	4.57	0.337	33.990	23.79	
Th	1.12	0.200	20.179✓	21.98	
Sn	1.30	0.021	2.141	26.56	
Ti	3.70	0.008	0.850	22.37	
W	1.42	0.035	3.496	22.08	
U	5.45	1.924	194.34	20.58	
V	4.55	0.016	1.657	20.90	
Zn	7.71	0.173	17.465✓	0.60	
Zr	4.86	0.032	3.278	26.87	

Dilution factor : 101.000

ICP Data Report - Sample F1085 - (File 8)

Sample name : F1085
 Sample code 1 : SAMPLE
 Sample code 2 : 500-10
 Sample code 3 : 000013
 Programme : SST

19-Apr-90 09:21:46

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	11.60	24.956	524.07	0.56	
Sb	0.39	0.260	5.470✓	16.34	
As	1.15	0.039	0.813✓	8.06	
Ba	4.37	0.022	0.467✓	12.31	
Be	0.74	0.001	0.031✓	4.81	
Bi	10.44	6.584	138.27	0.67	
B	5.01	0.027	0.574✓	6.67	
Cd	2.42	0.003	0.060✓	20.70	
Ca	4.15	0.187	3.925	0.36	
Ce	5.57	0.193	4.055✓	58.07	
Cr	2.94	0.438	9.193	1.38	
Co	0.28	0.059	1.229✓	38.30	
Cu	3.16	0.033	0.700✓	13.37	
Eu	4.30	0.003	0.058	65.98	
Fe	40.70	6.404	134.48✓	0.23	
La	0.37	0.040	0.839✓	24.35	
Pb	0.29	0.511	10.735✓	9.62	
Li	4.12	0.006	0.124	69.90	
Mg	1.83	0.066	1.386	0.29	
Mn	35.10	2.555	53.656	0.20	
Hg	4.19	(-0.029	(-0.601✓	-9.82	
Mo	1.80	0.016	0.335✓	13.38	
Nd	5.69	-0.342	-7.186✓	-44.51	
Ni	3.97	0.065	1.356✓	11.66	
P	4.85	2.984	62.670	2.21	
K	3.45	0.092	1.922✓	144.38	
Sm	5.32	0.163	3.416✓	77.57	
Se	1.92	0.308	6.468✓	13.53	
Si	5.65	1.533	32.198	3.75	
Ag	15.85	0.016	0.331✓	51.32	
Na	42.19	33.545	704.44	0.20	
Sr	9.71	0.243	5.110	0.21	
S	1.07	0.402	8.438✓	1.10	
Ia	3.88	0.035	0.730✓	17.69	
Tl	4.58	0.371	7.797✓	35.95	
Th	1.12	0.163	3.423	66.05	
Sn	1.93	0.031	0.644✓	24.10	
Ti	3.74	0.013	0.264✓	30.83	
W	1.45	0.057	1.193✓	6.08	
U	5.59	3.938	82.692✓	18.67	
V	4.54	0.015	0.325✓	42.05	
Zn	5.64	0.105	2.214	0.59	
Zr	4.94	0.061	1.278✓	17.58	

Dilution factor : 21.0000

ICP Data Report - Spike of Sample F1085 - (File 11)

Sample name : F1087
 Sample code 1 : SPIKE
 Sample code 2 : 100-10
 Sample code 3 : 000013
 Programme : SST 19-Apr-90 09:33:58

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	3.95	5.021	507.09	0.42	
Sb	0.39	0.133	13.402	29.40	
As	1.10	-0.006	-0.582	-151.41	
Be	5.53	0.107	10.831	1.87	
Br	0.71	0.000	0.020	152.03	
Bi	5.50	1.592	160.79	3.06	
B	6.47	0.140	14.099	0.83	
Cd	3.80	0.089	8.997	1.16	
Ca	4.44	0.202	20.399	1.38	
Co	5.32	-0.297	-30.01	-40.41	
Cr	2.49	0.302	30.544	0.76	
Co	0.28	0.082	8.300	9.46	
Cu	3.43	0.092	9.264	5.83	
Eu	4.12	-0.006	-0.566	-43.79	
Fe	14.85	2.162	218.35	1.12	
La	0.38	0.071	7.161	15.75	
Pb	0.27	0.170	17.210	14.43	
Li	4.83	0.092	9.244	4.74	
Mo	86.51	4.120	416.09	1.10	
Mn	8.34	0.563	56.883	1.21	
Hg	4.26	(-0.024	(-2.461	-12.56	
Na	2.22	0.088	8.933	1.90	
Nd	5.52	(-0.661	(-66.75	-21.22	
Ni	4.23	0.098	9.907	5.58	
P	2.66	1.156	116.71	3.69	
K	3.36	-0.337	-34.01	-45.88	
Sm	5.10	-0.361	-36.47	-40.03	
Se	1.81	0.071	7.169	63.81	
Si	3.99	0.418	42.189	4.34	
Ag	16.55	0.048	4.889	84.71	
Na	14.68	8.304	838.67	0.63	
Sr	7.26	0.143	14.464	0.43	
S	1.29	0.673	67.976	0.29	
Ta	3.78	-0.007	-0.700	-235.49	
Tl	4.36	-0.183	-18.49	-62.27	
Th	1.07	-0.189	-19.12	-43.37	
Sn	1.58	0.199	14.047	4.75	
Ti	4.43	0.093	9.345	3.03	
W	1.35	-0.020	-2.055	-73.65	
U	5.19	-1.741	-175.8	-51.50	
V	4.34	-0.009	-0.926	-39.04	
Zn	10.14	0.252	25.479	0.53	
Zr	4.82	0.018	1.827	70.96	

Dilution factor : 101.000

Sample name : F1087
 Sample code 1 : SPIKE
 Sample code 2 : 500-10
 Sample code 3 : 000013
 Programme : SST 19-Apr-90 09:38:10

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	10.68	22.571	473.99	0.53	

ICP Data Report - Spike of F1085 - (File 12)

Sample name : F1087
 Sample code 1 : SPIKE
 Sample code 2 : S00-10
 Sample code 3 : 000013
 Programme : SST 19-Apr-90 09:38:10

NAME	MV INT	CONCEN	DILCOR	RSD
Al	10.68	22.571	473.99	0.53
Si	0.42	0.678	14.242	4.35
As	1.16	0.049	1.021	14.61
Ba	10.96	0.503	10.565	0.24
Re	0.74	0.001	0.028	8.84
Bi	12.24	8.398	176.36	0.47
B	11.02	0.488	10.254	1.00
Cd	10.01	0.477	10.026	0.88
Ca	14.39	0.710	14.914	0.51
Ce	5.51	0.073	1.340	73.99
Cr	4.55	0.922	19.370	0.03
Co	0.39	0.468	9.831	5.31
Cu	5.38	0.515	10.824	0.23
Eu	4.28	0.002	0.040	45.94
Fe	63.36	10.122	212.56	0.37
La	0.48	0.469	9.854	1.26
Pb	0.31	0.994	20.873	0.00
Li	8.26	0.507	10.652	0.10
Hg	38.20	1.807	37.950	0.31
Hn	37.58	2.740	57.543	0.62
Hg	4.44	-0.013	-0.265	-7.65
Ho	4.46	0.470	9.871	1.15
Nd	5.88	0.022	0.468	646.39
Ni	7.65	0.541	11.358	0.70
P	8.02	5.630	118.32	1.18
K	3.52	0.448	9.406	8.78
Sm	5.27	0.029	0.617	172.07
Se	1.99	0.446	9.365	1.19
Si	5.18	1.219	25.604	0.66
Ag	21.33	0.272	5.708	16.77
Na	48.60	39.416	827.74	0.16
Sr	21.16	0.713	14.969	0.35
S	1.23	0.604	12.688	1.78
Ta	4.21	0.168	3.529	0.14
Tl	4.57	0.348	7.299	14.95
Th	1.11	0.105	2.208	41.76
Sn	2.49	0.522	10.967	0.69
Ti	7.70	0.471	9.897	0.22
W	1.44	0.048	0.999	11.10
U	5.51	2.903	60.957	11.26
V	4.54	0.015	0.319	23.24
Zn	22.10	0.643	13.503	0.69
Zr	5.60	0.284	5.970	1.20

Dilution factor : 21.0000

ICP Data Report - Acid Digested Standard 82C11A - (File 13)

Sample name : F1098
Sample code 1 : DIGEST
Sample code 2 : DIRECT
Sample code 3 : 000013
Programme : SST 19-Apr-90 09:43:08

NAME	MV	INT	CONCEN	RSD
Al	5.88	10.063	1.45	
St	0.39	0.246	18.33	
As	1.42	0.262	2.83	
Ba	130.62	9.228	1.74	
Be	0.79	0.004	4.42	
Bi	4.21	0.280	13.02	
B	5.31	0.050	11.73	
Cd	2.52	0.009	21.14	
Ca	5.75	0.269	1.89	
Ce	9.99	8.866	0.56	
Cr	29.93	8.555	1.83	
Co	2.56	8.600	3.63	
Cu	3.10	0.019	29.28	
Eu	4.70	0.021	4.16	
Fe	59.21	9.441	1.52	
La	0.38	0.083	9.76	
Pb	0.28	0.341	18.04	
Li	81.25	9.339	2.39	
Hg	2.33	0.090	1.03	
Mn	125.29	9.270	1.65	
Hg	4.47	-0.010	-47.80	
Mo	1.89	0.031	8.35	
Nd	10.04	7.736	4.51	
Ni	75.07	9.268	1.53	
P	1.49	0.176	8.13	
K	3.38	-0.263	-50.60	
Sm	5.22	-0.067	-135.88	
Se	3.23	2.921	2.60	
Si	4.33	0.645	4.64	
Ag	16.78	0.059	8.32	
Na	6.25	0.577	9.74	
Sr	3.96	0.008	11.46	
S	0.92	0.207	6.34	
Ta	21.42	7.325	0.93	
Tl	4.59	0.384	38.16	
Th	1.14	0.352	21.51	
Sn	23.32	9.354	1.21	
Ti	83.30	9.226	1.68	
W	2.31	0.739	3.69	
U	5.66	5.010	11.19	
V	4.42	0.000		
Zn	4.55	0.070	2.50	
Zr	32.26	9.328	1.63	

ICP Data Report - Acid Blank - (File 14)

Sample name : HNO3
Programme : SST 19-Apr-90 09:48:24

NAME	MV	INT	CONCEN	RSD
Al	1.96	-0.169	-16.21	
Sb	0.37	-0.044	-66.67	
As	1.07	-0.029	-17.39	
Ba	3.86	-0.015	-9.37	
Be	0.69	-0.000	-43.59	
Bi	3.79	-0.139	-34.05	
B	4.67	0.001	332.54	
Cd	2.26	-0.007	-9.03	
Ca	0.47	-0.001	-13.58	
Ce	5.23	-0.467	-12.83	
Cr	1.29	(-0.060	-7.45	
Co	0.26	-0.020	-56.25	
Cu	2.88	-0.027	-9.05	
Eu	4.04	-0.009	-10.82	
Fe	1.61	-0.010	-3.63	
La	0.35	-0.030	-32.83	
Pb	0.27	0.071	45.83	
Li	4.08	0.001	551.09	
Mg	0.43	-0.000	-29.04	
Mn	0.75	-0.002	-35.38	
Hg	4.19	(-0.029	-10.54	
Mo	1.63	-0.012	-5.72	
Nd	5.42	(-0.847	-9.40	
Ni	3.33	-0.019	-24.70	
P	1.29	0.012	168.99	
K	3.29	-0.696	-9.86	
Sm	5.02	-0.546	-12.21	
Se	1.71	-0.129	-19.31	
Si	3.26	-0.078	-8.60	
Ag	14.89	-0.029	-14.95	
Na	5.38	-0.227	-11.66	
Sr	3.64	-0.005	-12.98	
S	0.72	-0.038	-13.19	
Ta	3.62	-0.074	-10.21	
Tl	4.19	(-0.628	-10.05	
Th	1.05	-0.334	-16.76	
Sn	1.21	-0.021	-39.90	
Ti	3.47	-0.018	-12.54	
W	1.31	-0.051	-12.88	
U	5.07	-3.387	-10.46	
V	4.21	-0.025	-0.48	
Zn	2.33	-0.003	-6.18	
Zr	4.61	-0.053	-9.39	

ICP Data Report - IMCS Check Standard 78C11J - (File 15)

Sample name : 78C11J
 Sample code 1 : SST1
 Sample code 2 : DIRECT
 Programme : SST 19-Apr-90 09:52:37

NAME	MV	INT	CONCEN	RSD
Al	2.00	-0.068	-15.38	
Sb	1.09	10.591	1.18	
As	1.16	0.044	18.97	
Ba	146.91	10.416	0.94	
Be	0.71	0.000	123.72	
Bi	3.84	-0.088	-28.18	
B	137.29	10.173	0.55	
Cd	162.34	10.012	0.92	
Ca	209.66	10.689	0.86	
Ce	10.14	9.175	1.22	
Cr	33.25	9.551	1.09	
Co	2.87	9.727	0.57	
Cu	51.35	10.517	0.88	
Eu	4.54	0.014	7.31	
Fe	64.73	10.346	0.71	
La	0.37	0.036	30.93	
Pb	0.27	0.078	0.00	
Li	91.73	10.608	0.70	
Hg	219.35	10.479	0.97	
Mn	138.86	10.281	0.91	
Hg	4.09	(-0.035	-11.09	
Mo	1.73	0.004	36.37	
Nd	10.76	9.076	3.51	
Hi	81.91	10.154	0.63	
P	1.34	0.051	34.41	
K	8.51	24.914	1.12	
Sm	4.93	(-0.775	-4.39	
Se	3.42	3.316	2.26	
Si	3.27	-0.067	-9.81	
Ag	14.68	(-0.039	-6.98	
Na	33.43	25.503	0.87	
Sr	261.95	10.580	0.96	
S	0.93	0.217	4.65	
Ta	3.65	-0.062	-5.75	
Tl	4.31	-0.328	-16.88	
Th	1.07	-0.189	-23.69	
Sn	120.18	50.427	0.94	
Ti	3.43	(-0.023	-5.57	
W	1.55	0.136	8.71	
U	5.30	-0.080	-351.61	
V	4.20	-0.026	-17.47	
Zn	311.25	10.091	0.84	
Zr	4.60	-0.057	-6.57	

ICP Data Report - LMCS Check Standard 82B38F - (File 16)

Sample name : 82B38F
Sample code 1 : SST2
Sample code 2 : DIRECT
Programme : SST

19-Apr-90 09:57:20

NAME	MV	INT	CONCEN	RSD
Al	3.63	4.198	1.58	
Sb	0.41	0.506	1.68	
As	2.96	1.528	0.96	
Ba	4.20	0.010	17.94	
Be	0.72	0.001	34.69	
Bi	57.66	54.288	0.85	
B	5.47	0.063	4.91	
Cd	2.42	0.003	40.50	
Ca	0.73	0.012	0.64	
Ce	5.63	0.314	13.05	
Cr	1.63	0.044	11.62	
Co	0.27	0.024	9.12	
Cu	4.03	0.224	1.56	
Eu	220.96	9.892	0.09	
Fe	1.97	0.048	5.86	
La	12.55	47.153	0.49	
Pb	2.77	53.426	0.77	
Li	4.28	0.025	17.91	
Mg	0.59	0.006	0.89	
Mn	0.91	0.010	2.66	
Hg	4.89	0.017	14.65	
Mo	1.79	0.014	15.81	
Nd	6.00	0.235	35.15	
Ni	3.65	0.022	14.24	
P	1.62	0.286	5.77	
K	3.33	-0.487	-21.53	
Sm	9.43	9.936	0.75	
Se	1.88	0.226	5.77	
Si	4.16	0.531	3.11	
Ag	246.50	10.797	0.49	
Na	5.53	-0.091	-31.98	
Sr	3.89	0.005	13.79	
S	0.86	0.134	10.36	
Ta	4.16	0.147	3.21	
Tl	6.65	5.646	1.78	
Th	7.85	53.294	0.50	
Sn	1.42	0.070	6.68	
Ti	4.05	0.049	6.51	
W	1.39	0.009	92.71	
U	9.10	53.477	1.11	
V	6.20	0.220	3.16	
Zn	2.64	0.007	7.86	
Zr	5.07	0.105	8.25	

ICP Data Report - LMCS Check Standard 77C11I - (File 17)

Sample name : 77C11I
 Sample code 1 : SST3
 Sample code 2 : DIRECT
 Programme : SST 19-Apr-90 10:01:41

NAME	MV	INT	CONCEN	RSD
Al	21.27	50.184	0.81	
Sb	0.47	1.322	7.83	
As	71.23	57.765	0.66	
Ba	4.34	0.020	13.08	
Be	238.03	9.838	0.55	
Bi	4.97	1.052	3.17	
B	5.56	0.070	0.75	
Cd	2.62	0.015	10.58	
Ca	0.74	0.013	0.23	
Ce	9.58	0.221	45.03	
Cr	1.50	0.004	99.35	
Co	0.30	0.153	3.73	
Cu	3.30	0.064	8.80	
Eu	4.33	0.004	37.48	
Fe	1.97	0.049	13.03	
La	0.37	0.030	45.81	
Pb	0.29	0.454	9.76	
Li	4.23	0.019	2.23	
Mg	0.52	0.003	4.16	
Mn	1.04	0.019	4.69	
Hg	395.71	25.568	0.10	
Ho	286.53	48.572	0.80	
Nd	5.81	-0.108	-91.66	
Ni	7.35	0.501	0.75	
P	70.59	157.863	1.02	
K	3.45	0.082	129.01	
Sm	5.39	0.318	32.27	
Se	27.91	52.507	0.60	
Si	70.49	45.198	0.49	
Ag	22.48	0.326	0.77	
Na	5.87	0.320	21.74	
Sr	3.92	0.006	18.45	
S	42.86	153.038	0.68	
Ta	119.75	48.190	0.68	
Tl	25.27	52.995	1.13	
Th	1.24	1.117	6.33	
Sn	1.74	0.205	5.94	
Ti	439.15	50.431	0.96	
W	27.78	20.931	0.68	
U	6.29	13.916	4.64	
V	84.95	9.932	0.54	
Zn	3.56	0.037	0.71	
Zr	152.09	49.976	0.95	

ICP Data Report - Acid Blank - (File 22)

Sample name : HNO3
Programme : SST

19-Apr-90 10:31:48

NAME	MV	INT	CONCEN	RSD
Al	1.94	-0.232	-7.87	
Sb	0.37	-0.113	-52.71	
As	1.06	-0.034	-3.67	
Ba	3.81	(-0.019	-5.82	
Be	0.69	-0.001	-26.96	
Bi	3.73	(-0.203	-12.90	
B	4.58	-0.005	-65.95	
Cd	2.22	(-0.010	-7.10	
Ca	0.48	-0.001	-8.33	
Ce	5.15	(-0.622	-6.75	
Cr	1.28	(-0.063	-3.86	
Co	0.26	-0.016	-23.08	
Cu	2.84	(-0.036	-7.86	
Eu	3.98	(-0.012	-5.47	
Fe	1.59	(-0.014	-4.45	
La	0.35	-0.035	-29.40	
Pb	0.27	-0.014	-173.20	
Li	3.85	(-0.027	-9.23	
Hg	0.44	-0.001	-6.32	
Mn	0.75	-0.002	-13.88	
He	4.40	-0.015	-13.52	
Mo	1.62	-0.014	-8.71	
Nd	5.31	(-1.045	-4.18	
Ni	3.27	(-0.026	-8.51	
P	1.28	0.002	809.72	
K	3.28	-0.744	-12.25	
Sm	4.95	(-0.728	-6.26	
Se	1.70	-0.148	-13.04	
Si	3.21	-0.111	-6.65	
Ag	14.62	(-0.042	-6.40	
Na	5.30	(-0.300	-7.25	
Sr	3.59	-0.007	-5.68	
S	0.73	-0.037	-32.52	
Ta	3.59	(-0.089	-5.63	
Tl	4.13	(-0.770	-3.81	
Th	1.04	(-0.442	-2.73	
Sn	1.20	-0.022	-21.73	
Ti	3.42	(-0.023	-6.47	
W	1.31	-0.052	-10.09	
U	4.99	(-4.516	-6.44	
V	4.16	(-0.031	-9.86	
Zn	2.31	-0.004	-10.83	
Zr	4.56	-0.069	-7.46	

ICP Data Report - Acid Blank - (File 23)

Sample name
Programme

: HNO3

: SST

19-Apr-90 10:35:25

NAME	MV	INT	CONCEN	RSD
Al	1.92	(-0.278	-11.18	
Sb	0.37	-0.128	-35.25	
As	1.05	-0.044	-8.81	
Ba	3.78	(-0.021	-11.59	
Be	0.68	-0.001	-20.00	
Bi	3.71	(-0.225	-20.53	
B	4.53	-0.009	-66.96	
Cd	2.20	(-0.011	-1.19	
Ca	0.47	-0.001	-12.74	
Ce	5.12	(-0.688	-13.18	
Cr	1.26	(-0.068	-5.56	
Co	0.26	-0.001	-300.01	
Cu	2.82	(-0.040	-10.19	
Eu	3.95	(-0.013	-9.75	
Fe	1.57	(-0.017	-38.84	
La	0.35	-0.050	-19.32	
Pb	0.26	-0.128	-9.62	
Li	3.82	(-0.031	-10.12	
Mg	0.44	-0.001	-15.26	
Mn	0.74	(-0.003	-21.26	
Hg	4.46	-0.011	-108.21	
Mo	1.60	(-0.017	-20.41	
Nd	5.32	(-1.030	-7.12	
Ni	3.27	(-0.026	-6.48	
P	1.26	-0.013	-178.13	
K	3.24	(-0.937	-10.43	
Sm	4.92	(-0.804	-11.85	
Se	1.68	(-0.188	-10.69	
Si	3.18	(-0.127	-11.19	
Ag	14.53	(-0.046	-11.30	
Na	5.26	(-0.337	-15.02	
Sr	3.57	(-0.008	-14.01	
S	0.72	(-0.048	-37.62	
Ta	3.57	(-0.095	-16.69	
Tl	4.12	(-0.813	-15.82	
Th	1.03	(-0.492	-15.42	
Sn	1.20	-0.025	-14.32	
Ti	3.40	(-0.026	-11.09	
W	1.30	(-0.063	-8.04	
U	4.96	(-4.982	-12.47	
V	4.15	(-0.033	-17.17	
Zn	2.29	(-0.004	-23.36	
Zr	4.54	-0.075	-12.22	

ICP Data Report - Customer Id. 89-043, Sample F0068 - (File 24)

Sample name : FG8
Sample code 1 : SAMPLE
Sample code 2 : 100-10
Sample code 3 : B9043
Programme : SST 19-Apr-90 10:39:12

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	5.60	9.318	941.15	0.48	
Sb	0.38	0.044	4.467	152.75	
As	1.09	-0.010	-1.026	-103.52	
Ba	4.06	-0.000	-0.037	-682.39	
Be	0.71	0.000	0.011	255.26	
Bu	4.42	0.498	50.344	10.84	
B	4.85	0.015	1.549	22.82	
Cd	2.31	-0.004	-0.451	-47.44	
Ca	2.61	0.109	10.964	0.30	
Ce	5.36	-0.220	-22.21	-43.38	
Cr	1.63	0.044	4.475	8.34	
Co	0.27	0.020	2.012	65.85	
Cu	2.99	-0.004	-0.447	-124.13	
Eu	4.14	-0.004	-0.450	-34.45	
Fe	12.52	1.779	179.69	0.38	
La	0.36	-0.009	-0.911	-130.93	
Pb	0.27	0.085	8.605	38.19	
Li	3.99	-0.011	-1.063	-34.16	
Mg	17.67	0.824	83.227	0.42	
Mn	9.75	0.668	67.433	0.62	
Hg	4.75	0.008	0.773	7.12	
Ho	1.70	-0.001	-0.149	-243.76	
Nd	5.52	(-0.660	(-66.63	-16.98	
Ni	3.54	0.008	0.854	63.29	
P	1.62	0.287	29.031	13.46	
K	3.35	-0.423	-42.76	-18.11	
Sm	5.14	-0.259	-26.21	-44.07	
Se	1.78	0.009	0.879	384.31	
Si	3.80	0.290	29.290	6.01	
Ag	15.25	-0.012	-1.226	-50.33	
Na	14.21	7.875	795.34	0.96	
Sr	3.64	0.077	7.756	1.81	
S	0.84	0.113	11.365	1.71	
Ts	3.75	-0.023	-2.323	-85.74	
Tl	4.40	-0.082	-8.305	-127.42	
Th	1.08	-0.142	-14.34	-50.10	
Sn	1.28	0.010	1.056	93.54	
Ti	3.68	0.007	0.663	51.22	
W	1.36	-0.013	-1.334	-148.23	
U	5.30	-0.165	-16.63	-434.47	
V	4.42	0.000	0.033	1552.95	
Zn	4.64	0.073	7.335	0.99	
Zr	4.71	-0.017	-1.713	-63.45	

Dilution factor : 101.000

ICP Data Report - Customer Id. 89-043, Sample F0068 - (File 25)

Sample name : F68
 Sample code 1 : SAMPLE
 Sample code 2 : 500-10
 Sample code 3 : 89043
 Programme : SST 19-Apr-90 10:44:07

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	19.13	44.603	936.66	0.90	
Sb	0.39	0.275	5.779	17.22	
As	1.17	0.054	1.124	18.03	
Ba	4.54	0.035	0.736	4.16	
Be	0.74	0.001	0.030	10.19	
Bi	6.46	2.558	53.710	0.89	
B	5.03	0.029	0.616	13.08	
Cd	2.44	0.004	0.080	15.67	
Ca	8.54	0.412	8.642	0.50	
Ce	5.58	0.209	4.385	26.81	
Cr	2.45	0.290	6.081	1.93	
Co	0.27	0.037	0.784	11.55	
Cu	3.22	0.046	0.970	7.09	
Eu	4.32	0.004	0.078	25.86	
Fe	52.41	8.326	174.84	0.75	
La	0.37	0.032	0.677	6.93	
Pb	0.30	0.639	13.419	6.94	
Li	4.12	0.006	0.126	45.75	
Mg	18.50	0.864	18.143	0.41	
Mn	42.70	3.121	65.544	0.44	
Hg	4.92	0.019	0.402	19.98	
Mo	1.82	0.019	0.395	13.87	
Nd	5.74	-0.242	-5.081	-19.11	
Ni	4.18	0.091	1.919	3.51	
P	2.87	1.325	27.826	3.00	
K	3.46	0.131	2.746	60.97	
Sm	5.35	0.236	4.949	32.37	
Se	1.95	0.362	7.593	10.29	
Si	5.62	1.515	31.812	1.37	
Ag	16.06	0.026	0.536	15.92	
Na	46.21	37.231	781.86	0.36	
Sr	12.84	0.372	7.808	0.29	
S	0.95	0.243	5.105	8.44	
Ta	3.91	0.046	0.960	21.44	
Tl	4.76	0.824	17.303	8.65	
Th	1.13	0.226	4.748	13.21	
Sn	1.38	0.053	1.113	8.99	
Ti	4.27	0.075	1.572	6.52	
W	1.47	0.077	1.626	24.38	
U	5.94	8.892	186.72	4.37	
V	4.77	0.044	0.921	6.06	
Zn	4.42	0.066	1.376	0.13	
Zr	4.90	0.046	0.962	12.22	

Dilution factor : 21.0000

ICP Data Report - Duplicate of Sample F0068 - (File 26)

Sample name : F69
 Sample code 1 : DUPSAM
 Sample code 2 : 100-10
 Sample code 3 : 89043
 Programme : SST 19-Apr-90 10:48:09

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	5.29	8.503	858.81	0.91	
Sb	0.39	0.192	19.358	30.77	
As	1.12	0.012	1.192	129.09	
Ba	4.17	0.008	0.761	45.50	
Be	0.73	0.001	0.100	15.02	
Bi	4.47	0.547	55.276	3.07	
B	4.78	0.010	1.012	29.72	
Cd	2.37	-0.000	-0.023	-919.73	
Ca	2.18	0.087	8.738	1.74	
Ce	5.52	0.094	9.454	148.05	
Cr	1.56	0.022	2.237	28.61	
Co	0.27	0.031	3.144	6.93	
Cu	3.06	0.011	1.128	70.14	
Eu	4.27	0.001	0.144	169.64	
Fe	12.23	1.733	175.02	1.08	
La	0.37	0.026	2.604	52.68	
Pb	0.28	0.291	29.400	12.67	
Li	4.09	0.002	0.208	288.43	
Hg	3.34	0.138	13.943	1.57	
Mn	9.18	0.626	63.209	1.30	
Hg	4.77	0.009	0.949	26.47	
Mo	1.75	0.007	0.700	39.34	
Nd	5.68	-0.361	-36.44	-44.46	
Ni	3.64	0.021	2.110	38.79	
P	1.68	0.336	33.977	2.08	
K	3.42	-0.049	-4.953	-336.01	
Sm	5.30	0.113	11.381	138.61	
Se	1.83	0.110	11.159	20.97	
Si	3.76	0.258	26.093	11.55	
Ag	15.70	0.009	0.891	112.99	
Na	13.51	7.230	730.24	0.88	
Br	5.53	0.072	7.299	0.61	
S	0.79	0.048	4.834	12.15	
Ta	3.85	0.019	1.959	64.96	
Tl	4.51	0.192	19.435	84.07	
Th	1.11	0.103	10.355	94.00	
Sn	1.28	0.013	1.285	59.29	
Ii	3.77	0.017	1.684	27.52	
W	1.40	0.017	1.708	66.35	
U	5.44	1.825	184.36	50.38	
V	4.49	0.009	0.893	70.66	
Zn	3.22	0.026	2.644	3.51	
Zr	4.84	0.025	2.478	60.14	

Dilution factor : 101.000

ICP Data Report - Duplicate of Sample F0068 - (File 27)

Sample name : F69
 Sample code 1 : DUPSAM
 Sample code 2 : 500-10
 Sample code 3 : 89043
 Programme : SST 19-Apr-90 10:52:26

NAME	MV	INT	CONCEN	DILCOR	RSD
Al	18.13	41.987	881.73	2.55	
Sb	0.38	0.093	1.961	105.13	
As	1.12	0.016	0.346	90.05	
Ba	4.31	0.018	0.370	13.90	
Be	0.70	-0.000	-0.001	-454.33	
Bi	6.07	2.165	45.456	1.15	
B	4.77	0.009	0.192	27.25	
Cd	2.30	-0.005	-0.106	-18.35	
Ca	8.40	0.404	8.490	0.45	
Ce	5.26	-0.416	-8.742	-21.10	
Cr	2.27	0.235	4.932	2.66	
Co	0.26	0.004	0.078	351.17	
Cu	3.03	0.006	0.116	87.59	
Eu	4.07	-0.008	-0.159	-20.03	
Fe	52.23	8.295	174.19	0.58	
La	0.36	-0.009	-0.189	-137.77	
Pb	0.29	0.461	9.691	12.21	
Li	3.90	-0.021	-0.441	-18.84	
Mg	14.75	0.684	14.366	0.58	
Mn	40.78	2.978	62.548	0.74	
Hg	4.93	0.020	0.411	32.82	
Mo	1.73	0.004	0.076	96.11	
Nd	5.45	(-0.791	(-16.62	-17.50	
Ni	3.94	0.060	1.262	7.39	
P	2.58	1.090	22.888	1.10	
K	3.29	-0.709	-14.90	-9.38	
Sm	5.04	-0.498	-10.47	-19.82	
Se	1.84	0.145	3.051	15.54	
Si	5.23	1.249	26.236	11.09	
Ag	15.10	-0.020	-0.410	-28.48	
Na	43.07	34.349	721.33	0.46	
Sr	12.03	0.338	7.106	0.54	
S	0.89	0.173	3.641	5.24	
Ta	3.66	-0.057	-1.199	-23.04	
Tl	4.42	-0.043	-0.908	-262.68	
Th	1.06	-0.271	-5.686	-26.27	
Sn	1.31	0.024	0.513	18.70	
Ti	4.08	0.052	1.090	7.15	
W	1.39	0.009	0.183	118.65	
U	5.58	3.787	79.531	15.98	
V	4.47	0.006	0.130	56.30	
Zn	4.22	0.059	1.236	1.32	
Zr	4.80	0.011	0.235	101.52	

Dilution factor : 21.0000

ICP Data Report - Acid Blank - (File 32)

Sample name	:	HN03		
Programme	:	SST		
		19-Apr-90 11:13:28		
NAME	MV	INT	CONCEN	RSD
Al	1.93	-0.253	-16.20	
Sb	0.37	-0.074	-40.00	
As	1.05	-0.044	-20.44	
Ba	3.80	(-0.019	-8.95	
Be	0.68	-0.001	-26.15	
Bi	3.71	(-0.224	-28.45	
B	4.46	-0.014	-35.03	
Cd	2.21	(-0.010	-5.79	
Ca	0.47	-0.001	-11.27	
Ce	5.14	(-0.647	-8.84	
Cr	1.26	(-0.068	-4.38	
Co	0.26	-0.017	-44.61	
Cu	2.83	(-0.038	-12.61	
Eu	3.97	(-0.012	-8.86	
Fe	1.60	-0.012	-17.73	
La	0.35	-0.036	-26.96	
Pb	0.27	-0.000	*****	
Li	3.83	(-0.029	-12.16	
Hg	0.44	-0.001	-10.60	
Mn	0.74	-0.003	-5.14	
Hg	4.58	-0.003	-101.25	
Ho	1.62	(-0.015	-8.76	
Nd	6.30	(-1.071	-8.15	
Ni	3.24	(-0.030	-10.24	
P	1.29	0.008	296.65	
K	3.23	(-1.002	-2.99	
Sm	4.94	(-0.744	-8.34	
Se	1.70	-0.145	-5.23	
Si	3.18	(-0.129	-9.79	
Ag	14.57	(-0.044	-6.64	
Na	5.28	(-0.316	-9.66	
Sr	3.58	-0.008	-8.69	
S	0.72	-0.042	-33.52	
Ta	3.57	(-0.095	-8.10	
Tl	4.12	(-0.799	-7.55	
Th	1.04	(-0.463	-9.02	
Sn	1.19	(-0.028	-33.34	
Ti	3.41	(-0.025	-7.21	
W	1.30	(-0.061	-11.20	
U	4.97	(-4.780	-8.74	
V	4.14	(-0.034	-4.68	
Zn	2.29	(-0.004	-21.36	
Zr	4.55	-0.072	-10.58	

ICP Data Report - LMCS Check Standard 78C11J - (File 33)

Sample name : 78C11J
Sample code 1 : SST1
Sample code 3 : DIRECT
Programme : SST 19-Apr-90 11:17:13

NAME	MV	INT	CONCEN	RSD
Al	1.97	-0.187	-15.35	
Sb	1.07	10.257	0.36	
As	1.14	0.034	24.35	
Ba	144.69	10.253	0.70	
Be	0.69	-0.000	-34.64	
Bi	3.79	-0.141	-3.68	
B	134.29	9.943	0.65	
Cd	158.51	9.772	0.97	
Ca	206.02	10.503	0.57	
Ce	9.98	8.857	0.92	
Cr	32.51	9.330	0.99	
Co	2.76	9.322	0.25	
Cu	50.52	10.336	0.70	
Du	4.47	0.011	8.04	
Fe	63.53	10.150	0.88	
La	0.37	0.024	18.23	
Pb	0.27	0.014	396.88	
Li	88.69	10.361	0.52	
Mg	214.46	10.245	0.70	
Mn	135.96	10.065	0.84	
Hg	4.24	(-0.026	-7.84	
Mo	1.70	-0.001	-109.08	
Nd	10.59	8.752	1.94	
Ni	79.98	9.905	0.96	
P	1.34	0.053	32.82	
K	8.39	24.306	0.90	
Gm	4.86	(-0.947	-4.23	
Se	3.34	3.158	0.80	
Si	3.21	-0.112	-8.22	
Ag	14.44	(-0.050	-5.18	
Na	32.89	25.012	0.87	
Sr	257.58	10.401	0.66	
S	0.91	0.196	15.52	
Ta	3.58	(-0.092	-13.15	
Tl	4.24	-0.496	-15.01	
Th	1.06	-0.300	-10.64	
Sn	117.24	49.177	0.77	
Ti	3.38	(-0.029	-5.66	
W	1.54	0.129	15.81	
U	5.21	-1.327	-19.07	
V	4.14	(-0.034	-18.06	
Zn	304.88	9.882	0.86	
Zr	4.55	-0.074	-8.91	

ICP Data Report - LMCS Check Standard 82B38F - (File 34)

Sample name : 82B38F
 Sample code 1 : SST2
 Sample code 2 : DIRECT
 Programme : SST 19-Apr-90 11:21:20

NAME	MV	INT	CONCEN	RSD
Al	3.58	4.069	1.38	
Sb	0.41	0.452	4.98	
As	2.90	1.477	1.89	
Ba	4.15	0.006	29.78	
Be	0.72	0.001	5.88	
Bi	56.81	53.426	1.49	
B	5.34	0.053	7.04	
Cd	2.37	-0.000	-557.56	
Ca	0.72	0.012	2.17	
Ce	5.56	0.175	48.32	
Cr	1.60	0.034	7.54	
Co	0.26	0.002	149.99	
Cu	3.98	0.213	0.87	
Bu	218.33	9.772	1.47	
Fe	1.95	0.046	7.95	
La	12.40	346.554	1.62	
Pb	2.73	52.410	1.22	
Li	4.16	0.011	25.99	
Hg	0.58	0.006	1.89	
Mn	0.89	0.009	6.31	
Hg	5.12	0.032	5.58	
Ho	1.75	0.008	17.90	
Nd	5.93	0.110	49.02	
Ni	9.57	0.012	43.95	
P	1.62	0.282	6.00	
K	3.29	-0.683	-16.18	
Sm	9.31	9.654	0.99	
Se	1.86	0.176	16.23	
Si	4.09	0.487	3.07	
Ag	243.27	10.646	1.11	
Na	5.45	-0.159	-19.64	
Sr	3.85	0.003	27.75	
S	0.85	0.120	0.61	
Ta	4.10	0.125	10.61	
Tl	6.61	5.532	1.17	
Th	7.75	52.474	1.49	
Sn	1.40	0.061	1.59	
Ti	4.00	0.043	4.73	
W	1.38	0.001	377.53	
U	8.98	51.750	1.10	
V	6.18	0.217	2.11	
Zn	2.60	0.006	5.67	
Zr	5.02	0.088	8.18	

ICP Data Report - LMCS Check Standard 77C11I - (File 35)

Sample name : 77C11I
Sample code 1 : SST3
Sample code 2 : DIRECT
Programme : SST 19-Apr-90 11:25:06

NAME	MV	INT	CONCEN	RSD
Al	21.36	50.406	0.19	
Sb	0.46	1.288	6.31	
As	71.36	57.875	0.46	
Ba	4.28	0.016	20.19	
Be	235.91	9.750	1.00	
Bi	4.91	0.991	2.95	
B	5.46	0.062	1.83	
Cd	2.59	0.013	19.09	
Ca	0.74	0.013	1.21	
Ce	5.50	0.059	193.40	
Cr	1.49	0.000	2621.02	
Co	0.29	0.118	3.16	
Cu	3.26	0.055	10.19	
Eu	4.27	0.001	153.56	
Fe	1.95	0.045	6.19	
La	0.36	0.009	89.21	
Pb	0.28	0.284	4.33	
Li	4.15	0.009	27.52	
Mg	0.51	0.003	5.92	
Mn	1.02	0.018	6.79	
Hg	394.44	25.485	0.91	
Mo	286.54	48.570	0.58	
Nd	5.70	-0.317	-25.18	
Ni	7.35	0.502	1.43	
P	72.26	159.255	1.62	
X	3.40	-0.160	-96.82	
Sm	5.31	0.185	106.53	
Se	27.87	52.432	1.18	
Si	70.59	45.263	0.59	
Ag	22.41	0.322	0.69	
Na	5.76	0.128	44.89	
Sr	3.87	0.004	34.51	
S	43.60	153.973	1.14	
Ts	119.44	48.062	0.84	
Tl	25.32	53.112	0.17	
Th	1.22	1.004	6.23	
Sn	1.73	0.201	1.41	
Ti	441.46	50.698	0.22	
W	27.83	20.969	0.36	
U	6.23	13.003	1.81	
V	85.53	10.005	0.09	
Zn	3.53	0.036	3.64	
Zr	152.84	50.232	0.26	

7
6
5
4
3
2
1
0

Appendix A.

Analytical Cards

9 1 1 2 7 , 7 0 9 ? 9

Physical Properties

Serial No. F 53.-5001	Sample Point SEGMENT-2		Date 11-15-89	Time Issued 10:18	Priority 18
Determination VDA SAMP	Method/Standard LI-000-200	Result Units NONE	Charge Code WB75L	Runno 0	
Sample Size ? 3.0g	2.18g		Customer ID 89-043		
Remarks, Calculations, Results: DUPLICATE SAMPLE Batch # 268 TARE WT 22.30 23.78 268 TARE WT 22.63 22.14 3.0g 2.18g					
Sent to PNL					
Analyst-1 R24 KJP-JRS	Analyst-2 6A09 61300 65286	Analyst-3	Analyst-4	Analyst-5	
Hrs 1-15-89	Hrs	Hrs	Hrs	Hrs	
Date	Time Completed	Lab Unit Mgr	FMS		
54-6800-061 (R-10-43)					

Serial No. F 53.-5000	Sample Point SEGMENT-2		Date 11-15-89	Time Issued 10:18	Priority 18
Determination APPR/OTR	Method/Standard LI-000-200	Result Units NONE	Charge Code WB75L	Runno 0	
Sample Size ? 98.89	1040 N 313 3		Customer ID 89-043		
Remarks, Calculations, Results: A. JAR ID# 056 B. JAR TARE WT 224.06 C. JAR TOTAL WT 323.95 D. C-B = 98.89 E. EST. VOL. / LENGTH IN inches F. VISUAL REMARKS cable incorrect position but, cable very slack Sample firm, dark brown, creamy at top					
Analyst-1 R24 KJP-JRS	Analyst-2 6A09 61300 65286	Analyst-3	Analyst-4	Analyst-5	
Hrs 1-15-89	Hrs	Hrs	Hrs	Hrs	
Date	Time Completed	Lab Unit Mgr	FMS		
54-6800-061 (R-10-43)					

Serial No. F 53.-5002	Sample Point SEGMENT-2		Date 11-15-89	Time Issued 10:18	Priority 24
Determination PRT-SIZE	Method/Standard LI-000-200	Result Units NONE	Charge Code WB75L	Runno 0	
Sample Size ? 1.25g			Customer ID 89-043		
Remarks, Calculations, Results Batch # PARTICLE SIZE DISTRIBUTION Total wt 22.30 23.78 Tare 22.63 22.14 1.25					
Results: see attached sheet (6)					
Analyst-1 R24 KJP-JRS	Analyst-2	Analyst-3	Analyst-4	Analyst-5	
Hrs	Hrs	Hrs	Hrs	Hrs	
Date	Time Completed	Lab Unit Mgr	FMS		
54-6800-061 (R-10-43)					

Serial No. F 53.-5003	Sample Point SEGMENT-2		Date 11-15-89	Time Issued 10:18	Priority 16
Determination HOMOGZT	Method/Standard LI-000-200	Result Units NONE	Charge Code WB75L	Runno 0	
Sample Size ?			Customer ID 89-043		
Remarks, Calculations, Results: Homogenization complete 1-3-90					
Analyst-1 R24 KJP-JRS	Analyst-2 6A09 61300 65286	Analyst-3	Analyst-4	Analyst-5	
Hrs 1-3-90	Hrs	Hrs	Hrs	Hrs	
Date	Time Completed	Lab Unit Mgr	FMS		
54-6800-061 (R-10-43)					

9 1 1 2 7 3 7 0 9 7 0

Physical Properties

Serial No. F 55.-5201	Sample Point SEGMENT-4		Date 11-15-89	Time Issued 10:19	Priority 18
Determination VOA-SAMP	Method/Standard LI-000-200	Result Units NONE	Charge Code WB75L	Recons 0	
Sample Size ?			Customer ID 87-043		
Remarks, Calculations, Results: THIRD SAMPLE					
<p><i>sent to PNL</i></p> <p><i>No duplicate taken</i></p>					
Analyst -1	Analyst -2	Analyst -3	Analyst -4	Analyst -5	
Hrs	Hrs	Hrs	Hrs	Hrs	
Date	Time Completed	Lab Unit Mgr	<i>DMS</i>		

54-6400-061 (R-10-83)

Serial No. F 54.-5101	Sample Point SEGMENT-5		Date 11-15-89	Time Issued 10:18	Priority 18
Determination VOA-SAMP	Method/Standard LI-000-200	Result Units NONE	Charge Code WB75L	Recons 0	
Sample Size ?			Customer ID 89-043		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
<p><i>sent to PNL</i></p> <p><i>No duplicate taken</i></p>					
Analyst -1	Analyst -2	Analyst -3	Analyst -4	Analyst -5	
Hrs	Hrs	Hrs	Hrs	Hrs	
Date	Time Completed	Lab Unit Mgr	<i>DMS</i>		

54-6400-061 (R-10-83)

9 1 1 2 3 7 0 3 7 1

pH Analysis of Solid Sample

Serial No. F 54.-5115	Sample Point SEGMENT-3	Date 11-15-89	Time Issued 10:19	Priority 19
Determination pH	Method/Standard LA-212-103	Result Units NONE	Charge Code WB75L	Reruns 0
Sample Size ? 3.140g / 3.140 ml	Customer ID 089043			
Remarks, Calculations, Results: pH 11.76 SAMPLE TEMP 25.4				
Analyst -1 <i>LC269</i>	Analyst -2 <i>Mary</i>	Analyst -3 <i>Gretzky</i>	Analyst -4 <i>Cyr</i>	Analyst -5 <i>ReBennett</i>
Hrs	Hrs	Hrs	Hrs	Hrs
Date 1-4-90	Time Completed	Lab Unit Mgr	<i>Cyr</i>	

54-6400-061 (R-10-83)

Serial No. F 53.-5015	Sample Point SEGMENT-2	Date 11-15-89	Time Issued 10:18	Priority 19
Determination pH	Method/Standard LA-212-103	Result Units NONE	Charge Code WB75L	Reruns 0
Sample Size ? 3.470g / 3.470 ml	Customer ID 089043			
Remarks, Calculations, Results: pH 11.38 SAMPLE TEMP 25.4				
Analyst -1 <i>LC269</i>	Analyst -2 <i>Mary</i>	Analyst -3 <i>Gretzky</i>	Analyst -4 <i>Cyr</i>	Analyst -5 <i>ReBennett</i>
Hrs	Hrs	Hrs	Hrs	Hrs
Date 1-4-90	Time Completed	Lab Unit Mgr	<i>Cyr</i>	

#237
9.24g
WHC N 3134
54-6400-061 (R-10-83)

Serial No. F 73.-5315	Sample Point SEGMENT-22	Date 11-15-89	Time Issued 10:21	Priority 18
Determination pH	Method/Standard LA-212-103	Result Units NONE	Charge Code WB75L	Reruns 0
Sample Size ?	Customer ID			
Remarks, Calculations, Results: LMCS CHECK SAMPLE OH FOUND 10.02 STD ID 10CH-A SAMPLE TEMP 25.4 Reagent blank = 8.16				
Analyst -1 <i>LC269</i>	Analyst -2 <i>Mary</i>	Analyst -3 <i>Gretzky</i>	Analyst -4 <i>Cyr</i>	Analyst -5 <i>ReBennett</i>
Hrs	Hrs	Hrs	Hrs	Hrs
Date 1-4-90	Time Completed	Lab Unit Mgr	<i>Cyr</i>	

54-6400-061 (R-10-83)

Serial No. F 56.-5515	Sample Point SEGMENT-5	Date 11-15-89	Time Issued 10:19	Priority 19
Determination pH	Method/Standard LA-212-103	Result Units % RECOVERY	Charge Code WB75L	Reruns 0
Sample Size ?	Customer ID			
Remarks, Calculations, Results: LMCS CHECK SAMPLE OH FOUND 10.02 STD ID 10CH-A SAMPLE TEMP 25.4				
Analyst -1 <i>LC269</i>	Analyst -2 <i>Mary</i>	Analyst -3 <i>Gretzky</i>	Analyst -4 <i>Cyr</i>	Analyst -5 <i>ReBennett</i>
Hrs	Hrs	Hrs	Hrs	Hrs
Date 1-4-90	Time Completed	Lab Unit Mgr	<i>Cyr</i>	

K1
10.02 / 10.00 100.290
54-6400-061 (R-10-83)

9 1 1 2 1 3 2 0 0 7 2

pH Analysis of Solid Sample

Serial No.	Sample Point		Date	Time Issued	Priority
F 704.-5515	SEGMENT-A		12-11-89	8:13	26
Determination	Method/Standard	Result Units	Charge Code	Return	
DH	LA-212-103	% RECOVERY	WB75L	0	
Sample Size					Customer ID
?					H
Remarks, Calculations, Results:					
LMCS CHECK SAMPLE DH FOUND <u>99.9</u> QTD ID <u>1201-11</u> SAMPLE TEMP <u>25.5</u>					
Analyst - 1	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5	
<u>CC269</u>				<u>2600-11</u>	
<u>Mary</u>	Hrs	Hrs	Hrs	Hrs	
<u>Stratton</u>					
Date	Time Completed	Lab Unit Mgr	<u>Chas. W.</u>		
1-4-90			24-6800-061 (R-10-83)		

Percent Water Analysis

9 1 1 2 3 5 7 0 3 7 3

Serial No. F 54.-5110	Sample Point SEGMENT-3		Date 11-15-89	Time Issued 10:19	Priority 19
Determination % H ₂ O	Method/Standard LA-564-101	Result Units %	Charge Code WB75L	Reruns 0	
Sample Size ?			Customer ID 089043		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
G. 22.3601 T. 21.6722 37.6% W1 22.1018 W2 22.1033					
Analyst-1 <i>68598/H</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>REBmott</i>	
Date 1-10-90	Time Completed	Lab Unit Mgr <i>CJW</i>	QMS		
54-5600-061 (R-10-63)					

Serial No. F 52.-5510	Sample Point SEGMENT-1		Date 11-15-89	Time Issued 10:18	Priority 19
Determination % H ₂ O	Method/Standard LA-564-101	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 1 mL			Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <u>11C11A</u>					
G. 23.0149 G. 22.6870 T. 21.7581 T. 21.4071 95.0% 22.2912 W1 21.9409 56.0% / 58.98 22.2874 W2 21.9409					
Analyst-1 <i>68598/H</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>REBmott</i>	
Date 1-10-90	Time Completed	Lab Unit Mgr <i>CJW</i>	QMS		
54-5600-061 (R-10-63)					

Serial No. F 749.-5310	Sample Point SEGMENT-V		Date 12-11-89	Time Issued 9: 5	Priority 26
Determination % H ₂ O	Method/Standard LA-564-101	Result Units %	Charge Code WB75L	Reruns 0	
Sample Size ?			Customer ID		
Remarks, Calculations, Results: REAGENT BLANK					
G. 22.0476 G. 22.0058 T. 22.0476 T. 22.0058 51.3% 22.0404 W1 22.0007 22.0426 W2 22.0048 16.15 grams					
Analyst-1 <i>68598/H</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>REBmott</i>	
Date 1-10-90	Time Completed	Lab Unit Mgr <i>CJW</i>	QMS		
54-5600-061 (R-10-63)					

Serial No. F 732.-5510	Sample Point SEGMENT-E		Date 12-11-89	Time Issued 9: 3	Priority 26
Determination % H ₂ O	Method/Standard LA-564-101	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 1 mL			Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <u>11C11A</u>					
G. 22.5036 G. 22.5546 58.0% T. 21.3129 T. 21.2996 98.2% 21.8155 W1 21.8260 57.9% / 58.9% 21.8111 W2 21.8214					
Analyst-1 <i>68598/H</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>REBmott</i>	
Date 1-10-90	Time Completed	Lab Unit Mgr <i>CJW</i>	QMS		
54-5600-061 (R-10-63)					

9 1 1 2 1 1 2 0 3 7 4

Percent Water Analysis

Serial No F 53.-5010	Sample Point SEGMENT-2	Date 11-15-89	Time Issued 10:18	Priority 19
Determination % H ₂ O	Method/Standard LA-564-101	Result Units %	Charge Code WB75L	Re runs 0
Sample Size ?				Customer ID 089043
Remarks, Calculations, Results.				
G 22.6838 #239 T 21.8768 3.64 W1 22.3648 39.50% W2 22.3662 W4C N 3134				
Analyst-1 <i>16574/RH</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>REB</i>
Date 1-10-90	Time Completed <i>CGR</i>	Lab Unit Me <i>OMS</i>		

84-6400-061 (R-10-43)

9 1 1 2 3 6 7 0 0 3 7 5

Fusion Dissolution

Serial No. F 59.-6100	Sample Point SEGMENT-8		Date 11-15-89	Time Issued 10:19	Priority 18
Determination FUSION	Method/Standard LA-549-141	Result Units G/L	Charge Code WB75L	Re runs 0	
Sample Size ?		Customer ID 089043			
Remarks, Calculations, Results: DUPLICATE ANALYSIS GRAMS SAMPLE <u>0.4198</u> VOLUME ON COMPLETION <u>250 ml</u> NET WEIGHT: <u>1.676 g/ml</u> <u>1.68%</u> <u>1.676 g/ml</u> <u>0.4198</u> <u>0.05/00 0 11:29:12</u> <u>0.05/00 0 11:27:24</u>					
Analyst -1 <i>6.658/44</i>	Analyst -2 Hrs	Analyst -3 <i>Tell Me Now 5/10/90</i>	Analyst -4 Hrs	Analyst -5 <i>Gre</i>	Hrs
Date 1-5-90	Time Completed	Lab Unit Mgr <i>Gre</i>			

54-6000-061 (R-10-63)

Serial No. F 58.-6000	Sample Point SEGMENT-7		Date 11-15-89	Time Issued 10:19	Priority 18
Determination FUSION	Method/Standard LA-549-141	Result Units G/L	Charge Code WB75L	Re runs 0	
Sample Size ?		Customer ID 089043			
Remarks, Calculations, Results: GRAMS SAMPLE <u>0.5663</u> # SEQUENCE # : 98 VOLUME ON COMPLETION <u>250 ml</u> NET WEIGHT: <u>2.265 g/ml</u> <u>2.27</u> <u>2.265 g/ml</u> <u>WFC N 3134</u> <u>01-05/00 0 11:27:24</u>					
Analyst -1 <i>6.658/44</i>	Analyst -2 Hrs	Analyst -3 <i>Tell Me Now 5/10/90</i>	Analyst -4 Hrs	Analyst -5 <i>Gre</i>	Hrs
Date 1-5-90	Time Completed	Lab Unit Mgr <i>Gre</i>			

54-6000-061 (R-10-63)

Serial No. F 74B.-6300	Sample Point SEGMENT-U		Date 12-11-89	Time Issued 9:5	Priority 26
Determination FUSION	Method/Standard LA-549-141	Result Units G/L	Charge Code WB75L	Re runs 0	
Sample Size ?		Customer ID			
Remarks, Calculations, Results: REAGENT BLANK <i>Complete</i>					
Analyst -1 <i>6.658/44</i>	Analyst -2 Hrs	Analyst -3 Hrs	Analyst -4 Hrs	Analyst -5 Hrs	
Date 1-5-90	Time Completed	Lab Unit Mgr <i>Gre</i>			

54-6000-061 (R-10-63)

9 1 1 2 7 3 0 3 7 6

Total Alpha Analysis on the Fusion Dissolution

Serial No. F 58.-6020	Sample Point SEGMENT-7		Date 11-15-89	Time Issued 10:19	Priority 19
Determination AT	Method/Standard LA-548-101 500	Result Units uCi/L	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10-250			Customer ID 089043		
Remarks, Calculations, Results: 6.38 uCi/l					
Analyst -1 6A543	Analyst -2	Analyst -3	Analyst -4	Analyst -5	
Hrs	Hrs	Hrs	Hrs	Hrs	
<i>J. Hopkins</i>					
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Cja</i>	<i>SW</i>	<i>KJ</i>	
SI-5800-061 (R-10-83)					

Serial No. F 57.-6520	Sample Point SEGMENT-6		Date 11-15-89	Time Issued 10:19	Priority 19
Determination AT	Method/Standard LA-548-101 500	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 10ml			Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 83844					
Analyst -1 6A543	Analyst -2	Analyst -3	Analyst -4	Analyst -5	
Hrs	Hrs	Hrs	Hrs	Hrs	
<i>J. Hopkins</i>					
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Cja</i>	<i>SW</i>	<i>KJ</i>	
SI-5800-061 (R-10-83)					

Serial No. F 60.-6220	Sample Point SEGMENT-9		Date 11-15-89	Time Issued 10:19	Priority 19
Determination AT	Method/Standard LA-548-101 500	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10-250			Customer ID 089043		
Remarks, Calculations, Results: SPIKE SAMPLE SPIKE ID 83844 SPIKE VOLUME <i>real</i> spike too low					
Analyst -1 6A543	Analyst -2	Analyst -3	Analyst -4	Analyst -5	
Hrs	Hrs	Hrs	Hrs	Hrs	
<i>J. Hopkins</i>					
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Cja</i>	<i>SW</i>	<i>KJ</i>	
SI-5800-061 (R-10-83)					

Serial No. F 59.-6120	Sample Point SEGMENT-8		Date 11-15-89	Time Issued 10:19	Priority 19
Determination AT	Method/Standard LA-548-101 500	Result Units uCi/L	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10-250			Customer ID 089043		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
Analyst -1 6A543	Analyst -2	Analyst -3	Analyst -4	Analyst -5	
Hrs	Hrs	Hrs	Hrs	Hrs	
<i>J. Hopkins</i>					
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Cja</i>	<i>SW</i>	<i>KJ</i>	
SI-5800-061 (R-10-83)					

9 1 1 2 1 5 7 0 9 7 7

Total Alpha Analysis on the Fusion Dissolution

18/2

82
10

-.4

Alpha Calculation by AJ on 01-08-1990 at 17:54:22
 Det #18 2-inch mount Alpha eff. : .2095
 Sample size : .25 mL Dilution : 101

Mount # 1

73
10

82

 $\frac{82}{10} = 0.4 = 6.7755E+00 \text{ uCi/L alpha}$

10

Mount # 2

73

 $\frac{73}{10} = 0.4 = 5.9937E+00 \text{ uCi/L alpha}$

10

F 58.-6020

18/2

503
10

Alpha Calculation by EM3 on 01-08-1990 at 15:12:28
~~Det #18~~ 2 -inch mount Alpha eff. : .2095
 Sample size : 10 mL Dilution : 1

Mount # 1

482
10

503

 $\frac{482}{10} = 0.3 = 1.0751E-02 \text{ uCi/L alpha}$

10

Mount # 2

482

 $\frac{482}{10} = 0.3 = 1.0299E-02 \text{ uCi/L alpha}$

10

F 57.-6520

18/2

598
10

-.4

Alpha Calculation by AJ on 01-08-1990 at 17:52:33
 Det #18 2-inch mount Alpha eff. : .2095
 Sample size : .25 mL Dilution : 101

Mount # 1

598

 $\frac{598}{10} = 0.4 = 5.1598E+01 \text{ uCi/L alpha}$

10

Mount # 2

604

 $\frac{604}{10} = 0.4 = 5.2119E+01 \text{ uCi/L alpha}$

10

F 60.-6220

18/2

46
10

-.4

Alpha Calculation by AJ on 01-08-1990 at 17:53:22
 Det #18 2-inch mount Alpha eff. : .2095
 Sample size : .25 mL Dilution : 101

Mount # 1

46

 $\frac{46}{10} = 0.4 = 3.6483E+00 \text{ uCi/L alpha}$

10

Mount # 2

57

 $\frac{57}{10} = 0.4 = 4.6038E+00 \text{ uCi/L alpha}$

10

F 59.-6120

9 1 1 2 3 3 7 0 9 7 8

Total Alpha Analysis on the Fusion Dissolution

Serial No. F 737.-6520	Sample Point SEGMENT-J		Date 12-11-89	Time Issued 9: 4	Priority 26
Determination AT	Method/Standard LA-548-101	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ?	10ml		Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE <u>LMCS ID 83B44</u> 1.118^{-2} 1.0001^{-2} 11.870 RL					
Analyst -1 <u>6A543</u> Date 1-8-90	Analyst -2 Hrs	Analyst -3 Hrs	Analyst -4 Hrs	Analyst -5 Hrs	
Time Completed <u>O. Hopkins</u> Lab Unit Mgr <u>C. H. C.</u>					

54-600-061 (R-10-82)

Serial No. F 72.-6320	Sample Point SEGMENT-21		Date 11-15-89	Time Issued 10:21	Priority 18
Determination AT	Method/Standard LA-548-101	Result Units uCi/L	Charge Code WB75L	Reruns 0	
Sample Size ?			Customer ID		
Remarks, Calculations, Results: REAGENT BLANK $<1.29^{-2}$ <u>meif</u>					
Analyst -1 <u>6A543</u> Date 1-8-90	Analyst -2 Hrs	Analyst -3 Hrs	Analyst -4 Hrs	Analyst -5 Hrs	
Time Completed <u>O. Hopkins</u> Lab Unit Mgr <u>C. H. C.</u> <u>RL/SP</u>					

54-600-061 (R-10-82)

9 1 1 2 1 6 7 0 3 7 9

Total Alpha Analysis on the Fusion Dissolution

18/2

$$\frac{500}{10} - .4$$

Alpha Calculation by A3 on 01-08-1990 at 19:31:27
Det #18 2-inch mount Alpha eff. : .2095
Sample size : 10 mL Dilution : 1

Mount #1

$$\frac{548}{10} - .4 \frac{500}{10} - 0.4 = 1.0665E-02 \mu\text{Ci/L alpha}$$

Mount #2

$$\frac{546}{10} - 0.4 = 1.1697E-02 \mu\text{Ci/L alpha}$$

F 737,-6520

18/2

$$\frac{1}{10}$$

Alpha Calculation by EMS on 01-08-1990 at 15:18:42
Det #18 2-inch mount Alpha eff. : .2095
Sample size : 1 mL Dilution : 1

Mount #1

$$\cancel{\frac{6}{10}} \frac{1}{10} - 0.3 < 8.6772E-07 \mu\text{Ci/mL alpha}$$

Mount #2

$$\cancel{\frac{6}{10}} \frac{1}{10} - 0.3 < 1.7093E-06 \mu\text{Ci/mL alpha}$$

F 72,-6320

9 1 1 2 2 7 7 0 3 1 0

Total Beta Analysis on the Fusion Dissolution

Serial No. F 58.-6025	Sample Point SEGMENT-7		Date 11-15-89	Time Issued 10:19	Priority 19
Determination TB	Method/Standard LA-548-101 <i>SAB</i>	Result Units uCi/L	Charge Code WB75L	Reruns 0	
Sample Size ?	100-10-250		Customer ID 089043		
Remarks, Calculations, Results: 3.75 ³ <i>meil</i>					
Analyst - 1 <i>6A543</i>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
Date 1-8-90	Time Completed	Lab Unit Mgr <i>CJL</i>	<i>HL</i>	<i>KF</i>	
SI-6000-061 (R-10-83)					

Serial No. F 57.-6525	Sample Point SEGMENT-6		Date 11-15-89	Time Issued 10:19	Priority 19
Determination TB	Method/Standard LA-548-101 <i>SAB</i>	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ?	100-10-10ul		Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <i>83844</i>					
Analyst - 1 <i>6A543</i>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
Date 1-8-90	Time Completed	Lab Unit Mgr <i>CJL</i>	<i>HL</i>	<i>KF</i>	
SI-6000-061 (R-10-83)					

Serial No. F 60.-6225	Sample Point SEGMENT-9		Date 11-15-89	Time Issued 10:19	Priority 19
Determination TB	Method/Standard LA-548-101 <i>SAB</i>	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ?	100-10-250		Customer ID 089043		
Remarks, Calculations, Results: SPIKE SAMPLE SPIKE ID <i>83844</i> SPIKE VOLUME <i>10ul</i>					
Analyst - 1 <i>6A543</i>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
Date 1-8-90	Time Completed	Lab Unit Mgr <i>CJL</i>	<i>HL</i>	<i>KF</i>	
SI-6000-061 (R-10-83)					

Serial No. F 59.-6125	Sample Point SEGMENT-8		Date 11-15-89	Time Issued 10:19	Priority 19
Determination TB	Method/Standard LA-548-101 <i>SAB</i>	Result Units uCi/L	Charge Code WB75L	Reruns 0	
Sample Size ?	100-10-250		Customer ID 089043		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
Analyst - 1 <i>6A543</i>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
Date 1-8-90	Time Completed	Lab Unit Mgr <i>CJL</i>	<i>HL</i>	<i>KF</i>	
SI-6000-061 (R-10-83)					

Total Beta Analysis on the Fusion Dissolution

9 1 1 2 7 5 7 0 3 4 1	
<u>18/2</u> <u>65709</u> <u>10</u> - 6	<u>DF 101</u> <u>55,250</u> <u>18/2</u> <u>9836</u> <u>10</u> <u>Beta Calculation by AJ on 01-08-1990 at 17:54:20</u> <u>Set #18 2-inch mount Beta eff. : .3151</u> <u>Sample size : .25 mL Dilution : 101</u> <u>Mount # 1</u> <u>65709</u> <u>10</u> <u>-----</u> <u>- 6.0 = 3.7915E+03 uCi/L beta</u> <u>Mount # 2</u> <u>64313</u> <u>10</u> <u>-----</u> <u>- 6.0 = 3.7108E+03 uCi/L beta</u> <u>F 58.-6025</u>
<u>64313</u> <u>10</u>	<u>9585</u> <u>10</u> <u>-----</u> <u>- 6.0 = 1.3975E-01 uCi/L beta</u> <u>Mount # 2</u> <u>9565</u> <u>10</u> <u>-----</u> <u>- 6.0 = 1.3618E-01 uCi/L beta</u> <u>F 57.-6625</u>
<u>18/2</u> <u>78046</u> <u>10</u> - 6	<u>DF 101</u> <u>55,250</u> <u>18/2</u> <u>46360</u> <u>10</u> - 6
<u>78164</u> <u>10</u>	<u>Beta Calculation by AJ on 01-08-1990 at 17:52:30</u> <u>Set #18 2-inch mount Beta eff. : .3151</u> <u>Sample size : .25 mL Dilution : 101</u> <u>Mount # 1</u> <u>78046</u> <u>10</u> <u>-----</u> <u>- 6.0 = 4.5040E+03 uCi/L beta</u> <u>Mount # 2</u> <u>78164</u> <u>10</u> <u>-----</u> <u>- 6.0 = 4.5108E+03 uCi/L beta</u> <u>F 60.-6225</u>
	<u>46445</u> <u>10</u> <u>-----</u> <u>- 6.0 = 2.6740E+03 uCi/L beta</u> <u>Mount # 2</u> <u>46445</u> <u>10</u> <u>-----</u> <u>- 6.0 = 2.6789E+03 uCi/L beta</u> <u>F 59.-6125</u>

9 1 1 2 2 3 2 0 3 4 2

Total Beta Analysis on the Fusion Dissolution

<i>182</i>				
Serial No. F 737.-6525	Sample Point SEGMENT-J	Date 12-11-89	Time Issued 9: 4	Priority 26
Determination TB	Method/Standard LA-549-101	Result Units % RECOVERY	Charge Code WB75L	Reruns 0
Sample Size ? <i>10 ml</i>	Customer ID			
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <i>833847</i>				
1.406^{-1} / 1.3913^{-1} <i>101.100</i>				
Analyst -1 <i>6A543</i>	Analyst -2 Hrs	Analyst -3 Hrs	Analyst -4 Hrs	Analyst -5 Hrs
<i>J. Hopkins</i>				
Date <i>1-8-90</i>	Time Completed	Lab Unit Mgr <i>C. J. S.</i>		
SA-6000-061 (R-10-83)				

Serial No. F 72.-6325	Sample Point SEGMENT-21	Date 11-15-89	Time Issued 10:21	Priority 18
Determination TB	Method/Standard LA-549-101	Result Units uCi/L	Charge Code WB75L	Reruns 0
Sample Size ? <i>10 ml</i>	Customer ID 089043			
Remarks, Calculations, Results: REAGENT BLANK				
<i><3.50</i> - <i>A</i> <i>meq/l</i>				
Analyst -1 <i>6A543</i>	Analyst -2 Hrs	Analyst -3 Hrs	Analyst -4 Hrs	Analyst -5 Hrs
<i>J. Hopkins</i>				
Date <i>1-8-90</i>	Time Completed	Lab Unit Mgr <i>C. J. S.</i>		
SA-6000-061 (R-10-83)				

9 1 1 2 5 3 7 0 8 1 3

Total Beta Analysis on the Fusion Dissolution

18/2

9853
10 - 6

Beta Calculation by AJ on 01-08-1990 at 19:31:25
Det #18 2-inch count Beta eff.: .3151
Sample size: 10 uL Dilution: 1

Mount # 1

9930
10 - 6

9853
----- - 6.0 = 1.4000E-01 uCi/L Beta
10

Mount # 2

9930
----- - 6.0 = 1.4110E-01 uCi/L Beta
10

F 737.-6525

10ml 18/2

72
10

~~Beta Calculation by EM8 on 01-08-1990 at 15:18:40~~
Det #18 2-inch count Beta eff.: .3151
Sample size: 1 ea Dilution: 1

Mount # 1

51
----- - 6.0 < 4.4255E-06 uCi/ea beta
10
100

Mount # 2

51
----- - 6.0 < 2.5801E-06 uCi/ea beta
10
100

F 72.-6325

9 1 1 2 7 5 3 0 9 1 4

Gamma Energy Analysis of the Fusion Dissolution

<i>2750</i>				
Serial No. F 58.-6030	Sample Point SEGMENT-7	Date 11-15-89	Time Issued 10:19	Priority 19
Determination GEA	Method/Standard LA-548-121	Result Units uCi/L	Charge Code WB75L	Returns 0
Sample Size ? <i>500</i>	Customer ID <i>089043</i>			
Remarks, Calculations, Results: <i>Cs¹³⁷ 6.98 mCi/l or 3.09 mCi/g</i>				
Analyst-1 <i>6 B598/PA</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>gmc</i>
Date 1-10-90	Time Completed	Lab Unit Mgr <i>Chap</i>	GMS	
54-6000-081 (R-10-63)				
<i>1010</i>				
Serial No. F 57.-6530	Sample Point SEGMENT-6	Date 11-15-89	Time Issued 10:19	Priority 19
Determination GEA	Method/Standard LA-548-121	Result Units % RECOVERY	Charge Code WB75L	Returns 0
Sample Size ? <i>500</i>	Customer ID			
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <i>82044</i> <i>Cs¹³⁷ 2.28 mCi/g / 2.247% 102.50%</i>				
Analyst-1 <i>6 B598/PA</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>gmc</i>
Date 1-10-90	Time Completed	Lab Unit Mgr <i>Chap</i>	GMS	
54-6000-081 (R-10-63)				
<i>2754</i>				
Serial No. F 736.-6230	Sample Point SEGMENT-1	Date 12-11-89	Time Issued 9: 3	Priority 26
Determination GEA	Method/Standard LA-548-121	Result Units % RECOVERY	Charge Code WB75L	Returns 0
Sample Size ? <i>500</i>	Customer ID <i>089083</i>			
Remarks, Calculations, Results: SPIKE SAMPLE <i>F178</i> SPIKE ID <i>82044</i> SPIKE VOLUME <i>500</i> <i>Cs¹³⁷ 1.12 - 7.10 = 4.10 / 383 107.50%</i>				
Analyst-1 <i>6 B598/PA</i>	Analyst-2 Hrs	Analyst-3 <i>Jill M. Bal 510/90</i>	Analyst-4 Hrs	Analyst-5 <i>gmc</i>
Date 1-10-90	Time Completed	Lab Unit Mgr <i>Chap</i>	GMS	
54-6000-081 (R-10-63)				
<i>3889</i>				
Serial No. F 59.-6130	Sample Point SEGMENT-8	Date 11-15-89	Time Issued 10:19	Priority 19
Determination GEA	Method/Standard LA-548-121	Result Units uCi/L	Charge Code WB75L	Returns 0
Sample Size ? <i>500</i>	Customer ID <i>089043</i>			
Remarks, Calculations, Results: DUPLICATE SAMPLE <i>Cs¹³⁷ 6.21 mCi/l or 3.70 mCi/g</i>				
Analyst-1 <i>6 B598/PA</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 <i>gmc</i>
Date 1-10-90	Time Completed	Lab Unit Mgr <i>Chap</i>	GMS	
54-6000-081 (R-10-63)				

9 1 1 2 1 3 7 0 8 1 5

Gamma Energy Analysis of the Fusion Dissolution

3893				
Serial No.	Sample Point	Date	Time Issued	Priority
F 748.-6330	SEGMENT-U	12-11-89	9: 5	26
Determination	Method/Standard	Result Units	Charge Code	Reruns
GEA	LA-548-121	uCi/L	WB75L	0
Sample Size	Customer ID			
? 1mL				
Remarks, Calculations, Results:				
REAGENT BLANK -1 Cs ¹³⁷ 1.71 ⁻¹ uCi/L <3.5 ⁻¹ uCi/L				
Analyst -1 6.8598/101	Analyst -2	Analyst -3	Analyst -4	Analyst -5
Hrs	Hrs	Hrs	Hrs	Hrs
Date 1-10-90	Time Completed	Lab Unit Mgr <i>CJF</i>	GMS	
SA-6400-061 (R-10-83)				

1015				
Serial No.	Sample Point	Date	Time Issued	Priority
F 737.-6530	SEGMENT-J	12-11-89	9: 4	26
Determination	Method/Standard	Result Units	Charge Code	Reruns
GEA	LA-548-121	% RECOVERY	WB75L	0
Sample Size	Customer ID			
? Soon				
Remarks, Calculations, Results:				
LMCS CHECK SAMPLE LMCS ID <u>89844</u>				
Cs ⁶⁰ 2.30 ⁻¹ uCi/L / 2.225 ⁻¹ 103.40%				
Cs ¹³⁷ 3.73 ⁻¹ uCi/L / 3.8188 ⁻¹ 97.8%				
Analyst -1 6.8598/101	Analyst -2	Analyst -3	Analyst -4	Analyst -5 CJF
Hrs	Hrs	Hrs	Hrs	Hrs
Date 1-10-90	Time Completed	Lab Unit Mgr <i>CJF</i>	GMS	
SA-6400-061 (R-10-83)				

9 1 1 2 3 7 0 9 1 6

Uranium Analysis of the Fusion Dissolution

Serial No. F 58.-6040	Sample Point SEGMENT-7		Date 11-15-89	Time Issued 10:19	Priority 23
Determination U	Method/Standard LA-925-106	Result Units G/L	Charge Code WB75L	Reurn 0	
Sample Size ? 100-10-100			Customer ID 089043		
Remarks, Calculations, Results:					
$\begin{array}{l} \text{Sample: .18} \\ \text{Spk. Vol: 100} \\ \text{Spk. ID: } 5.62^{-4} \\ \text{Spk. Vol: } 100 \times (18)(5.62^{-4})(.1)(10) = 3.19 \text{ g/l} \\ \text{Spk. ID: } 5.62^{-4} \end{array}$					
Analyst -1 <i>LC269</i>	Analyst -2 <i>Moore</i>	Analyst -3 <i>Grady</i>	Analyst -4 <i>Claire</i>	Analyst -5 <i>g/m</i>	Hrs <i>00</i>
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Claire</i>			
54-6000-061 (R-10-83)					

Serial No. F 57.-6540	Sample Point SEGMENT-6		Date 11-15-89	Time Issued 10:19	Priority 23
Determination U	Method/Standard LA-925-106	Result Units % RECOVERY	Charge Code WB75L	Reurn 0	
Sample Size ? 100-10-100			Customer ID		
Remarks, Calculations, Results:					
$\begin{array}{l} \text{LMCS CHECK SAMPLE} \\ \text{LMCS ID: } 58938 \\ \text{94.9\% Std: .24 g/l} \\ \text{Std Spk: .72} \\ \text{Spk Vol: 100} \\ \text{Spk ID: } 5.62^{-4} \\ \text{Spk Vol: } 100 \times (.24)(5.62^{-4})(.1)(10) = 2.83 \text{ g/l} \\ \text{Spk ID: } 5.62^{-4} \end{array}$					
Analyst -1 <i>LC269</i>	Analyst -2 <i>Moore</i>	Analyst -3 <i>Grady</i>	Analyst -4 <i>Claire</i>	Analyst -5 <i>g/m</i>	Hrs <i>00</i>
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Claire</i>			
54-6000-061 (R-10-83)					

Serial No. F 60.-6240	Sample Point SEGMENT-9		Date 11-15-89	Time Issued 10:19	Priority 23
Determination U	Method/Standard LA-925-106	Result Units % RECOVERY	Charge Code WB75L	Reurn 0	
Sample Size ? 100-10-100			Customer ID 089043		
Remarks, Calculations, Results:					
$\begin{array}{l} \text{SPIKE SAMPLE} \\ \text{SPIKE ID: } 58938 \\ \text{SPIKE VOLUME: } 100-10-100 \text{ no recovery} \\ \text{Sample: .18} \\ \text{Spk Vol: 100} \\ \text{Spk ID: } 5.62^{-4} \\ \text{Spk Vol: } 100 \times (18)(5.62^{-4})(.1)(10) = 3.19 \text{ g/l} \\ \text{Spk Vol: } 100 \times .18 = .18 \text{ g/l} \\ \text{Spk ID: } 5.62^{-4} \end{array}$					
Analyst -1 <i>LC269</i>	Analyst -2 <i>Moore</i>	Analyst -3 <i>Grady</i>	Analyst -4 <i>Claire</i>	Analyst -5 <i>g/m</i>	Hrs <i>00</i>
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Claire</i>			
54-6000-061 (R-10-83)					

Serial No. F 59.-6140	Sample Point SEGMENT-8		Date 11-15-89	Time Issued 10:19	Priority 23
Determination U	Method/Standard LA-925-106	Result Units G/L	Charge Code WB75L	Reurn 0	
Sample Size ? 100-10-100			Customer ID 089043		
Remarks, Calculations, Results:					
$\begin{array}{l} \text{DUPLICATE SAMPLE} \\ \text{Sample: .14} \\ \text{Spk Vol: 100} \\ \text{Spk ID: } 5.62^{-4} \\ \text{Spk Vol: } 100 \times (.14)(5.62^{-4})(.1)(10) = 2.48 \text{ g/l} \\ \text{Spk ID: } 5.62^{-4} \end{array}$					
Analyst -1 <i>LC269</i>	Analyst -2 <i>Moore</i>	Analyst -3 <i>Grady</i>	Analyst -4 <i>Claire</i>	Analyst -5 <i>g/m</i>	Hrs <i>00</i>
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Claire</i>			
54-6000-061 (R-10-83)					

9 1 1 2 7 6 7 0 3 1 7

Uranium Analysis of the Fusion Dissolution

Serial No. F 748.-6340	Sample Point SEGMENT-U	Date 12-11-89	Time Issued 9: 5	Priority 26
Determination U	Method/Standard LA-925-106	Result Units G/L	Charge Code WB75L	Retuns 0
Sample Size ? 100-10-100		Customer ID		
Remarks, Calculations, Results REAGENT BLANK Blk : .04				
$\text{Spk Vol: } 100\text{A} \quad \text{Blk + Spk: } 24$ $\text{Spk ID: } 5.113^{-5} \cdot (04) \cdot (5.113^{-5}) \cdot (1) \cdot (1010) \cdot 3 = 1.03 \text{ g/l}$ $\cdot 24 - 0.04$				
Analyst - 1 <i>GC269</i>	Analyst - 2 <i>CMony</i>	Analyst - 3 <i>Sherry</i>	Analyst - 4 <i>Chm</i>	Analyst - 5 <i>SPK</i>
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Chm</i>	Signature	
54-6800-061 (R-10-83)				

Serial No. F 737.-6540	Sample Point SEGMENT-J	Date 12-11-89	Time Issued 9: 4	Priority 26
Determination U	Method/Standard LA-925-106	Result Units % RECOVERY	Charge Code WB75L	Retuns 0
Sample Size ? 100-10-100		Customer ID		
Remarks, Calculations, Results LMCS CHECK SAMPLE LMCS ID <i>58638</i>				
$\text{Std: } .18 \quad \text{#}$ $\text{Spk Vol: } 100\text{A} \quad \text{Std + Spk: } .48$ $\text{Spk ID: } 5.62^{-4} \cdot (18) \cdot (5.62^{-4}) \cdot (1) \cdot (1010) = 3400^{-2}$ $.48 - .18$ $113.9\% \quad 2.99$				
Analyst - 1 <i>GC269</i>	Analyst - 2 <i>CMony</i>	Analyst - 3 <i>Sherry</i>	Analyst - 4 <i>Chm</i>	Analyst - 5 <i>SPK</i>
Date 1-8-90	Time Completed	Lab Unit Mgr <i>Chm</i>	Signature	
54-6800-061 (R-10-83)				

Water Digestion

9 1 1 2 3 5 7 0 3 4 3

Serial No. F 64.-7100	Sample Point SEGMENT-13		Date 11-15-89	Time Issued 10:20	Priority 19
Determination H ₂ O-DGST	Method/Standard LA-504-101	Result Units G/L	Charge Code WB75L	Run No. 0	
Sample Size ?		Customer ID 089043			
Remarks, Calculations, Results: DUPLICATE ANALYSIS GRAMS SAMPLE .317g VOLUME ON COMPLETION 50ml 1.036⁻² g/ml 1.036⁻⁵ g/l 10.49/L					
Analyst - 1 81098	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
20 min					
Date 1/5/90	Time Completed	Lab Unit/Mgr <i>CJW</i>			
54-5800-061 (R-10-83)					

Serial No. F 63.-7000	Sample Point SEGMENT-12		Date 11-15-89	Time Issued 10:20	Priority 19
Determination H ₂ O-DGST	Method/Standard LA-504-101	Result Units G/L	Charge Code WB75L	Run No. 0	
Sample Size ?		Customer ID 089043			
Remarks, Calculations, Results: GRAMS SAMPLE .5035g #243 VOLUME ON COMPLETION 50ml 1.007⁻³ g/ml 1.007⁻⁵ g/l 10.19/L					
Analyst - 1 81098	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
20 min					
Date 1/5/90	Time Completed	Lab Unit/Mgr <i>CJW</i>			
54-5800-061 (R-10-83)					

Serial No. F 74.-7300	Sample Point SEGMENT-23		Date 11-15-89	Time Issued 10:21	Priority 18
Determination H ₂ O-DGST	Method/Standard LA-504-101	Result Units G/L	Charge Code WB75L	Run No. 0	
Sample Size ?		Customer ID 089043			
Remarks, Calculations, Results: REAGENT BLANK <i>Complete</i>					
Analyst - 1 81098	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
10 min					
Date 1/5/90	Time Completed	Lab Unit/Mgr <i>CJW</i>			
54-5800-061 (R-10-83)					

Serial No. F 65.-7200	Sample Point SEGMENT-14		Date 11-15-89	Time Issued 10:20	Priority 19
Determination H ₂ O-DGST	Method/Standard LA-504-101	Result Units % RECOVERY	Charge Code WB75L	Run No. 0	
Sample Size ?		Customer ID 089043			
Remarks, Calculations, Results: SPiked ANALYSIS GRAMS SAMPLE .5276g VOLUME ON COMPLETION 50ml VOLUME SPIKE 50ml SPIKE ID _____ 1.055⁻² g/ml 1.055⁻⁵ g/l 10.19/L					
Analyst - 1 81098	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	
20 min					
Date 1/5/90	Time Completed	Lab Unit/Mgr <i>CJW</i>			
54-5800-061 (R-10-83)					

9 1 1 2 2 5 7 0 8 1 9

Water Digestion

** JET_LT ** REV B **

SEQUENCE #: 88
WT 1: 97.6430
WT 2: 96.1699

NET WEIGHT:

---> 0.5179 GRAMS

01/05/90 @ 10:59:43

SEQUENCE #: 87
WT 1: 98.0563
WT 2: 96.5598

NET WEIGHT:

---> 0.5035 GRAMS

01/05/90 @ 10:53:38

F 63.-7000

F 64.-7100

** JET_LT ** REV B **

SEQUENCE #: 89
WT 1: 97.9591
WT 2: 98.4867

NET WEIGHT:

---> 0.5276 GRAMS

01/05/90 @ 11:05:10

F 65.-7200

F 74.-7300

9 1 1 2 7 6 0 0 2 - 0

Ion Chromatographic Analysis of the Water Digestion - Fluoride Analysis

Serial No F 64.-7171	Sample Point SEGMENT-13		Date 11-15-89	Time Issued 10:20	Priority 19
Determination F	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results DUPLICATE SAMPLE					
$\sim 10.1 \text{ ppm}$					
Analyst - 1 6B107/kew	Analyst - 2 Hrs .5	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	Analyst - 6 Hrs
Date 2/16/90	Time Completed	Lab Unit Mgr CJW			
54-6800-061 (R-10-83)					

Serial No F 113.-7271	Sample Point SEGMENT-14		Date 11-15-89	Time Issued 10:57	Priority 19
Determination F	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 100 μL = 10 ml			Customer ID 89-045		
Remarks, Calculations, Results SPIKE SAMPLE SPIKE ID 35C9-67 SPIKE VOLUME .300 / 5 mL					
$\frac{(5.3 \text{ mL})}{(5.3 \text{ mL})} \times 100 = 100$ $\frac{(181.9 \text{ ppm})}{(10.6 \text{ ppm})} \times 100 = 96.3\%$ $\frac{(.300 \text{ mL}) \times 17 \text{ ppm}}{5.3 \text{ mL}} \times 100 = 101$					
Analyst - 1 6B107	Analyst - 2 Hrs .5	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	Analyst - 6 Hrs
Date 2/15/90	Time Completed	Lab Unit Mgr CJW			
54-6800-061 (R-10-83)					

Serial No F 66.-7571	Sample Point SEGMENT-15		Date 11-15-89	Time Issued 10:21	Priority 19
Determination F	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size 100-10			Customer ID		
Remarks, Calculations, Results LMCS CHECK SAMPLE LMCS ID 6C11H2					
$\sim 10.1 \text{ ppm}$					
Analyst - 1 6B107/kew	Analyst - 2 Hrs .5	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	Analyst - 6 Hrs
Date 2/15/90	Time Completed	Lab Unit Mgr CJW			
54-6800-061 (R-10-83)					

Serial No F 63.-7071	Sample Point SEGMENT-12		Date 11-15-89	Time Issued 10:20	Priority 19
Determination F	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results					
$\sim 10.1 \text{ ppm}$					
Analyst - 1 6B107/kew	Analyst - 2 Hrs .5	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs	Analyst - 6 Hrs
Date 2/16/90	Time Completed	Lab Unit Mgr CJW			
54-6800-061 (R-10-83)					

9 1 1 2 3 5 7 9 9 7 1

Ion Chromatographic Analysis of the Water Digestion - Fluoride Analysis

Serial No F 122.-7371		Sample Point SEGMENT-23		Date 11-15-89	Time Issued 10:58	Priority 18
Determination F	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0		
Sample Size ? 100-10 Direct		Customer ID 089045				
Remarks, Calculations, Results: REAGENT BLANK						
$\sim 1 \text{ ppm}$						
Analyst - 1 <i>6B107/NEW</i>	Analyst - 2	Analyst - 3	Analyst - 4	Chemist <i>OPX0417</i>		
Hrs .5	Hrs	Hrs	Hrs	Hrs		
Date 2/15/90	Time Completed	Lab Unit Mgr <i>CGK</i>	Lab Unit Mgr <i>CGK</i>	Lab Unit Mgr		
54-4600-061 (R-10-83)						

Serial No F 110.-7571		Sample Point SEGMENT-11		Date 11-15-89	Time Issued 10:56	Priority 19
Determination F	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0		
Sample Size 100-10		Customer ID <i>CGK/HIE</i>		Customer ID 089045		
Remarks, Calculations, Results LMCS CHECK SAMPLE LMCS ID <u>6C1181</u>						
67.04						
$(\frac{67}{72}) \times 100 = 93.1\%$						
Analyst - 1 <i>6B107/NEW</i>	Analyst - 2	Analyst - 3	Analyst - 4	Chemist <i>OPX0417</i>		
Hrs .5	Hrs	Hrs	Hrs	Hrs		
Date 2/15/90	Time Completed	Lab Unit Mgr <i>CGK</i>	Lab Unit Mgr <i>CGK</i>	Lab Unit Mgr		
54-4600-061 (R-10-83)						

9 1 1 2 7 3 0 0 3 5 2

Ion Chromatographic Analysis of the Water Digestion - Chloride Analysis

Serial No. F 64.-7172	Sample Point SEGMENT-13		Date 11-15-89	Time Issued 10:20	Priority 19
Determination CL	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Retruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
$\sim 10.1 \text{ ppm}$					
Analyst-1 <i>6B107/nw</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date <i>2/14/90</i>	Time Completed	Lab Unit Mgr <i>Chp</i>	<i>585</i>		
54-0000-061 (R-10-83)					

Serial No. F 113.-7272	Sample Point SEGMENT-14		Date 11-15-89	Time Issued 10:57	Priority 19
Determination CL	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Retruns 0	
Sample Size ? 100 μl - 10 mL			Customer ID 89-045		
Remarks, Calculations, Results: SPIKE SAMPLE SPIKE ID 35C9-67 SPIKE VOLUME .300 / 5mL					
$\frac{(1.06)(347) - (0)(.948)}{(300)(60)} \times 100 = 107.2\%$					
Analyst-1 <i>6B107</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date <i>2/15/90</i>	Time Completed	Lab Unit Mgr <i>Chp</i>	<i>585</i>		
54-0000-061 (R-10-83)					

Serial No. F 66.-7572	Sample Point SEGMENT-15		Date 11-15-89	Time Issued 10:21	Priority 19
Determination CL	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Retruns 0	
Sample Size 100-10			Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 6C1115					
$\frac{(33.8)}{87} 100 = 96.3\%$ <i>AM 5</i>					
Analyst-1 <i>6B107/nw</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date <i>2/15/90</i>	Time Completed	Lab Unit Mgr <i>Chp</i>	<i>585</i>		
54-0000-061 (R-10-83)					

Serial No. F 63.-7072	Sample Point SEGMENT-12		Date 11-15-89	Time Issued 10:20	Priority 19
Determination CL	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Retruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results:					
$\sim 1.64 \text{ ppm}$					
Analyst-1 <i>6B107/nw</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date <i>2/16/80</i>	Time Completed	Lab Unit Mgr <i>Chp</i>	<i>585</i>		
54-0000-061 (R-10-83)					

9 1 1 2 7 1 7 0 3 7 3

Ion Chromatographic Analysis of the Water Digestion - Chloride Analysis

Serial No. F 122.-7372	Sample Point SEGMENT-23		Date 11-15-89	Time Issued 10:58	Priority 18
Determination CL	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size <i>? Direct</i>			Customer ID 089045		
Remarks, Calculations, Results: REAGENT BLANK					
<i>2.1 ppm</i> <i>, 15 ppm</i>					
Analyst-1 <i>60107/HW</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5 <i>60107/HW</i>	Element
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 2/15/90	Time Completed	Lab Unit Mgr.	<i>copy</i>	<i>copy</i>	
54-5800-061 (R-10-83)					

Serial No. F 110.-7572	Sample Point SEGMENT-11		Date 11-15-89	Time Issued 10:56	Priority 19
Determination CL	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size 100-10			Customer ID 089045		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 6C11R1					
<i>97.0 % + HLR</i> <i>(85.2 -) / 100 = 97.9</i> <i>2/15/90</i>					
Analyst-1 <i>60107/HW</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5 <i>60107/HW</i>	Element
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 2/15/90	Time Completed	Lab Unit Mgr.	<i>copy</i>	<i>copy</i>	
54-5800-061 (R-10-83)					

9 1 1 2 7 5 0 9 7 4

Ion Chromatographic Analysis of the Water Digestion - Nitrate Analysis

Serial No F 64.-7173	Sample Point SEGMENT-13		Date 11-15-89	Time Issued 10:20	Priority 19
Determination NOS	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results DUPLICATE SAMPLE					
4.67°ppm					
Analyst-1 68107/kew	Analyst-2 Hrs .5	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 Signature	
Date 2/16/90	Time Completed	Lab Unit Mgr CJW	Lab Unit Mgr KEL		
2/15/90 I.C.					
54-5800-061 (R-10-83)					

Serial No F 66.-7573	Sample Point SEGMENT-15		Date 11-15-89	Time Issued 10:21	Priority 19
Determination NOS	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size 100-10			Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <u>EC11/H1</u>					
$(\frac{75.3}{722})100 = 105.3\%$ 9m.s					
Analyst-1 68107/kew	Analyst-2 Hrs .5	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 Signature	
Date 2/15/90	Time Completed	Lab Unit Mgr CJW	Lab Unit Mgr KEL		
54-5800-061 (R-10-83)					

Serial No F 113.-7273	Sample Point SEGMENT-14		Date 11-15-89	Time Issued 10:57	Priority 19
Determination NOS	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10 ml			Customer ID 89-145		
Remarks, Calculations, Results SPIKE SAMPLE SPIKE ID 35C9-67 SPIKE VOLUME 1300/5ML					
$\frac{(1.06)(2951) - (270.3)(.948)}{(1.300)(481)} \times 100 = 104.4\%$ 5.3					
Analyst-1 68107	Analyst-2 Hrs .5	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 Signature	
Date 2-15-90	Time Completed	Lab Unit Mgr CJW	Lab Unit Mgr KEL	Signature	
54-5800-061 (R-10-83)					

Serial No F 63.-7073	Sample Point SEGMENT-12		Date 11-15-89	Time Issued 10:20	Priority 19
Determination NOS	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results					
5.51°ppm					
Analyst-1 68107/kew	Analyst-2 Hrs .5	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 Signature	
Date 2/16/90	Time Completed	Lab Unit Mgr CJW	Lab Unit Mgr KEL		
54-5800-061 (R-10-83)					

9 1 1 2 2 1 7 0 3 5 5

Ion Chromatographic Analysis of the Water Digestion - Nitrate Analysis

Serial No F 122.-7373 Sample Point SEGMENT-23 Date 11-15-89 Time Issued 10:58 Priority 18 Determination NOS Method/Standard LA-533-105 Result Units PPM Charge Code WB75L Reruns 0 Sample Size ? Direct Customer ID 089045 Remarks, Calculations, Results: REAGENT BLANK <i><1 ppm</i>				
Analyst-1 68107/nec Analyst-2 Analyst-3 Analyst-4 <i>(Signature)</i> Hrs .5 Hrs Hrs Hrs Hrs Date 2/15/80 Time Completed <i>CJA</i> Lab Unit Mgr <i>SX</i> <small>SA-6800-081 (R-10-82)</small>				
Serial No F 110.-7573 Sample Point SEGMENT-11 Date 11-15-89 Time Issued 10:56 Priority 19 Determination NOS Method/Standard LA-533-105 Result Units % RECOVERY Charge Code WB75L Reruns 0 Sample Size 100-10 Customer ID 089045 Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <u>6C11A</u> <i>Rm 8</i> $\left(\frac{710}{722}\right) \times 100 = 98.3\%$				
Analyst-1 68107/nec Analyst-2 Analyst-3 Analyst-4 <i>(Signature)</i> Hrs .5 Hrs Hrs Hrs Hrs Date 2/15/80 Time Completed <i>CJA</i> Lab Unit Mgr <i>SX</i> <small>SA-6800-081 (R-10-82)</small>				

9 1 1 2 0 6 7 0 9 5 6

Ion Chromatographic Analysis of the Water Digestion - Sulphate Analysis

Serial No F 64.-7175						Sample Point SEGMENT-13		Date 11-15-89		Time Issued 10:20		Priority 19	
Determination SO4		Method/Standard LA-533-105		Result Units PPM		Charge Code WB75L		Reruns 0					
Sample Size ? 100-10						Customer ID 089043							
Remarks, Calculations, Results: DUPLICATE SAMPLE													
$\sim 101 \text{ ppm}$													
Analyst-1 <i>63107/rew</i>		Analyst-2 Hrs .5		Analyst-3 Hrs		Analyst-4 Hrs		Analyst-5 <i>63107/rew</i> Hrs					
Date <i>2/14/90</i>		Time Completed		Lab Unit Mgr <i>CJW</i>									
54-8800-061 (R-10-83)													
Serial No F 66.-7575						Sample Point SEGMENT-15		Date 11-15-89		Time Issued 10:21		Priority 19	
Determination SO4		Method/Standard LA-533-105		Result Units % RECOVERY		Charge Code WB75L		Reruns 0					
Sample Size 100-10						Customer ID							
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <i>401171</i>													
$(\frac{741}{747}) 100 = 98.9\%$ <i>ppm</i>													
Analyst-1 <i>63107/rew</i>		Analyst-2 Hrs .5		Analyst-3 Hrs		Analyst-4 Hrs		Analyst-5 <i>63107/rew</i> Hrs					
Date <i>2/15/90</i>		Time Completed		Lab Unit Mgr <i>CJW</i>									
54-8800-061 (R-10-83)													
Serial No F 63.-7075						Sample Point SEGMENT-12		Date 11-15-89		Time Issued 10:20		Priority 19	
Determination SO4		Method/Standard LA-533-105		Result Units PPM		Charge Code WB75L		Reruns 0					
Sample Size ? 100-10						Customer ID 089043							
Remarks, Calculations, Results:													
$\sim 101 \text{ ppm}$													
Analyst-1 <i>63107/rew</i>		Analyst-2 Hrs		Analyst-3 Hrs		Analyst-4 Hrs		Analyst-5 <i>63107/rew</i> Hrs					
Date <i>2/14/90</i>		Time Completed		Lab Unit Mgr <i>CJW</i>									
54-8800-061 (R-10-83)													

9 1 1 2 0 6 7 0 9 7 7

Ion Chromatographic Analysis of the Water Digestion - Sulphate Analysis

Serial No. F 110.-7575	Sample Point SEGMENT-11	Date 11-15-89	Time Issued 10:56	Priority 19
Determination SO4	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Returns 0
Sample Size 100-10	Customer ID 089045			
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <u>10C1H1</u> $\frac{6.96}{7.49} \times 100 = 92.9\% \text{ PMS}$				
Analyst - 1 <u>60107/reu</u>	Analyst - 2	Analyst - 3	Analyst - 4 <u>60107/reu</u>	Analyst - 5 <u>60107/reu</u>
.5 Hrs	Hrs	Hrs	Hrs	Hrs
Date <u>2/15/90</u>	Time Completed	Lab Unit Mgr <u>CJW</u>	Sig <u>588</u>	
SA-8800-041 (R-10-83)				

Serial No. F 122.-7375	Sample Point SEGMENT-23	Date 11-15-89	Time Issued 10:58	Priority 18
Determination SO4	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Returns 0
Sample Size ? Direct	Customer ID 089045			
Remarks, Calculations, Results: REAGENT BLANK $<1 \text{ ppm}$				
Analyst - 1 <u>60107/reu</u>	Analyst - 2	Analyst - 3	Analyst - 4 <u>60107/reu</u>	Analyst - 5 <u>60107/reu</u>
.5 Hrs	Hrs	Hrs	Hrs	Hrs
Date <u>2/15/90</u>	Time Completed	Lab Unit Mgr <u>CJW</u>	Sig <u>588</u>	
SA-8800-041 (R-10-83)				

9 1 1 2 3 5 7 0 8 7 3

Ion Chromatographic Analysis of the Water Digestion - Phosphate Analysis

Serial No. F 113.-7574	Sample Point SEGMENT-0		Date 11-15-89	Time Issued 10:57	Priority 26
Determination PO4	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code E2LD1	Reruns 0	
Sample Size ?			Customer ID		
Remarks, Calculations, Results LMCS CHECK SAMPLE LMCS ID <u>6CL1AT</u> <i>101.0 %</i>					
Analyst - 1 <u>6B107/REW</u>	Analyst - 2	Analyst - 3	Analyst - 4 <u>CJH/21171</u>	Analyst - 5 Chemical	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 2/22/90	Time Completed	Lab Unit Mgr <u>CJH</u>			
54-6800-061 (R-10-53)					

Serial No. F 113.-7274	Sample Point SEGMENT-14		Date 11-15-89	Time Issued 10:57	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 1	
Sample Size ? 100-10			Customer ID		
Remarks, Calculations, Results: SPIKE SAMPLE SPIKE ID <u>33C9-69</u> SPIKE VOLUME <u>.300/5 ml</u>					
RERUN					
Analyst - 1 <u>6B107/REW</u>	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 2/22/90	Time Completed	Lab Unit Mgr <u>CJH</u>	9pm		
54-6800-061 (R-10-53)					

Serial No. F 63.-7074	Sample Point SEGMENT-12		Date 11-15-89	Time Issued 10:20	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 1	
Sample Size ? 100-10			Customer ID		
Remarks, Calculations, Results RERUN <i><101 ppm</i>					
Analyst - 1 <u>6B107/REW</u>	Analyst - 2	Analyst - 3	Analyst - 4 <u>CJH/21171</u>	Analyst - 5 Chemical	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 2/22/90	Time Completed	Lab Unit Mgr <u>CJH</u>	10mS		
54-6800-061 (R-10-53)					

Serial No. F 64.-7174	Sample Point SEGMENT-13		Date 11-15-89	Time Issued 10:20	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 1	
Sample Size ? 100-10			Customer ID		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
RERUN					
Analyst - 1 <u>6B107/REW</u>	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 2/22/90	Time Completed	Lab Unit Mgr			
54-6800-061 (R-10-53)					

Ion Chromatographic Analysis of the Water Digestion - Phosphate Analysis

$$\frac{\frac{(5.3)}{5} \left(\frac{(4.738)}{(5.555)} - \frac{(1.000)}{(10.6)} \right) \left(\frac{10.000}{10.6} \right)}{\frac{(2.300)(6.01)}{5.3}} \times 100 = 103.2\%$$

F 115-7274

9 1 1 1 2 2 3 0 0 9 7 9

9 1 1 2 1 3 7 0 9 4 0

Ion Chromatographic Analysis of the Water Digestion - Phosphate Analysis

Serial No. F 110.-7574	Sample Point SEGMENT-11	Date 11-15-89	Time Issued 10:56	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0
Sample Size 100-10		Customer ID		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 73C115				
$\frac{692.2}{722.0} \times 100 = 95.9\%$				
<i>Analyst 1</i> GB107				
Analyst - 1 Hrs .5	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs
Date 2/22/80	Time Completed <i>10:00 AM</i>	Lab Unit No. <i>100</i>		
54-6000-061 (R-10-83)				

Serial No. F 122.-7374	Sample Point SEGMENT-23	Date 11-15-89	Time Issued 10:58	Priority 18
Determination PO4	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 1
Sample Size <i>? Direct</i>		Customer ID		
Remarks, Calculations, Results: REAGENT BLANK				
RERUN <i>1.1 ppm</i>				
<i>Analyst - 1</i> 103107/100				
Analyst - 1 Hrs .5	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs
Date 2/22/80	Time Completed <i>10:00 AM</i>	Lab Unit No. <i>100</i>		
54-6000-061 (R-10-83)				

9 1 1 2 2 3 0 0 3 : 1

Ion Chromatographic Analysis of the Water Digestion - Phosphate Analysis

Serial No. F 429.-7274	Sample Point SEGMENT-N		Date 11-30-89	Time Issued 8: 8	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10			Customer ID 089070		
Remarks, Calculations, Results: SPIKE SAMPLE SPIKE ID 3509-77 SPIKE VOLUME 300/5 ml					
<i>See Reverse Side</i>					
1.07 (3.452³) PP 3464.5 $\times 100 = 101.5\%$					
Analyst - 1 <i>6B107/mew</i>	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5 <i>SPK/71</i>	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 4/5/90	Time Completed	Lab Unit Mgr <i>SP</i>	<i>SP</i>	<i>SP</i>	
54-6400-061 (R-10-63)					

Serial No. F 64.-7174	Sample Point SEGMENT-13		Date 11-15-89	Time Issued 10:20	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size ? 100-10			Customer ID 089043		
Remarks, Calculations, Results: DUPLICATE SAMPLE					
$\times 101^2$ ppm					
Analyst - 1 <i>6B107/mew</i>	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5 <i>SPK/71</i>	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 3/5/90	Time Completed	Lab Unit Mgr <i>SP</i>	<i>SP</i>	<i>SP</i>	
54-6400-061 (R-10-63)					

Serial No. F 574.-7574	Sample Point SEGMENT-0		Date 12- 1-89	Time Issued 11:37	Priority 19
Determination PO4	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0	
Sample Size 100-10			Customer ID 089076		
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 6C1170					
<i>K</i> $607.9 / 599 = 101.5\%$					
Analyst - 1 <i>6B107/mew</i>	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5 <i>SPK/71</i>	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 4/5/90	Time Completed	Lab Unit Mgr <i>SP</i>	<i>SP</i>	<i>SP</i>	
54-6400-061 (R-10-63)					

Serial No. F 438.-7374	Sample Point SEGMENT-W		Date 11-30-89	Time Issued 8: 9	Priority 18
Determination PO4	Method/Standard LA-533-105	Result Units PPM	Charge Code WB75L	Reruns 0	
Sample Size ? Direct			Customer ID 089070		
Remarks, Calculations, Results: REAGENT BLANK					
<i><1 ppm</i>					
Analyst - 1 <i>6B107/mew</i>	Analyst - 2	Analyst - 3	Analyst - 4	Analyst - 5 <i>SPK/71</i>	
Hrs .5	Hrs	Hrs	Hrs	Hrs	
Date 4/5/90	Time Completed	Lab Unit Mgr <i>SP</i>	<i>SP</i>	<i>SP</i>	
54-6400-061 (R-10-63)					

Ion Chromatographic Analysis of the Water Digestion - Phosphate Analysis

$$\frac{(1.06)(5450) - 0}{1.350(606) \cdot 101} \times 100 = 105.6\%$$

5.3

Johnnetta Bell
8-23-90

F 4296-7274

9 1 1 2 1 3 0 0 9 1 2

9 1 1 2 2 6 0 0 3 4 3

Ion Chromatographic Analysis of the Water Digestion - Phosphate Analysis

Serial No. F 426.-7574	Sample Point SEGMENT-K	Date 11-30-89	Time Issued 8: 7	Priority 19
Determination P04	Method/Standard LA-533-105	Result Units % RECOVERY	Charge Code WB75L	Re runs 0
Sample Size 100-10				Customer ID C89070
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID <u>60107</u> * 603.8 / 699				
Analyst-1 <u>60107/286</u>	Analyst-2	Analyst-3	Analyst-4	Analyst-5 <u>DKB/2417</u>
Hrs 5	Hrs	Hrs	Hrs	Hrs
Date <u>4/5/90</u>	Time Completed	Lab. Ugn. Mgr <u>CP</u>		<u>OK</u>

84-5000-061 (R-10-82)

9 1 1 2 2 5 2 0 3 ; 4

Total Organic Carbon Analysis on the Water Digestion

Serial No F 62.-7526	Sample Point SEGMENT-11	Date 11-15-89	Time Issued 10:20	Priority 19
Determination TOC	Method/Standard LA-344-105	Result Units % RECOVERY	Charge Code WB75L	Reruns 0
Sample Size <u>200uL - 2ML - 200uL</u>	Customer ID			
Remarks, Calculations, Results. LMCS CHECK SAMPLE LMCS ID <u>70C11B</u>				
<p style="text-align: center;"><u>2.958</u> <u>3.000</u> <u>98.6%</u></p>				
Analyst - 1 <u>80028</u> <i>Ed Cohen</i> <u>1-11-90</u>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 <u>R.E. Scott</u> Hrs
Date 1-11-90	Time Completed	Lab Unit Mgr <i>Coy</i>	Comments <i>DM</i>	

Serial No. F 65.-7226	Sample Point SEGMENT-14	Date 11-15-89	Time Issued 10:20	Priority 19
Determination TOC	Method/Standard LA-344-105	Result Units % RECOVERY	Charge Code WB75L	Recons 0
Sample Size ? 2004L				Customer ID 089043
Remarks, Calculations, Results: SPIKE SAMPLE F63 SPIKE ID 70C1LB SPIKE VOLUME 2004L				
$\frac{185.8 - 10.9}{200} \times 100 = 87.4\%$				
Analyst - 1 20028 <i>Ed Cohn</i>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs
Date 1-11-90	Time Completed	Lab Unit Mgr <i>Cly</i>	Comments <i>JTM</i>	

Serial No. F 64.-7126	Sample Point SEGMENT-13	Date 11-15-89	Time Issued 10:20	Priority 19
Determination TOC	Method/Standard LA-344-105	Result Units G/L	Charge Code WB75L	Reruns 0
Sample Size 7 200cc	Customer # 089043			
Remarks, Calculations Results: DUPLICATE SAMPLE				
<i>2.59 -2 g/l</i>				
Analyst - 1 <i>70028</i> <i>ed Cohn</i>	Analyst - 2 Hrs	Analyst - 3 Hrs	Analyst - 4 Hrs	Analyst - 5 Hrs
Date 1-11-90	Time Completed	Lab Unit MCR <i>65</i>	Comments <i>DMs</i>	

9 1 1 2 0 3 0 0 8 : 5

Total Organic Carbon Analysis on the Water Digestion

Serial No. F 74-7326	Sample Point SEGMENT-23		Date 11-15-89	Time Issued 10:21	Priority 18
Determination TOC	Method/Standard LA-344-105	Result Units G/L	Charge Code WB75L	Retuns 0	
Sample Size 200uL					Customer ID 089043
Remarks, Calculations, Results: REAGENT BLANK					
$\frac{710 \text{ mg/min.}}{7 \text{ min.}}$ $\frac{5.320 \text{ mg}}{}$					
Analyst-1 80028 <i>Ed Cohn</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 R. Schmidt	
Date 1-11-90	Time Completed	Lab Unit Hrs <i>Ed Cohn</i>		10M 8	

54-6000-061 (R-10-83)

Serial No. F 66-7526	Sample Point SEGMENT-15		Date 11-15-89	Time Issued 10:21	Priority 19
Determination TOC	Method/Standard LA-344-105	Result Units % RECOVERY	Charge Code WB75L	Retuns 0	
Sample Size 200uL - 2 mL = 200uL					Customer ID
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 70C11B					
$\frac{2.815}{3.00} \quad 93.8\%$					
Analyst-1 80028 <i>Ed Cohn</i>	Analyst-2 Hrs	Analyst-3 Hrs	Analyst-4 Hrs	Analyst-5 R. Schmidt	
Date 1-11-90	Time Completed	Lab Unit Hrs <i>Ed Cohn</i>		10M 8	

54-6000-061 (R-10-83)

2 1 1 2 7 6 0 0 3 : 6

Acid Digestion

Serial No. F 69.-B100	Sample Point SEGMENT-18	Date 11-15-89	Time Issued 10:21	Priority 23
Determination ACD-DGST	Method/Standard LA-505-159	Result Units g/ml sp	Charge Code WB75L	Reruns 0
Sample Size ?	Customer ID 089043			
Remarks, Calculations, Results: DUPLICATE ANALYSIS GRAMS SAMPLE VOLUME ON COMPLETION 5ml 9.7⁻³ g/ml				
Analyst-1 69769	Analyst-2 Hrs K. Sotulka	Analyst-3 Hrs	Analyst-4 Hrs J. Jones	Analyst-5 Hrs
Date 1/31/90	Time Completed	Lab Unit Mgr <i>Cop</i>		

54-0000-001 (R-10-83)

Serial No. F 68.-B000	Sample Point SEGMENT-17	Date 11-15-89	Time Issued 10:21	Priority 23
Determination ACD-DGST	Method/Standard LA-505-159	Result Units g/ml sp	Charge Code WB75L	Reruns 0
Sample Size ?	Customer ID 089043			
Remarks, Calculations, Results: GRAMS SAMPLE VOLUME ON COMPLETION 5ml 1.00⁻³ g/ml W/H N 210				
Analyst-1 69769	Analyst-2 Hrs K. Sotulka	Analyst-3 Hrs	Analyst-4 Hrs J. Jones	Analyst-5 Hrs
Date 1/31/90	Time Completed	Lab Unit Mgr <i>Cop</i>		

54-0000-001 (R-10-83)

Serial No. F 75.-B300	Sample Point SEGMENT-24	Date 11-15-89	Time Issued 10:22	Priority 18
Determination ACD-DGST	Method/Standard LA-505-159	Result Units g/ml sp	Charge Code WB75L	Reruns 0
Sample Size ?	Customer ID 089043			
Remarks, Calculations, Results: REAGENT BLANK VOLUME ON COMPLETION 5ml Shots-34 C/1C0 35C11CK				
Analyst-1 69769	Analyst-2 Hrs K. Sotulka	Analyst-3 Hrs	Analyst-4 Hrs J. Jones	Analyst-5 Hrs
Date 1/31/90	Time Completed	Lab Unit Mgr <i>Cop</i>		

54-0000-001 (R-10-83)

9 1 1 2 1 6 9 0 8 6 7

Acid Digestion

Serial No. F 1084.-8350	Sample Point SEG.COMP#20	Date 2-16-90	Time Issued 8:16	Priority 26
Determination ICP	Method/Standard LA-505-151	Result Units PPM	Charge Code E21D1	Retuns 0
Sample Size ? Direct	Customer ID 000013			
Remarks, Calculations, Results: REAGENT BLANK <i>Complete</i>				
Analyst-1 <i>65283</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5
Hrs	Hrs	Hrs	Hrs	Hrs
<i>J. White</i>	<i>Todd Paul</i>			
Date 4-19-90	Time Completed 08	Lab Unit Mgr <i>D. Sutliff</i>	S4-8000-061 (R-10-83)	

Serial No. F 1083.-8350	Sample Point SEG.COMP#19	Date 2-16-90	Time Issued 8:15	Priority 26
Determination ICP	Method/Standard LA-505-151	Result Units % RECOVERY	Charge Code E21D1	Retuns 0
Sample Size ? Direct	Customer ID 000013			
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 81CULAT <i>Complete</i>				
Analyst-1 <i>65283</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5
Hrs	Hrs	Hrs	Hrs	Hrs
<i>J. White</i>	<i>Todd Paul</i>			
Date 4-19-90	Time Completed 08	Lab Unit Mgr <i>D. Sutliff</i>	S4-8000-061 (R-10-83)	

Serial No. F AB.-8050	Sample Point SEGMENT-17	Date 11-15-89	Time Issued 10:21	Priority 23
Determination ICP	Method/Standard LA-505-151	Result Units PPM	Charge Code WB75L	Retuns 0
Sample Size ? 100-10 E 500-10	Customer ID 89043			
Remarks, Calculations, Results: <i>RERUN</i> <i>Complete</i>				
Analyst-1 <i>65283</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5
Hrs	Hrs	Hrs	Hrs	Hrs
<i>J. White</i>	<i>Todd Paul</i>			
Date 4-19-90	Time Completed 08	Lab Unit Mgr <i>D. Sutliff</i>	S4-8000-061 (R-10-83)	

Serial No. F AB.-8150	Sample Point SEGMENT-18	Date 11-15-89	Time Issued 10:21	Priority 23
Determination ICP	Method/Standard LA-505-151	Result Units PPM	Charge Code WB75L	Retuns 0
Sample Size ? 100-10 E 500-10	Customer ID 89043			
Remarks, Calculations, Results: DUPLICATE SAMPLE <i>RERUN</i> <i>Complete</i>				
Analyst-1 <i>65283</i>	Analyst-2	Analyst-3	Analyst-4	Analyst-5
Hrs	Hrs	Hrs	Hrs	Hrs
<i>J. White</i>	<i>Todd Paul</i>			
Date 4-19-90	Time Completed 08	Lab Unit Mgr <i>D. Sutliff</i>	S4-8000-061 (R-10-83)	

9 1 1 2 0 6 7 0 9 4 8

ICP Analysis

Serial No. F 1087,-8250	Sample Point SEG.COMP#23	Date 2-16-90	Time Issued 8:16	Priority 26
Determination ICP	Method/Standard LA-505-151	Result Units PPM	Charge Code E21D1	Reruns 0
Sample Size ? 100-0	Customer ID 600013			
Remarks, Calculations, Results: SPIKE SAMPLE SPIKE ID SPIKE VOLUME _____				
<i>Complete</i>				
Analyst-1 605283	Analyst-2	Analyst-3	Analyst-4	Analyst-5
Hrs JWhite	Hrs	Hrs <i>Tell. Pd.</i>	Hrs	Hrs
Date 4-19-90	Time Completed <i>af</i>	Lab Unit Mgr 6000061 (R-10-83)	Dynam Saitch	

Serial No. F 1088,-8550	Sample Point SEG.COMP#24	Date 2-16-90	Time Issued 8:16	Priority 26
Determination ICP	Method/Standard LA-505-151	Result Units % RECOVERY	Charge Code E21D1	Reruns 0
Sample Size ? Direct	Customer ID 000013			
Remarks, Calculations, Results: LMCS CHECK SAMPLE LMCS ID 82C11A				
<i>Digested STD.</i> <i>Complete</i>				
Analyst-1 605283	Analyst-2	Analyst-3	Analyst-4	Analyst-5
Hrs JWhite	Hrs	Hrs <i>Tell. Pd.</i>	Hrs	Hrs
Date 4-19-90	Time Completed <i>af</i>	Lab Unit Mgr 6000061 (R-10-83)	Dynam Saitch	