

Lockheed Environmental Systems & Technologies Co.
Lockheed Analytical Services
975 Kelly Johnson Drive Las Vegas, Nevada 89119-3705
Telephone 702-361-0220 800-582-7605 Facsimile 702-361-8146


LK5440

0044408


LOCKHEED MARTIN

November 9, 1995

Ms. Joan Kessner
Bechtel Hanford, Inc.
345 Hills
P.O. Box 969
Richland, WA 99352



RE: Log-in No.:	L5440
Quotation No.:	Q400000-B
SAF:	B95-099
Document File No.:	0926596
WHC Document File No.:	276
SDG No.:	LK5440



The attached data report contains the analytical results of samples that were submitted to Lockheed Analytical Services on 26 September 1995.

The temperature of the cooler upon receipt was 5°C. Sample containers received agree with the chain-of-custody documentation. Sample containers were received intact. Samples were received in time to meet the analytical holding time requirements. The vials for volatile analyses did not contain headspace. All discrepancies identified upon receipt of the samples have been forwarded to the client and are documented in the enclosed chain-of-custody records. (See attached Sample Receiving Checklist).

The case narratives included in the following attachments provide a detailed description of all events that occurred during sample preparation, analysis, and data review specific to the samples and analytical methods requested.

A list of data qualifiers, chain-of-custody forms, sample receiving checklist, and log-in report are also enclosed representing the samples received within this group.

If you have any questions concerning the analysis or the data please call Kathleen Hall at (509) 375-4741.

000003

Lockheed Analytical Services

Log-in No.: L5440
Quotation No.: Q400000-B
SAF: B95-099
Document File No.: 0926596
WHC Document File No.: 276
SDG No.: LK5440
Page No.: 1

Release of this data report has been authorized by the Laboratory Director or the Director's designee as evidenced by the following signature.

" I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data contained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."

Sincerely,

A handwritten signature in black ink, appearing to read "Kathleen M. Hall for".

Kathleen M. Hall
Client Services Representative

cc: Client Services
Document Control

000004

**CASE NARRATIVE
INORGANIC NON METALS ANALYSES
WATER**

The routine calibration and quality control analyses performed for this batch include as applicable: initial and continuing calibration verification, initial and continuing calibration blanks, method blank(s), laboratory control sample(s), matrix spike sample(s), and duplicate sample(s).

Preparation and Analysis Requirements

- One water sample was received for LK5440 and analyzed in batches 926 bh for selected analytes as requested on the chain of custody. Quality control analysis was performed on the following sample:

Client ID	LAL #		Method
BOGKN5	L5440-9	MS, DUP	300.0 Chloride, Fluoride, Nitrate-Nitrogen, Orthophosphate, Sulfate
	L5440-10	MS, DUP	950.1 Ammonia
	L5440-11	MS, DUP	9030 Sulfide

Holding Time Requirements

- All samples were analyzed within the method-specific holding time with the exception of Method 300.0 Nitrate-Nitrogen and Orthophosphate which were received outside of holding time. The associated samples are flagged with an "H".

Method Blanks

- The concentration levels of all the requested analytes in the method blank were below the reporting detection limits.

Internal Quality Control

- All Internal Quality Control were within acceptance limits.

Kay McCann
Prepared By

October 15, 1995
Date

000005

CASE NARRATIVE INORGANIC METALS ANALYSES

The routine calibration and quality control analyses performed for this batch include as applicable: instrument tune (ICP/MS only), initial and continuing calibration verification, initial and continuing calibration blanks, method blank(s), laboratory control sample(s), ICP interference check samples (ICP only), serial dilutions, analytical (post-digestion) spike samples, matrix spike (predigestion) sample(s), duplicate sample(s).

Preparation and Analysis Requirements

All samples were received on September 26, 1995. The samples were logged in as L5440 and were prepared and analyzed in batch 926 bhT for total metals and 926 bhD for dissolved metals.

Holding Time Requirements

- All samples were analyzed within the method-specific holding times.

Method Blanks

- The concentration levels of all the requested analytes in the method blank were below the reporting detection limits.

Internal Quality Control

- All Internal Quality Control were within acceptance limits with the following exceptions: The matrix spike recoveries for thallium for both total (70%) and dissolved (72%) were outside of acceptance limits. The recoveries based on the LCS (91% total and 103.4 dissolved) support that the analytical system was operating within control limits.

Shellee McGrath
Prepared By

November 1, 1995
Date

000006

**CASE NARRATIVE
ORGANIC ANALYSES**

Analytical Method 8240

The associated samples were analyzed in two analytical batches.

Analytical Batch 100295-8260-E1,E2

The samples were analyzed within the required holding time on October 2 and 3, 1995. The instrument tunes, initial and continuing calibrations were within QC criteria. There were no target compounds detected in the Method Blank (MB). Surrogate recoveries were within QC limits. Compound recoveries were within QC limits in the Matrix Spike (MS), Matrix Spike Duplicate (MSD), and Laboratory Control Sample (LCS). The Relative Percent Differences (RPDs) between the MS and MSD recoveries were within QC limits. All samples met internal standard area counts and retention times criteria.

Christine Davy
Prepared By

November 9, 1995
Date

CASE NARRATIVE RADIOCHEMICAL ANALYSES

The routine calibration and quality control (QC) analyses performed for this batch include as applicable: instrument calibration, initial and continuing calibration verification, quench monitoring standards, instrument background analysis, method blanks, yield tracer, laboratory control samples, matrix spike samples, duplicate samples.

NOTE: Chemical recoveries and minimum detectable activities can be found on the preparation sheets and calculation sheets on the attached raw data for each method.

Holding Time Requirements

All holding times were met.

Analytical Method Gross Alpha Beta

The gross alpha beta analysis was performed using standard operating procedure, LAL-91-SOP-0060. The samples were analyzed in workgroup 27812. No problems were encountered during the analysis and all QC criteria were met with the following exceptions: The minimum detectable activity of the matrix spike and duplicate (27812MS1 and 27812DUP1) was greater than the reporting detection limit due to residue weight limitations forcing a volume reduction. Data quality is not believed to be adversely affected. No re-analyses were performed.

Yvonne M. Jacoby
Prepared By

October 20, 1995
Date

Lockheed Analytical Services
DATA QUALIFIERS FOR INORGANIC ANALYSES

[Revised 08/28/92]

For Use on the Analytical Data Reporting Forms	
B	<i>For CLP Analyses Only</i> -- Reported value is less than the contract required detection limit (CRDL) but greater than or equal to the instrument detection limit (IDL).
C	<i>For Routine, Non-CLP Analyses Only</i> -- Any constituent that was also detected in the associated blank whose concentration was greater than the reporting detection limit (RDL).
D	Presence of high levels of interfering constituents required dilution of sample which increased the RDL by the dilution factor.
E	Estimated value due to presence of interference.
H	Sample analysis performed outside of method-or client-specified maximum holding time requirement.
M	<i>For CLP Analyses Only</i> -- Duplicate injection precision criterion was not met.
N	Matrix spike recovery exceeded acceptance limits.
S	Reported value was determined from the method of standard addition.
U	<i>For CLP Reporting Only</i> -- Constituent was analyzed for but not detected (sample quantitation must be corrected for dilution and percent moisture).
W	<i>For AAS Only</i> -- Post-digestion spike for Furnace AAS did not meet acceptance criteria and sample absorbance is less than 50% of spike absorbance.
X, Y, or Z	Analyst-defined qualifier.
*	Relative percent difference (RPD) for duplicate analysis exceeded acceptance limits.
+	Correlation coefficient (r) for the MSA is less than 0.995.
For Use on the QC Data Reporting Forms	
a¹	The spike recovery and/or RPD for matrix spike and matrix spike duplicates cannot be evaluated due to insufficient spiking level compared to the elevated sample analyte concentration.
b¹	The RPD cannot be computed because the sample and/or duplicate concentration was below the RDL.

¹ Used as footnote designations on the QC summary form.

000008B

Lockheed Analytical Services

DATA QUALIFIERS FOR ORGANIC ANALYSES

[Revised 04/12/1995]

For Use On The Analytical Data Reporting Forms	
A	<i>For CLP analyses Only</i> -- The TIC is a suspected aldol-condensation product.
B	Any constituent that was also detected in the associated blank whose concentration was greater than the practical or reporting detection limit (PQL or RDL).
C	Constituent confirmed by GC/MS analysis. <i>[pesticide/PCB analyses only]</i>
D	Constituent detected in the diluted sample. It also indicates that an accurate quantitation is not possible due to <u>surrogates</u> being diluted out of the samples during the course of the analysis.
E	Constituent concentration exceeded the calibration range.
G	The quantitation is not gasoline or diesel but believed to be some other combination of hydrocarbons.
H	Sample analysis performed outside of method- or client-specified maximum holding time requirement.
J	<i>Estimated value</i> -- (1) constituent detected at a level less than the RDL or PQL and greater than or equal to the MDL; (2) estimated concentration for TICs (<i>For CLP Reporting Only</i>).
N	<i>For CLP Reporting Only</i> -- Tentatively identified constituents (TICs) identified based on mass spectral library search.
P	<i>For CLP Reporting Only</i> -- The percent difference between the concentrations detected on both GC columns was greater than 25 percent <i>[pesticide/PCB analyses only]</i> .
U	<i>For CLP Reporting Only</i> -- Constituent was analyzed for but not detected (sample quantitation must be corrected for dilution and percent moisture).
X, Y, or Z	Analyst-defined qualifier.
N/A (% Moisture)	N/A in the % moisture cell indicates that data are reported on an "as received" basis. A value in the % moisture cell indicates that data are reported based on a "dry weight" basis.
For Use On The QC Data Reporting Forms	
*	QC data (i.e., percent recovery data for matrix spike, matrix spike duplicate, laboratory control standard, or surrogates; and RPD for matrix spike duplicate or unspiked duplicate) exceeded acceptance limits.
a ¹	The spike recovery and/or RPD for matrix spike and matrix spike duplicates cannot be evaluated due to insufficient spiking level compared to the elevated sample analyte concentration.
b ¹	The RPD cannot be computed because the sample and/or duplicate concentration was below the RDL.

¹ Used as footnote designations on the QC Summary Form.

000008C

Lockheed Analytical Services
DATA QUALIFIERS FOR RADIOCHEMICAL ANALYSES
[Revised 08/28/92]

For Use on the Analytical Data Reporting Forms	
B	Any constituent that was also detected in the associated blank whose concentration was greater than the reporting detection limit (RDL) and/or minimum detectable activity (MDA).
C	Presence of high TDS in sample required reduction of sample size which increased the MDA.
D	Constituent detected in the diluted sample.
E	Constituent concentration exceeded the calibration or attenuation curve range.
F	<i>For Alpha Spectrometry Only</i> -- FWHM exceeded acceptance limits.
H	Sample analysis performed outside of method-specified maximum holding time requirement.
Y	Chemical yield exceeded acceptance limits.
For Use on the QC Data Reporting Forms	
*	QC data (i.e., percent recovery data for laboratory control standard and matrix spike; and RPD for replicate analyses) exceeded acceptance limits.
a¹	The spike recovery and/or RPD for matrix spike and duplicates cannot be evaluated due to insufficient spiking level compared to the elevated sample analyte concentration.
b¹	The RPD cannot be computed because the sample and/or duplicate concentration was below the MDA.

¹ Used as foot note designations on the QC summary form.



Lockheed Analytical Services

SAMPLE LOGIN AND CHAIN OF CUSTODY

000008E

LOCKHEED ANALYTICAL SERVICES
 LOGIN CHAIN OF CUSTODY REPORT (ln01)
 Sep 26 1995, 03:11 pm

Login Number: L5440
 Account: 596 Bechtel Hanford, Inc. * Richland, WA
 Project: BECHTEL-HANFORD Bechtel Hanford Project

Laboratory Sample Number	Client Sample Number	Collect Date	Receive Date	Due PR Date
L5440-1 TEMP 5 Location: RFG01-43D Water 1 S SCREENING	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
		Hold:21-MAR-96		
L5440-2 TEMP 5 Location: RFG18-48A6 Water 1 S 8240 VOLATILES	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
		Hold:07-OCT-95		
L5440-3 TEMP 5 Location: RFG18-48A6	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
L5440-4 TEMP 5 Location: RFG18-48A6	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
L5440-5 TEMP 5 Location: RFG18-48A6 Water 1 S 8240 VOLATILES	BOGKN7	23-SEP-95	26-SEP-95	31-OCT-95
		Hold:07-OCT-95		
L5440-6 TEMP 5 Location: RFG18-48A6	BOGKN7	23-SEP-95	26-SEP-95	31-OCT-95
L5440-7 TEMP 5 Location: RFG18-48A6	BOGKN7	23-SEP-95	26-SEP-95	31-OCT-95
L5440-8 TEMP 5 "GFAA METALS=As,Pb,Se,Tl" Location: RFG02-22A Water 1 S 6010 ICP METALS Water 1 S 7000 FURNACE METALS	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
		Hold:21-MAR-96		
		Hold:21-MAR-96		
L5440-9 TEMP 5 Location: RFG02-22A Water 1 S 300.0 CHLORIDE Water 1 S 300.0 FLUORIDE Water 1 S 300.0 NITRATE Water 1 S 300.0 PHOSPHATE	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
		Hold:21-OCT-95		
		Hold:21-OCT-95		
		Hold:25-SEP-95		
		Hold:25-SEP-95		

LOCKHEED ANALYTICAL SERVICES
 LOGIN CHAIN OF CUSTODY REPORT (ln01)
 Sep 26 1995, 03:11 pm

Login Number: L5440
 Account: 596 Bechtel Hanford, Inc. * Richland, WA
 Project: BECHTEL-HANFORD Bechtel Hanford Project

Laboratory Sample Number	Client Sample Number	Collect Date	Receive Date	Due PR Date
Water 1 S 300.0 SULFATE		Hold:21-OCT-95		
L5440-10 TEMP 5 Location: RFG02-22A	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
Water 1 S 350.1 NH3/N		Hold:21-OCT-95		
L5440-11 TEMP 5 Location: RFG02-22A	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
Water 1 S 9030 SULFIDE		Hold:30-SEP-95		
L5440-12 TEMP 5 Location: 157	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
Water 1 S GR ALP/BETA LAL-0060		Hold:21-MAR-96		
Water 1 S U TOTAL KPA (INORG)		Hold:21-MAR-96		
L5440-13 TEMP 5 Location: 157	BOGKN5	23-SEP-95	26-SEP-95	31-OCT-95
L5440-14 TEMP 5 Location: RFG02-22A	BOGKN6 "GFAA METALS=As,Pb,Se,Tl"	23-SEP-95	26-SEP-95	31-OCT-95
Filt H2O 15 S 6010 ICP METALS		Hold:21-MAR-96		
Filt H2O 15 S 7000 FURNACE METALS		Hold:21-MAR-96		
L5440-15 Location:	REPORT TYPE	26-SEP-95	26-SEP-95	31-OCT-95
Water 1 S EDD - DISK DEL.				
Water 1 S GCMS2				
Water 1 S INORG TYPE 2 RPT +				
Water 1 S RAD RPT TYPE 2				

Signature: Paul C. Jones

Date: 9-26-95

000010

0926596

Bechtel Hanford, Inc.		CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST						LS440				Page <u>1</u> of <u>1</u>	
Collector <i>K Lee / D. ST. JOHN</i>		Company Contact M. J. Gulgoul				Telephone (509) 372-9597				Data Turnaround <input type="checkbox"/> Priority <input checked="" type="checkbox"/> Normal			
Project Designation 300-FF-2 618-10 and 618-11 Burial Ground Wells		Sampling Location 618-10 and 618-11 Burial Grounds				SAF No. B95-099							
Ice Chest No. <i>6WS025</i>		Field Logbook No. <i>EFL-1123</i>				Method of Shipment Federal Express							
Shipped To Lockhead		Offsite Property No. <i>W95-0-0600-02</i>				Bill of Lading/Air Bill No. <i>2904641941</i>							
Possible Sample Hazards/Remarks		Preservation	HCl	HNO ₃	Cool 4°C	H ₂ SO ₄	*1	HNO ₃	None		HNO ₃		
		Type of Container	Gs	P/G	P/G	P/G	P	P/G	P/G		P/G		
		No. of Container(s)	3	1	1	1	1				1		
Special Handling and/or Storage Maintain samples between 2°C and 6°C.		Volume	40mL	1L	500mL	1L	1L				20mL	1L	
SAMPLE ANALYSIS		VOA - TCL	ICP Metals (unfiltered) - TAL, GFAA Metals - As, Pb, Se, Ti	Anions (IC) - F, Cl, SO ₄ , NO ₃ , PO ₄	Ammonia	Sulfide	Gross Alpha, Gross Beta, Total U	Activity Scan		ICP Metals (filtered) - TAL, GFAA Metals - As, Pb, Se, Ti			
		Sample No.	Matrix*	Date Sampled	Time Sampled								
BOGKN5		W	9/23/95	1420	X	X	X	X	X	X			
BOGKN6		W	9/23/95	1420							X		
BOGKN7		W	9/23/95	1420	X								
CHAIN OF POSSESSION		Sign/Print Names				SPECIAL INSTRUCTIONS				Matrix*			
Relinquished By <i>D. St. John</i> Date/Time <i>0855</i>		Received By <i>[Signature]</i> Date/Time <i>0855</i>				*1 ZnAc + NaOH *2 1, 1L and 1, 250mL Sample analysis for nitrate and phosphate by EPA 300.0 is being requested for information only. The ERC Contractor acknowledges that the 48-hour holding time will not be met.				S = Soil SE = Sediment SO = Solid SL = Sludge W = Water O = Oil A = Air DS = Drum Solids DL = Drum Liquids T = Tissue WI = Wipe L = Liquid V = Vegetation X = Other			
Relinquished By <i>[Signature]</i> Date/Time <i>0925-95</i>		Received By <i>[Signature]</i> Date/Time <i>9-25-95</i>											
Relinquished By <i>[Signature]</i> Date/Time <i>0859</i>		Received By <i>[Signature]</i> Date/Time <i>9-25-95</i>											
Relinquished By <i>[Signature]</i> Date/Time <i>9-25-95</i>		Received By <i>[Signature]</i> Date/Time <i>9-25-95</i>											
LABORATORY SECTION		Received By <i>[Signature]</i>		Title <i>Sample Custodian</i>		Date/Time <i>9-26-95 0900</i>							
FINAL SAMPLE DISPOSITION		Disposal Method		Disposed By		Date/Time							

000011

755056


Environmental
Restoration
Contractor

ERC Team

Interoffice Memorandum

Job No. 22192
Written Response Required: NO
CCN: N/A
OU: 300 FF-2
TSD: N/A
ERA: N/A
Subject Code: 3830

TO: W. S. Thompson N3-06 DATE: September 20, 1995

COPIES: J. E. Parsons X0-23 FROM: S. K. De Mers 
M. J. Galgoul H6-01 Radiological Controls
T7-05/373-1913

SUBJECT: Sampling of Wells 699-S6-E4A, E4B, and E4C and Wells 699-12-4D and 699-13-1A&B

There is no need to perform total activities prior to offsite shipment to NRC licensed labs of samples taken from these wells.

The wells were reviewed for radiological content based on the previous sampling data. Additionally, other wells in the same local were reviewed as recent sampling data is not available for all wells. The wells listed have a β activity $< 100,000$ pCi/l ($< .1$ uCi/sample based on a 1 liter sample size) and the α activity is $< 10,000$ pCi/l ($< .01$ uCi/l based on a 1 liter sample). The well shows activities $< 2,000$ pCi/gm (< 2 nCi/gm D.O.T. limit). The highest activity in recent samples is 36,600 pCi/l $\beta(\text{H}^3)$ and 15 pCi/l α . Other wells in the vicinity showed a recent high of 86,000 pCi/l of Tritium. While this value exceeds the drinking water limit, it does not exceed the limit for DOT shipping.

None of the wells reviewed are located within radiological areas and will not require any RCT support.

skd

000012

092657

SAMPLE CHECK-IN LIST

Date/Time Received: 9-26-95/9:00 AM

SDG#: 0117

Work Order Number: 0117

SAF #: B95-099

Shipping Container ID: GWS-025 Chain of Custody #: 0117

1. Custody Seals on shipping container intact? Yes ☒ No ☐
2. Custody Seals dated and signed? Yes ☒ No ☐
3. Sample temperature 52
4. Vermiculite/packing materials is Wet ☐ Dry ☒
5. Each sample is in a plastic bag? Yes ☒ No ☐
6. Sample holding times exceeded? Yes ☒ No ☐

7. Samples have:

☐ tape ☐ hazard labels
☒ custody seals ☐ appropriate sample labels

8. Samples are:

☒ in good condition ☐ leaking
☐ broken ☐ have air bubbles

9. Is the information on the COC and Sample bottles in agreement?

Yes ☐

No ☒

Notes: Holding Time for 300.0 minute was passed

Sample Custodian/Laboratory: Paul Davis/Lockhead Date: 9-26-95

Telephoned To: _____ On _____ By _____

LOCKHEED MARTIN



Sample Login Login Review Checklist

Lot Number LS440

The login review should be conducted by that person logging in the samples as well as a peer. Please use this checklist to ensure that such reviews occur in a uniform basis. Please sign and date below to verify that a login review has occurred. This checklist should be affixed to each login package prior to distribution.

For effective login review, at a minimum, five reports from the login process are required. These are the COC (or equivalent), the login COC report, the sample summary report, the sample receiving checklist, and the login quotation. Before beginning review, ensure that these five components are available. Jobs with single component samples, the sample summary report may be omitted.

SAMPLE SUMMARY REPORT

	<u>YES</u>	<u>NO</u>	<u>N/A</u>	<u>Comment</u>
1. Are all sample ID's correct?	<u>X</u>	—	—	_____
2. Are all samples present?	<u>X</u>	—	—	_____
3. Are all matrices indicated correctly?	<u>X</u>	—	—	_____
4. Are all analyses on the COC logged in for the appropriate samples?	<u>X</u>	—	—	_____
5. Are all analyses logged in for the correct container?	<u>X</u>	—	—	_____
6. Are samples logged in according to LAS batching procedures?	<u>X</u>	—	—	_____

LOGIN CHAIN OF CUSTODY

	<u>YES</u>	<u>NO</u>	<u>N/A</u>	<u>Comment</u>
1. Are the collect, receive, and due dates correct for every sample?	<u>X</u>	—	—	_____
2. Have all appropriate comments been indicated in the comment section?	—	—	<u>X</u>	_____

SAMPLE RECEIVING CHECKLIST

	<u>YES</u>	<u>NO</u>	<u>N/A</u>	<u>Comment</u>
1. Are all discrepancies between the COC and the login noted (if applicable)?	—	—	<u>X</u>	_____

Paul J. Davis
primary review signature

9-26-95
date

Wm. J. Hall
secondary review signature

9-26-95
date

000014

0926596

Lockheed Analytical Services Sample Receiving Checklist

Page 1 of

Client Name: Westinghouse - Hanford

Job No. LS440

Cooler ID: 1117

COOLER CONDITION UPON RECEIPT

Temperature of cooler upon receipt: 50

temperature of temp. blank upon receipt: —

	Yes	No	* Comments/Discrepancies
custody seals intact	X		
chain of custody present	X		
blue ice (or equiv.) present/frozen	X		
rad survey completed	X		

SAMPLE CONDITION UPON RECEIPT

	Yes	No	* Comments/Discrepancies
all bottles labeled	X		
samples intact	X		
proper container used for sample type	X		
sample volume sufficient for analysis	X		
proper pres. indicated on the COC	X		
VOA's contain headspace		X	
are samples bi-phasic (if so, indicate sample ID'S):			<u>1117</u>

MISCELLANEOUS ITEMS

	Yes	No	* Comments/Discrepancies
samples with short holding times	X		<u>3000 nitrate, passed Holding Time.</u>
samples to subcontract		<u>1117</u>	

ADDITIONAL COMMENTS/DISCREPANCIES

Completed by / date: Paula Davis 9-26-95

Sent to the client (date/initials):

** Client's signature upon receipt:

Notes: * = contact the appropriate CSR of any discrepancies immediately upon receipt

** = please review this information and return via facsimile to the appropriate CSR (702) 361-8146

000015

Lockheed Analytical Laboratory
SAMPLE SUMMARY REPORT (su02)
Bechtel Hanford, Inc. * Richland, WA

Client Sample Number	LAL Sample Number	SDG Number	Matrix	Method
BOGKN5 _	L5440-1		Water	SCREENING
	L5440-2		Water	8240 VOLATILES
	L5440-8		Water	6010 ICP METALS
	L5440-8		Water	7000 FURNACE META
	L5440-9		Water	300.0 CHLORIDE
	L5440-9		Water	300.0 FLUORIDE
	L5440-9		Water	300.0 NITRATE
	L5440-9		Water	300.0 PHOSPHATE
	L5440-9		Water	300.0 SULFATE
	L5440-10		Water	350.1 NH3/N
	L5440-11		Water	9030 SULFIDE
	L5440-12		Water	GR ALP/BETA LAL-(
	L5440-12		Water	U TOTAL KPA (INOF
BOGKN6 _	L5440-14		Filt H2O	6010 ICP METALS
	L5440-14		Filt H2O	7000 FURNACE META
BOGKN7 _	L5440-5		Water	8240 VOLATILES
REPORT TYPE _	L5440-15		Water	EDD - DISK DEL.
	L5440-15		Water	GCMS2
	L5440-15		Water	INORG TYPE 2 RPT
	L5440-15		Water	RAD RPT TYPE 2

000016A

0926596

LOCKHEED ANALYTICAL SERVICES
COMMON IONS AND ADDITIONAL ANALYTES
Sample Results

Client Sample ID: BOGKN5	Date Collected: 23-SEP-95
Matrix: Water	Date Received: 26-SEP-95

Constituent	Units	Method	Result	Reporting Det Limit	Data Qualifier(s)	Date Analyzed	LAS Batch ID	LAS Sample ID
Chloride	mg/L	300.0	11.	0.02		28-SEP-95	27883	L5440-9
Fluoride	mg/L	300.0	0.27	0.1		02-OCT-95	27884	L5440-9
Nitrate-N	mg/L	300.0	5.8	0.02	H	28-SEP-95	27885	L5440-9
Ortho Phosphate	mg/L	300.0	< 0.1	0.1	H	02-OCT-95	27886	L5440-9
Sulfate	mg/L	300.0	47.	0.1		28-SEP-95	27887	L5440-9
Ammonia Nitrogen	mg/L	350.1	< 0.05	0.05		29-SEP-95	27888	L5440-10
Sulfide	mg/L	9030	< 3	3		28-SEP-95	27876	L5440-11

000017

LOCKHEED ANALYTICAL SERVICES

Sample Results

Client Sample ID: BOGKN5	Date Collected: 23-SEP-95
Matrix: Water	Date Received: 26-SEP-95
Percent Solids: N/A	

Constituent	Units	Method	Result	IDL	RDL	Data Qual	Dilution	Date Analyzed	LAS Batch ID	LAS Sample ID
ALUMINUM, TOTAL	mg/L	6010	< 0.021	0.021	0.20	U	1	24-OCT-95	28809	L5440-8
ANTIMONY, TOTAL	mg/L	6010	< 0.051	0.051	0.060	U	1	24-OCT-95	28809	L5440-8
BARIUM, TOTAL	mg/L	6010	0.049	0.014	0.20	B	1	24-OCT-95	28809	L5440-8
BERYLLIUM, TOTAL	mg/L	6010	< 0.0010	0.0010	0.0050	U	1	24-OCT-95	28809	L5440-8
CADMIUM, TOTAL	mg/L	6010	< 0.0050	0.0050	0.0050	U	1	24-OCT-95	28809	L5440-8
CALCIUM, TOTAL	mg/L	6010	48.	0.026	5.0		1	24-OCT-95	28809	L5440-8
CHROMIUM, TOTAL	mg/L	6010	0.0046	0.0040	0.010	B	1	24-OCT-95	28809	L5440-8
COBALT, TOTAL	mg/L	6010	< 0.0060	0.0060	0.050	U	1	24-OCT-95	28809	L5440-8
COPPER, TOTAL	mg/L	6010	< 0.0030	0.0030	0.025	U	1	24-OCT-95	28809	L5440-8
IRON, TOTAL	mg/L	6010	0.44	0.0090	0.10		1	24-OCT-95	28809	L5440-8
MAGNESIUM, TOTAL	mg/L	6010	13.	0.038	5.0		1	24-OCT-95	28809	L5440-8
MANGANESE, TOTAL	mg/L	6010	0.0021	0.0020	0.015	B	1	24-OCT-95	28809	L5440-8
NICKEL, TOTAL	mg/L	6010	< 0.014	0.014	0.040	U	1	24-OCT-95	28809	L5440-8
POTASSIUM, TOTAL	mg/L	6010	6.4	0.52	5.0		1	24-OCT-95	28809	L5440-8
SILVER, TOTAL	mg/L	6010	< 0.0030	0.0030	0.010	U	1	24-OCT-95	28809	L5440-8
SODIUM, TOTAL	mg/L	6010	17.	0.046	5.0		1	24-OCT-95	28809	L5440-8
VANADIUM, TOTAL	mg/L	6010	0.010	0.0040	0.050	B	1	24-OCT-95	28809	L5440-8
ZINC, TOTAL	mg/L	6010	0.012	0.0030	0.020	B	1	24-OCT-95	28809	L5440-8
ARSENIC, Total	mg/L	7060	0.0061	0.0040	0.010	BW	1	26-OCT-95	28810	L5440-8
LEAD, TOTAL	mg/L	7421	< 0.0010	0.0030	0.0030	U	1	26-OCT-95	28810	L5440-8
SELENIUM, TOTAL	mg/L	7740	< 0.0030	0.0030	0.0050	U	1	26-OCT-95	28810	L5440-8
THALLIUM, TOTAL	mg/L	7840	0.0040	0.0040	0.010	NWU	1	27-OCT-95	28810	L5440-8

000022

LOCKHEED ANALYTICAL SERVICES

Sample Results

Client Sample ID: BOGKN6	Date Collected: 23-SEP-95
Matrix: Filt H2O	Date Received: 26-SEP-95
Percent Solids: N/A	

Constituent	Units	Method	Result	IDL	RDL	Data Qual	Dilution	Date Analyzed	LAS Batch ID	LAS Sample ID
ALUMINUM, DISSOLVED	mg/L	6010	< 0.021	0.021	0.20	U	1	24-OCT-95	28790	L5440-14
ANTIMONY, DISSOLVED	mg/L	6010	0.064	0.051	0.060		1	24-OCT-95	28790	L5440-14
BARIUM, DISSOLVED	mg/L	6010	0.052	0.014	0.20	B	1	24-OCT-95	28790	L5440-14
BERYLLIUM, DISSOLVED	mg/L	6010	< 0.0010	0.0010	0.0050	U	1	24-OCT-95	28790	L5440-14
CADMIUM, DISSOLVED	mg/L	6010	< 0.0050	0.0050	0.0050	U	1	24-OCT-95	28790	L5440-14
CALCIUM, DISSOLVED	mg/L	6010	54.	0.026	5.0		1	24-OCT-95	28790	L5440-14
CHROMIUM, DISSOLVED	mg/L	6010	< 0.0040	0.0040	0.010	U	1	24-OCT-95	28790	L5440-14
COBALT, DISSOLVED	mg/L	6010	< 0.0060	0.0060	0.050	U	1	24-OCT-95	28790	L5440-14
COPPER, DISSOLVED	mg/L	6010	< 0.0030	0.0030	0.025	U	1	24-OCT-95	28790	L5440-14
IRON, DISSOLVED	mg/L	6010	< 0.0090	0.0090	0.10	U	1	24-OCT-95	28790	L5440-14
MAGNESIUM, DISSOLVED	mg/L	6010	14.	0.038	5.0		1	24-OCT-95	28790	L5440-14
MANGANESE, DISSOLVED	mg/L	6010	< 0.0020	0.0020	0.015	U	1	24-OCT-95	28790	L5440-14
NICKEL, DISSOLVED	mg/L	6010	< 0.014	0.014	0.040	U	1	24-OCT-95	28790	L5440-14
POTASSIUM, DISSOLVED	mg/L	6010	6.5	0.52	5.0		1	24-OCT-95	28790	L5440-14
SILVER, DISSOLVED	mg/L	6010	0.0030	0.0030	0.010	B	1	24-OCT-95	28790	L5440-14
SODIUM, DISSOLVED	mg/L	6010	18.	0.046	5.0		1	24-OCT-95	28790	L5440-14
VANADIUM, DISSOLVED	mg/L	6010	0.0093	0.0040	0.050	B	1	24-OCT-95	28790	L5440-14
ZINC, DISSOLVED	mg/L	6010	< 0.0030	0.0030	0.020	U	1	24-OCT-95	28790	L5440-14
ARSENIC, DISSOLVED	mg/L	7060	0.0057	0.0040	0.010	B	1	27-OCT-95	28811	L5440-14
LEAD, DISSOLVED	mg/L	7421	< 0.0030	0.0030	0.0030	U	1	26-OCT-95	28811	L5440-14
SELENIUM, DISSOLVED	mg/L	7740	< 0.0030	0.0030	0.0050	U	1	28-OCT-95	28811	L5440-14
THALLIUM, DISSOLVED	mg/L	7840	< 0.0040	0.0040	0.010	UN	1	27-OCT-95	28811	L5440-14

000023

LOCKHEED ANALYTICAL SERVICES

RAD DATA REPORT (ra01)

Bechtel Hanford, Inc. * Richland, WA

Bechtel Hanford Project (Project BECHTEL-HANFORD)

Client Sample ID: BOGKNS

LAL Sample ID: L5440-12

Date Collected: 23-SEP-95

Date Received: 26-SEP-95

Matrix: Water

Login Number: L5440

Constituent	Analyzed	Batch	Activity	Error	MDA	DataQual	Units
Gross Alpha	11-OCT-95	GR ALP/BETA LAL-0060_27812	2.1	1.6	2.2		pCi/L
Gross Beta	11-OCT-95	GR ALP/BETA LAL-0060_27812	6.5	1.7	2.2		pCi/L
Uranium	06-OCT-95	U TOTAL KPA (INORG)_27889	6.29	0.32	0.63		ug/L

LOCKHEED ANALYTICAL SERVICES

RAD DATA REPORT (ra01)

Bechtel Hanford, Inc. * Richland, WA

Bechtel Hanford Project (Project BECHTEL-HANFORD)

Client Sample ID: BOGKN5

LAL Sample ID: L5440-12

Date Collected: 23-SEP-95

Date Received: 26-SEP-95

Matrix: Water

Login Number: L5440

Constituent	Analyzed	Batch	Activity	Error	MDA	Data Qual	Units
Gross Alpha	11-OCT-95	GR ALP/BETA LAL-0060_27812	2.1	1.6	2.2		pCi/L
Gross Beta	11-OCT-95	GR ALP/BETA LAL-0060_27812	6.5	1.7	2.2		pCi/L
Uranium	06-OCT-95	U TOTAL KPA (INORG)_27889	6.29	0.32	0.63		ug/L

Lockheed Analytical Laboratory

Metals Analytical Data

Technical Review Checklist (Analyst)



Analyst Name (Print): <u>Paul Locks</u>		Instrument: <u>Chromat</u> <u>EA-11</u>		Method: <u>V Total K₂</u>	
Batch Number	Client Name	Code	Comments	Bench Sheet included Y/N	ACS updated Y/N
27889	BENTLEY HANCOCK	COMPLETE		Y	Y

CODE ANOMALY

- 10 Prep Blank data was not within criteria
- 11 Laboratory Control Sample was not within criteria
- 12 Duplicate Precision was not met
- 13 Matrix Spike recovery was not within criteria
- 00 Other

Description	Yes	No	Comments
Completeness Review			
1. Were the standard operating procedures (SOP) followed?	✓		
2. Are <u>all</u> raw data available and labeled properly (e.g., methods used, units, sample IDs, dilution factors, reruns)?	✓		
3. Are <u>all</u> abnormalities in the raw data noted and/or explained?	✓		
4. Were <u>all</u> the client samples analyzed for all constituents and QC as specified on the LAL Bench Sheets?	✓		
Data Quality Assessment			
5. Was the sample properly preserved and analyzed within the method-specified holding time?	✓		
6. Were the instrument calibration criteria met?	✓		
7. Are the initial and continuing calibration verification samples data bracketing the samples of interest within criteria?	✓		
8. Are the bracketing initial and continuing calibration blank data within criteria?	✓		
9. For ICP Only: Are the interference check standard recovery data within criteria?			
Notes and comments:			

I certify, to the best of my knowledge, that the data are acceptable and in compliance with the laboratory policies and client requests, except as noted above.

10/06/95
 Analyst Signature/Date

10/10/95

Secondary Reviewer Initials/Date

000042

Lockheed Analytical Laboratory

Sample Preparation Worksheet for Total Uranium (KPA) Analysis

000043

Date Prep Started : 10/04/95

Matrix : Water

Workgroup Number : U TOTAL KPA (INORG) 27889

Prep Due Date : 31-Oct-95

CLIENT ID	LAL ID	QC	ALIUOT (ml, g, sample)	DILUTION	COMMENTS	Client	Collection Date
L5440-12	27889DUP1	1	DUP1 10	1x	Rep: 5.1% Rep: 0.49	DUP	09/29/95
Lab Ctrl Sample	27889LCS1	2	LCS1	1x	Rep: 112%	LCS	09/29/95
Method Blank	27889MBB1	3	MBB1	1x		MB	09/29/95
L5440-12	27889MS1	4	MS1	1x	Rep: 103%	MS	09/29/95
BOGKN5	L5440-12	5	SMP1, MSS1	1x		Bechtel Hanford, Inc. *	09/23/95
		6					
		7					
		8					
		9					
		10					
		11					
		12					
		13					
		14					
		15					
		16					
		17					
		18					
		19					
		20					
		21					
		22					
		23					
		24					

COMMENTS: _____

Amount of CCV	1x	1x	Amount of LCS	0.1-1g (10ppm)	Amount of MS	0.1-1g (10ppm)
CCV Activity	100 ug/L	5 ug/L	LCS Activity	100 ppb	MS Activity	100 ppb
CCV ID#			LCS ID#		MS ID#	

Balance Number : _____ ()

Pipette Number : _____ ()

Tracer, LCS, & MS added by: Pu

Witnessed by: _____

Sample Prep Analyst : Pu 10/04/95

Checked by: _____

RADIATION RESULTS CHECK REPORT

Workgroup Number: U TOTAL KPA (INORG)_27889

Sample	Parameter	Value	Error	MDA
27889DUP1	Uranium	5.97504	0.308021	0.634
27889LCS1	Uranium	111.841	6.54819	0.634
27889MBB1	Uranium	-0.0439651	0.00234615	0.634
27889MS1	Uranium	109.746	6.41925	0.634
L5440-12	Uranium	6.28828	0.324168	0.634

ug/L

RAJ 10/06/95

000045

Lockheed Analytical Laboratory

Uranium Total by KPA (0168)

U TOTAL KPA (INORG)_27889

V95234

LALID	Count Date	Nuclide	Final Activity	Total Error	MDA	Count Error	Aliquot (mL)	Dilution Factor
					0.634			
27889DUP1	10/06/95	Uranium	5.975	0.308	0.634	0.075	10	1
27889LCS1	10/06/95	Uranium	111.841	6.548	0.634	3.407	10	1
27889MBB1	10/06/95	Uranium	-0.044	0.002	0.634	0.001	10	1
27889MS1	10/06/95	Uranium	109.746	6.419	0.634	3.331	10	1
L5440-12	10/06/95	Uranium	6.288	0.324	0.634	0.079	10	1

LCS Recovery = $111.8/100.0 = 111.8\%$.

MS1 Recovery = $103.458/100.000 = 103.5$ SMP1,DUP1 RER = 0.50, RPD = 5.1 %.

RAF 10/6/95

Lockheed Analytical Laboratory
Method Detection Concentration (MDC) Worksheet

Total U by KPA

Aqueous Matrix

Date	Batch #	Method Blank ug/L
10/6/95 8:57:51 AM	27889	-0.04397
10/4/95 4:13:56 PM	27683	-0.04138
9/18/95	26757	-0.0215
9/14/95	27052	0.0351
9/14/95	26756	0.0399
9/14/95	27355	0.0385
9/8/95 8:28:39 AM	26576	-0.01937
9/8/95	26755	-0.201
9/7/95 11:56:37 AM	26755	0.0636
9/7/95 9:53:42 AM	26476	0.07079
9/6/95 2:08:53 PM	26475	0.10922
8/29/95 10:44:05 AM	25666	-0.10535
8/24/95	16826228	-0.0424
8/23/95	16826123	-0.0818
8/19/95	16826424	0.
8/15/95 6:40:30 PM	26117	0.
8/15/95	16826045	0.
8/9/95	16825940	0.436
8/9/95	16825829	0.
8/9/95	16826051	0.295

Method Blank Average = 0.02657

Standard Deviation = 0.13626

MDC = 0.63361 ug/L

MDC = 4.65 * Standard Deviation

RAF 10/06/95

000047



Certificate of Analysis

Standard Reference Material 3164

Spectrometric Standard Solution

Uranium

Batch Code 390709

This Standard Reference Material (SRM) is intended for use in atomic absorption spectrometry, optical emission (plasma) spectrometry, spectrophotometry, or any other analytical technique that requires aqueous standard solutions for calibrating instruments. SRM 3164 is a single element solution prepared gravimetrically to contain 10 mg/mL of uranium with a nitric acid concentration (V/V) of 10 percent. The certified value is based on a gravimetric procedure, i.e., weight per volume composition of the high-purity uranium oxide dissolved in NIST high-purity reagents. The uncertainty listed is based on gravimetric and volumetric uncertainties of the preparation and the effect of solvent transpiration through the container walls for one year after the bottle is removed from the plastic sleeve.

Metal	Concentration (mg/mL)	Source Purity, %	Acid Conc. (V/V) Approximate
U	10.00 \pm 0.03	NBL-CRM 129 (99.968%) (formerly SRM 950b)	HNO ₃ , 10%

Procedures for Use

Stability: This certification is valid for one year from the date of shipment from NIST provided the solutions are kept tightly capped and stored under normal laboratory conditions. NIST will monitor the stability of representative solutions from this SRM lot and if changes occur that invalidate this certification, NIST will notify purchasers.

Preparation of Working Standard Solutions: All solutions should be brought to 22 ± 1 °C and all glass or plastic surfaces coming into contact with the standard must have been previously cleaned. A working standard solution can be prepared from the SRM solution by serial dilution. Dilutions should be made with certified volumetric class A flasks and 5 or 10 mL class A pipets. All volumetric transfers of solutions should be performed using a proven analytical technique. Each dilution should be acidified with an appropriate high-purity acid and diluted to calibrated volume using high-purity water. The stability of the working standard solution will depend on the final acid concentration; therefore, care should be exercised to ensure that the final acid concentration of the dilution closely approximates that of the SRM. To achieve the highest accuracy, the analyst should prepare daily working solutions from 100 µg/mL dilutions of the original SRM solution.

SRM 3164 was prepared by T.A. Butler of the NIST Inorganic Analytical Research Division. Inductively coupled plasma emission spectrometric analyses were made by T.A. Butler and L.J. Wood.

The technical and support aspects involved in the preparation, certification, and issuance of this SRM were coordinated through the Standard Reference Materials Program by J.S. Kane.

Gaithersburg, MD 20899
October 5, 1993

Thomas E. Gills, Acting Chief
Standard Reference Materials Program

000051

LOCKHEED ANALYTICAL SERVICES

GC/MS FOR VOLATILE ORGANICS
8240 VOLATILES

Client Sample ID: BOGKN5
Date Collected: 23-SEP-95
Date Analyzed: 02-OCT-95
Matrix: Water

LAL Sample ID: L5440-2
Date Received: 26-SEP-95
Analytical Dilution: 1
Analytical Batch ID: 100295-8260-E2
Preparation Dilution: 1.00

SURROGATE RECOVERY (%)		
		QC Limits
1,2-Dichloroethane-d4	100	84-122
Toluene-d8	108	87-117
Bromofluorobenzene	102	83-118

CONSTITUENT	CAS NO.	RESULT ug/L	PRACTICAL QUANTITATION LIMIT	DATA QUALIFIER(s)
			ug/L	
Chloromethane	74-87-3	<5.0	5.0	
Vinyl Chloride	75-01-4	<5.0	5.0	
Bromomethane	74-83-9	<5.0	5.0	
Chloroethane	75-00-3	<5.0	5.0	
Trichlorofluoromethane	75-69-4	<5.0	5.0	
Acetone	67-64-1	<10.	10.	
1,1-Dichloroethene	75-35-4	<5.0	5.0	
Carbon Disulfide	75-15-0	<5.0	5.0	
Methylene Chloride	75-09-2	<5.0	5.0	
trans-1,2-Dichloroethene	156-60-5	<5.0	5.0	
Vinyl Acetate	108-05-4	<10.	10.	
1,1-Dichloroethane	75-34-3	<5.0	5.0	
2-Butanone	78-93-3	<10.	10.	
cis-1,2-Dichloroethene	156-59-2	<5.0	5.0	
Chloroform	67-66-3	<5.0	5.0	
1,1,1-Trichloroethane	71-55-6	<5.0	5.0	
Carbon tetrachloride	56-23-5	<5.0	5.0	
1,2-Dichloroethane	107-06-2	<5.0	5.0	
Benzene	71-43-2	<5.0	5.0	
Trichloroethene	79-01-6	<5.0	5.0	
1,2-Dichloropropane	78-87-5	<5.0	5.0	
Bromodichloromethane	75-27-4	<5.0	5.0	
2-Chloroethylvinylether	110-75-8	<20.	20.	
4-Methyl-2-Pentanone	108-10-1	<10.	10.	
cis-1,3-Dichloropropene	10061-01-5	<5.0	5.0	
Toluene	108-88-3	<5.0	5.0	
trans-1,3-Dichloropropene	10061-02-6	<5.0	5.0	
2-Hexanone	591-78-6	<10.	10.	
1,1,2-Trichloroethane	79-00-5	<5.0	5.0	
Tetrachloroethene	127-18-4	<5.0	5.0	
Dibromochloromethane	124-48-1	<5.0	5.0	
Chlorobenzene	108-90-7	<5.0	5.0	
Ethylbenzene	100-41-4	<5.0	5.0	
m,p-Xylene	1330-20-7	<5.0	5.0	
o-Xylene	95-47-6	<5.0	5.0	
Styrene	100-42-5	<5.0	5.0	
Bromoform	75-25-2	<5.0	5.0	
1,1,2,2-Tetrachloroethane	79-34-5	<5.0	5.0	
1,3-Dichlorobenzene	541-73-1	<5.0	5.0	
1,4-Dichlorobenzene	106-46-7	<5.0	5.0	
1,2-Dichlorobenzene	95-50-1	<5.0	5.0	

LOCKHEED ANALYTICAL SERVICES

GC/MS FOR VOLATILE ORGANICS
8240 VOLATILES

Client Sample ID: BOGKN7
Date Collected: 23-SEP-95
Date Analyzed: 03-OCT-95
Matrix: Water

LAL Sample ID: L5440-5
Date Received: 26-SEP-95
Analytical Dilution: 1
Analytical Batch ID: 100295-8260-E2
Preparation Dilution: 1.00

SURROGATE RECOVERY (%)		
		QC Limits
1,2-Dichloroethane-d4	101	84-122
Toluene-d8	106	87-117
Bromofluorobenzene	101	83-118

CONSTITUENT	CAS NO.	RESULT ug/L	PRACTICAL QUANTITATION LIMIT ug/L	DATA QUALIFIER(S)
Chloromethane	74-87-3	<5.0	5.0	
Vinyl Chloride	75-01-4	<5.0	5.0	
Bromomethane	74-83-9	<5.0	5.0	
Chloroethane	75-00-3	<5.0	5.0	
Trichlorofluoromethane	75-69-4	<5.0	5.0	
Acetone	67-64-1	<10.	10.	
1,1-Dichloroethene	75-35-4	<5.0	5.0	
Carbon Disulfide	75-15-0	<5.0	5.0	
Methylene Chloride	75-09-2	<5.0	5.0	
trans-1,2-Dichloroethene	156-60-5	<5.0	5.0	
Vinyl Acetate	108-05-4	<10.	10.	
1,1-Dichloroethane	75-34-3	<5.0	5.0	
2-Butanone	78-93-3	<10.	10.	
cis-1,2-Dichloroethene	156-59-2	<5.0	5.0	
Chloroform	67-66-3	<5.0	5.0	
1,1,1-Trichloroethane	71-55-6	<5.0	5.0	
Carbon tetrachloride	56-23-5	<5.0	5.0	
1,2-Dichloroethane	107-06-2	<5.0	5.0	
Benzene	71-43-2	<5.0	5.0	
Trichloroethene	79-01-6	<5.0	5.0	
1,2-Dichloropropane	78-87-5	<5.0	5.0	
Bromodichloromethane	75-27-4	<5.0	5.0	
2-Chloroethylvinylether	110-75-8	<20.	20.	
4-Methyl-2-Pentanone	108-10-1	<10.	10.	
cis-1,3-Dichloropropene	10061-01-5	<5.0	5.0	
Toluene	108-88-3	<5.0	5.0	
trans-1,3-Dichloropropene	10061-02-6	<5.0	5.0	
2-Hexanone	591-78-6	<10.	10.	
1,1,2-Trichloroethane	79-00-5	<5.0	5.0	
Tetrachloroethene	127-18-4	<5.0	5.0	
Dibromochloromethane	124-48-1	<5.0	5.0	
Chlorobenzene	108-90-7	<5.0	5.0	
Ethylbenzene	100-41-4	<5.0	5.0	
m,p-Xylene	1330-20-7	<5.0	5.0	
o-Xylene	95-47-6	<5.0	5.0	
Styrene	100-42-5	<5.0	5.0	
Bromoform	75-25-2	<5.0	5.0	
1,1,2,2-Tetrachloroethane	79-34-5	<5.0	5.0	
1,3-Dichlorobenzene	541-73-1	<5.0	5.0	
1,4-Dichlorobenzene	106-46-7	<5.0	5.0	
1,2-Dichlorobenzene	95-50-1	<5.0	5.0	

LOCKHEED ANALYTICAL SERVICES

SPIKED SAMPLE RESULT
GC/MS FOR VOLATILE ORGANICS

Client Sample ID: BOGKN7
Date Collected: 23-SEP-95
Date Analyzed: 03-OCT-95

LAL Sample ID: 28098MS
Date Received: 26-SEP-95
Analytical Dilution: 1
Analytical Batch ID: 100295-8260-E2
Preparation Dilution: 1.00

SURROGATE RECOVERY (%)		
		QC Limits
1,2-Dichloroethane-d4	103	84-122
Toluene-d8	104	87-117
Bromofluorobenzene	103	83-118

CONSTITUENT	CAS NO.	RESULT ug/L	PRACTICAL QUANTITATION LIMIT ug/L	DATA QUALIFIER(s)
Chloromethane	74-87-3	<5.0	5.0	
Vinyl Chloride	75-01-4	<5.0	5.0	
Bromomethane	74-83-9	<5.0	5.0	
Chloroethane	75-00-3	<5.0	5.0	
Trichlorofluoromethane	75-69-4	<5.0	5.0	
Acetone	67-64-1	<10.	10.	
1,1-Dichloroethene	75-35-4	37.	5.0	
Carbon Disulfide	75-15-0	<5.0	5.0	
Methylene Chloride	75-09-2	<5.0	5.0	
trans-1,2-Dichloroethene	156-60-5	<5.0	5.0	
Vinyl Acetate	108-05-4	<10.	10.	
1,1-Dichloroethane	75-34-3	<5.0	5.0	
2-Butanone	78-93-3	<10.	10.	
cis-1,2-Dichloroethene	156-59-2	<5.0	5.0	
Chloroform	67-66-3	<5.0	5.0	
1,1,1-Trichloroethane	71-55-6	<5.0	5.0	
Carbon tetrachloride	56-23-5	<5.0	5.0	
1,2-Dichloroethane	107-06-2	<5.0	5.0	
Benzene	71-43-2	48.	5.0	
Trichloroethene	79-01-6	43.	5.0	
1,2-Dichloropropane	78-87-5	<5.0	5.0	
Bromodichloromethane	75-27-4	<5.0	5.0	
2-Chloroethylvinylether	110-75-8	<20.	20.	
4-Methyl-2-Pentanone	108-10-1	<10.	10.	
cis-1,3-Dichloropropene	10061-01-5	<5.0	5.0	
Toluene	108-88-3	49.	5.0	
trans-1,3-Dichloropropene	10061-02-6	<5.0	5.0	
2-Hexanone	591-78-6	<10.	10.	
1,1,2-Trichloroethane	79-00-5	<5.0	5.0	
Tetrachloroethene	127-18-4	<5.0	5.0	
Dibromochloromethane	124-48-1	<5.0	5.0	
Chlorobenzene	108-90-7	52.	5.0	
Ethylbenzene	100-41-4	<5.0	5.0	
m,p-Xylene	1330-20-7	<5.0	5.0	
o-Xylene	95-47-6	<5.0	5.0	
Styrene	100-42-5	<5.0	5.0	
Bromoform	75-25-2	<5.0	5.0	
1,1,2,2-Tetrachloroethane	79-34-5	<5.0	5.0	
1,3-Dichlorobenzene	541-73-1	<5.0	5.0	
1,4-Dichlorobenzene	106-46-7	<5.0	5.0	
1,2-Dichlorobenzene	95-50-1	<5.0	5.0	

LOCKHEED ANALYTICAL SERVICES

SPIKED SAMPLE RESULT
GC/MS FOR VOLATILE ORGANICS

Client Sample ID: BOGKN7
Date Collected: 23-SEP-95
Date Analyzed: 03-OCT-95

LAL Sample ID: 28098MSD
Date Received: 26-SEP-95
Analytical Dilution: 1
Analytical Batch ID: 100295-8260-E2
Preparation Dilution: 1.00

SURROGATE RECOVERY (%)		
		QC Limits
1,2-Dichloroethane-d4	102	84-122
Toluene-d8	107	87-117
Bromofluorobenzene	105	83-118

CONSTITUENT	CAS NO.	RESULT ug/L	PRACTICAL QUANTITATION LIMIT ug/L	DATA QUALIFIER(S)
Chloromethane	74-87-3	<5.0	5.0	
Vinyl Chloride	75-01-4	<5.0	5.0	
Bromomethane	74-83-9	<5.0	5.0	
Chloroethane	75-00-3	<5.0	5.0	
Trichlorofluoromethane	75-69-4	<5.0	5.0	
Acetone	67-64-1	<10.	10.	
1,1-Dichloroethene	75-35-4	37.	5.0	
Carbon Disulfide	75-15-0	<5.0	5.0	
Methylene Chloride	75-09-2	<5.0	5.0	
trans-1,2-Dichloroethene	156-60-5	<5.0	5.0	
Vinyl Acetate	108-05-4	<10.	10.	
1,1-Dichloroethane	75-34-3	<5.0	5.0	
2-Butanone	78-93-3	<10.	10.	
cis-1,2-Dichloroethene	156-59-2	<5.0	5.0	
Chloroform	67-66-3	<5.0	5.0	
1,1,1-Trichloroethane	71-55-6	<5.0	5.0	
Carbon tetrachloride	56-23-5	<5.0	5.0	
1,2-Dichloroethane	107-06-2	<5.0	5.0	
Benzene	71-43-2	54.	5.0	
Trichloroethene	79-01-6	44.	5.0	
1,2-Dichloropropane	78-87-5	<5.0	5.0	
Bromodichloromethane	75-27-4	<5.0	5.0	
2-Chloroethylvinylether	110-75-8	<20.	20.	
4-Methyl-2-Pentanone	108-10-1	<10.	10.	
cis-1,3-Dichloropropene	10061-01-5	<5.0	5.0	
Toluene	108-88-3	49.	5.0	
trans-1,3-Dichloropropene	10061-02-6	<5.0	5.0	
2-Hexanone	591-78-6	<10.	10.	
1,1,2-Trichloroethane	79-00-5	<5.0	5.0	
Tetrachloroethene	127-18-4	<5.0	5.0	
Dibromochloromethane	124-48-1	<5.0	5.0	
Chlorobenzene	108-90-7	54.	5.0	
Ethylbenzene	100-41-4	<5.0	5.0	
m,p-Xylene	1330-20-7	<5.0	5.0	
o-Xylene	95-47-6	<5.0	5.0	
Styrene	100-42-5	<5.0	5.0	
Bromoform	75-25-2	<5.0	5.0	
1,1,2,2-Tetrachloroethane	79-34-5	<5.0	5.0	
1,3-Dichlorobenzene	541-73-1	<5.0	5.0	
1,4-Dichlorobenzene	106-46-7	<5.0	5.0	
1,2-Dichlorobenzene	95-50-1	<5.0	5.0	

LOCKHEED ANALYTICAL SERVICES

MATRIX SPIKE DATA SUMMARY
GC/MS FOR VOLATILE ORGANICS

Client Sample ID: BOGKN7
Date Collected: 23-SEP-95
Date Analyzed: 03-OCT-95

LAL Sample ID: 28098MS
Date Received: 26-SEP-95
Analytical Dilution: 1
Analytical Batch ID: 100295-8260-E2
Preparation Dilution: 1.00

SURROGATE RECOVERY (%)		
		QC Limits
1,2-Dichloroethane-d4	103	84-122
Toluene-d8	104	87-117
Bromofluorobenzene	103	83-118

Constituent	Spike Added ug/L	Sample Concentration ug/L	MS Concentration ug/L	% Recovery	QC Limits
					% Recovery
1,1-Dichloroethene	50.0	0.000	36.8	74	62-124
Benzene	50.0	0.000	48.5	97	68-128
Trichloroethene	50.0	0.000	43.0	86	65-125
Toluene	50.0	0.315	48.8	97	69-129
Chlorobenzene	50.0	0.000	51.6	103	68-128

LOCKHEED ANALYTICAL SERVICES

MATRIX SPIKE DUPLICATE DATA SUMMARY
GC/MS FOR VOLATILE ORGANICS

Client Sample ID:	BOGKN7	LAL Sample ID:	28098MSD
Date Collected:	23-SEP-95	Date Received:	26-SEP-95
Date Analyzed:	03-OCT-95	Analytical Dilution:	1
		Analytical Batch ID:	100295-8260-E2
		Preparation Dilution:	1.00

SURROGATE RECOVERY (%)		
		QC Limits
1,2-Dichloroethane-d4	102	84-122
Toluene-d8	107	87-117
Bromofluorobenzene	105	83-118

Constituent	Spike Added ug/L	MSD Concentration ug/L	% Recovery	RPD	QC Limits	
					RPD	% Recovery
1,1-Dichloroethene	50.0	36.7	73	0	14	62-124
Benzene	50.0	54.3	109	11	11	68-128
Trichloroethene	50.0	43.6	87	2	14	65-125
Toluene	50.0	49.4	98	1	13	69-129
Chlorobenzene	50.0	53.7	107	4	13	68-128

LOCKHEED ANALYTICAL SERVICES

RAD DATA REPORT (ra01)

Bechtel Hanford, Inc. * Richland, WA

Bechtel Hanford Project (Project BECHTEL-HANFORD)

Client Sample ID: BOGKN5

LAL Sample ID: L5440-12

Date Collected: 23-SEP-95

Date Received: 26-SEP-95

Matrix: Water

Login Number: L5440

Constituent	Analyzed	Batch	Activity	Error	NDA	Data Qual	Units
Gross Alpha	11-OCT-95	GR ALP/BETA LAL-0060_27812	2.1	1.6	2.2		pCi/L
Gross Beta	11-OCT-95	GR ALP/BETA LAL-0060_27812	6.5	1.7	2.2		pCi/L
Uranium	06-OCT-95	U TOTAL KPA (INORG)_27889	6.29	0.32	0.63		ug/L

RADIATION RESULTS CHECK REPORT

Workgroup Number: GR ALP/BETA LAL-0060_27812

Sample	Parameter	Value	Error	MDA
27812DUP1	Gross Alpha	0.0146056	2.97087	6.16435
27812LCS1	Gross Alpha	41.0937	4.77935	1.57387
27812MBB1	Gross Alpha	0.700113	0.695432	1.08298
27812MS1	Gross Alpha	82.0275	13.0683	5.8528
L5379-12	Gross Alpha	1.7533	3.20938	5.75075
L5440-12	Gross Alpha	2.05197	1.57114	2.20882
27812DUP1	Gross Beta	10.352	3.48101	4.97015
27812LCS1	Gross Beta	41.9867	3.64313	2.12547
27812MBB1	Gross Beta	0.570641	1.19384	2.03893
27812MS1	Gross Beta	103.728	8.84446	5.14088
L5379-12	Gross Beta	7.94663	3.42358	5.1305
L5440-12	Gross Beta	6.47903	1.65388	2.18383

000075A

INTERDEPARTMENTAL COMMUNICATION

DATE August 08, 1994

TO Document Control DEPT./ ORGN. BLDG./ BLDG 9 ZONE PLANT/ FAC.

FROM Carl Schloesslin DEPT./ 5014 BLDG./ LAS ZONE PLANT/ FAC. EXT. 242

CS

SUBJECT: Tennelec LB4000.1 (LB1) Gross Alpha Calibration

Attached is calibration data of Americium-241 for gross alpha analysis by gas proportional counting. This calibration was performed during July 12-15, 1994 ^{cr 2475} on the LB4000.1 GPC. The results of this calibration is to be put in use beginning August 08, 1994 and continue until a new calibration is performed and approved.

Each calibration standard was counted in each detector long enough to acquire at least 10,000 counts. Data regression techniques were used to produce a quadratic-exponential fit of each detector's attenuation curve (efficiency curve). A normalization factor was determined for each detector to relate each detector to detector A1. Multiplying the efficiency determined from the attenuation curve for detector A1 by the normalization factor for the detector in use produces a result within 1% of the actual efficiency of that detector. Thus, a common absorption curve equation may be used for all detectors. This equation is:

$$\text{Efficiency} = \text{Exp} (11.284 * \text{wt}^2 - 10.158 * \text{wt} - 1.525)$$

The normalization factor determined for each detector is:

A1	1.0000	B1	1.0149	C1	1.0007	D1	1.0087
A2	1.0530	B2	1.0272	C2	0.9871	D2	1.0007
A3	1.0653	B3	1.0521	C3	0.9875	D3	1.0144
A4	1.0710	B4	1.0656	C4	0.9796	D4	1.0145

The alpha into beta crosstalk equation used for each of the detectors is:

$$\text{Crosstalk Factor} = \text{Exp} (21.717 * \text{wt}^2 - 1.612 * \text{wt} - 1.355)$$

This calibration is valid for sample weights of 0.1 mg to 146.7 mg.

A copy of this data package should be kept on file in document control with previous radiochemistry calibrations of the Tennelec LB4000 gas proportional counter for gross alpha analysis.

Approved by:

Russ Stimmel, Supervisor 8/8/94

SECONDARY / WORKING LEVEL STANDARD DILUTION RECORD

NS
7/16/94

Dilution Source Information

Isotope: Am-241

From NIST traceable standard?: YES.

Vendor or Certificate I.D. # of parent standard: [91-0225-60-1] 7/14/94 388-100-1

Diluted source logbook I.D. #: 91-0225-60-1

Balance verification?: ROUTINE CHECK

Diluent used: 0.5 M HCl

Dilution

Diluent: 1 M HCl

Density of diluent (g/ml): NA

a. Parent standard activity: 9,810 Pa/ml

b. Amount of standard transferred: 6.0 ml

c. Total amount of dilution: 50.0 ml

d. Activity of dilution [a * b / c]: 1,177.2 Pa/ml

Dilution logbook I.D. #: LAL-93-106-0474-86

Prepared by: N. Nguyen

Preparation date: 7/7/94

Reviewed by: Joe Hutchinson

Review date: 7/26/94

If the diluent remains unchanged from the diluent used for the dilution source, then a weight dilution of a volume unit source can be performed without a density conversion. If the diluent changes, a weighted proportion density conversion is necessary.

LAL-91-SOP-0174

Continued on Page

Read and Understood By

Signed

Date

Signed

Date

000078

S 1 & Diluted to 10 ml & make 91-0225-60-1 M7WV00

CERTIFICATE OF CALIBRATION ALPHA STANDARD SOLUTION

Radionuclide Am-241
Half Life: 432.7 \pm 0.5 years
Catalog No.: 7241
Source No.: 388-100-1

Customer: LOCKHEED ENGINEERING & SCIENCES Co.
P.O.No.: 06LAB1245
Reference Date: November 1 1991 12:00 PST.
Contained Radioactivity: 0.997 μ Ci.

Description of Solution

a. Mass of solution: 5.0007 grams.
b. Chemical form: AmCl₃ in 0.5N HCl
c. Carrier content: None added
d. Density: 1.0077 gram/ml @ 20°C.

Radioimpurities

None detected

Radioactive Daughters

None detected

Radionuclide Concentration

0.1994 μ Ci/gram.

Method of Calibration

Weighed aliquots of the solution were assayed using a liquid scintillation counter.

Uncertainty of Measurement

a. Systematic uncertainty in instrument calibration: $\pm 2.0\%$
b. Random uncertainty in assay: $\pm 0.7\%$
c. Random uncertainty in weighing(s): $\pm 0.0\%$
d. Total uncertainty at the 99% confidence level: $\pm 2.7\%$

NIST Traceability

This calibration is implicitly traceable to the National Institute of Standards and Technology.

Notes

1. Nuclear data were taken from "Table of Isotopes", Seventh Edition, edited by Virginia S. Shirley.
2. IPL participates in an NIST measurement assurance program to establish and maintain implicit traceability for a number of nuclides, based on the blind assay (and later NIST certification) of Standard Reference Materials. (As in NRC Regulatory Guide 4.15)



ISOTOPE PRODUCTS LABORATORIES
1800 No. Keystone Street.,
Burbank, California 91504
(818) 843 - 7000

Gary A. Wilmore
QUALITY CONTROL

000080

LB4000.1 Am-241 Gross Alpha Calibration Data (Filename gacal193.lb1)

ID	Desc	Count Time	Alpha Counts	Beta Counts	Hi Voltage	Time	Date	CPM Alpha	CPM Beta	EFF Alpha	EFF Beta	Net Weight	A>>B X-Talk	EFF Fit (qd-exp)	X-T Fit (qd-exp)
A1	ACAL01	25	0	24	1417.5	14:06:25	7-12-94	0.00	0.96	0.0000	0.0000	0.0010			
A1	ACAL14	25	12947	4934	1417.5	13:06:32	7-13-94	517.88	197.36	0.1990	0.0755	0.0001	0.3792	0.2173	0.2579
A1	ACAL02	25	14521	3695	1417.5	14:41:54	7-14-94	580.84	147.80	0.2232	0.0564	0.0090	0.2528	0.1987	0.2546
A1	ACAL03	25	11434	2909	1417.5	13:52:40	7-14-94	457.36	116.36	0.1758	0.0444	0.0188	0.2523	0.1804	0.2521
A1	ACAL04	25	11807	3006	1417.5	13:24:15	7-14-94	472.28	120.24	0.1815	0.0458	0.0190	0.2526	0.1801	0.2521
A1	ACAL05	25	9909	2343	1417.5	12:29:47	7-14-94	396.36	93.72	0.1523	0.0356	0.0374	0.2340	0.1512	0.2503
A1	ACAL06	25	8523	2047	1417.5	12:02:21	7-14-94	340.92	81.88	0.1310	0.0311	0.0555	0.2374	0.1282	0.2521
A1	ACAL07	25	7210	1930	1417.5	11:24:13	7-14-94	288.40	77.20	0.1108	0.0293	0.0738	0.2644	0.1093	0.2577
A1	ACAL08	25	7008	1799	1417.5	10:50:44	7-14-94	280.32	71.96	0.1077	0.0273	0.0739	0.2533	0.1092	0.2578
A1	ACAL09	25	5435	1528	1417.5	16:53:15	7-13-94	217.40	61.12	0.0836	0.0231	0.0931	0.2767	0.0932	0.2679
A1	ACAL10	25	5319	1487	1417.5	15:51:27	7-13-94	212.76	59.48	0.0818	0.0225	0.1070	0.2751	0.0835	0.2783
A1	ACAL11	25	4838	1442	1417.5	15:18:33	7-13-94	193.52	57.68	0.0744	0.0218	0.1284	0.2931	0.0711	0.3000
A1	ACAL12	25	5221	1527	1417.5	14:50:59	7-13-94	208.84	61.08	0.0803	0.0231	0.1283	0.2879	0.0712	0.2998
A1	ACAL13	25	3770	1299	1417.5	14:00:15	7-13-94	150.80	51.96	0.0580	0.0196	0.1467	0.3382	0.0625	0.3249

Efficiency Regression Output:

Constant -1.5253
Std Err of Y Est 0.07579
R Squared 0.97426
No. of Observations 13
Degrees of Freedom 10

X-T Regression Output:

Constant -1.3552
Std Err of Y Est 0.0293
R Squared 0.9239
No. of Observations 10
Degrees of Freedom 7

Regressions for all efficiency curves & the A1 crosstalk curve are quadratic exponential fits.

ACAL14, ACAL05, & ACAL06 were not used for the crosstalk curve - poor data points.

X Coefficient(s) -10.1580 11.2837 X Coefficient(s) -1.6119 21.7165
Std Err of Coef. 1.6846 11.3911 Std Err of Coef. 0.8114 5.3127

Am-241 standard is 1.0 mL of LAL-93-LOG-474-86, 2602 dpm/mL on date of calibration.

000081

Sr-90

INITIAL STANDARD DILUTION RECORD

Standard Information:

Isotope:	<u>Sr-90</u>	Vendor:	<u>EPA</u>
Activity of Standard Received:	<u>2.7×10^4 uCi</u>	Vendor I.D. #	<u>94003-1</u>
Weight of Standard Received (g):	<u>50 g</u>	LAL I.D. #:	<u>AC5281</u>
Standard Activity (pCi/g):	<u>5.4×10^3 pCi/g</u>	NIST Traceable ?	<u>yes</u>
Half-life in Years or Days:	<u>28.6 yrs</u>	Certificate #:	<u>94003-1</u>
Reference Date:	<u>4-1-1994</u>	Receiver's Name:	<u>K Free</u>
		Date Received:	<u>5-3-94</u>

Primary Dilution

Balance Verification?:	<u>yes</u>
Diluent Used:	<u>0.1 M HCl</u>
a: Decay Corrected Standard Activity (pCi/g):	<u>5.4×10^3 pCi/g</u>
b: Weight of the Source Transferred (g):	<u>4.9670 g</u>
c: Total diluted weight (g):	<u>49.91 g</u>
d: Total Diluted Volume (mL)	<u>50 mL</u>
e: Activity of Dilution by Weight (pCi/g) [a * b / c]:	<u>537.4 pCi/g</u>
f: Calculated Density of Solution (g/mL) [c / d]:	<u>0.9982 g/mL</u>
g: Activity of Dilution by Volume (pCi/mL) [e * f]:	<u>536.44 pCi/mL</u>
h. Dilution Logbook I.D. #:	<u>93-474-81-1</u>
Prepared By: <u>Dyane Wong</u>	Preparation Date: <u>6-15-94</u>
Reviewed By: <u>Joe Hutchinson</u>	Review Date: <u>6/30/94</u>
Purity/Cross Check Performed By: _____	Check Date: _____

Signed

Date

Signed

Date

000157

RLVD 5/31/94
ACSA
RKS

U.S. Environmental Protection Agency
Environmental Monitoring Systems Laboratory-Las Vegas
Nuclear Radiation Assessment Division

Calibration Certificate

Description

Principal radionuclide **Strontium-90** Half-life **28.6 years**
Nominal activity **27** **nano** curies
Nominal volume **5** ml in ampoule/bottle number **94003-1**

Measurement Activity of principal radionuclide

Activity per gram of this solution

5.40 **nano** curies of **Strontium-90**
at 0400 hours PST on **April 1, 1994**

Activity of daughter radionuclide

The principal activity was accompanied at the quoted time by

5.40 **nano** curies Per gram

of the daughter nuclide **Yttrium-90**

Total mass of this solution

Approximately 5.0 grams

Method of measurement

The activity of the primary solution was measured by liquid scintillation counting.

The activity of the dilution was measured by liquid scintillation counting.

Useful Life

This radionuclide has decayed through **0.0** half lives since it was obtained by EMSL-LV

We recommend that this solution should not be used after

August 1994

This dilution was prepared for the 1994 ASTM Collaborative Study of a test method for the determination of Sr-90 in water.

000158

SOP-LAL-91-0060

Calibration Check

[illegible]

Lowest Recovery = 93% \rightarrow Average Recovery = 98%

run log (✓) maint log (✓) calibration (✓) inst check (✓) inst bkg (✓) MBB () LCS () DUP () calcs (✓)

Date Completed : 8-8-94

Anlst Signature : Carl Schreodlin

Supervisor's Signature :

Remarks

0001594

SECONDARY/WORKING LEVEL
STANDARD DILUTION RECORD

Dilution Source Information

Isotope: Am-241 and Sr-90

Parent Barcode Number: AA0030 AA0046
Am-241 IPL 388-100-1

Vendor or Certificate I.D. # of Parent Standard: Sr-90 NIST SRM 4219G
Am-241 91-0225-60-1

Diluted Source Logbook I.D. #: Sr-90 91-0225-30-2

Balance Verification?: Yes

Diluent Used: 0.1 N HNO₃

Dilution

*Diluent: 0.1 N HNO₃ + 42mg Sr(NO₃)₂/mL

*Density of diluent (g/ml): NA

a: Parent Specific Activity: Am-241 9810 pCi/mL
Sr-90 6000 pCi/mL m 8/1/90

b: Amount of Source Transferred: Am-241 0.5 mL
Sr-90 0.5 mL

c: Total amount of Dilution: 500 $\frac{\text{mL}}{\text{g}}$

d: Total Volume of Dilution: 500 mL

e: Activity of Dilution (a * b / c): NA

f: Activity of Dilution (a * b / d): Am-241 9.81 pCi/mL
Sr-90 12 pCi/mL m 8/1/90

Dilution Logbook I.D. #: 95-721-13-1

Prepared By: Joe HutchinsonPreparation Date: 8/23/95Reviewed By: 97 Ar M. L.Review Date: 8/24/95

*If the diluent remains unchanged from the diluent used for the dilution source, then a weight dilution of a volume unit source can be performed without a density conversion. If the diluent changes, a weighted proportion density conversion is necessary.

Read and Understood By

Signed

Date

Signed

Date

000160

71-0225-69-1 ANX030

CERTIFICATE OF CALIBRATION

ALPHA STANDARD SOLUTION

Radionuclide	Am-241	Customer:	LOCKHEED ENGINEERING & SCIENCES Co.
Half Life:	432.7 \pm 0.5 years	P.O.No.:	06LAB1245
Catalog No.:	7241	Reference Date:	November 1 1991 12:00 PST.
Source No.:	388-100-1	Contained Radioactivity:	0.997 μ Cl.

Description of Solution

a. Mass of solution:	5.0007	grams.
b. Chemical form:	AmCl ₃ in 0.5N HCl	
c. Carrier content:	None added	
d. Density:	1.0077	gram/ml @ 20°C.

Radioimpurities

None detected

Radioactive Daughters

None detected

Radionuclide Concentration

0.1994 μ Cl/gram.

Method of Calibration

Weighed aliquots of the solution were assayed using a liquid scintillation counter.

Uncertainty of Measurement

a. Systematic uncertainty in instrument calibration:	$\pm 2.0\%$
b. Random uncertainty in assay:	$\pm 0.7\%$
c. Random uncertainty in weighing(s):	$\pm 0.0\%$
d. Total uncertainty at the 99% confidence level:	$\pm 2.7\%$

NIST Traceability

This calibration is implicitly traceable to the National Institute of Standards and Technology.

Notes

1. Nuclear data were taken from "Table of Isotopes", Seventh Edition, edited by Virginia S. Shirley.
2. IPL participates in an NIST measurement assurance program to establish and maintain implicit traceability for a number of nuclides, based on the blind assay (and later NIST certification) of Standard Reference Materials. (As in NRC Regulatory Guide 4.15)



ISOTOPE PRODUCTS LABORATORIES
1800 No. Keystone Street.,
Burbank, California 91504
(818) 843 - 7000

Harry A. Gilmore
QUALITY CONTROL

000161



THIS IS A PHOTOCOPY OF THE CERTIFICATE
WHICH IS BEING MAILED TO YOU UNDER
SEPARATE COVER.

HA 0046

National Institute of Standards & Technology

Certificate

Standard Reference Material 4919-G Radioactivity Standard

Radionuclide	Strontium-90
Source identification	4919-G
Source description	Solution in NIST borosilicate-glass ampoule ^{(1)*}
Solution composition	Strontium-90 plus yttrium-90 plus approximately 95 μ g each of non-radioactive strontium and yttrium per gram of 1-molar hydrochloric acid ⁽²⁾
Mass	Approximately 5.0 grams
Radioactivity concentration	4.514×10^3 Bq g ⁻¹
Reference time	1200 EST August 1, 1990
Overall uncertainty	1.05 percent ⁽³⁾
Photon-emitting impurities	None observed ⁽⁴⁾
Alpha-particle-emitting impurities	None observed ⁽⁵⁾
Half life	28.5 ± 0.2 years ⁽⁶⁾
Measuring instrument	4 π β liquid-scintillation counter

This standard reference material was prepared in the Center for Radiation Research, Ionizing Radiation Division, Radioactivity Group, Dale D. Hoppes, Group Leader.

Gaithersburg, MD 20899
January, 1991

William P. Reed, Acting Chief
Office of Standard Reference Materials

*Notes on back

000163

CERTIFICATE OF CALIBRATION ALPHA STANDARD SOLUTION

Radionuclide	Am-241	Customer: LOCKHEED ENGINEERING & SCIENCES Co.
Half Life:	432.7 \pm 0.5 years	P.O.No.: 06LAB1245
Catalog No.:	7241	Reference Date: November 1 1991 12:00 PST.
Source No.:	388-100-1	Contained Radioactivity: 0.997 μ Cl.

Description of Solution

a. Mass of solution:	5.0007
b. Chemical form:	AmCl ₃ in 0.5N HCl
c. Carrier content:	None added
d. Density:	1.0077

gram/ml @ 20°C.

Radioimpurities

None detected

Radioactive Daughters

None detected

Radionuclide Concentration

0.1994

μ Cl/gram.

Method of Calibration

Weighed aliquots of the solution were assayed using a liquid scintillation counter.

Uncertainty of Measurement

a. Systematic uncertainty in instrument calibration:	±2.0%
b. Random uncertainty in assay:	±0.7%
c. Random uncertainty in weighing(s):	±0.0%
d. Total uncertainty at the 99% confidence level:	±2.7%

NIST Traceability

This calibration is implicitly traceable to the National Institute of Standards and Technology.

Notes

1. Nuclear data were taken from "Table of Isotopes", Seventh Edition, edited by Virginia S. Shirley.
2. IPL participates in an NIST measurement assurance program to establish and maintain implicit traceability for a number of nuclides, based on the blind assay (and later NIST certification) of Standard Reference Materials. (As in NRC Regulatory Guide 4.15)



ISOTOPE PRODUCTS LABORATORIES
1800 No. Keystone Street.,
Burbank, California 91504
(818) 843 - 7000

Stan A. Milmore
QUALITY CONTROL

20.4 5/31/77
AC5881
RIS

U.S. Environmental Protection Agency
Environmental Monitoring Systems Laboratory-Las Vegas
Nuclear Radiation Assessment Division

Calibration Certificate

Description	Principal radionuclide	Strontium-90	Half-life	28.6 years
	Nominal activity	27 nano curies		
	Nominal volume	5 ml in ampoule/bottle number	94003-1	

Measurement Activity of principal radionuclide

Activity per gram of this solution

5.40	nano curies	of	Strontium-90
		at 0400 hours PST on	April 1, 1994

Activity of daughter radionuclide

The principal activity was accompanied at the quoted time by

5.40	nano curies	Per gram
of the daughter nuclide	Yttrium-90	

Total mass of this solution

Approximately 5.0 grams

Method of measurement

The activity of the primary solution was measured by liquid scintillation counting.

The activity of the dilution was measured by liquid scintillation counting.

Useful Life

This radionuclide has decayed through 0.0 half lives since it was obtained by EMSL-LV

We recommend that this solution should not be used after

August 1994

This dilution was prepared for the 1994 ASTM Collaborative Study of a test method for the determination of Sr-90 in water.

000169

C57 300

Purity

The manufacturer states that activities other than that of the principal nuclide and of its daughter nuclides, if any, were estimated/known to be.

(1) <input type="text"/>	less than equal to <input type="text"/> %	of the principal activity
(2) <input type="text"/>	less than equal to <input type="text"/> %	of the principal activity
(3) <input type="text"/>	less than equal to <input type="text"/> %	of the principal activity

The activity of impurity (1) is not (2) is not (3) is not included in the quoted figures of the principal activity.

Random Errors

The precision of this standard was such that the certified value of the radioactive concentration of the principal activity had a standard error (sm) not greater than $\pm 0.1\%$ (The 99.7% confidence limits are given by $t(sm)$ where t is obtained from the student t factor for the degree of freedom ($n-1$)).

The maximum uncertainty due to the assessable systematic errors (dilution, counting, and known uncertainty of the standard) is obtained by the separate arithmetic summation of the positive and negative systematic error ($+\delta - \delta'$). These have been estimated not to exceed

$+3.8\%$ or -3.8%

the overall uncertainty (often called accuracy) is an estimate of the possible divergence of the quoted result from the true value. It is a combination of random error $[t(sm)]$ at the 99.7% confidence limits and the worst case estimate of the systematic errors ($+\delta, -\delta'$)

The overall uncertainty is therefore calculated on the basis of $+ [t(sm) + \delta], - [t(sm) + \delta']$ and is $+4.0\%$, -4.0% of the quoted radioactive concentration.

Decay Schemes

This standardization is based on the following assumptions of the principle nuclide, its daughter nuclides and impurities (no allowance for error in these assumptions or the assumption of quoted half-life have been included in the statement of accuracy above).

Strontium-90 decays 100 percent by beta emission to yttrium-90. Yttrium-90 also decays 100 percent by beta emission.

**Chemical
Composition
of Solution**

Carrier content per gram of solution:

30 micrograms strontium

Other components:

0.1 M HCl

Preservative:

Remarks

Date Certificate Prepared

April 26, 1994

Approval Signature

Paul B. Fahn

INITIAL STANDARD DILUTION RECORD

Standard Information:

Isotope:

Sr-90

Vendor:

EPA

Activity of Standard Received:

 2.7×10^4 uCi

Vendor I.D. #

94003-1

Weight of Standard Received (g):

5.0 g

LAL I.D. #:

AC5281

Standard Activity (pCi/g):

 5.4×10^3 pCi/g

NIST Traceable ?

yes

Half-life in Years or Days:

28.6 yrs

Certificate #:

94003-1

Reference Date:

4-1-1994

Receiver's Name:

K. Free

Date Received:

5-3-94

Primary Dilution

Balance Verification?:

yes

Diluent Used:

0.1M HCl

a: Decay Corrected Standard Activity (pCi/g):

 5.4×10^3 pCi/g

b: Weight of the Source Transferred (g):

4.9670 g

c: Total diluted weight (g):

49.91 g

d: Total Diluted Volume (mL)

50 mL

e: Activity of Dilution by Weight (pCi/g) [a * b / c]:

537.4 pCi/g

f: Calculated Density of Solution (g/mL) [c / d]:

0.9982 g/mL

g: Activity of Dilution by Volume (pCi/mL) [e * f]:

536.44 pCi/mL

h: Dilution Logbook I.D. #:

93-474-82-1
93-474-81-1 CP 4/7/95Prepared By: Dyane Wong

Preparation Date:

6-15-94Reviewed By: Joe Hutchinson

Review Date:

6/30/94

Purity/Cross Check Performed By: _____

Check Date: _____

000171

Signed

Date

Signed

Date