

0069110

SAF-RC-001
Industrial Hygiene Sampling
FINAL DATA

NO DISTRIBUTION REQUIRED

COMMENTS:

SDG 06I-0215-01 SAF-RC-001

Rad only ☒ Chem only Rad & Chem

☒ Complete Partial

300 Area 334 Trench

RECEIVED
MAR 21 2006
EDMC



Cover Page

Page 1 of 7



Report Identification Number: 06I-0215-01
Subcontract Number: 0000X-BO-G0058-B-Mod#4
Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby
Laboratory Identification Number: DCHM
SAF#: RC-001 / R33400 J452
Payroll#: 72520

Sample Information

Sample Date	Customer Sample Number	Laboratory Sample Number	Method	Analytical Batch Identification	Sample Matrix
19 Jan 2006	J10XH3	06I01777	NMAM 7300M	G060M00P	G WIPE
19 Jan 2006	J10XH4	06I01778	NMAM 7300M	G060M00P	G WIPE
19 Jan 2006	J10XH5	06I01779	NMAM 7300M	G060M00P	G WIPE
19 Jan 2006	J10XH6	06I01780	NMAM 7300M	G060M00P	G WIPE
19 Jan 2006	J10XH7	06I01781	NMAM 7300M	G060M00P	G WIPE

I certify that this electronic image and all hardcopies produced from this image accurately represent the data and are in compliance with the contract specific requirements, both technically and for completeness, other than the conditions detailed above or in the sample data package narrative. Release, by submission through email, the data contained in this electronic image and the computer-readable EDD (as applicable), has been authorized by the laboratory Manager or the Manager's designee.

Name: Lisa M. Reid
Title: Chemist
Date: January 23, 2006



Case Narrative Page

Page 2 of 7

Report Identification Number: 06I-0215-01
Subcontract Number: 0000X-BO-G0058-B-Mod#4
Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby
Laboratory Identification Number: DCHM
SAF#: RC-001 / R33400 J452
Payroll#: 72520

General Set Information: There are 5 samples in set 06I-0213-02, 4 samples in set 06I-0214-01 and 5 samples in set 06I-0215-01. The samples were analyzed for cadmium, lead and beryllium on Ghost Wipe. No problems were encountered with the receipt of these samples and no contact with the CTR was required.

Method Summary: Samples were transferred to 50 ml centrifuge tubes and digested in the presence of 5 mL of nitric acid and 5 mL of ASTM Type II water. Samples were digested in a hot block set at 110°C for 60 minutes. Samples were then diluted to a 25 mL volume with ASTM Type II Water. Samples were shaken and delivered for ICP analysis.

Sample Preparation: All samples were prepared in accordance with DCL SOP "IH-AN-021" and NIOSH method NMAM 7300 modified for hot block digestion.

Holding Times: The holding times were met for both sample preparation and analysis.

Instrument Calibration: Instrument calibration was performed in accordance with NIOSH method NMAM 7300.

Initial and Continuing Calibration Verification Analysis: Beryllium, cadmium and lead recoveries in all Initial Calibration Verification (ICV) and Continuing Calibration Verification (CCV) samples are within the quality control limits of +/- 10%.

Initial and Continuing Calibration Blank Analysis: No beryllium results were found in the Initial Calibration Blank (ICB) or Continuing Calibration Blanks (CCB) at levels above the Contract Required Detection Limits (CRDL) of 0.01 ug/sample. No cadmium results were found in the Initial Calibration Blank (ICB) or Continuing Calibration Blanks (CCB) at levels above the Contract Required Detection Limits (CRDL) of 0.1 ug/sample. No lead results were found in the Initial Calibration Blank (ICB) or Continuing Calibration Blanks (CCB) at levels above the Contract Required Detection Limits (CRDL) of 3. ug/sample.

Method Blank Analysis: No beryllium, cadmium or lead was found in any of the media blank samples above the Contract Required Detection Limit (CRDL).

Dilution(s): None.

Laboratory Control Sample and Duplicate Analysis: One Laboratory Control Sample (LCS) and one Laboratory Control Sample Duplicate (LCSD) were prepared and analyzed with the sample batch. The LCS results were within the control limits of +/- 20%. The Relative Percent Difference (RPD) between the LCS and the LCSD were within the control limit of 20%.

Replicate Analysis: Two samples in this batch were replicated. The RPD between the samples and the replicates was within the control limit of 20%. If the result of the sample or replicate is below the CRDL, replicate analysis is negligible.

Flagging Codes: None

Nonconformance/Corrective Action Report (NC/CAR): N/A

Sample Calculation: The final results are calculated by the following equation:
Final result for aqueous samples ($\mu\text{g}/\text{sample}$) = (A) x (B) x (C)

Where:

A = Analyte concentration from instrument determination ($\mu\text{g}/\text{L}$)

B = Concentration factor from sample preparation

= $\frac{\text{Final Volume of Digestate (L)}}{\text{Sample}}$

C = Dilution performed at time of analysis

Example Calculation: $(1 \mu\text{g}/\text{L}) \times (0.025 \text{ L}/\text{sample}) \times (1) = 0.025 \mu\text{g}/\text{sample}$

Miscellaneous Comments: None



Report Page

Page 4 of 7

Report Identification Number: 06I-0215-01

Subcontract Number: 0000X-BO-G0058-B-Mod#4

Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby

Laboratory Identification Number: DCHM

SAF#: RC-001 / R33400 J452

Payroll#: 72520

Customer Sample Number	Laboratory Sample Number	Date Analyzed	Beryllium µg/sample		Cadmium µg/sample		Lead µg/sample	
J10XH3	06I01777	20 Jan 2006	<0.01	U	<0.1	U	<3.	U
J10XH4	06I01778	20 Jan 2006	<0.01	U	<0.1	U	<3.	U
J10XH5	06I01779	20 Jan 2006	<0.01	U	<0.1	U	<3.	U
J10XH6	06I01780	20 Jan 2006	<0.01	U	<0.1	U	<3.	U
J10XH7	06I01781	20 Jan 2006	<0.01	U	<0.1	U	<3.	U
Limit of Detection (LOD)			0.01		0.1		3.	
Required Detection Limit (RDL)								

U - Parameter not detected above LOD.

J - Parameter between LOD and RDL.



QC Summary Page

Page 5 of 7

Report Identification Number: 06I-0215-01
Subcontract Number: 0000X-BO-G0058-B-Mod#4
Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby
Laboratory Identification Number: DCHM
SAF: RC-001 / R33400 J452
Payroll#: 72520

Batch ID: G060M00P

QC Sample ID	QC Type	Analyte	Units	Result	Parent Result	Target	Percent Rec.	Relative Percent Diff.
BL-240257-1	MB	Beryllium	µg/sample	ND	NA	NA	NA	NA
BL-240257-1	MB	Cadmium	µg/sample	ND	NA	NA	NA	NA
BL-240257-1	MB	Lead	µg/sample	ND	NA	NA	NA	NA
QC-240257-1	LCS	Beryllium	µg/sample	11.4	NA	10.0	114.	NA
QC-240257-1	LCS	Cadmium	µg/sample	33.9	NA	30.0	113.	NA
QC-240257-1	LCS	Lead	µg/sample	106.	NA	100.	106.	NA
QD-240257-1	LCSD	Beryllium	µg/sample	11.4	11.4	10.0	114.	0.0868
QD-240257-1	LCSD	Cadmium	µg/sample	33.5	33.9	30.0	112.	1.14
QD-240257-1	LCSD	Lead	µg/sample	105.	106.	100.	105.	0.956

MB - Method Blank

LCS - Laboratory Control Sample

LCSD - Laboratory Control Sample Duplicate

MS - Matrix Spike

MSD - Matrix Spike Duplicate

LD - Laboratory Duplicate

NA - Not Applicable

ND - Parameter not detected above LOD

$LCS, LCSD \text{ Percent Rec.} = (\text{Result} / \text{Target}) * 100.0$

$MS, MSD \text{ Percent Rec.} = ((\text{Result} - \text{Parent}) / \text{Target}) * 100.0$

$LCS, LCSD \text{ Relative Percent Diff.} = ((|\text{LCS} - \text{LCSD}|) / ((\text{LCS} + \text{LCSD})/2.0)) * 100.$

$MS, MSD \text{ Relative Percent Diff.} = ((|\text{MS} - \text{MSD}|) / ((\text{MS} + \text{MSD})/2.0)) * 100.$

$LD \text{ Relative Percent Diff.} = ((|\text{Parent} - \text{LD}|) / ((\text{Parent} + \text{LD})/2.0)) * 100$

0215.01



CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST

Collector: CJ Williams		Company Contact Denise A. Pitts and Henry W. Ruby		Telephone No. 531-1229		Project Coordinator Joan H. Kessner		Data Turnaround 24 hrs	
Payroll #: 72520		Sampling Location 300 area/334 trench		SPECIAL INSTRUCTIONS All relevant COAs must be provided: R 334 00 3452		SAF No. RC-001		Method of Shipment Fed Ex	
Type of Sample: Wipe		Wipe Sample Media: Ghost <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No Other _____		ANALYSIS METHOD (SPECIFIC): N105H 7300		Bill of Lading/Air Bill No. 8541 9337 5340			
Shipped To: Data Chem Salt Lake City UT		POSSIBLE SAMPLE HAZARD/REMARKS N/A		MATRIX A - AIR WI - WIPE X - OTHER		Preservation (i.e., cooling required, etc.)		No No No No No No No No	
Special Handling and/or Storage Be Cd/Pb									

SAMPLE ANALYSIS				Ashes/Airborne	Lead Airborne	Beryllium Airborne	Beryllium Wipe	Mold	Lead Wipe	Cd Wipe	Cd Airborne
SAMPLE NO.	MATRIX	SAMPLE DATE	VOLUME (L) or Area _____ cm ²	Comments							
J10xH3	WI	1-19-06	100 cm ²				X		X	X	
J6xH4	↑	↑	100 cm ²				X		X	X	
J10xH5	↓	↓	100 cm ²				X		X	X	
J10xH6	↓	↓	Blanks				X		X	X	
J10xH7	WI	1-19-06	Blanks				X		X	X	

Enter on line below the first Sample Number from Page One:

CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST			
SIGN / PRINT NAMES / USE MILITARY TIME			
Received By/Sign:	DATE / TIME	Received By/Sign:	DATE / TIME
CJ Williams	1-19-06 / 1450	3746 Bldg Rm 16 Locked cabinet	1-19-06 / 1450
Cynthia Williams	1-19-06 / 1515	3746 Bldg Rm 16 Locked Cabinet	1-19-06 / 1515
John Peoples	1-19-06 / 1515	RZ Steffler R. J. Steffler	1-19-06 / 1515
RZ Steffler R. J. Steffler	1-19-06 / 1530	Fed Ex	
Fed Ex		Meredith Edwards	2/2/06 / 1000
Meredith Edwards	2/2/06 / 1000		
LABORATORY SECTION	Received By	Title	DATE / TIME
	Meredith Edwards		2/2/06 / 1000

REVIEWED BY: _____ DATE: _____

PRINT/SIGN NAME

CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST

Collector: <i>CJ Williams</i>	Company Contact Denise A. Pitts and Henry W. Ruby		Telephone No. 531-1229	Project Coordinator Joan H. Kessner	Data Turnaround <i>24 hrs</i>
Payroll #: <i>72520</i>	Sampling Location <i>300 area / 334 trench</i>	SPECIAL INSTRUCTIONS All relevant COAs must be provided: <i>R 334 00 3452</i> ANALYSIS METHOD (SPECIFIC): <i>N105H 7300</i>		SAF No. RC-001	
Type of Sample: <i>wipes</i>				Method of Shipment <i>Fed Ex</i>	
Shipped To: <i>Data Chem Salt Lake City UT</i>	Wipe Sample Media: Ghost <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No Other _____			Bill of Lading/Air Bill No. <i>8541 9337 5340</i>	

POSSIBLE SAMPLE HAZARD/REMARKS N/A	MATRIX A - AIR WI - WIPE X - OTHER	Preservation (i.e., cooling required, etc.)	No	No	No	No	No	No	No	No	No
Special Handling and/or Storage Be/Cd/Pb											

SAMPLE ANALYSIS					Asbestos Airborne	Lead Airborne	Beryllium Airborne	Beryllium Wipe	Mold	Lead Wipe	Cd Wipe	Cd Airborne
SAMPLE NO.	MATRIX	SAMPLE DATE	VOLUME (L) or Area _____ cm ²	Comments								
J10xH3	WI	1-19-06	100 cm ²	CJW 1-19-06				X		X	X	CJW 1-19-06
J10xH4	↑	↑	100 cm ²					X		X	X	
J10xH5	↓	↓	100 cm ²					X		X	X	
J10xH6	↓	↓	Blanks					X		X	X	
J10xH7	WI	1-19-06	Blanks					X		X	X	

COPY

CJW
1-19-06

FIELD SAMPLE COPY

Enter on line below the first Sample Number from Page One:

CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST

SIGN / PRINT NAMES / USE MILITARY TIME

<p>Relinquished By/Stored: <i>CJ Williams</i> DATE / TIME: <i>1-19-06 / 1450</i></p>	<p>Received By/Stored: <i>3746 Bldg Rm 16 locked cabinet</i> DATE / TIME: <i>1-19-06 / 1450</i></p>
<p>Relinquished By/Stored: <i>3746 Bldg Rm 16 locked cabinet</i> DATE / TIME: <i>1-19-06 / 1515</i></p>	<p>Received By/Stored: <i>John Peoples</i> DATE / TIME: <i>1-19-06 / 1515</i></p>
<p>Relinquished By/Stored: <i>John Peoples</i> DATE / TIME: <i>1-19-06 / 1515</i></p>	<p>Received By/Stored: <i>RZ Steffler R.Z. Steffler</i> DATE / TIME: <i>1-19-06 / 1515</i></p>
<p>Relinquished By/Stored: <i>RZ Steffler R.Z. Steffler</i> DATE / TIME: <i>1-19-06 / 1515</i></p>	<p>Received By/Stored: <i>Fed Ex</i> DATE / TIME: <i></i></p>
<p>Relinquished By/Stored: <i></i> DATE / TIME: <i></i></p>	<p>Received By/Stored: <i></i> DATE / TIME: <i></i></p>
<p>Relinquished By/Stored: <i></i> DATE / TIME: <i></i></p>	<p>Received By/Stored: <i></i> DATE / TIME: <i></i></p>
<p>Relinquished By/Stored: <i></i> DATE / TIME: <i></i></p>	<p>Received By/Stored: <i></i> DATE / TIME: <i></i></p>
<p>Relinquished By/Stored: <i></i> DATE / TIME: <i></i></p>	<p>Received By/Stored: <i></i> DATE / TIME: <i></i></p>

COPY

LABORATORY SECTION	Received By	Title	DATE / TIME
---------------------------	-------------	-------	-------------

REVIEWED BY: _____ DATE: _____
 PRINT/SIGN NAME