

SAF-RC-001
Industrial Hygiene Sampling
FINAL DATA

NO DISTRIBUTION REQUIRED

COMMENTS:

SDG 06I-0474-01 SAF-RC-001

Rad only ☒ Chem only Rad & Chem

☒ Complete Partial

300 Area 333 Bldg

RECEIVED
MAY 3 4 2006
EDMC



Cover Page

Page 1 of 8



Report Identification Number: 06I-0474-01
Subcontract Number: 0000X-BO-G0058-B-Mod#4
Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby
Laboratory Identification Number: DCHM
SAF#: RC-001 / R371202000
Payroll#: 72570

Sample Information

Sample Date	Customer Sample Number	Laboratory Sample Number	Method	Analytical Batch Identification	Sample Matrix
02 Feb 2006	J11377	06I03786	NMAM 7300M	G061600L	MCE
02 Feb 2006	J11378	06I03787	NMAM 7300M	G061600L	MCE
02 Feb 2006	J11379	06I03788	NMAM 7300M	G061600L	MCE
02 Feb 2006	J11375	06I03789	NMAM 7300M	G061600L	MCE
02 Feb 2006	J11376	06I03790	NMAM 7300M	G061600L	MCE

I certify that this electronic image and all hardcopies produced from this image accurately represent the data and are in compliance with the contract specific requirements, both technically and for completeness, other than the conditions detailed above or in the sample data package narrative. Release, by submission through email, the data contained in this electronic image and the computer-readable EDD (as applicable), has been authorized by the laboratory Manager or the Manager's designee.

Name: Lisa M. Reid
Title: Chemist
Date: February 08, 2006

Report Identification Number: 06I-0474-01
Subcontract Number: 0000X-BO-G0058-B-Mod#4
Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby
Laboratory Identification Number: DCHM
SAF#: RC-001 / R371202000
Payroll#: 72570

General Set Information: There are 5 samples in set 06I-0474-01 which were analyzed for beryllium, lead and cadmium on MCE filter. No problems were encountered with the receipt of these samples and no contact with the CTR was required.

Method Summary: Samples were transferred to 50 ml centrifuge tubes and digested in the presence of 10 mL of 1:1 (v/v) nitric acid. Samples were digested in a hot block set at 110°C for 40 minutes. Samples were then diluted to a 25 mL volume with ASTM Type II Water. Samples were shaken and delivered for ICP analysis.

Sample Preparation: All samples were prepared in accordance with DCL SOP "IH-AN-021" and NIOSH method NMAM 7300 modified for hot block digestion.

Holding Times: The holding times were met for both sample preparation and analysis.

Instrument Calibration: Instrument calibration was performed in accordance with NIOSH method NMAM 7300.

Initial and Continuing Calibration Verification Analysis: Beryllium, cadmium and lead recoveries in all Initial Calibration Verification (ICV) and Continuing Calibration Verification (CCV) samples are within the quality control limits of +/- 10%.

Initial and Continuing Calibration Blank Analysis: No beryllium results were found in the Initial Calibration Blank (ICB) or Continuing Calibration Blanks (CCB) at levels above the Limit of Quantitation (LOQ) of 0.02 ug/sample. No cadmium results were found in the Initial Calibration Blank (ICB) or Continuing Calibration Blanks (CCB) at levels above the Limit of Quantitation (LOQ) of 0.06 ug/sample. No lead results were found in the Initial Calibration Blank (ICB) or Continuing Calibration Blanks (CCB) at levels above the Limit of Quantitation (LOQ) of 0.5 ug/sample.

Method Blank Analysis: No beryllium, cadmium or lead was found in the media blank sample above the Contract Required Detection Limit (CRDL).

Dilution(s): NA.

Laboratory Control Sample and Duplicate Analysis: One Laboratory Control Sample (LCS) and one Laboratory Control Sample Duplicate (LCSD) were prepared and analyzed with the sample batch. The LCS result was within the control limit of +/- 20%. The Relative Percent Differences (RPD) between the LCS and the LCSD was within the control limit of 20%.

Replicate Analysis: One sample was replicated with this analysis run. The RPD between the sample and the replicate was within the control limit of 20%. If the result of the sample or replicate is below the CRDL, replicate analysis is negligible.

Flagging Codes: None

Nonconformance/Corrective Action Report (NC/CAR): N/A

Sample Calculation: The final results are calculated by the following equation:

Final result for aqueous samples ($\mu\text{g}/\text{sample}$) = (A) x (B) x (C)

Where:

A = Analyte concentration from instrument determination ($\mu\text{g}/\text{L}$)

B = Concentration factor from sample preparation

= $\frac{\text{Final Volume of Digestate (L)}}{\text{Sample}}$

C = Dilution performed at time of analysis

Example Calculation: $(1 \mu\text{g}/\text{L}) \times (0.025 \text{ L}/\text{sample}) \times (1) = 0.025 \mu\text{g}/\text{sample}$

Miscellaneous Comments: None.

Report Identification Number: 06I-0474-01

Subcontract Number: 0000X-BO-G0058-B-Mod#4

Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby

Laboratory Identification Number: DCHM

SAF#: RC-001 / R371202000

Payroll#: 72570

Customer Sample Number	Laboratory Sample Number	Date Analyzed	Beryllium $\mu\text{g}/\text{sample}$		Beryllium $\mu\text{g}/\text{m}^3$		Air Volume L	
J11377	06I03786	07 Feb 2006	<0.02	U	<0.096	U	209.	
J11378	06I03787	07 Feb 2006	<0.02	U	<0.052	U	382.	
J11379	06I03788	07 Feb 2006	<0.02	U	<0.051	U	390.	
J11375	06I03789	07 Feb 2006	<0.02	U	**		0.00	
J11376	06I03790	07 Feb 2006	<0.02	U	**		0.00	
Limit of Detection (LOD)			0.02					
Required Detection Limit (RDL)								

Customer Sample Number	Laboratory Sample Number	Date Analyzed	Lead $\mu\text{g}/\text{sample}$		Lead $\mu\text{g}/\text{m}^3$		Cadmium $\mu\text{g}/\text{sample}$	
J11377	06I03786	07 Feb 2006	2.5		12.		0.14	
J11378	06I03787	07 Feb 2006	0.71		1.9		<0.06	U
J11379	06I03788	07 Feb 2006	<0.5	U	<1.3	U	<0.06	U
J11375	06I03789	07 Feb 2006	<0.5	U	**		<0.06	U
J11376	06I03790	07 Feb 2006	<0.5	U	**		<0.06	U
Limit of Detection (LOD)			0.5				0.06	
Required Detection Limit (RDL)								

Customer Sample Number	Laboratory Sample Number	Date Analyzed	Cadmium $\mu\text{g}/\text{m}^3$	
J11377	06I03786	07 Feb 2006	0.67	
J11378	06I03787	07 Feb 2006	<0.16	U
J11379	06I03788	07 Feb 2006	<0.15	U
J11375	06I03789	07 Feb 2006	**	
J11376	06I03790	07 Feb 2006	**	
Limit of Detection (LOD)				
Required Detection Limit (RDL)				



Report Page

Page 5 of 8

U - Parameter not detected above LOD.

J - Parameter between LOD and RDL.



QC Summary Page

Page 6 of 8

Report Identification Number: 06I-0474-01
Subcontract Number: 0000X-BO-G0058-B-Mod#4
Name of Industrial Hygienist: Denise A. Pitts / Henry W. Ruby
Laboratory Identification Number: DCHM
SAF: RC-001 / R371202000
Payroll#: 72570

Batch ID: G061600L

QC Sample ID	QC Type	Analyte	Units	Result	Parent Result	Target	Percent Rec.	Relative Percent Diff.
BL-241016-1	MB	Beryllium	µg/sample	ND	NA	NA	NA	NA
BL-241016-1	MB	Lead	µg/sample	ND	NA	NA	NA	NA
BL-241016-1	MB	Cadmium	µg/sample	ND	NA	NA	NA	NA
QC-241016-1	LCS	Beryllium	µg/sample	10.5	NA	10.0	105.	NA
QC-241016-1	LCS	Lead	µg/sample	102.	NA	100.	102.	NA
QC-241016-1	LCS	Cadmium	µg/sample	31.2	NA	30.0	104.	NA
QD-241016-1	LCSD	Beryllium	µg/sample	10.5	10.5	10.0	105.	0.0666
QD-241016-1	LCSD	Lead	µg/sample	104.	102.	100.	104.	1.31
QD-241016-1	LCSD	Cadmium	µg/sample	31.5	31.2	30.0	105.	1.08

MB - Method Blank

LCS - Laboratory Control Sample

LCSD - Laboratory Control Sample Duplicate

MS - Matrix Spike

MSD - Matrix Spike Duplicate

LD - Laboratory Duplicate

NA - Not Applicable

ND - Parameter not detected above LOD

$LCS, LCSD \text{ Percent Rec.} = (\text{Result} / \text{Target}) * 100.0$

$MS, MSD \text{ Percent Rec.} = ((\text{Result} - \text{Parent}) / \text{Target}) * 100.0$

$LCS, LCSD \text{ Relative Percent Diff.} = ((|LCS - LCSD|) / ((LCS + LCSD)/2.0)) * 100.$

$MS, MSD \text{ Relative Percent Diff.} = ((|MS - MSD|) / ((MS + MSD)/2.0)) * 100.$

$LD \text{ Relative Percent Diff.} = ((|Parent - LD|) / ((Parent + LD)/2.0)) * 100$

CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST											
Company Contact		Telephone No.		Project Coordinator		Data Turnaround					
Desiree A. Pitts and Henry W. Ruby		531-1229		Joan H. Kessner		24 hrs					
Sampling Location		SPECIAL INSTRUCTIONS		SAF No.		Method of Shipment					
300 area/333 B106		All relevant COAs must be provided: Q37170 7000 ANALYSIS METHOD (SPECIFIC): N10SIN 7300		RC-001		Fed Ex					
Wipe Sample Media:		Preservation (i.e., cooling required, etc.)		Bill of Lading/Air Bill No.							
Glove <input type="checkbox"/> Yes <input type="checkbox"/> No				8544 9435 4737							
Other											
MATRIX											
A - AIR											
W1 - WPE											
X - OTHER											
SAMPLE ANALYSIS											
SAMPLE NO.	MATRIX	SAMPLE DATE	VOLUME (L) or Area (sq ft)	Adhesive Ashtray	Lead Ashtray	Beryllium Ashtray	Beryllium Wipe	Mold	Lead Wipe	Cd Wipe	No
J11377	A	2-2-06	209	X	X	X	X	No	No	Cd Ashtray	No
J11378	↑	2-2-06	382	X	X	X	X	No	No	Cd Wipe	No
J11379	↓	2-2-06	390	X	X	X	X	No	No	Lead Wipe	No
J11375	↓	2-2-06	N/A	X	X	X	X	No	No	Mold	No
J11376	A	2-2-06	N/A	X	X	X	X	No	No	Lead Wipe	No

(5002/65780) 20c-HS-H2M

Page 1 of 2

Page 2 of 2



CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST

Collector: CJ Williams	Company Contact Denise A. Pitts and Henry W. Ruby	Telephone No. 531-1229	Project Coordinator Joan H. Kessner	Data Turnaround 24 hrs								
Payroll #: 72520	Sampling Location 300 area/333 B106	SPECIAL INSTRUCTIONS All relevant COAs must be provided: 837120 2000 ANALYSIS METHOD (SPECIFIC): NIOSH 7300		SAF No. RC-001								
Type of Sample: Personal	Wipe Sample Media: Ghost <input type="checkbox"/> Yes <input type="checkbox"/> No Other _____	Method of Shipment Fed Ex										
Shipped To: Datachem Salt Lake City UT	Bill of Lading/Air Bill No. 8544 9435 4737											
POSSIBLE SAMPLE HAZARD/REMARKS Be/Cd/Pb	MATRIX A - AIR WI - WIPE X - OTHER	Preservation (i.e., cooling required, etc.)	No	No	No	No	No	No	No	No		
Special Handling and/or Storage Nla			Asbestos Airborne	Lead Airborne	Beryllium Airborne	Beryllium Wipe	Mold	Lead Wipe	Cd Wipe	Cd Airborne		
SAMPLE NO.	MATRIX	SAMPLE DATE	VOLUME (L) or Area ____ cm ²	Comments	Asbestos Airborne	Lead Airborne	Beryllium Airborne	Beryllium Wipe	Mold	Lead Wipe	Cd Wipe	Cd Airborne
J11377	A	2-2-06	209			X	X				X	
J11378			382			X	X				X	
J11379			390			X	X				X	
J11375			Nla			X	X				X	
J11376	A	2-2-06	Nla			X	X				X	

COPY
FIELD SAMPLE COPY

Enter on line below the first Sample Number from Page One:

J11377

CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST

SIGN / PRINT NAMES / USE MILITARY TIME

Relinquished By/Stored:	DATE / TIME:	Received By/Stored:	DATE / TIME:
Cynthia Williams / Cynthia Williams	2-2-06 / 1430	3746 Bldg Rm 16 locked cabinet	2-2-06 / 1430
locked cabinet bldg 3746 Rm #16			
Goldie Malhan	02-06-06 / 1500	RZ Steffler R. J. Steffler	2-6-06 / 1500
RZ Steffler R. J. Steffler	wch 2-6-06 / 1600	Fed Ex	
LABORATORY SECTION	Received By	Title	DATE / TIME

REVIEWED BY: _____ DATE: _____
 PRINT/SIGN NAME