



RECEIVED AUGUST 1, 2008

**EBERLINE**  
SERVICES

0080319

EBERLINE ANALYTICAL CORPORATION  
2030 Wright Avenue  
Richmond, California 94804-3849  
Phone (510) 235-2633 Fax (510) 235-9438  
Toll Free (800) 841-5487  
www.eberlineservices.com

August 1, 2008

Mr. Steve Trent  
Fluor Hanford Inc.  
1200 Jadwin Avenue  
Richland, WA 99352

Reference: P.O. #33677 ✓  
Eberline Services R8-06-086-7116, SDG H3767

Dear Mr. Trent:

Enclosed is the data report for one solid (soil) sample designated under SAF No. F08-045 received at Eberline Services on June 11, 2008. The sample was analyzed according to the accompanying chain-of-custody document.

Please call if you have any questions concerning this report.

Sincerely,

Melissa C. Mannion  
Senior Program Manager

MCM/njv

Enclosure: Data Package

RECEIVED  
FEB 19 2009  
EDMC

**1.0 GENERAL**

Fluor Hanford Inc. (FH) Sample Delivery Group H3767 was composed of one solid (soil) sample designated under SAF No. F08-045 with a Project Designation of: 200-UP-1 OU Monitoring Wells-Waste Designation.

The sample was received as stated on the Chain-of-Custody document. Any discrepancies are noted on the Eberline Services Sample Receipt Checklist.

**2.0 ANALYSIS NOTES**

**2.2 Carbon-14 Analysis**

No problems were encountered during the course of the analyses.

**2.4 Technetium-99 Analysis**

The Tc-99m tracer yield for the QC blank analysis was 106%, greater than the upper control limit of 105%. No other problems were encountered during the course of the analyses.

**2.5 Protactinium-231 Analysis**

The initial analyses of the sample were rejected due to low tracer yields of the sample and QC samples; the third analysis of the sample produced acceptable tracer yields.

**2.6 Neptunium-237 Analysis**

No problems were encountered during the course of the analyses.

**3.0 Case Narrative Certification Statement**

"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."

  
\_\_\_\_\_  
Melissa C. Mannion  
Senior Program Manager

  
\_\_\_\_\_  
Date

EBERLINE SERVICES / RICHMOND  
SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

Client Hanford  
Contract No. 33677  
Case no SDG\_H3767

S U M M A R Y   D A T A   S E C T I O N

T A B L E   O F   C O N T E N T S				
About this section	.	.	.	1
Sample Summaries	.	.	.	3
Prep Batch Summary	.	.	.	5
Work Summary	.	.	.	6
Method Blanks	.	.	.	8
Lab Control Samples	.	.	.	10
Duplicates	.	.	.	12
Data Sheets	.	.	.	14
Method Summaries	.	.	.	15
Report Guides	.	.	.	19
End of Section	.	.	.	33

*W. Juill*  
Prepared by

*Melissa Mannion*  
Reviewed by

Lab id EBRINE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-TOC  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG\_H3767

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 33677  
Case no SDG\_H3767

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 2

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

**LAB SAMPLE SUMMARY**

SDG 7116  
 Contact Melissa C. Mannion

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

LAB						CHAIN OF	
SAMPLE ID	CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	SAF NO	CUSTODY	COLLECTED
R806086-01	B1V9L7	C4974	SOLID		F08-045	F08-045-015	06/05/08 13:05
R806086-02	Lab Control Sample		SOLID		F08-045		
R806086-03	Method Blank		SOLID		F08-045		
R806086-04	Duplicate (R806086-01)	C4974	SOLID		F08-045		06/05/08 13:05
R806086-08	Lab Control Sample		SOLID		F08-045		
R806086-09	Method Blank		SOLID		F08-045		
R806086-10	Duplicate (R806086-01)	C4974	SOLID		F08-045		06/05/08 13:05

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LS  
 Version 3.06  
 Report date 07/31/08

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

**QC SUMMARY**

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

QC BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL	LAB SAMPLE ID	DEPARTMENT SAMPLE ID
7116	F08-045-015	B1V9L7	SOLID	86.0	410 g		06/11/08	6	R806086-01	7116-001
		Method Blank	SOLID						R806086-03	7116-003
		Method Blank	SOLID						R806086-09	7116-009
		Lab Control Sample	SOLID						R806086-02	7116-002
		Lab Control Sample	SOLID						R806086-08	7116-008
		Duplicate (R806086-01)	SOLID	86.0	410 g		06/11/08	6	R806086-04	7116-004
		Duplicate (R806086-01)	SOLID	86.0	410 g		06/11/08	6	R806086-10	7116-010

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-OS  
 Version 3.06  
 Report date 07/31/08

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

**PREP BATCH SUMMARY**

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED			QUALI-	
			BATCH	2σ %	CLIENT	MORE	RE		BLANK
<b>Alpha Spectroscopy</b>									
NP	SOLID	Neptunium in Solids	6152-152	14.8	1		1	1	1/1
PA	SOLID	Pa 231 in Solids	6152-152	14.8	1		1	1	1/1
<b>Beta Counting</b>									
TC	SOLID	Technetium 99 in Solids	6152-152	13.2	1		1	1	1/1
<b>Liquid Scintillation Counting</b>									
C	SOLID	Carbon 14 in Solids	6152-152	10.0	1		1	1	1/1

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.  
 Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-PBS  
 Version 3.06  
 Report date 07/31/08

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

**LAB WORK SUMMARY**

SDG 7116  
 Contact Melissa C. Mannion

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

LAB SAMPLE	CLIENT SAMPLE ID				SUF-					
COLLECTED	LOCATION	MATRIX			FIX	ANALYZED	REVIEWED	BY	METHOD	
RECEIVED	CUSTODY	SAF No	PLANCHET	TEST						
R806086-01	B1V9L7		7116-001	C		07/25/08	07/29/08	BW	Carbon 14 in Solids	
06/05/08	C4974	SOLID	7116-001	NP		07/24/08	07/29/08	BW	Neptunium in Solids	
06/11/08	F08-045-015	F08-045	7116-001	PA	A2	07/25/08	07/28/08		Pa 231 in Solids	
			7116-001	TC		07/23/08	07/24/08	BW	Technetium 99 in Solids	
R806086-02	Lab Control Sample		7116-002	C		07/25/08	07/29/08	BW	Carbon 14 in Solids	
		SOLID	7116-002	NP		07/24/08	07/29/08	BW	Neptunium in Solids	
		F08-045	7116-002	TC		07/22/08	07/24/08	BW	Technetium 99 in Solids	
R806086-03	Method Blank		7116-003	C		07/25/08	07/29/08	BW	Carbon 14 in Solids	
		SOLID	7116-003	NP		07/28/08	07/29/08	BW	Neptunium in Solids	
		F08-045	7116-003	TC		07/22/08	07/24/08	BW	Technetium 99 in Solids	
R806086-04	Duplicate (R806086-01)		7116-004	C		07/25/08	07/29/08	BW	Carbon 14 in Solids	
06/05/08	C4974	SOLID	7116-004	NP		07/24/08	07/29/08	BW	Neptunium in Solids	
06/11/08		F08-045	7116-004	TC		07/23/08	07/24/08	BW	Technetium 99 in Solids	
R806086-08	Lab Control Sample		7116-008	PA		07/28/08	07/28/08		Pa 231 in Solids	
		SOLID								
		F08-045								
R806086-09	Method Blank		7116-009	PA		07/30/08	07/31/08	BW	Pa 231 in Solids	
		SOLID								
		F08-045								
R806086-10	Duplicate (R806086-01)		7116-010	PA		07/28/08	07/28/08		Pa 231 in Solids	
06/05/08	C4974	SOLID								
06/11/08		F08-045								

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LWS  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3767

WORK SUMMARY, cont.

SDG 7116  
 Contact Melissa C. Mannion

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP SPIKE	TOTAL
C	F08-045	Carbon 14 in Solids	C14_COX_LSC	1			1	1	1	4
NP	F08-045	Neptunium in Solids	NP237_LLE_PLATE_AEA	1			1	1	1	4
PA	F08-045	Pa 231 in Solids	PA231_IE_PLATE_AEA	1			1	1	1	4
TC	F08-045	Technetium 99 in Solids	TC99_TR_SEP_GPC	1			1	1	1	4
TOTALS				4			4	4	4	16

Lab id EBRINE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LWS  
 Version 3.06  
 Report date 07/31/08

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H3767**

7116-003

Method Blank

**METHOD BLANK**

SDG <u>7116</u>	Client/Case no <u>Hanford</u>	SDG <u>H3767</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R806086-03</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7116-003</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F08-045</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALIFIERS	TEST
Carbon 14	14762-75-5	-0.394	1.7	2.92	50.0	U	C
Technetium 99	14133-76-7	0.081	0.18	0.329	12.0	U	TC
Neptunium 237	13994-20-2	-0.006	0.023	0.055	1.00	U	NP

200UP1 OU Monit.Wells-WsteDesignatn

QC-BLANK #66093
-----------------

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

7116-009

Method Blank

METHOD BLANK

SDG <u>7116</u>	Client/Case no <u>Hanford</u>	SDG <u>H3767</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R806086-09</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7116-009</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F08-045</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALIFIERS	TEST
Protactinium 231	14331-85-2	0.070	0.14	0.269	1.00	U	PA

200UP1 OU Monit.Wells-WsteDesignatn

QC-BLANK #66514
-----------------

METHOD BLANKS

Page 2

SUMMARY DATA SECTION

Page 9

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>



**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

7116-008

Lab Control Sample

**LAB CONTROL SAMPLE**

SDG <u>7116</u>	Client/Case no <u>Hanford</u> <span style="float:right"><u>SDG H3767</u></span>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>
Lab sample id <u>R806086-08</u>	Client sample id <u>Lab Control Sample</u>
Dept sample id <u>7116-008</u>	Material/Matrix <u>SOLID</u>
	SAF No <u>F08-045</u>

ANALYTE	RESULT	2σ ERR	MDA	RDL	QUALI-	ADDED	2σ ERR	REC	3σ LMTS	PROTOCOL
	pCi/g	(COUNT)	pCi/g	pCi/g	FIERS TEST	pCi/g	pCi/g	%	(TOTAL)	LIMITS
Protactinium 231	5.38	1.2	0.532	1.00	PA	4.99	0.20	108	56-144	80-120

200UP1 OU Monit.Wells-WsteDesignatn

QC-LCS #66513
---------------

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

7116-004

B1V9L7

**DUPLICATE**

SDG <u>7116</u> Contact <u>Melissa C. Mannion</u> Duplicates Lab sample id <u>R806086-04</u> Dept sample id <u>7116-004</u> % solids <u>86.0</u>	ORIGINAL Lab sample id <u>R806086-01</u> Dept sample id <u>7116-001</u> Received <u>06/11/08</u> % solids <u>86.0</u>	Client/Case no <u>Hanford</u> SDG <u>H3767</u> Contract <u>No. 33677</u> Client sample id <u>B1V9L7</u> Location/Matrix <u>C4974</u> <u>SOLID</u> Collected/Weight <u>06/05/08 13:05</u> <u>410 g</u> Custody/SAP No <u>F08-045-015</u> <u>F08-045</u>
---	---	---

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD %	3σ TOT	DER σ
Carbon 14	-0.322	1.5	2.62	50.0	U	C	-0.671	1.6	2.73	U	-	0.3	
Technetium 99	0.152	0.28	0.364	12.0	U	TC	0.058	0.23	0.232	U	-	0.5	
Neptunium 237	0.004	0.015	0.036	1.00	U	NP	0.044	0.044	0.056	U	-	1.7	

200UP1 OU Monit.Wells-WasteDesignatn

QC-DUP#1 66094

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

7116-010

B1V9L7

**DUPLICATE**

SDG <u>7116</u>		Client/Case no <u>Hanford</u>	SDG <u>H3767</u>
Contact <u>Melissa C. Mannion</u>		Contract No. <u>33677</u>	
<b>DUPLICATE</b>	<b>ORIGINAL</b>		
Lab sample id <u>R806086-10</u>	Lab sample id <u>R806086-01</u>	Client sample id <u>B1V9L7</u>	
Dept sample id <u>7116-010</u>	Dept sample id <u>7116-001</u>	Location/Matrix <u>C4974</u>	<u>SOLID</u>
	Received <u>06/11/08</u>	Collected/Weight <u>06/05/08 13:05</u>	<u>410 g</u>
% solids <u>86.0</u>	% solids <u>86.0</u>	Custody/SAF No <u>F08-045-015</u>	<u>F08-045</u>

ANALYTE	DUPLICATE	2σ ERR	MDA	RDL	QUALI-	TEST	ORIGINAL	2σ ERR	MDA	QUALI-	RPD	3σ	DER
	pCi/g	(COUNT)	pCi/g	pCi/g	FIERS		pCi/g	(COUNT)	pCi/g	FIERS	%	TOT	σ
Protactinium 231	0.202	0.30	0.559	1.00	U	PA	0.298	0.27	0.390	U	-		0.5

200UP1 OU Monit.Wells-WasteDesignatn

QC-DUP#1 66515

DUPLICATES

Page 2

SUMMARY DATA SECTION

Page 13

Lab id <u>EBRINE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES / RICHMOND**  
**SAMPLE DELIVERY GROUP H3767**

7116-001

B1V9L7

**DATA SHEET**

SDG <u>7116</u>	Client/Case no <u>Hanford</u>	SDG <u>H3767</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R806086-01</u>	Client sample id <u>B1V9L7</u>	
Dept sample id <u>7116-001</u>	Location/Matrix <u>C4974</u>	<u>SOLID</u>
Received <u>06/11/08</u>	Collected/Weight <u>06/05/08 13:05</u>	<u>410 g</u>
% solids <u>86.0</u>	Custody/SAF No <u>F08-045-015</u>	<u>F08-045</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Carbon 14	14762-75-5	-0.671	1.6	2.73	50.0	U	C
Technetium 99	14133-76-7	0.058	0.23	0.232	12.0	U	TC
Neptunium 237	13994-20-2	0.044	0.044	0.056	1.00	U	NP
Protactinium 231	14331-85-2	0.298	0.27	0.390	1.00	U	PA

200UP1 OU Monit.Wells-WsteDesignatn

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

Test NP Matrix SOLID  
 SDG 7116  
 Contact Melissa C. Mannion

**LAB METHOD SUMMARY**

NEPTUNIUM IN SOLIDS  
 ALPHA SPECTROSCOPY

Client Hanford  
 Contract No. 33677  
 Contract SDG H3767

**RESULTS**

<b>LAB</b>	<b>RAW</b>	<b>SUF-</b>		<b>Neptunium</b>
<b>SAMPLE ID</b>	<b>TEST FIX</b>	<b>PLANCHET</b>	<b>CLIENT SAMPLE ID</b>	<b>237</b>

Preparation batch 6152-152

R806086-01	7116-001	B1V9L7		U
R806086-02	7116-002	Lab Control Sample		ok
R806086-03	7116-003	Method Blank		U
R806086-04	7116-004	Duplicate (R806086-01)		- U

Nominal values and limits from method      RDLs (pCi/g)      1.00  
 200UP1 OU Monit.Wells-WsteDesignatn

**METHOD PERFORMANCE**

<b>LAB</b>	<b>RAW</b>	<b>SUF-</b>		<b>MDA</b>	<b>ALIQ</b>	<b>PREP</b>	<b>DILU-</b>	<b>YIELD</b>	<b>EFF</b>	<b>COUNT</b>	<b>FWHM</b>	<b>DRIFT</b>	<b>DAYS</b>		<b>ANAL-</b>	
<b>SAMPLE ID</b>	<b>TEST FIX</b>	<b>CLIENT SAMPLE ID</b>		<b>pCi/g</b>	<b>g</b>	<b>FAC</b>	<b>TION</b>	<b>%</b>	<b>%</b>	<b>min</b>	<b>keV</b>	<b>KeV</b>	<b>HELD</b>	<b>PREPARED</b>	<b>YZED</b>	<b>DETECTOR</b>

Preparation batch 6152-152      2σ prep error 14.8 %      Reference Lab Notebook #6152      pg. 152

R806086-01	B1V9L7		0.056	0.500				45		925			49	07/24/08	07/24	SS-063
R806086-02	Lab Control Sample		0.034	0.500				69		925				07/24/08	07/24	SS-064
R806086-03	Method Blank		0.055	0.500				54		765				07/24/08	07/28	SS-033
R806086-04	Duplicate (R806086-01)		0.036	0.500				80		925				07/24/08	07/24	SS-066

Nominal values and limits from method      1.00      0.500      20-105      100      180

<b>PROCEDURES</b>	<b>REFERENCE</b>	<b>NP237_LLE_PLATE_AEA</b>
SPP-070	Soil Dissolution, < 1.0g Aliquot, rev 7	
CP-930	Neptunium from Solids and Water by Extraction Chromatography, rev 1	
CP-008	Heavy Element Electroplating, rev 12	

<b>AVERAGES ± 2 SD</b>	<b>MDA</b>	<u>0.045</u> ± <u>0.024</u>
<b>FOR 4 SAMPLES</b>	<b>YIELD</b>	<u>62</u> ± <u>31</u>

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 15

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LMS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

Test PA Matrix SOLID  
 SDG 7116  
 Contact Melissa C. Mannion

**LAB METHOD SUMMARY**

PA 231 IN SOLIDS  
 ALPHA SPECTROSCOPY

Client Hanford  
 Contract No. 33677  
 Contract SDG H3767

**RESULTS**

<b>LAB</b>	<b>RAW</b>	<b>SUF-</b>		<b>Protactinium</b>
<b>SAMPLE ID</b>	<b>TEST FIX</b>	<b>PLANCHET</b>	<b>CLIENT SAMPLE ID</b>	<b>231</b>

Preparation batch 6152-152

R806086-01	A2	7116-001	B1V9L7	U
R806086-08		7116-008	Lab Control Sample	ok
R806086-09		7116-009	Method Blank	U
R806086-10		7116-010	Duplicate (R806086-01)	- U

Nominal values and limits from method RDLs (pCi/g) 1.00  
 2000U1 OU Monit.Wells-WsteDesignatn

**METHOD PERFORMANCE**

<b>LAB</b>	<b>RAW</b>	<b>SUF-</b>	<b>MDA</b>	<b>ALIQ</b>	<b>PREP</b>	<b>DILU-</b>	<b>YIELD</b>	<b>EFF</b>	<b>COUNT</b>	<b>FWHM</b>	<b>DRIFT</b>	<b>DAYS</b>	<b>ANAL-</b>	
<b>SAMPLE ID</b>	<b>TEST FIX</b>	<b>CLIENT SAMPLE ID</b>	<b>pCi/g</b>	<b>g</b>	<b>FAC</b>	<b>TION</b>	<b>%</b>	<b>%</b>	<b>min</b>	<b>keV</b>	<b>KeV</b>	<b>HELD PREPARED</b>	<b>YZED</b>	<b>DETECTOR</b>

Preparation batch 6152-152 2σ prep error 14.8 % Reference Lab Notebook #6152 pg. 152

R806086-01	A2	B1V9L7	0.390	0.200			23		1002			50	07/23/08	07/25	SS-036
R806086-08		Lab Control Sample	0.532	0.200			32		435				07/23/08	07/28	SS-031
R806086-09		Method Blank	0.269	0.200			27		662				07/23/08	07/30	SS-027
R806086-10		Duplicate (R806086-01)	0.559	0.200			31		435				07/23/08	07/28	SS-035

Nominal values and limits from method MDA 1.00 ALIQ 0.200 YIELD 20-105 EFF 200 DRIFT 180

<b>PROCEDURES</b>	<b>REFERENCE</b>	<b>PA231_IE_PLATE_AEA</b>
SPP-061	Determination of Moisture Content in Solid Samples rev 0	
SPP-062	Sample Aliquoting, rev 0	
SPP-060	Soil Preparation, rev 0	
SPP-070	Soil Dissolution, < 1.0g Aliquot, rev 7	
CP-910	Protactinium-231 in Soil, (0 to 0.25 g) Aliquot, rev 2	
CP-008	Heavy Element Electroplating, rev 12	

<b>AVERAGES ± 2 SD</b>	<b>MDA</b> <u>0.438</u> ± <u>0.269</u>
<b>FOR 4 SAMPLES</b>	<b>YIELD</b> <u>28</u> ± <u>8</u>

METHOD SUMMARIES

Page 2

SUMMARY DATA SECTION

Page 16

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LMS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

**LAB METHOD SUMMARY**

TECHNETIUM 99 IN SOLIDS

BETA COUNTING

Test TC Matrix SOLID

SDG 7116

Contact Melissa C. Mannion

Client Hanford

Contract No. 33677

Contract SDG H3767

**RESULTS**

<b>LAB</b>	<b>RAW</b>	<b>SUF-</b>		<b>Technetium</b>
<b>SAMPLE ID</b>	<b>TEST FIX</b>	<b>PLANCHET</b>	<b>CLIENT SAMPLE ID</b>	<b>99</b>

Preparation batch 6152-152

R806086-01	7116-001	B1V9L7		U
R806086-02	7116-002	Lab Control Sample		ok
R806086-03	7116-003	Method Blank		U
R806086-04	7116-004	Duplicate (R806086-01)		- U

Nominal values and limits from method RDLs (pCi/g) 12.0  
200UP1 OU Monit.Wells-WsteDesignatn

**METHOD PERFORMANCE**

<b>LAB</b>	<b>RAW</b>	<b>SUF-</b>		<b>MDA</b>	<b>ALIQ</b>	<b>PREP</b>	<b>DILU-</b>	<b>YIELD</b>	<b>EFF</b>	<b>COUNT</b>	<b>FWHM</b>	<b>DRIFT</b>	<b>DAYS</b>		<b>ANAL-</b>	
<b>SAMPLE ID</b>	<b>TEST FIX</b>	<b>CLIENT SAMPLE ID</b>		<b>pCi/g</b>	<b>g</b>	<b>FAC</b>	<b>TION</b>	<b>%</b>	<b>%</b>	<b>min</b>	<b>keV</b>	<b>KeV</b>	<b>HELD</b>	<b>PREPARED</b>	<b>YZED</b>	<b>DETECTOR</b>

Preparation batch 6152-152 2σ prep error 13.2 % Reference Lab Notebook #6152 pg. 152

R806086-01	B1V9L7		0.232	1.00				104	200			48	07/18/08	07/23	GRB-224
R806086-02	Lab Control Sample		0.337	1.00				103	100				07/18/08	07/22	GRB-202
R806086-03	Method Blank		0.329	1.00				<u>106</u>	100				07/18/08	07/22	GRB-203
R806086-04	Duplicate (R806086-01)		0.364	1.00				101	100			48	07/18/08	07/23	GRB-227

Nominal values and limits from method 12.0 1.00 20-105 50 180

<b>PROCEDURES</b>	<b>REFERENCE</b>	<b>TC99_TR_SEP_GPC</b>
CP-021	Preparation of Tc-99m Tracer, rev 4	
SPP-062	Sample Aliquoting, rev 0	
CP-431	Technetium-99 Purification of Soil or Resin by Extraction Chromatography, rev 2	
CP-008	Heavy Element Electroplating, rev 12	

<b>AVERAGES ± 2 SD</b>	<b>MDA</b> <u>0.316</u> ± <u>0.115</u>
<b>FOR 4 SAMPLES</b>	<b>YIELD</b> <u>104</u> ± <u>4</u>

METHOD SUMMARIES

Page 3

SUMMARY DATA SECTION

Page 17

Lab id <u>EBRINE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LMS</u>
Version <u>3.06</u>
Report date <u>07/31/08</u>

**EBERLINE SERVICES/RICHMOND**

SAMPLE DELIVERY GROUP H3767

**LAB METHOD SUMMARY**

CARBON 14 IN SOLIDS

LIQUID SCINTILLATION COUNTING

Test C Matrix SOLID  
 SDG 7116  
 Contact Melissa C. Mannion

Client Hanford  
 Contract No. 33677  
 Contract SDG H3767

**RESULTS**

LAB RAW SUF-  
 SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Carbon 14

Preparation batch 6152-152

R806086-01	7116-001	B1V9L7	U
R806086-02	7116-002	Lab Control Sample	ok
R806086-03	7116-003	Method Blank	U
R806086-04	7116-004	Duplicate (R806086-01)	- U

Nominal values and limits from method RDLs (pCi/g) 50.0  
 200UP1 OU Monit.Wells-WasteDesignatn

**METHOD PERFORMANCE**

LAB RAW SUF- MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-  
 SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/g g FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6152-152 2σ prep error 10.0 % Reference Lab Notebook #6152 pg. 152

R806086-01	B1V9L7	2.73	0.424	100	50	50	07/25/08	07/25	LSC-005
R806086-02	Lab Control Sample	6.06	0.400	100	12	07/25/08	07/25	LSC-005	
R806086-03	Method Blank	2.92	0.400	100	50	07/25/08	07/25	LSC-005	
R806086-04	Duplicate (R806086-01)	2.62	0.443	100	50	50	07/25/08	07/25	LSC-005

Nominal values and limits from method 50.0 0.400 10 180

PROCEDURES REFERENCE C14\_COX\_LSC  
 CP-251 Tritium/Carbon-14 Oxidation, rev 8

AVERAGES ± 2 SD MDA 3.58 ± 3.31  
 FOR 4 SAMPLES YIELD 100 ± 0

METHOD SUMMARIES

Page 4

SUMMARY DATA SECTION

Page 18

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-LMS  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
Contract No. 33677  
Case no SDG H3767

SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- \* LAB SAMPLE ID is the lab's primary identification for a sample.
- \* DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- \* CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- \* QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- \* All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 19

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG\_H3767

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- \* The preparation batches are shown in the same order as the Method Summary Reports are printed.
- \* Only analyses of planchets relevant to the SDG are included.
- \* Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- \* The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- \* TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- \* SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- \* The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- \* PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- \* For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- \* The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG\_H3767

DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- \* TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- \* The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- \* ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- \* A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- \* When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

- U The RESULT is less than the MDA (Minimum Detectable Activity).

REPORT GUIDES

Page 4

SUMMARY DATA SECTION

Page 22

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
  - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
  - H Similar to 'L' except the recovery was high.
  - P The RESULT is 'preliminary'.
  - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
  - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- \* An MDA is underlined if it is bigger than its RDL.

REPORT GUIDES

Page 5

SUMMARY DATA SECTION

Page 23

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

GUIDE , cont .

Client Hanford  
Contract No. 33677  
Case no SDG H3767

DATA SHEET

- \* An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- \* A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- \* When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

REPORT GUIDES

Page 6

SUMMARY DATA SECTION

Page 24

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- \* An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- \* The first, computed limits for the recovery reflect:
  1. The error of RESULT, including that introduced by rounding the result prior to printing.
 

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
  2. The error of ADDED.
  3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- \* The second limits are protocol defined upper and lower QC limits for the recovery.
- \* The recovery is underlined if it is outside either of these ranges.

REPORT GUIDES

Page 7

SUMMARY DATA SECTION

Page 25

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- \* The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- \* The second limit for the RPD is the larger of:
  1. A fixed percentage specified in the protocol.

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

GUIDE , cont .

Client Hanford  
Contract No. 33677  
Case no SDG H3767

DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- \* The RPD is underlined if it is greater than either limit.
- \* If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- \* The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

REPORT GUIDES

Page 9

SUMMARY DATA SECTION

Page 27

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- \* All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- \* An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- \* REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- \* The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- \* The second limits are protocol defined upper and lower QC limits

REPORT GUIDES

Page 10

SUMMARY DATA SECTION

Page 28

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford  
Contract No. 33677  
Case no SDG\_H3767

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- \* The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 29

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford  
 Contract No. 33677  
 Case no SDG\_H3767

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- \* Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- \* The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- \* If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- \* Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- \* Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
 Contract No. 33677  
 Case no SDG H3767

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- \* Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
  - \* If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.
- MDAs are underlined if greater than the printed RDL.
- \* Aliquots are underlined if less than the nominal value specified for the method.
  - \* Preparation factors are underlined if greater than the nominal value specified for the method.
  - \* Dilution factors are underlined if greater than the nominal value specified for the method.
  - \* Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
  - \* Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
  - \* Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

REPORT GUIDES

Page 13

SUMMARY DATA SECTION

Page 31

Lab id EBRLNE  
 Protocol Fluor  
 Version Ver 1.0  
 Form DVD-RG  
 Version 3.06  
 Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 33677  
Case no SDG\_H3767

METHOD SUMMARY

- \* Count times are underlined if less than the nominal value specified for the method.
- \* Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- \* Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- \* Days Held are underlined if greater than the holding time specified in the protocol.
- \* Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

REPORT GUIDES

Page 14

SUMMARY DATA SECTION

Page 32

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3767

SDG 7116  
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford  
Contract No. 33677  
Case no SDG H3767

METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

REPORT GUIDES

Page 15

SUMMARY DATA SECTION

Page 33

Lab id EBRLNE  
Protocol Fluor  
Version Ver 1.0  
Form DVD-RG  
Version 3.06  
Report date 07/31/08

COLLECTOR

NCO Sampler

COMPANY CONTACT

TRENT, SJ

TELEPHONE NO.

373-5869

PROJECT COORDINATOR

WIDRIG, DL

PRICE CODE

8N

DATA TURNAROUND

45 Days / 45 Days

SAMPLING LOCATION

C4974

PROJECT DESIGNATION

200-UP-1 OU Monitoring Wells - Waste Designation

H3767 (7116)

SAF NO.

F08-045

AIR QUALITY

ICE CHEST NO.

GRP-08-04

FIELD LOGBOOK NO.

HNF N-4881

ACTUAL SAMPLE DEPTH

COA

123074ES10

METHOD OF SHIPMENT

FEDERAL EXPRESS

SHIPPED TO

Eberline Services

BILL OF LADING/AIR BILL NO.

7920-6971-0404

MATRIX\*

A=Air  
DL=Drum  
Liquids  
DS=Drum  
Solids  
L=Liquid  
O=Oil  
S=Soil  
SE=Sediment  
T=Tissue  
V=Vegetation  
W=Water  
WI=Wipe  
X=Other

POSSIBLE SAMPLE HAZARDS/ REMARKS

Contains Radioactive Material at concentrations that are not regulated for transportation per 49 CFR but are not releasable per DOE Order 5400.5 (1990/1993)

PRESERVATION

None

TYPE OF CONTAINER

G/P

NO. OF CONTAINER(S)

1

VOLUME

250mL

SPECIAL HANDLING AND/OR STORAGE

SAMPLE ANALYSIS

SEE ITEM (1) IN SPECIAL INSTRUCTIONS

SAMPLE NO.

B1V9L7

MATRIX\*

SOIL

SAMPLE DATE SAMPLE TIME

6/5/2008 1305 X

029557

CHAIN OF POSSESSION

SIGN/ PRINT NAMES

SPECIAL INSTRUCTIONS

RELINQUISHED BY/REMOVED FROM

DATE/TIME

RECEIVED BY/STORED IN

DATE/TIME

LABORATORY SECTION

RECEIVED BY

TITLE

DATE/TIME

FINAL SAMPLE DISPOSITION

DISPOSAL METHOD

DISPOSED BY

DATE/TIME



# RICHMOND, CA LABORATORY

## SAMPLE RECEIPT CHECKLIST

Client: F. HAWFORD City PICKLAND State WA

Date/Time received 06/11/08 09:30 CoC No. FO8-045-015

Container I.D. No. GRP-08-04 Requested TAT (Days) 45 P.O. Received Yes [ ] No [ ]

### INSPECTION

1. Custody seals on shipping container intact? Yes  No [ ] N/A [ ]
2. Custody seals on shipping container dated & signed? Yes  No [ ] N/A [ ]
3. Custody seals on sample containers intact? Yes  No [ ] N/A [ ]
4. Custody seals on sample containers dated & signed? Yes  No [ ] N/A [ ]
5. Packing material is: Wet [ ] Dry
6. Number of samples in shipping container: 1 Sample Matrix S
7. Number of containers per sample: 1 (Or see CoC \_\_\_\_\_)
8. Samples are in correct container Yes  No [ ]
9. Paperwork agrees with samples? Yes  No [ ]
10. Samples have: Tape [ ] Hazard labels [ ] Rad labels [ ] Appropriate sample labels
11. Samples are: In good condition  Leaking [ ] Broken Container [ ] Missing
12. Samples are: Preserved [ ] Not preserved [ ] pH \_\_\_\_\_ Preservative \_\_\_\_\_
13. Describe any anomalies:  
\_\_\_\_\_  
\_\_\_\_\_

14. Was P.M. notified of any anomalies? Yes [ ] No [ ] Date \_\_\_\_\_

15. Inspected by MZU Date: 06/11/08 Time: 10:20

Customer Sample No.	Beta/Gamma cpm	Ion Chamber mR/hr	Wipe	Customer Sample No.	Beta/Gamma cpm	Ion Chamber mR/hr	wipe
<u>B1V9L7</u>	<u>260</u>						

Ion Chamber Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Alpha Meter Ser. No. \_\_\_\_\_

Calibration date \_\_\_\_\_

Beta/Gamma Meter Ser. No. 99574

Calibration date 08 MAY 09