



RECEIVED SEPTEMBER 24, 2008

EBERLINE
SERVICES

EBERLINE ANALYTICAL CORPORATION
2030 Wright Avenue
Richmond, California 94804-3849
Phone (510) 235-2633 Fax (510) 235-0438
Toll Free (800) 841-5487
www.eberlineservices.com

September 24, 2008

Mr. Steve Trent
Fluor Hanford Inc.
1200 Jadwin Avenue
Richland, WA 99352

Reference: **P.O. #33677**
Eberline Services R8-07-145-7151, SDG H3802

Dear Mr. Trent:

Enclosed is a data report for two water samples designated under SAF No. F08-133 received at Eberline Services on July 24, 2008. The samples were analyzed according to the accompanying chain-of-custody documents.

Please call if you have any questions concerning this report.

Sincerely,

Melissa C. Mannion
Senior Program Manager

MCM/njv

Enclosure: Data Package

RECEIVED
FEB 03 2009

EDMC

1.0 GENERAL

Fluor Hanford Inc. (FH) Sample Delivery Group H3802 was composed of two water samples designated under SAF No. F08-133 with a Project Designation of: 200-BP-5 OU Characterization of Wells 699-52-55B("H")-Groundwater.

The samples were received as stated on the Chain-of-Custody documents. Any discrepancies were noted on the Eberline Services Sample Receipt Checklist.

2.0 ANALYSIS NOTES

2.1 Tritium Analysis

The tritium recovery for the QC matrix spike was 78%, less than the lower control limit of 80%; no other problems were encountered during the course of the analyses.

2.2 Carbon-14 Analysis

No problems were encountered during the course of the analyses.

2.3 Technetium-99 Analysis

No problems were encountered during the course of the analyses.

2.4 Iodine-129 Analysis

No problems were encountered during the course of the analyses.

2.5 Isotopic Thorium Analysis

No problems were encountered during the course of the analyses.

2.6 Neptunium-237 Analysis

No problems were encountered during the course of the analyses.

3.0 Case Narrative Certification Statement

"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."



Melissa C. Mannion
Senior Program Manager



Date


EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

Client Hanford
Contract No. 33677
Case no SDG_H3802

S U M M A R Y D A T A S E C T I O N

T A B L E O F C O N T E N T S				
About this section	.	.	.	1
Sample Summaries	.	.	.	3
Prep Batch Summary	.	.	.	5
Work Summary	.	.	.	6
Method Blanks	.	.	.	8
Lab Control Samples	.	.	.	9
Duplicates	.	.	.	10
Matrix Spikes	.	.	.	11
Data Sheets	.	.	.	12
Method Summaries	.	.	.	14
Report Guides	.	.	.	19
End of Section	.	.	.	33


Prepared by _____

Reviewed by _____

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-TOC
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 33677

Case no SDG_H3802

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 33677

Case no SDG_H3802

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 2

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

LAB SAMPLE SUMMARY

Client Hanford
 Contract No. 33677
 Case no SDG H3802

LAB	CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	SAF NO	CHAIN OF CUSTODY	COLLECTED
R807145-01	B1W1B1	C5862, I-004	WATER		F08-133	F08-133-003	07/16/08 10:00
R807145-02	B1W1B2	C5862, I-004-D	WATER		F08-133	F08-133-007	07/16/08 10:00
R807145-03	Lab Control Sample		WATER		F08-133		
R807145-04	Method Blank		WATER		F08-133		
R807145-05	Duplicate (R807145-01)	C5862, I-004	WATER		F08-133		07/16/08 10:00
R807145-06	Spike (R807145-01)	C5862, I-004	WATER		F08-133		07/16/08 10:00

LAB SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

QC SUMMARY

Client Hanford
 Contract No. 33677
 Case no SDG H3802

QC BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL	LAB SAMPLE ID	DEPARTMENT SAMPLE ID
7151	F08-133-003	B1W1B1	WATER		6.0 L		07/24/08 8	R807145-01		7151-001
	F08-133-007	B1W1B2	WATER		6.0 L		07/24/08 8	R807145-02		7151-002
		Method Blank	WATER					R807145-04		7151-004
		Lab Control Sample	WATER					R807145-03		7151-003
		Duplicate (R807145-01)	WATER		6.0 L		07/24/08 8	R807145-05		7151-005
		Spike (R807145-01)	WATER		6.0 L		07/24/08 8	R807145-06		7151-006

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-QS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

PREP BATCH SUMMARY

Client Hanford
Contract No. 33677
Case no SDG H3802

TEST	MATRIX	METHOD	PREPARATION ERROR			PLANCHETS ANALYZED			QUALI-
			BATCH	2σ %	CLIENT MORE	RE BLANK	LCS	DUP/ORIG MS/ORIG	
Alpha Spectroscopy									
NP	WATER	Neptunium in Water	6157-120	14.8	2	1	1	1/1	
TH	WATER	Thorium, Isotopic in Water	6157-120	8.0	2	1	1	1/1	
Gamma Spectroscopy									
I	WATER	Iodine 129 in Water	6157-120	19.4	2	1	1	1/1	
Liquid Scintillation Counting									
C	WATER	Carbon 14 in Water	6157-120	10.0	2	1	1	1/1	1/1 X
H	WATER	Tritium in Water	6157-120	10.0	2	1	1	1/1	1/1 X

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.
Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-PBS
Version 3.06
Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 33677
 Case no SDG H3802

LAB WORK SUMMARY

LAB SAMPLE	CLIENT SAMPLE ID										
COLLECTED	LOCATION	MATRIX	SUF-								
RECEIVED	CUSTODY	SAF No	PLANCHET	TEST	FIX	ANALYZED	REVIEWED	BY	METHOD		
R807145-01	B1WB1		7151-001	C		09/11/08	09/16/08	BW	Carbon 14 in Water		
07/16/08	C5862, I-004		7151-001	H		09/03/08	09/09/08	BW	Tritium in Water		
07/24/08	F08-133-003	F08-133	7151-001	I		09/12/08	09/16/08	BW	Iodine 129 in Water		
			7151-001	NP		09/14/08	09/18/08	BW	Neptunium in Water		
			7151-001	TH		09/05/08	09/23/08	BW	Thorium, Isotopic in Water		
R807145-02	B1WB2		7151-002	C		09/11/08	09/16/08	BW	Carbon 14 in Water		
07/16/08	C5862, I-004-D		7151-002	H		09/03/08	09/09/08	BW	Tritium in Water		
07/24/08	F08-133-007	F08-133	7151-002	I		09/13/08	09/16/08	BW	Iodine 129 in Water		
			7151-002	NP		09/14/08	09/18/08	BW	Neptunium in Water		
			7151-002	TH		09/05/08	09/23/08	BW	Thorium, Isotopic in Water		
R807145-03	Lab Control Sample		7151-003	C		09/11/08	09/16/08	BW	Carbon 14 in Water		
			7151-003	H		09/03/08	09/09/08	BW	Tritium in Water		
		F08-133	7151-003	I		09/13/08	09/16/08	BW	Iodine 129 in Water		
			7151-003	NP		09/14/08	09/18/08	BW	Neptunium in Water		
			7151-003	TH		09/05/08	09/23/08	BW	Thorium, Isotopic in Water		
R807145-04	Method Blank		7151-004	C		09/11/08	09/16/08	BW	Carbon 14 in Water		
			7151-004	H		09/03/08	09/09/08	BW	Tritium in Water		
		F08-133	7151-004	I		09/15/08	09/16/08	BW	Iodine 129 in Water		
			7151-004	NP		09/14/08	09/18/08	BW	Neptunium in Water		
			7151-004	TH	R1	09/19/08	09/23/08	BW	Thorium, Isotopic in Water		
R807145-05	Duplicate (R807145-01)		7151-005	C		09/11/08	09/16/08	BW	Carbon 14 in Water		
07/16/08	C5862, I-004		7151-005	H		09/03/08	09/09/08	BW	Tritium in Water		
07/24/08		F08-133	7151-005	I		09/15/08	09/16/08	BW	Iodine 129 in Water		
			7151-005	NP		09/14/08	09/18/08	BW	Neptunium in Water		
			7151-005	TH		09/05/08	09/23/08	BW	Thorium, Isotopic in Water		
R807145-06	Spike (R807145-01)		7151-006	C		09/11/08	09/16/08	BW	Carbon 14 in Water		
07/16/08	C5862, I-004		7151-006	H		09/03/08	09/09/08	BW	Tritium in Water		
07/24/08		F08-133									

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LWS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

WORK SUMMARY, cont.

SDG 7151 _____
 Contact Melissa C. Mannion

Client Hanford _____
 Contract No. 33677 _____
 Case no SDG H3802 _____

COUNTS OF TESTS BY SAMPLE TYPE											
TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP SPIKE	TOTAL	
C	F08-133	Carbon 14 in Water	C14_CHEM_LSC		2		1	1	1	1	6
H	F08-133	Tritium in Water	906.0_H3_LSC		2		1	1	1	1	6
I	F08-133	Iodine 129 in Water	I129_SEP_LEPS_GS		2		1	1	1		5
NP	F08-133	Neptunium in Water	NP237_LLE_PLATE_AEA		2		1	1	1		5
TH	F08-133	Thorium, Isotopic in Water	THISO_IE_PLATE_AEA		2		1	1	1		5
TOTALS					10		5	5	5	2	27

WORK SUMMARY

Page 2

SUMMARY DATA SECTION

Page 7

Lab id EBRLNE _____
 Protocol Fluor _____
 Version Ver 1.0 _____
 Form DVD-L&S _____
 Version 3.06 _____
 Report date 09/24/08 _____

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

7151-004

Method Blank

METHOD BLANK

SDG <u>7151</u>	Client/Case no <u>Hanford</u>	SDG <u>H3802</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R807145-04</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7151-004</u>	Material/Matrix _____	<u>WATER</u>
	SAF No <u>F08-133</u>	

ANALYTE	CAS NO	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST
Tritium	10028-17-8	811	1100	<u>1750</u>	400	U	H
Carbon 14	14762-75-5	10.7	24	39.6	200	U	C
Iodine 129	15046-84-1	0.037	0.89	2.02	5.00	U	I
Thorium 228	14274-82-9	0.020	0.045	0.074		U	TH
Thorium 230	14269-63-7	0.031	0.039	0.052	1.00	U	TH
Thorium 232	TH-232	0	0.017	0.031	1.00	U	TH
Neptunium 237	13994-20-2	0.036	0.073	0.109	1.00	U	NP

200BP5 OU Charctrztn6995255B("H")-GW

QC-BLANK #66705

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>09/24/08</u>

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

7151-003

Lab Control Sample

LAB CONTROL SAMPLE

SDG <u>7151</u>	Client/Case no <u>Hanford</u>	<u>SDG H3802</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R807145-03</u>	Client sample id <u>Lab Control Sample</u>	
Dept sample id <u>7151-003</u>	Material/Matrix <u>WATER</u>	
	SAF No <u>F08-133</u>	

ANALYTE	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS TEST	ADDED pCi/L	2σ ERR pCi/L	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	22400	1700	<u>1740</u>	400	H	23200	930	97	81-119	80-120
Carbon 14	7810	90	35.3	200	C	7970	320	98	84-116	80-120
Iodine 129	265	2.8	4.06	5.00	I	232	9.3	114	66-134	80-120
Thorium 230	17.6	1.7	0.184	1.00	TH	18.9	0.76	93	81-119	80-120
Neptunium 237	22.7	2.7	0.105	1.00	NP	19.8	0.79	115	67-133	80-120

200BP5 OU Charctrztn6995255B ("H")-GW

QC-LCS #66704

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LCS
 Version 3.06
 Report date 09/24/08

LAB CONTROL SAMPLES

Page 1

SUMMARY DATA SECTION

Page 9

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

7151-005

B1W1B1

DUPLICATE

SDG <u>7151</u>		Client/Case no <u>Hanford</u>	SDG <u>H3802</u>
Contact <u>Melissa C. Mannion</u>		Contract No. <u>33677</u>	
DUPLICATE	ORIGINAL		
Lab sample id <u>R807145-05</u>	Lab sample id <u>R807145-01</u>	Client sample id <u>B1W1B1</u>	
Dept sample id <u>7151-005</u>	Dept sample id <u>7151-001</u>	Location/Matrix <u>C5862, I-004</u>	<u>WATER</u>
	Received <u>07/24/08</u>	Collected/Volume <u>07/16/08 10:00</u>	<u>6.0 L</u>
		Custody/SAF No <u>F08-133-003</u>	<u>F08-133</u>

ANALYTE	DUPLICATE		MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST	ORIGINAL pCi/L	2σ ERR		MDA pCi/L	QUALI- FIERS	RPD %	3σ TOT	DER σ
	pCi/L	(COUNT)						(COUNT)	(COUNT)					
Tritium	39.8	100	176	400	U	H	18.9	100	176	U	-	-	0.3	
Carbon 14	-6.84	22	37.9	200	U	C	12.3	23	37.6	U	-	-	1.2	
Iodine 129	0.528	1.4	3.19	5.00	U	I	0.083	1.4	3.12	U	-	-	0.4	
Thorium 228	0.122	0.14	0.192		U	TH	-0.044	0.13	0.297	U	-	-	1.7	
Thorium 230	-0.052	0.069	0.165	1.00	U	TH	-0.044	0.044	0.168	U	-	-	0.2	
Thorium 232	0	0.034	0.132	1.00	U	TH	0	0.044	0.168	U	-	-	0	
Neptunium 237	0	0.072	0.109	1.00	U	NP	0	0.091	0.137	U	-	-	0	

200BP5 OU Charctrztn6995255B("H") -GW

QC-DUP#1 66706

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-DUP
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

7151-006

B1W1B1

MATRIX SPIKE

SDG <u>7151</u>	Client/Case no <u>Hanford</u>	SDG <u>H3802</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
MATRIX SPIKE	ORIGINAL	
Lab sample id <u>R807145-06</u>	Lab sample id <u>R807145-01</u>	Client sample id <u>B1W1B1</u>
Dept sample id <u>7151-006</u>	Dept sample id <u>7151-001</u>	Location/Matrix <u>C5862, I-004</u> <u>WATER</u>
	Received <u>07/24/08</u>	Collected/Volume <u>07/16/08 10:00</u> <u>6.0 L</u>
		Custody/SAF No <u>F08-133-003</u> <u>F08-133</u>

ANALYTE	SPIKE pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS TEST	ADDED pCi/L	2σ ERR pCi/L	ORIGINAL pCi/L	2σ ERR (COUNT)	REC 3σ % (TOTAL)	LMTS (LIMITS)	PROTOCOL
Tritium	20400	430	183	400	X H	26000	1000	18.9	100	<u>78</u>	87-113	60-140
Carbon 14	23600	190	55.1	200	X C	23900	960	12.3	23	99	84-116	60-140

200BP5 OU Charctrztn6995255B("H")-GW

QC-MS#1 66707

MATRIX SPIKES

Page 1

SUMMARY DATA SECTION

Page 11

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-MS</u>
Version <u>3.06</u>
Report date <u>09/24/08</u>

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3802

7151-001

B1W1B1

D A T A S H E E T

SDG <u>7151</u>	Client/Case no <u>Hanford</u>	<u>SDG H3802</u>
Contact <u>Melissa C. Mannion</u>	Contract <u>No. 33677</u>	
Lab sample id <u>R807145-01</u>	Client sample id <u>B1W1B1</u>	
Dept sample id <u>7151-001</u>	Location/Matrix <u>C5862, I-004</u>	<u>WATER</u>
Received <u>07/24/08</u>	Collected/Volume <u>07/16/08 10:00</u>	<u>6.0 L</u>
	Custody/SAF No <u>F08-133-003</u>	<u>F08-133</u>

ANALYTE	CAS NO	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST
Tritium	10028-17-8	18.9	100	176	400	U	H
Carbon 14	14762-75-5	12.3	23	37.6	200	U	C
Iodine 129	15046-84-1	0.083	1.4	3.12	5.00	U	I
Thorium 228	14274-82-9	-0.044	0.13	0.297		U	TH
Thorium 230	14269-63-7	-0.044	0.044	0.168	1.00	U	TH
Thorium 232	TH-232	0	0.044	0.168	1.00	U	TH
Neptunium 237	13994-20-2	0	0.091	0.137	1.00	U	NP

200BP5 OU Charctrztn6995255B("H")-GW

DATA SHEETS
Page 1
SUMMARY DATA SECTION
Page 12

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>09/24/08</u>

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3802

7151-002

B1W1B2

D A T A S H E E T

SDG <u>7151</u>	Client/Case no <u>Hanford</u>	<u>SDG H3802</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R807145-02</u>	Client sample id <u>B1W1B2</u>	
Dept sample id <u>7151-002</u>	Location/Matrix <u>C5862, I-004-D</u>	<u>WATER</u>
Received <u>07/24/08</u>	Collected/Volume <u>07/16/08 10:00</u>	<u>6.0 L</u>
	Custody/SAF No <u>F08-133-007</u>	<u>F08-133</u>

ANALYTE	CAS NO	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST
Tritium	10028-17-8	-21.0	100	176	400	U	H
Carbon 14	14762-75-5	18.4	22	36.8	200	U	C
Iodine 129	15046-84-1	-0.570	0.81	1.84	5.00	U	I
Thorium 228	14274-82-9	0.034	0.10	0.187		U	TH
Thorium 230	14269-63-7	-0.033	0.067	0.128	1.00	U	TH
Thorium 232	TH-232	0	0.033	0.128	1.00	U	TH
Neptunium 237	13994-20-2	0	0.11	0.162	1.00	U	NP

200BP5 OU Charctrztn6995255B("H")-GW

Lab id <u>EBRLNE</u>
Protocol <u>Fluor</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>09/24/08</u>

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

Test NP Matrix WATER
 SDG 7151
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

NEPTUNIUM IN WATER
 ALPHA SPECTROSCOPY

Client Hanford
 Contract No. 33677
 Contract SDG H3802

RESULTS

LAB	RAW	SUF-	Neptunium	
SAMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	237
Preparation batch 6157-120				
R807145-01		7151-001	B1W1B1	U
R807145-02		7151-002	B1W1B2	U
R807145-03		7151-003	Lab Control Sample	ok
R807145-04		7151-004	Method Blank	U
R807145-05		7151-005	Duplicate (R807145-01)	- U

Nominal values and limits from method RDLs (pCi/L) 1.00
 200BP5 OU Charctrztn6995255B("H")-GW

METHOD PERFORMANCE

LAB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-		
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/L	L	PAC	TION	%	%	min	keV	KeV	HELD	PREPARED	YZED	DETECTOR
Preparation batch 6157-120 2σ prep error 14.8 % Reference Lab Notebook #6156, pg. 120															
R807145-01		B1W1B1	0.137	0.500			47	107				60	09/14/08	09/14	SS-033
R807145-02		B1W1B2	0.162	0.500			48	107				60	09/14/08	09/14	SS-034
R807145-03		Lab Control Sample	0.105	0.500			55	110					09/14/08	09/14	SS-035
R807145-04		Method Blank	0.109	0.500			57	110					09/14/08	09/14	SS-036
R807145-05		Duplicate (R807145-01)	0.109	0.500			53	110				60	09/14/08	09/14	SS-037

Nominal values and limits from method 1.00 0.500 20-105 100 180

PROCEDURES REFERENCE NP237_LLE_PLATE_AEA
 SPP-062 Sample Aliquoting, rev 0
 CP-930 Neptunium from Solids and Water by Extraction Chromatography, rev 1
 CP-008 Heavy Element Electroplating, rev 12

AVERAGES ± 2 SD MDA 0.124 ± 0.049
 FOR 5 SAMPLES YIELD 52 ± 9

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 14

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

Test TH Matrix WATER
 SDG 7151
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

THORIUM, ISOTOPIC IN WATER
 ALPHA SPECTROSCOPY

Client Hanford
 Contract No. 33677
 Contract SDG H3802

RESULTS

LAB RAW SUF-
 SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Thorium 230

Preparation batch 6157-120

R807145-01		7151-001	B1W1B1	U
R807145-02		7151-002	B1W1B2	U
R807145-03		7151-003	Lab Control Sample	ok
R807145-04	R1	7151-004	Method Blank	U
R807145-05		7151-005	Duplicate (R807145-01)	- U

Nominal values and limits from method RDLs (pCi/L) 1.00
 200BP5 OU Charctrztn6995255B(*H*)-GW

METHOD PERFORMANCE

LAB RAW SUF- MAX MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-
 SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/L L FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6157-120 2σ prep error 8.0 % Reference Lab Notebook #6156, pg. 120

R807145-01		B1W1B1	0.168	0.500	61	166	51	09/04/08	09/05	SS-027
R807145-02		B1W1B2	0.128	0.500	93	167	51	09/04/08	09/05	SS-028
R807145-03		Lab Control Sample	0.184	0.500	96	168		09/04/08	09/05	SS-032
R807145-04	R1	Method Blank	0.052	0.500	89	883		09/04/08	09/19	SS-027
R807145-05		Duplicate (R807145-01)	0.165	0.500	100	168	51	09/04/08	09/05	SS-034

Nominal values and limits from method 1.00 0.500 20-110 150 100 180

PROCEDURES	REFERENCE	THISO_IE_PLATE_AEA
SPP-062		Sample Aliquoting, rev 0
SPP-040		Environmetnal Water Dissolution, rev 0
CP-900		Thorium in Water and Dissolved Solid Samples by Extraction Chromatography, rev 1
CP-008		Heavy Element Electroplating, rev 12

AVERAGES ± 2 SD MDA 0.139 ± 0.106
 FOR 5 SAMPLES YIELD 88 ± 31

METHOD SUMMARIES

Page 2

SUMMARY DATA SECTION

Page 15

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

Test I Matrix WATER
 SDG 7151
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

IODINE 129 IN WATER
 GAMMA SPECTROSCOPY

Client Hanford
 Contract No. 33677
 Contract SDG H3802

RESULTS

LAB RAW SUF-
 SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Iodine 129

Preparation batch 6157-120

R807145-01		7151-001	B1W1B1	U
R807145-02		7151-002	B1W1B2	U
R807145-03		7151-003	Lab Control Sample	ok
R807145-04		7151-004	Method Blank	U
R807145-05		7151-005	Duplicate (R807145-01)	- U

Nominal values and limits from method RDLs (pCi/L) 5.00
 200BP5 OU Charctrztn6995255B(*H*)-GW

METHOD PERFORMANCE

LAB RAW SUF- MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-
 SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/L L FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6157-120 2σ prep error 19.4 % Reference Lab Notebook #6156, pg. 120

R807145-01		B1W1B1	3.12	0.500			75	605	58	09/05/08	09/12	XSPEC-002
R807145-02		B1W1B2	1.84	0.500			77	1028	59	09/05/08	09/13	XSPEC-004
R807145-03		Lab Control Sample	4.06	0.500			81	1027		09/05/08	09/13	XSPEC-002
R807145-04		Method Blank	2.02	0.500			80	540		09/05/08	09/15	XSPEC-004
R807145-05		Duplicate (R807145-01)	3.19	0.500			73	540	61	09/05/08	09/15	XSPEC-002

Nominal values and limits from method 5.00 0.500 20-105 300 100 180

PROCEDURES REFERENCE I129_SEP_LEPS_GS
 SPP-062 Sample Aliquoting, rev 0
 CP-530 Iodine-129 Purification, rev 1

AVERAGES ± 2 SD MDA 2.85 ± 1.83
 FOR 5 SAMPLES YIELD 77 ± 7

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

Test C Matrix WATER
 SDG 7151
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

CARBON 14 IN WATER

LIQUID SCINTILLATION COUNTING

Client Hanford
 Contract No. 33677
 Contract SDG H3802

RESULTS

LAB	RAW	SUF-			
SAMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	Carbon 14	
Preparation batch 6157-120					
R807145-01		7151-001	B1W1B1	U	
R807145-02		7151-002	B1W1B2	U	
R807145-03		7151-003	Lab Control Sample	ok	
R807145-04		7151-004	Method Blank	U	
R807145-05		7151-005	Duplicate (R807145-01)	-	U
R807145-06		7151-006	Spike (R807145-01)	ok	X

Nominal values and limits from method RDLs (pCi/L) 200
 200BP5 OU Charctrztn6995255B(*H*)-GW

METHOD PERFORMANCE

LAB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-		
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/L	L	FAC	TION	%	%	min	keV	KeV	HELD	PREPARED	YZED	DETECTOR
Preparation batch 6157-120 2σ prep error 10.0 % Reference Lab Notebook #6156, pg. 120															
R807145-01		B1W1B1	37.6	0.0300			100	100				57	09/09/08	09/11	LSC-005
R807145-02		B1W1B2	36.8	0.0300			100	100				57	09/09/08	09/11	LSC-005
R807145-03		Lab Control Sample	35.3	0.0300			100	100					09/09/08	09/11	LSC-005
R807145-04		Method Blank	39.6	0.0300			100	100					09/09/08	09/11	LSC-005
R807145-05		Duplicate (R807145-01)	37.9	0.0300			100	100				57	09/09/08	09/11	LSC-005
R807145-06		Spike (R807145-01)	55.1	<u>0.0200</u>			100	100				57	09/09/08	09/11	LSC-005

Nominal values and limits from method 200 0.0300 50 180

PROCEDURES REFERENCE C14_CHEM_LSC
 CP-241 Carbon-14 in Aqueous Samples, rev 6

AVERAGES ± 2 SD MDA 40.4 ± 14.7
 FOR 6 SAMPLES YIELD 100 ± 0

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3802

Test H Matrix WATER
 SDG 7151
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

TRITIUM IN WATER

LIQUID SCINTILLATION COUNTING

Client Hanford
 Contract No. 33677
 Contract SDG H3802

RESULTS

LAB	RAW	SUF-		
SAMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	Tritium
Preparation batch 6157-120				
R807145-01		7151-001	B1W1B1	U
R807145-02		7151-002	B1W1B2	U
R807145-03		7151-003	Lab Control Sample	ok
R807145-04		7151-004	Method Blank	<u>811</u> U
R807145-05		7151-005	Duplicate (R807145-01)	- U
R807145-06		7151-006	Spike (R807145-01)	<u>LOW</u> X

Nominal values and limits from method RDLs (pCi/L) 400
 200BP5 OU Charctrztn6995255B("H")-GW

METHOD PERFORMANCE

LAB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-		
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/L	L	FAC	TION	%	%	min	keV	KeV	HELD	PREPARED	YZED	DETECTOR
Preparation batch 6157-120 2σ prep error 10.0 % Reference Lab Notebook #6156, pg. 120															
R807145-01		B1W1B1	176	0.0100			100	100				49	09/01/08	09/03	LSC-007
R807145-02		B1W1B2	176	0.0100			100	100				49	09/01/08	09/03	LSC-007
R807145-03		Lab Control Sample	<u>1740</u>	0.0100			10	100					09/01/08	09/03	LSC-007
R807145-04		Method Blank	<u>1750</u>	0.0100			10	100					09/01/08	09/03	LSC-007
R807145-05		Duplicate (R807145-01)	176	0.0100			100	100				49	09/01/08	09/03	LSC-007
R807145-06		Spike (R807145-01)	183	0.0300			33	100				49	09/01/08	09/03	LSC-007
Nominal values and limits from method			400	0.0100				25					180		

PROCEDURES REFERENCE 906.0_H3_LSC
 CP-210 Tritium in Water Samples by Distillation, rev 8

AVERAGES ± 2 SD MDA 700 ± 1620
 FOR 6 SAMPLES YIELD 59 ± 92

METHOD SUMMARIES

Page 5

SUMMARY DATA SECTION

Page 18

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG_H3802

SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- * LAB SAMPLE ID is the lab's primary identification for a sample.
- * DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- * CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- * QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- * All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3802

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- * The preparation batches are shown in the same order as the Method Summary Reports are printed.
- * Only analyses of planchets relevant to the SDG are included.
- * Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- * The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG_H3802

WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- * TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- * SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- * The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- * PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- * For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- * The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

REPORT GUIDES

Page 3

SUMMARY DATA SECTION

Page 21

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG_H3802

DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- * TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- * The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- * ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- * A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- * When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

- U The RESULT is less than the MDA (Minimum Detectable Activity).

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

GUIDE , cont .

Client Hanford
 Contract No. 33677
 Case no SDG H3802

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
 - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
 - H Similar to 'L' except the recovery was high.
 - P The RESULT is 'preliminary'.
 - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
 - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- * An MDA is underlined if it is bigger than its RDL.

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 33677

Case no SDG_H3802

DATA SHEET

- * An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- * A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- * When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

REPORT GUIDES

Page 6

SUMMARY DATA SECTION

Page 24

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
 Contract No. 33677
 Case no SDG H3802

LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- * An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- * The first, computed limits for the recovery reflect:
 1. The error of RESULT, including that introduced by rounding the result prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
 2. The error of ADDED.
 3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- * The second limits are protocol defined upper and lower QC limits for the recovery.
- * The recovery is underlined if it is outside either of these ranges.

REPORT GUIDES

Page 7

SUMMARY DATA SECTION

Page 25

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
 Contract No. 33677
 Case no SDG H3802

DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- * The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- * The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 33677
Case no SDG_H3802

DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- * The RPD is underlined if it is greater than either limit.
- * If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- * The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

REPORT GUIDES

Page 9

SUMMARY DATA SECTION

Page 27

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3802

MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- * The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- * The second limits are protocol defined upper and lower QC limits

REPORT GUIDES

Page 10

SUMMARY DATA SECTION

Page 28

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151

Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford

Contract No. 33677

Case no SDG_H3802

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- * The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 29

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
 Contract No. 33677
 Case no SDG_H3802

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- * Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- * The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- * If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- * Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- * Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
 Contact Melissa C. Mannion

GUIDE , c o n t .

Client Hanford
 Contract No. 33677
 Case no SDG_H3802

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- * Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- * If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- * Aliquots are underlined if less than the nominal value specified for the method.
- * Preparation factors are underlined if greater than the nominal value specified for the method.
- * Dilution factors are underlined if greater than the nominal value specified for the method.
- * Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- * Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- * Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

REPORT GUIDES

Page 13

SUMMARY DATA SECTION

Page 31

Lab id EBRLNE
 Protocol Fluor
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 33677
Case no SDG_H3802

METHOD SUMMARY

- * Count times are underlined if less than the nominal value specified for the method.
- * Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- * Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- * Days Held are underlined if greater than the holding time specified in the protocol.
- * Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

Lab id EBRLNE
Protocol Fluor
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 09/24/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3802

SDG 7151

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 33677

Case no SDG_H3802

METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

REPORT GUIDES

Page 15

SUMMARY DATA SECTION

Page 33

Lab id EBRLNE

Protocol Fluor

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 09/24/08

COLLECTOR MA White	COMPANY CONTACT TRENT, SJ	TELEPHONE NO. 373-5869	PROJECT COORDINATOR WIDRIG, DL	PRICE CODE 7N	DATA TURNAROUND 45 Days / 45 Days
SAMPLING LOCATION C5862, I-004-D	PROJECT DESIGNATION 200-BP-5 OU Characterization of Well 699-52-55B ("H") - Groundwater	SAF NO. F08-133	AIR QUALITY <input type="checkbox"/>		
ICE CHEST NO. 605-027	FIELD LOGBOOK NO. HNF-N-488-1	ACTUAL SAMPLE DEPTH 232'	COA 123517ES10	METHOD OF SHIPMENT GOVERNMENT VEHICLE	

SHIPPED TO Eberline Services	OFFSITE PROPERTY NO. N/A	BILL OF LADING/AIR BILL NO. N/A, 7920-8534-7509
--	------------------------------------	---

MATRIX* A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other	POSSIBLE SAMPLE HAZARDS/ REMARKS Contains Radioactive Material at concentrations that may or may not be regulated for transportation per 49 CFR / IATA Dangerous Goods Regulations but are not releasable per DOE Order 5400.5 (1990/1993)	PRESERVATION	None	None	None	HNO3 to pH <2	HNO3 to pH <2					
		TYPE OF CONTAINER	G/P	G/P	G	G/P	G/P					
		NO. OF CONTAINER(S)	1	4	1	1	1					
		VOLUME	125mL	1000mL	125mL	1000mL	1000mL					
		SPECIAL HANDLING AND/OR STORAGE Radioactive Tie To: B1W194	SAMPLE ANALYSIS	Carbon-14; ✓	Iodine-129; ✓	TRITIUM - MIDDLE LEVEL; ✓	SEE ITEM (1) IN SPECIAL INSTRUCTIONS ✓	Neptunium-237; ✓				

SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME								
B1W1B2	WATER	7-16-08	1000	✓	✓	✓	✓	✓			
	LOT#			027006	028688	027259	031204	031204			

CHAIN OF POSSESSION		SIGN/ PRINT NAMES		SPECIAL INSTRUCTIONS	
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME	** The 200 Area S&GRP Characterization and Monitoring Sampling and Analysis GKI applies to this SAF. (1) Isotopic Thorium {Thorium-228, Thorium-230, Thorium-232}	
MA White, M.G. White	7-16-08 1200	MO 413 Eric	7-16-08 1200		
MO 413 Eric	7/27/08 10:35	Paula Ann	7/27/08 10:35		
Paula Ann	7/27/08 1400	Paula Ann			
FED EX		Paula Ann	07/24/08 08:30		
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME		
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME		

LABORATORY SECTION	RECEIVED BY	TITLE	DATE/TIME
FINAL SAMPLE DISPOSITION	DISPOSAL METHOD	DISPOSED BY	DATE/TIME

HR 7/24/08

Client: F. HANFORD City JUCHLAND State WA
 Date/Time received 07/24/08 08:30 CoC No. FO8-133-003,007
 Container I.D. No. GWS-027 Requested TAT (Days) 45 P.O. Received Yes [] No []

INSPECTION

1. Custody seals on shipping container intact? Yes [x] No [] N/A []
2. Custody seals on shipping container dated & signed? Yes [x] No [] N/A []
3. Custody seals on sample containers intact? Yes [x] No [] N/A []
4. Custody seals on sample containers dated & signed? Yes [x] No [] N/A []
5. Packing material is: Wet [] Dry [x]
6. Number of samples in shipping container: 2 Sample Matrix W
7. Number of containers per sample: 8 (Or see CoC _____)
8. Samples are in correct container Yes [x] No []
9. Paperwork agrees with samples? Yes [x] No []
10. Samples have: Tape [] Hazard labels [] Rad labels [] Appropriate sample labels [x]
11. Samples are: In good condition [x] Leaking [] Broken Container [] Missing []
12. Samples are: Preserved [x] Not preserved [] pH 1/7 Preservative HNO3
13. Describe any anomalies:

14. Was P.M. notified of any anomalies? Yes [] No [] Date _____
 15. Inspected by TR Date: 07/24/08 Time: 10:15

Customer Sample No.	Beta/Gamma cpm	Ion Chamber mR/hr	Wipe	Customer Sample No.	Beta/Gamma cpm	Ion Chamber mR/hr	wipe
<u>Full Skupers</u>	<u><60</u>						

Ion Chamber Ser. No. _____ Calibration date _____
 Alpha Meter Ser. No. _____ Calibration date _____
 Beta/Gamma Meter Ser. No. 100482 Calibration date 10 JUL 08