Date: 19 January 2000

To: Bechtel Hanford Inc. (technical representative)

From: TechLaw, Inc.

Project: 105-DR FSB Concrete

Subject: PCB - Data Package No. H0475-RLN (SDG No. H04

### INTRODUCTION

This memo presents the results of data validation on Summary Data Pockey No. H0475-RLN prepared by Recra LabNet (RLN). A list of the samples validated along with the analyses reported and the method of analysis is provided in the following table.

Sample ID	Sample Date	Media	Validation	Analysis
B0W0Y1	7/20/99	Solid	С	EPA8082*
BOWOY2	7/20/99	Solid	С	EPA 8082*
B0W0Y3	7/20/99	Solid	С	EPA 8082*

<sup>\*</sup>Equivalent to the requested method (EPA 8080)

Data validation was conducted in accordance with the "Sample and Analysis Plan for 105F and 105DR Phase III Below Grade Structures and Underlying Soils" (DOE/RL-99-35). Appendices 1 through 5 provide the following information as indicated below:

Appendix 1. Glossary of Data Reporting Qualifiers

Appendix 2. Summary of Data Qualification

Appendix 3. Qualified Data Summary and Annotated Laboratory Reports

Appendix 4. Laboratory Narrative and Chain-of-Custody Documentation

Appendix 5. Data Validation Supporting Documentation

#### DATA QUALITY OBJECTIVES

### Holding Times

Sample data were assessed to ascertain whether the holding time requirements were met by the laboratory. The holding time requirements are as follows: Solid samples must be extracted within 14 days of the date of sample collection and analyzed within 40 days from the date of extraction.

If holding times are exceeded by less than two times the limit, all associated sample results are qualified as estimates and flagged "J" for detects and "UJ" for non-detects. If holding times are exceeded by greater than two times the limit, all associated detected sample results are qualified as estimates and flagged "J" and all nondetects are rejected and flagged "UR".

Holding times were met for all samples.

### Blanks

Method blank analyses are performed to determine the extent of laboratory contamination introduced through sampling, sample preparation or analysis. At least one method blank analysis must be conducted for every 20 samples. Method blanks should not contain target compounds at a concentration greater than CRQL. If target compounds are present, sample results less than five times the blank concentration are qualified as undetected and flagged "U". If the sample result is less than five times the blank concentration and less than CRQL, the result is qualified as undetected and elevated to the CRQL.

All method blank target compound results were acceptable.

### Accuracy

### Matrix Spike

Matrix spike analyses are used to assess the analytical accuracy of the reported data and the effect of the matrix on the ability to accurately quantify sample concentrations. Matrix spike analyses are performed in duplicate and must be within 70% to 130%. If spike recoveries are outside control limits, detected sample results less than five times the spike concentration are qualified as estimates and flagged "J". Nondetected sample results with spike recoveries outside control limits are qualified as estimates and flagged "UJ". Sample results greater than five times the spike concentration require no qualification.

All accuracy results were acceptable.

### Surrogate Recovery

The analysis of surrogate compounds provides a measure of performance for individual samples. Matrix-specific surrogate compound recovery control windows have been established by the laboratory. When a surrogate compound recovery is outside the control window, all positively identified target compounds associated with the unacceptable surrogate recoveries are qualified

as estimates and flagged "J". Nondetected compounds with surrogate recoveries less than the lower control limit are qualified as having an estimated detection limit and flagged "UJ". Nondetected compounds with surrogate recoveries above the upper control limit require no qualification.

Due to surrogate recoveries outside QC limits, all detected PCB results in samples BOW0Y2 and BOW0Y3 were qualfied as estimates and flagged "J" and all undetected PCB results in samples BOW0Y2 and BOW0Y3 were rejected and flagged "UR".

All other surrogate recovery results were acceptable.

### Precision

### Matrix Spike/Matrix Spike Duplicate Samples

Matrix spike/matrix spike duplicate results provide matrix-specific information on the precision of the method for specific target compound classes. Precision is expressed as the RPD between the recoveries of duplicate matrix spike analyses performed on a sample. For soil samples, results must be within RPD limits of plus/minus 30%. If RPD values are out of specification and the sample concentration is less than five times the spike concentration, all associated detected sample results are qualified as estimates and flagged "J". If RPD values are out of specification and the sample concentration is greater than five times the spike concentration, no qualification is required.

All matrix spike results were accetable.

### Analytical Detection Levels

Reported analytical detection levels are compared against the 105DR PQLs to ensure that laboratory detection levels meet the required criteria. The reported detection limit for all analytes except aroclor-1254 were exceeded in samples B0W0Y2 and B0W0Y3. Under the BHI statement of work, no qualification is required. All other analytes meth the analyte specific PQL.

### Completeness

Data Package No. H0475-RLN (SDG No. H0475) was submitted for validation and verified for completeness. The completion percentage was 43%.

#### **MAJOR DEFICIENCIES**

Due to surrogate recoveries outside QC limits, all undetected PCB results in samples B0W0Y2 and B0W0Y3 were rejected and flagged "UR". Rejected data is invalid and should not be reported.

#### MINOR DEFICIENCIES

Due to surrogate recoveries outside QC limits, all detected PCB results in samples BOWOY2 and BOWOY3 were qualfied as estimates and flagged "J". Data flagged 'J' is an estimate, but under the BHI validation SOW, the data may be usable for decision-making purposes. All other validated results are considered accurate within the standard error associated with the methods.

The reported detection limit for all analytes except aroclor-1254 were exceeded in samples BOW0Y2 and BOW0Y3. Under the BHI statement of work, no qualification is required.

#### REFERENCES

BHI, MRB-SBB-A23665, Validation Statement of Work, Bechtel Hanford Incorporated, September 5, 1997.

DOE/RL-99-35, Sample and Analysis Plan for 105F and 105DR Phase III Below Grade Structures and Underlying Soils.

Appendix 1

Glossary of Data Reporting Qualifiers

Qualifiers which may be applied by data validators in compliance with the procedures herein are as follows:

- Indicates the compound or analyte was analyzed for and not detected in the sample. The value reported is the sample quantitation limit corrected for sample dilution and moisture content by the laboratory.
- Indicates the compound or analyte was analyzed for and not detected in the sample. Due to a QC deficiency identified during the data validation, the associated quantitation limit is an estimate.
- Indicates the compound or analyte was analyzed for and detected. The associated concentration is an estimate, but the data are usable for decision-making purposes.
- R Indicates the compound or analyte was analyzed for, detected, and due to an identified QC deficiency, the data are unusable.
- UR Indicates the compound or analyte was analyzed for and not detected in the sample. Additionally, the data is unusable due to an identified QC deficiency.
- NJ Indicates presumptive evidence of a compound at an estimated value.
   The data may not be valid for some specific applications (i.e., usable for decision-making purposes).
- Indicates presumptive evidence of a compound. The data may not be valid for some specific applications (i.e., usable for decision-making purposes).

Summary of Data Qualification

### **DATA QUALIFICATION SUMMARY**

SDG: H0475	REVIEWER: TLI	DATE: 1/19/00	PAGE_1_OF_1_
COMMENTS:			
COMPOUND	QUALIFIER	SAMPLES AFFECTED	REASON
All except arochlor-1254	UR	BOWOY2, BOWOY3	Surrogate diluted out
Arochlor-1254	J	BOWOY2, BOWOY3	Surrogate diluted out

Qualified Data Summary and Annotated Laboratory Reports

		· _	7																					
Project: BECHTEL-HA			4																					
Laboratory: Recra Lai			_																					
	SDG: H		ļ		<del></del>								,											
Sample Number		BOWOYT	BOW0Y2		BOW0Y3																			
Location		Α	C-1		C-1				ļ						1									
Remarks			<u> </u>										<u> </u>											
Sample Date		07/20/99	07/20/99		07/20/99				ļ						<u> </u>		1						<u> </u>	
PCB	CRDL	Result Q				_	Result	<u>a</u>	Result	a	Result	α	Result	a	Result	Q	Result	<u>a</u>	Result	a	Result	a	Result	<u> </u>
Arochlor-1016	100				410			<u> </u>		L								<u> </u>			<u> </u>			
Arochlor-1221	100		820		820							L		L	l	L								
Arochlor-1232	100	84 U	410	UR	410										<u> </u>									
Arochlor-1242	100	84 U	410	UR	410	UR																[		
Arochlor-1248	100	84 U	410	UR	410	UR									]							Π	[ _ · ·	
Arochlor-1254	100	250	1100	J	740	J												Γ.						
Arochlor-1260	100	84 U	410	UR	410	UR										Γ	,						ŀ	
			1									Г												
																								$\top$
										$\vdash$													-	
			1								····· <del>·</del>						i							$\top$
											-													
																								$\neg \neg$
	•	_																				·		
·																								Т.
							,												•					$\top$
·						$\Box$						_												
						П												•		٠.				
																							-	$\top$
			<u> </u>																					
				П																				$\top$
			<del> </del>	П		Н					· · · · · · · · · · · · · · · · · · ·	-												一
			1	Н	-	Н										_	· · · • • • · · · ·				-			
		<del></del>	+	$\vdash$		$\vdash \vdash$								$\vdash$				_					-	_
			<del>                                     </del>	Н			-							-								-		+
		-	<del> </del>	$\vdash$		$\vdash$				$\vdash$								-		_				_
			<del> </del>	Н		$\vdash$				-	· ·			-		Н				-		$\vdash$		
		<del></del>	<del> </del>	Н		$\vdash \vdash$				$\vdash$				-		H						$\vdash$		+-
					L				<u> </u>					L	L	Щ.								

010000

PCBs by GC Report Date: 08/05/99 12:06

RFW Batch Number: 9907L501 Client: TNU-HANFORD B99-076 Work Order: 10985001001 Page: 1

KEW BOLCH NE	Imber: 330/LSUI	Cilent:	TNU-	HANFORD B9	9-07	5 W	ork O	rder: 1098	500100	1 Page	<u>1</u>		
	Cust ID:	B0W0Y	1	B0W0Y1	,	BOWOY	L	BOW0Y2	<b>:</b>	BOWOY:	<b>3</b> 1	PBLKPG	000
Sample	RFW#:	00	1	001 MS		001 MSI	)	002	<b>:</b>	003	3 :	99LE0873-	MB1
Information	Matrix:	SOLID	)	SOLID		SOLID		SOLID		SOLID		SOIL	. <i>'</i>
•	D.F.:		00	2.0	0	2.0	00	10.	0	10	. 0		.00
	Units:	UG/	KG	UG/K	G	UG/I	(G	UG/F	KG .	UG/1	KG .	· UG/	'KG
Surrogate:	Tetrachloro-m-xylene	68	*	72	ŧ	82	1	D	ŧ	D	ł	78	*
	Decachlorobiphenyl	47	¥	48	*	55	Ł	.D	*	D	¥	72	*
******	***************		fl-	******	-fl=:		-fl-		=f1===	******	fl-		==fl
Aroclor-1016		_ 84	U	250	U	250	U	410	ūΚ	410	υ≪		U
Aroclor-1221		170	U	510	U	510	U	820	បឩ	820	UR		ט י
Aroclor-1232		_ 84	U	250	U	250	U	410	ሀ 🞗	410	n &	33	U
Aroclor-1242	<u>.                                    </u>	84	Ū	250	U	250	Ū	410	υR	410	UR	33	
Aroclor-1248		84	U	250	U	· 250	U	410	UR	410	UR		
Aroclor-1254		_ 250		90	ŧ	87	ł	1100	J	740	I	33	
Aroclor-1260		84	Ū	250		250	U	410	n (5-	410	n V	_ 33	ט
	Cust ID:	PBLKPG BS		<u>.</u>	· · · · · · · · · · · · · · · · · · ·		· · · · · ·						
Sample	RFW#:	99LE0873-1	<b>6</b> 81										
Information	Matrix:	SOIL					. •			1	u		
	D.F.:	1.0	00							00	. 10	120/95	
	Units:	UG/I	KG			•		•	. •		10		
Surrogate:	Tetrachloro-m-xylene	85	*	·		······································							
	Decachlorobiphenyl	78	* ==fl=:		.fl==		=fl=:		=fl===:		.=fl=:		f1
	*************		 		+==								

Surrogate: Tetrachloro-m-xylene Decachlorobiphenyl 78 \$

Aroclor-1016 33 U

Aroclor-1221 67 U

Aroclor-1232 33 U

Aroclor-1242 33 U

Aroclor-1248 33 U

Aroclor-1254 88 \$

Aroclor-1260 33 U

U= Analyzed, not detected. J= Present below detection limit. B= Present in blank. NR= Not reported. NS= Not spiked. %= Percent recovery. D= Diluted out. I= Interference. NA= Not Applicable. \*= Outside of EPA CLP QC

Laboratory Narrative and Chain-of-Custody Documentation

### Recra LabNet Philadelphia Analytical Report

Client: TNU-HANFORD B99-016

RFW#: 9907L501

SDG/SAF#: H0475/B99-016

W.O.#: 10985-001-001-9999-00

Date Received: 07-23-99

#### **PCB**

The set of samples consisted of three (3) solid samples collected on 07-20-99.

The samples and their associated QC samples were extracted on 07-27-99 and analyzed according to Recra OPs based on SW846, 3rd Edition procedures on 07-29,30-99. The extraction procedure was based on method 3540 and the extracts were analyzed based on method 8082 for Aroclors only.

The following is a summary of the QC results accompanying the sample results and a description of any problems encountered during their analyses:

- 1. The cooler temperature has been recorded on the chain-of-custody.
- 2. All required holding times for extraction and analysis have been met.
- 3. The samples and their associated QC samples received a sulfuric acid and sulfur cleanup.
- 4. The method blank was below the reporting limits for all target compounds.
- 5. All obtainable surrogate recoveries were within acceptance criteria.
- 6. The blank spike recovery was within acceptance criteria.
- 7. All matrix spike recoveries were within acceptance criteria.
- 8. All samples required instrument dilutions due to high concentrations of target analytes. Reporting limits have been adjusted to reflect the necessary dilutions.
- 9. All initial calibrations associated with this data set were within acceptance criteria.

The results presented in this report relate only to the analytical testing and conditions of the samples at receipt and during storage. All pages of this report are integral parts of the analytical data. Therefore, this report should only be reproduced in its entirety of 11 pages.



10. All continuing calibration standards analyzed prior to sample extracts were within acceptance criteria. The CCV run after the samples was increased for Aroclor 1260 on the RTX-5 column only. All results were reported from the RTX-35 column. A copy of the Sample Discrepancy Report (SDR) has been enclosed.

Rr. J. Michael Taylor

Vice President

Philadelphia Analytical Laboratory

pef\r:\group\data\pest\07L-501.pcb

08-1299

Date



Recra LabNet Philadelphia Sample Discrepancy Report (SDR) SDR #: 4466 / 90
Initiator: Blator RFW Batch: 99074501  Date: 815/97 Samples: ALL Matrix: Soil  Client: TNU HANDEL Method: 6W846/MCAWW/CLPI  Prep Batch: 99460873
1. Reason for SDR a. COC DiscrepancyTech Profile ErrorClient RequestSampler Error on C-O-CTranscription ErrorWrong Test CodeOther b. General DiscrepancyMissing Sample/ExtractContainer BrokenWrong Sample PulledLabel ID's IllegibleHold Time ExceededInsufficient SamplePreservation WrongReceived Past HoldImproper Bottle TypeNot Amenable to Analysis
3. Discussion and Proposed Action Other Description:  Re-log Entire Batch Following Samples: Re-leach Re-extract Re-digest Revise EDD Change Test Code to Place On/Take Off Hold (circle)
4. Project Manager Instructionssignature/date:
5. Final Actionsignature/date:
When Final Action has been recorded, forward original to QA Specialist for distribution and filing.  Route Distribution of Completed SDR  X Initiator X Lab.Manager: M. Taylor X Project Mgr. Stone/Carey/Schrenkel/Johnson X Section Mgr. Wesson/Daniels X QA (file): Racioppi Data Management: Feldman Sample Prep: Schnell/Doughty/Kauffman  Other:    Distribution of Completed SDR   Metals: Doughty   Inorganic: Perrone   GC/LC: Schnell   MS: LeMin/Taylor   Log-in: Toder   Admin: Soos   Other:   Completed SDR

Bechtel Hanford	Inc.	C	HAIN OF CUS	TODY	SAMPL	E ANAL	YSIS	REQUES	T	B	99-076-01	Page 1	of <u>1</u>	
Collector Falilberg/Porter			pany Contact	Telepho 373-4	one No.			Project Coord TRENT, SJ	inator	Price Code	9K	Data To	urnaround	
Project Designation 105-DR FSB - Concrete		Sampl	oling Location				<u> </u>	SAF No.				15 Days		
ice Chest No.		Field	Logbook No.	<del></del>				B99-076 Method of Shi	pment	<u> </u>		0		
Shipped To	<u>4</u>		. 1281		<del>-</del> ;			Fed	Ex	<del></del>				
TAMARECRA TO TO S	9.9		le Property No.	·				Bill of Lading/	Air biu r	10.	•		: 	
·	. •							COA T	105	D4	287	ري	,	
POSSIBLE SAMPLE HAZA	RDS/REMARKS		Preservation	Cool 4C	None	Nane								
		- -	Type of Container	aG	#G	»G					T			
Special Handling and/or Store	age	. •	Na. of Container(s)  Volume	60mL	1 60mŁ	1 120mL .								
	SAMPLE ANA	ALYSIS		PCBs - 8080	NCP Metals - 6010A (Add- on) (Lead); Afercury - 7478 - (CV)	See item (1) in Special Instructions								
Sample No.	Matrix *	Sample Date	Sample Time			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1			11.54			1 de	sarb Car	
B0W0Y1	Other Solid	7.20-9	9 0855	X	_X						tioto	Bou	046	
B0W0Y2	Other Solid	7.20.	99 0905	X	X						•	ROW	1 '	
BOW0Y3	Other Solid	- I - ·	99 09 20	×	Х					<u> </u>		Bow		
				<del> </del>	ļ		<b> </b>	<del>-  </del>						
CHAIN OF POSSESSION  Relinquished By  Relinquished By  Relinquished By  Relinquished By  Relinquished By  Relinquished By	Date Time 81 22.99 080	Received By	Da Da Da Ex	ate/Time / \$7.20.0 ate/Time 80 ate/Time ate/Time	(i) G Europ 29,90	ium-i 55); Isolo	scopy (Cesi Inpic Plutoni	S ium-137, Cobalt-tium; Isotopic Ura 9; Nickel-63; Carl	mium; Ame	ericium-241; Stro		Matrix Soil Water Vapor Other Solid Other Liquid		
LABORATORY Received by SECTION	Millel			Ťúl	le.	<del></del>	<del></del>	<del>,</del>		<u> </u>	コル	hate/Time	054)	
FINAL SANIPLE Disposal Met	inter -	<u> </u>				Dispos	ed By		*=			ate/Time	<u> </u>	

**Data Validation Supporting Documentation** 

### PESTICIDE/PCB DATA VALIDATION CHECKLIST

VALIDATION LEVEL:	Α .	В	©	D	E
PROJECT:   O	SDR FOB Q	<u> </u>	DATA PACKAGI	E: HOY75	
VALIDATOR:	1057N F4	LAB: Re	CRA	DATE: /0/	11/85
CASE:	14		SDG: HO	4.75	
	<u> </u>	ANALYSES	PERFORMED		
[] CLP3/90	□ SW-846 8080	□ SW-846 8081	X 2025	0	0
SAMPLES/MAT	RIX BOW	741 B	०००५२	Bowo	42
			`	· ·	
-				<del></del>	solid
• • • • • • • • • • • • • • • • • • • •					
2. HOLDING			•	¥ .	
	holding times			,	Yes No N/A
Comments:					
				· · · · · · · · · · · · · · · · · · ·	***
3.1 INSTRU	ENT PERFORMANC MENT PERFORMAN	CE (METHOD 80	080 AND 8081)		( )
	ention times a	-			
	tion standard		•		\ \
WLE INT SUG	endrin breakd	owns acceptab	)1 <b>e</b> ?		Yes No NA

1000017

# PESTICIDE/PCB DATA VALIDATION CHECKLIST

Is the GC/MS tuning/performance check acceptable? Yes No WA  Comments:  3.2 CALIBRATIONS (METHOD 8080 AND 8081)  Are EVAL standard calibration factors and %RSD values acceptable? Yes No N/A  Are quantitation column calibration factor %RSD values acceptable?	Sun DDC materation times agreeatables	No	Chi
Comments:  3.2 CALIBRATIONS (METHOD 8080 AND 8081)  Are EVAL standard calibration factors and %RSD values acceptable?	·		(11.4)
3.2 CALIBRATIONS (METHOD 8080 AND 8081)  Are EVAL standard calibration factors and %RSD values acceptable?		NO	
3.2 CALIBRATIONS (METHOD 8080 AND 8081)  Are EVAL standard calibration factors and			<del></del>
3.2 CALIBRATIONS (METHOD 8080 AND 8081)  Are EVAL standard calibration factors and			
3.2 CALIBRATIONS (METHOD 8080 AND 8081)  Are EVAL standard calibration factors and %RSD values acceptable?			
Are EVAL standard calibration factors and %RSD values acceptable?	<u> </u>		
Are EVAL standard calibration factors and %RSD values acceptable?			
*RSD values acceptable?	3.2 CALIBRATIONS (METHOD 8080 AND 8081)		
Are quantitation column calibration factor  %RSD values acceptable?	Are EVAL standard calibration factors and %RSD values acceptable? Yes	No	(N/A
Are continuing calibration %D values acceptable? Yes No N/A  3.3 INSTRUMENT PERFORMANCE AND INITIAL CALIBRATION (3/90 SOW)  Was the initial calibration sequence performed? Yes No N/A  Was the resolution acceptable in the resolution check mix? . Yes No N/A  Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A  Are DDT and Endrin breakdowns acceptable? Yes No N/A  Are retention times in PEMs and calibration mixes acceptable? Yes No N/A  Are %RSD values in the PEMs acceptable? Yes No N/A  Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW)  Were the analytical sequence requirements met? Yes No N/A	Are quantitation column calibration factor	No	N/A
3.3 INSTRUMENT PERFORMANCE AND INITIAL CALIBRATION (3/90 SOW)  Was the initial calibration sequence performed? Yes No N/A was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are %RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW)  Were the analytical sequence requirements met? Yes No N/A	Were the analytical sequence requirements met? Yes	No	N/A
3.3 INSTRUMENT PERFORMANCE AND INITIAL CALIBRATION (3/90 SOW)  Was the initial calibration sequence performed? Yes No Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are RPD values in PEMs and calibration mixes acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW)  Were the analytical sequence requirements met? Yes No N/A	Are continuing calibration %D values acceptable? Yes	No	N/A
3.3 INSTRUMENT PERFORMANCE AND INITIAL CALIBRATION (3/90 SOW)  Was the initial calibration sequence performed? Yes No Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are RPD values in PEMs and calibration mixes acceptable? Yes No N/A Are %RSD values acceptable? Yes No Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW)  Were the analytical sequence requirements met? Yes No N/A	Comments:		
Was the initial calibration sequence performed? Yes No N/A Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are %RSD values in the PEMs acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A		-	
Was the initial calibration sequence performed? Yes No N/A Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A			
Was the initial calibration sequence performed? Yes No N/A Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A			
Was the initial calibration sequence performed? Yes No N/A Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A			
Was the initial calibration sequence performed? Yes No N/A Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A	3.3 INSTRUMENT PERFORMANCE AND INITIAL CALIBRATION (3/90 SOW)	·	$\overline{\wedge}$
Was the resolution acceptable in the resolution check mix? . Yes No N/A Is resolution acceptable in the PEM, INDA and INDB? Yes No N/A Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A	• •	No	'l N A
Is resolution acceptable in the PEM, INDA and INDB? Yes No Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Are %RSD values acceptable?	·		1.1
Are DDT and Endrin breakdowns acceptable? Yes No N/A Are retention times in PEMs and calibration mixes acceptable? Yes No N/A Are RPD values in the PEMs acceptable? Yes No N/A Comments:    Comments:	••		1 1
Are retention times in PEMs and calibration mixes acceptable? . Yes No Are RPD values in the PEMs acceptable? Yes No Are %RSD values acceptable? Yes No Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW)  Were the analytical sequence requirements met? Yes No N/A	• •		- 1 ° 1
Are RPD values in the PEMs acceptable? Yes No N/A  Are %RSD values acceptable?		•	1 1
Are %RSD values acceptable? Yes No N/A Comments:  3.4 CALIBRATION VERIFICATION (3/90 SOW)  Were the analytical sequence requirements met? Yes No N/A	· ·		/ · · · · · · · · · · · · · · · · · · ·
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A	<b>1</b>		A 1. 1
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A		No	N/A/
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A	Comments:		<u> </u>
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A			<del></del>
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A			
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A			<u>-</u>
3.4 CALIBRATION VERIFICATION (3/90 SOW) Were the analytical sequence requirements met? Yes No N/A	•		
Were the analytical sequence requirements met? Yes No $\int N/A$			
l · ·	•	No.	(N/A
Are initial calibrations acceptable? Yes No N/A			\ '.



### PESTICIDE/PCB DATA VALIDATION CHECKLIST

Are retention times acceptable in the		•		
PEMs, INDA and INDB mixes?				N/A
Are RPD values in the PEMs acceptable?				N/A
Are the DDT and endrin breakdowns acceptable?	• •	Yes	s No	N/A
Was GPC cleanup performed?		Yes	s No	N/A
Is the GPC calibration check acceptable?	• •	. Yes	s No	N/A
Was Florisil cleanup performed?	. • •	Ye	s No	N/A
Is the Florisil performance check acceptable?		Yes	s No	( N/A
Comments:				
•			·	
4. BLANKS	•,	· · · · ·		
Were laboratory blanks analyzed?		(e	on (a	N/A
Are laboratory blank results acceptable?			•	N/A
Were field/trip blanks analyzed?		_		N/A
Are field/trip blank results acceptable?				MTA
Comments:				0
5. ACCURACY	<del></del>			<del></del>
Were surrogates analyzed?		(Ye	s) No	N/A
Are surrogate recoveries acceptable?		Ye	s No	
Were MS/MSD samples analyzed?		(Ye	$\overline{}$	N/A
Are MS/MSD results acceptable?		. Ye	_	N/A
Were LCS samples analyzed?		Ye		
Are LCS results acceptable?		Ye	,	N/A
Comments: 42 + 43 - delete out - J7	UR		-	
		L		
		<del> </del>		<del></del>

W 000019

### PESTICIDE/PCB DATA VALIDATION CHECKLIST

5. PRECISION	
Are MS/MSD RPD values acceptable? Yes No Ny	Ά.
Are laboratory duplicate results acceptable? Yes No	' <b>A</b> ) '
Are field duplicate RPD values acceptable? Yes No $\sqrt{N}$	À
Are field split RPD values acceptable? Yes No VI	אני
Comments:	<del>-</del> .
	_
7. SYSTEM PERFORMANCE	$\overline{}$
Is chromatographic performance acceptable? Yes No N	/A `
Are positive results resolved acceptably? Yes No	/A)
Comments:	_
	_
8. COMPOUND IDENTIFICATION AND QUANTITATION	—
Is compound identification acceptable? Yes No	
Is compound quantitation acceptable? Yes No	″ · · ∖ l/A
Comments:	
	—
9. REPORTED RESULTS AND QUANTITATION LIMITS	
Are results reported for all requested analyses? Yes No	肾
Are all results supported in the raw data? Yes No (	!/A)
13461	N/A
Comments:	—
	—

N-1000020

Date:

19 January 2000

To:

Bechtel Hanford Inc. (technical representative)

From:

TechLaw. Inc.

Project:

105-DR FSB - Concrete

Subject: Inorganics - Data Package No. H0475-RLN (SDG No. H0475)

### INTRODUCTION

This memo presents the results of data validation on Data Package No. H0475-RLN prepared by RECRA LabNet (RLN). A list of samples validated along with the analyses reported and the method of analysis is provided in the following table.

Sample ID	Sample Date	Media	Validation	Analysis
BOWOY1	7/20/99	Solid	C	See note 1
B0W0Y2	7/20/99	Solid	С	See note 1
BOW0Y3	7/20/99	Solid	С	See note 1

<sup>1 -</sup> ICP metals by 6010B (lead); mercury by 7471A.

Data validation was conducted in accordance with the "Sample and Analysis Plan for 105F and 105DR Phase III Below Grade Structures and Underlying Soils" (DOE/RL-99-35). Appendices 1 through 5 provide the following information as indicated below:

Appendix 1. Glossary of Data Reporting Qualifiers

Appendix 2. Summary of Data Qualification

Appendix 3. Qualified Data Summary and Annotated Laboratory Reports

Appendix 4. Laboratory Narrative and Chain-of-Custody Documentation

Appendix 5. Data Validation Supporting Documentation

### DATA QUALITY OBJECTIVES

### Holding Times

Analytical holding times for metals are assessed to ascertain whether the holding time requirements were met by the laboratory. The holding time requirements are as follows: Samples must be analyzed within six (6) months for lead and 28 days for mercury.

All holding times were acceptable.

#### Blanks

### Preparation Blanks

At least one preparation blank, consisting of deionized distilled water processed through each sample preparation and analysis procedure, must be prepared and analyzed with every sample delivery group. In the case of positive blank results, samples with digestate concentrations less than five times the preparation blank value have had their associated values qualified as non-detected and flagged "U". Samples with concentrations of greater than five times the highest blank concentration do not require qualification.

In the case of negative blank results, if the absolute value exceeds the Contract Required Detection Limit (CRDL), all nondetects are rejected and flagged "UR" and all detects that are less than ten times the absolute value of the associated preparation blank result are qualified as estimates and flagged "J". If the absolute value of the negative preparation blank is greater than the IDL and less than or equal to the CRDL, all nondetects are qualified as estimates and flagged "UJ" and all detects less than ten times the absolute value of the blank are qualified as estimates and flagged "J". If the sample results are greater than ten times the absolute value of the preparation blank, no qualification is necessary.

All preparation blank results were acceptable.

### Accuracy

### Matrix Spike

Matrix spike analyses are used to assess the analytical accuracy of the reported data and the effect of the matrix on the ability to accurately quantify sample concentrations. Matrix spike recoveries must fall within the range of 70% to 130%. Samples with a spike recovery of less than 30% and a sample result below the IDL are rejected and flagged "UR". Samples with a spike recovery of 30% to 69% and a sample result less than the IDL are qualified "UJ". Samples with a spike recovery of greater than 130% or less than 70% and a sample result greater than the IDL are qualified as estimates and flagged "J". Finally, for samples with a spike recovery greater than 130% and a sample result less than the IDL, no qualification is required.

Due to a matrix spike recovery of 182%, all mercury results were qualified as estimates and flagged "J".

All other matrix spike recovery results were acceptable.

#### Precision

### Laboratory Duplicate Samples

Laboratory duplicate sample analyses are used to measure laboratory precision and sample homogeneity. Results must be within RPD limits of plus or minus 30% for solid samples. If RPD values are out of specification and the sample concentration is greater than five times the CRDL, all associated sample results are qualified as estimated and flagged "J". If RPD values are plus or minus two times the CRDL and the sample concentration is less than five times the CRDL, all associated sample results are qualified as estimated and flagged "J/UJ". The performance criteria for aqueous laboratory duplicates are an RPD less than 20% for positive sample results greater than five times the CRDL or plus or minus the CRDL for positive sample results less than five times the CRDL. Sample results outside the criteria are qualified as estimates and flagged "J/UJ".

Due to an RPD of 161%, all mercury results were qualified as estimates and flagged "J".

All other laboratory duplicate results were acceptable.

### Analytical Detection Levels

Reported analytical detection levels are compared against the 105DR PQLs to ensure that laboratory detection levels meet the required criteria. All reported laboratory detection levels met the analyte specific PQL.

### Completeness

Data package No. H0475-RLN (SDG No. H0475) was submitted for validation and verified for completeness. The completion percentage was 100%.

### **MAJOR DEFICIENCIES**

None found.

### **MINOR DEFICIENCIES**

Due to a matrix spike recovery of 182%, all mercury results were qualified as estimates and flagged "J". Due to an RPD of 161%, all mercury results were qualified as estimates and flagged "J". Data flagged "J" is an estimate, but under the BHI validation SOW, the data may be usable for decision-making purposes. All other validated results are considered accurate within the standard error

associated with the methods.

### **REFERENCES**

BHI, MRB-SBB-A23665, Validation Statement of Work, Bechtel Hanford Incorporated, September 5, 1997.

DOE/RL-99-35, Sample and Analysis Plan for 105F and 105DR Phase III Below Grade Structures and Underlying Soils.

Glossary of Data Reporting Qualifiers

Qualifiers which may be applied by data validators in compliance with BHI validation SOW are as follows:

- Indicates the compound or analyte was analyzed for and not detected in the sample. The value reported is the sample quantitation limit corrected for sample dilution and moisture content by the laboratory.
- UJ Indicates the compound or analyte was analyzed for and not detected in the sample. Due to a QC deficiency identified during the data validation, the associated quantitation limit is an estimate.
- Indicates the compound or analyte was analyzed for and detected. Due to a QC deficiency identified during the data validation, the associated concentration is an estimate, but the data are usable for decision-making purposes.
- BJ Applied to inorganic analyses only. Indicates the analyte concentration was greater than the IDL but less than the CRDL and is considered an estimated value.
- Indicates the compound or analyte was analyzed for, detected, and due to an identified QC deficiency, the data are unusable.
- UR Indicates the compound or analyte was analyzed for and not detected in the sample. Additionally, the data is unusable due to an identified QC deficiency.
- NJ Indicates presumptive evidence of a compound at an estimated value.
   The data may not be valid for some specific applications (i.e., usable for decision-making, purposes).
- N '- Indicates presumptive evidence of a compound. The data may not be valid for some specific applications (i.e., usable for decision-making purposes).

Appendix 2
Summary of Data Qualification

### **DATA QUALIFICATION SUMMARY**

SDG: H0475	REVIEWER: TLI	DATE: 1/19/00	PAGE_1_OF_1_
COMMENTS:			
COMPOUND	QUALIFIER	SAMPLES AFFECTED	REASON
Mercury	J	All	Matrix spike
Mercury	J	All	RPD

**Qualified Data Summary and Annotated Laboratory Reports** 

aboratory: RECRA L	abblet																				
ase	SDG: HO	475																			
Sample Number		BOWOY1		BOW0Y2		BOW0Y3				1		T		<u> </u>		1					
ocation		Α		C-1		C-1			_			1			_	f					
lemarks		-				<del>                                     </del>		1				1			_			<del>                                     </del>			
ample Date		7/20/99		7/20/99		7/20/99		•	_	i —				T				<u> </u>			
norganics	CROL	Result		Result		Result	Q	Result	Q	Result	Q	Result	Q	Result	a	Result	Q	Result	Q	Result	7
lercury	0.08			0.28	5	1.1	J														T
ead	20	29.0		60.3		45.4				<u> </u>	$\vdash$	-			1.						7
									1		二		1	ļ	#						#
											上		<del>  -</del>	<u> </u>	1		1				7
		┡}		<b></b>	_	<del> </del> -	-		├		╄	<del> </del> -	╁	-	╁		┾╌	-	-	<del> </del> -	$\dashv$
							ļ		1		二	ļ <u>.</u>			1						_
								<u> </u>			士	\ <u> </u>		ļ	上						1
						<del> </del>			╁	-	┼	<b> </b>		ļ-	╁-	<b> </b> -	<b>-</b>	<del>                                     </del>	<del> </del>	<del> </del> -	-
									匚			<u> </u>		1	二						_
											_				1-						_
											┢		-	<del> </del>	$\vdash$				-	<del> </del>	4
									1		$\vdash$			-	$\perp$		1				<del>-</del>
	<del></del>				_	<u> </u>					$\perp$			<u></u>	士						<del> </del>
									-		<del>-</del>		$\leftarrow$	<b></b>	-						_
					_										二						_
		┝──┤		·		<b> </b> -	-	-			上	<del> </del>	1				<u> </u>			<u> </u>	-
										ļ			$\mathbf{I}$		Ţ		<del>                                     </del>	·			
	l								<b></b>	<u> </u>	↓		_	ļ <u>.</u>		<b> </b>	ـــ	——	⊢		_

#### Regra LabNet - Lionville

### INORGANICS DATA SURGARY REPORT 08/04/99

CLIENT: THU-HANFORD B99-076

WORK ORDER: 10985-001-001-9999-00

RECEA LOT #1 99071501

					REPORTING	DILUTION
Sample	SITE ID	AMALYTE	RESULT	UNITS	LIMIT	PACTOR
******	20070707022200227026	# # # # # # # # # # # # # # # # # # #				****
-001	BOWOY1	Mercury, Total	0.33 J	MG/KG	0.02	1.0
		Lead, Total	29.0	Ma\Ká	3.4	1.0
-002	BOMOX3	Mercury, Total	o.2 <b>•</b> I	MG/RG	. 0.02	1.0
		Lead, Total	60.3	Mg/Kg	3.6	1.0
			/			•
-003	BOMO X3	Mercury, Total	1.1 ]	Mg/Kg	0.02	1.0
		Lead, Total	45.4	Mg/Kg	3.4	1.0

10/18/99

Laboratory Narrative and Chain-of-Custody Documentation



Chemical and Environmental Measurement Information

### Recra LabNet Philadelphia Analytical Report

W.O.#: 10985-001-001-9999-00

Date Received: 07-23-99

AUB 1999

RECEIVED

Client: TNU-HANFORD B99-076

**RFW#: 9907L501** 

**SDG/SAF#:** H0475/B99-076

### **METALS CASE NARRATIVE**

- 1. This narrative covers the analyses of 3 solid samples.
- 2. The samples were prepared and analyzed in accordance with methods checked on the attached glossary.
- 3. All analyses were performed within the required holding times.
- 4. The cooler temperature has been recorded on the Chain of Custody.
- 5. All Initial and Continuing Calibration Verifications (ICV/CCVs) were within the 90-110% control limits (80-120% for Mercury).
- 6. All Initial and Continuing Calibration Blanks (ICB/CCBs) were within control limits (less than the PQL).
- 7. All preparation/method blanks (MB) were within method criteria {less than the Practical Quantitation Limit (3X the IDL or samples greater than 20X MB value}. Refer to the Inorganics Method Blank Data Summary.
- 8. All ICP Interference Check Standards were within control limits.
- 9. All laboratory control sample (LCS) were within the laboratory control limits. Refer to the Inorganics Laboratory Control Standards Report.
- 10. The matrix spike (MS) recovery for Mercury was outside the 75-125% control limits. Refer to the Inorganics Accuracy Report. When the MS is outside the control limits, a serial dilution is performed.

The results presented in this report relate only to the analytical testing and conditions of the samples at receipt and during storage. All pages of this report are integral parts of the analytical data. Therefore, this report should only be reproduced in its entirety of pages.

- 11. The Mercury duplicate analysis was outside the 20% Relative Percent Difference (RPD) control limits. Refer to the Inorganics Precision Report.
- 12. For the purposes of this report, the data has been reported to the Instrument Detection Limit (IDL). Values between the IDL and the Practical Quantitation Limit (PQL) are acquired in a region of less-certain quantification.

J. Michael Taylor

Vice President

Philadelphia Analytical Laboratory

mld/m07-501

<u>8-4-99</u>

Date



200

Callector F ahiberg/Porter Project Designation			Company Contact Telephone No.  J Adler 373-4316 Project Coordinator TRENT, SJ  Sampling Location SAF No.								9K	Data Turneround 15 Days		
105-DR FSB - Concrete		105-		B99-076	Ì			is Days						
Ice Chest No. Field Logbook No. EL 1281								Method of Shi	-		,			
Shipped To  AMAJRECRA  RS 7.20.	9	Offsite	Property No.	-			-	Rill of Lading	Air Bill N	0.				
		<del></del>						COA TO	105	D4	287	زے		
POSSIBÍ E SAMPLE HAZA	ARDS/REMARKS		Preservation	Cool 4C	Name	None								
			Type of Container	aG	aC	#G								
			No. of Container(s)	, , , , ,	,	<u> </u>					1			
Special Handling and/or Stor	rage	-	Volume	60mL	60mL	120mL								
	SAMPLE ANA	LYSIS		PCBs - 1000	ICP Menh - 6010A (Add- on) {Lend}; Mentary - 7471 - (CV)	See item (1) in Special Instructions.								
Sample No.	Matrix •	Sample Date	Sample Time	(A) ISS	為大學	A STATE F	1	<b>2</b> 63 1385	TATE OF	\$ 1640 P		建级军城	400	
30 <b>W</b> 0Y1	Other Solid	7.20-7	9 0855	Х	x						tick	Bou	046	
30M0Y2	Other Solid	7.20.9	9 0905	X	Х			· <u>                                     </u>			•	Row	9Y7_	
30 <del>(40</del> Y3	Other Solid		19 09 20	*	X				<u> </u>			BOW	OYE	
<u>0</u>								<b></b>		•	<del>                                     </del>		<u> </u>	
<u>C7</u>		<u> </u>	'		SPEC	AL INSTR	UCTION	S	<u>.                                    </u>			Matrix	·	
CITAIN OF POSSESSION		Sign/Print				amma Spectros	copy (Ces	ium-137, Cohalt ium; Isotopic Ur	60, Europia	m-152, Europius	H154,	Soil Water		
elinquished By	Dute/Time ( 9:	r Rank	1-C 7	7. 20.8	\$9,90	Total Sr; Te	chaetium-9	nam; menopic or 9; Nickel-63; Ca	nbon-14; Tri	tium - H3	-	Vapor Other Solid Other Liqui	•	
elinquished By  Ref 2-5 7- clinquished By	22 · 55 0 86		1250 hlla	te/Time/So ee 7-22 te/Time	<del>द</del> ुर									
elinquished By  Clinquished By	DeloTime		Ex_	te/Time			·			•			,	
LABORATORY Receives 4	. 1			Tic	ie .							Oste/Time	0011	
SECTION Disposal M	Melles					Dispo	sed By		•	_		13/99 Date/Time	<u>0950)</u>	
OSITION			·										<u> </u>	

# Appendix 5

**Data Validation Supporting Documentation** 

## WHC-SD-EN-SPP-002, Rev. 2

#### INORGANIC ANALYSIS DATA VALIDATION CHECKLIST

VALIDATION LEVEL:	Α	В	(0)	D	E
PROJECT:  O	SDR ASK	concrete	DATA PACKAGE	: HO4	1'5
VALIDATOR:	TLI	LAB: Rec	ra	DATE:  O	18 97
CASE:			SDG: HO	475	
		ANALYSES	PERFORMED		
□ CLP/ICP	C CLP/GFAA	□ CUP/Hg	□ CLP/Cyenide	a	0
SW-846/ICP	SW-846/GFAA	ELEN-846Mg	□ SW-846 Cyenide	Ġ	a
SAMPLES/MATE	RIX BOW	oyl Bo	۵ ، ۱۶ م	30-2043	
	·			<u> </u>	
			٠.		
		<del> </del>	·	<u> </u>	
		··	••		Salid
Is technical Is a case nar	CAGE COMPLETEN verification rative preser	documentation	n present? .	,	Yes No N/A
				•	<del> </del>
2. HOLDING		,		<u> </u>	<u> </u>
	olding times a				Yes) No N/A
		_	<del></del>		
					<del></del>
···			. ·		

## WHC-SD-EN-SPP-002, Rev. 2

#### INORGANIC ANALYSIS DATA VALIDATION CHECKLIST

3. INSTRUMENT PERFORMANCE AND CALIBRATIONS	
Were initial calibrations performed on all instruments? Yes	No NA
Are initial calibrations acceptable? Yes	No N/A
Are ICP interference checks acceptable? Yes	No N/A
Were ICV and CCV checks performed on all instruments? Yes	No N/A
Are ICV and CCV checks acceptable? Yes	No N/A
Comments:	
	·
	<u> </u>
4. BLANKS	
Were ICB and CCB checks performed for all applicable analyses? Yes	No NA
Are ICB and CCB results acceptable? Yes	No N/A
Were preparation blanks analyzed? Yes	No N/A
Are preparation blank results acceptable? Yes	No N/A
Were field/trip blanks analyzed? Yes	No N/A
Are field/trip blank results acceptable? Yes	No TOP
Comments:	
5. ACCURACY	
Were spike samples analyzed? Yes	No N/A
Are spike sample recoveries acceptable? Yes	No N/A
Were laboratory control samples (LCS) analyzed? Yes	No (N/A
Are LCS recoveries acceptable? Yes	No N/A
Comments: 182 70 for Hy Jall (all delection	3
	·-··

## WHC~SD-EN-SPP-002, Rev. 2

# INORGANIC ANALYSIS DATA VALIDATION CHECKLIST

6. PRECISION						
Were laboratory duplicates analyzed?	•	•		. Yes	No	N/A
Are laboratory duplicate samples RPD values acceptable?	•		•	. Yes	(NO)	N/A
Were ICP serial dilution samples analyzed?				. Yes	No	(N/A)
Are ICP serial dilution %D values acceptable?					No	WA
Are field duplicate RPD values acceptable?					(No)	N/A
Are field split RPD values acceptable?					No	10A)
Comments: Ha 16170 rpd						
T. CURVACE AS AUGUSTA						$\overline{}$
7. FURNACE AA QUALITY CONTROL						()
Were duplicate injections performed as required?					No	N/A
Are duplicate injection %RSD values acceptable?					No	/ N/A
Were analytical spikes performed as required?					No	N/A
Are analytical spike recoveries acceptable?					No	N/A
Was MSA performed as required?	•	•"	•	. Yes	No \	N/A
Are MSA results acceptable?	•	•		. Yes	No '	\ n/ay
Comments:		_				$\stackrel{\smile}{-}$
		_	_			
			_	<del> </del>		
			_			
8. REPORTED RESULTS AND DETECTION LIMITS						
Are results reported for all requested analyses?	•		•	. Yes	No	N/A
Are all results supported in the raw data?					No	N/A
Are results calculated properly?					No	₹ŽÀ
Do results meet the CRDLs?					No	N/A
Comments:						
			_	<del></del>		
		_		<del></del>		
			_			

# Recra LabWet - Lionville

# INCRGANICS ACCURACY MEPORT 09/04/9

	96.0	. 61.3 86.8	29.0	82.2	Lead, Total		
•	0.20 181.9	0.20	0.33	0.70	Mercury, Total	TAOMOR	-001
		*******	•	***			
FACTOR (8	RECOV	AMOUNT RESCOV	RESULT	EYOUE	ELLTORY	STITE ID	\$710LT
MOLLATICA		SPIXED	Telesia	SPIKED			
	i				00	WORK ORDER: 10985-001-001-9999-00	HORK ORDI
	9	#: 9907L5	RECEA LOT #: 9907L501			CLIEBT: THU-HAMPOID B99-076	CLIENT:

# Regra Labiet - Liouville

# INORGANICS PRECISION REPORT 08/04/9

RECRA LOT #: 99071501			REPLICATE RPD	1 161.3	33.4 . 34.1
RECEA LA				3.1	3
		DITTOR	RESULT	0.33	29.0
	00		ARALYTH	Mercury, Total	Lead, Total
CLIENT: THU-HANFORD B99-076	WORK ORDER: 10985-061-061-9999-08	_	erre ro	BOWOY1	
CLIENT: T	MORK ORDE		SAMPLE	-001XKP	

PACTOR (REP)

Date:

19 January 2000

To:

Bechtel Hanford, Inc. (technical representative)

From:

TechLaw, Inc.

Project:

105-DR FSB - Concrete

Subject: Radiochemistry - Data Package No. H0475-TNU (SDG No. H0475)

#### INTRODUCTION

This memo presents the results of data validation on Summary Data Package No. H0475-TNU which was prepared by Thermo NUtech (TNU). A list of samples validated along with the analyses reported and the requested analytes is provided in the following table.

Sample ID	Sample Date	Media	Validation	Analysis
BOWOX9	07/19/99	Solid	С	See note1
BOWOYO	07/19/99	Solid	С	See note 1

<sup>1 -</sup> Gamma spectroscopy; alpha spectroscopy (isotopic uranium, isotopic plutonium and americium-241); total strontium; nickel-63; tritium; carbon-14; technetium-99.

Data validation was conducted in accordance with the "Sample and Analysis Plan for 105F and 105DR Phase III Below Grade Structures and Underlying Soils" (DOE/RL-99-35). Appendices 1 through 5 provide the following information as indicated below:

- Appendix 1. Glossary of Data Reporting Qualifiers
- Appendix 2. Summary of Data Qualification
- Appendix 3. Qualified Data Summary and Annotated Laboratory Reports
- Appendix 4. Laboratory Narrative and Chain-of-Custody Documentation
- Appendix 5. Data Validation Supporting Documentation

#### DATA QUALITY OBJECTIVES

#### Holding Times

Holding times are calculated from Chain-of-Custody forms to determine the validity of the results. The maximum holding time for radiochemical analysis is 6 months with liquid scintillation requiring analysis within 7 days of distillation.

All holding times were acceptable.

#### Blanks

#### Laboratory Blanks

Blank samples are analyzed to determine if positive results are due to laboratory reagent, sample container, or detector contamination. If blank analysis results indicate the presence of an analyte above the MDA, the following qualifiers are applied: All positive sample results less than five times the highest blank concentration are qualified as estimates and flagged "J"; sample results below the MDA are qualified as undetected and flagged "U"; sample results above the MDA and greater than five times the highest blank concentration are not qualified.

All laboratory blank results were acceptable.

#### Accuracy

Accuracy is evaluated by analyzing distilled water or field samples spiked with known amounts of radionuclides. The sample activity as determined by analysis is compared to the known activity to assess accuracy. The acceptable laboratory control sample and matrix spike recovery is 70-130% (80-120% for gamma spectroscopy). In addition, samples may be spiked with a radiochemical tracer to assist in isolating the radioisotope of interest with the yield of the tracer being used in calculating sample activity. The acceptable range for tracer recovery is 20% to 105%. Spike sample results outside the above ranges result in associated sample results being qualified as estimates, rejected, or not qualified, depending on the activity of the individual sample.

All accuracy results were acceptable.

#### Precision

Analytical precision is expressed by the RPD between the recoveries of duplicate matrix spike analyses performed on a sample. Precision may also be assessed using unspiked duplicate sample analyses. If both sample and replicate activities are greater than five times the CRDL and the RPD is less than 30 percent, the results are acceptable. If either activities are less then five times the CRDL, a control limit of less than or equal to two times the CRDL is used for soil samples and less than or equal to the CRDL for water samples. If either the original or replicate value is below the CRDL, the applicable control limits are less than or equal to the CRDL for water samples and less than or equal to two times the CRDL for soil samples. If the RPD is outside the applicable control limit, associated results are qualified as estimated detects or estimated non-detects.

All duplicate results were acceptable.

#### Detection Levels

Reported analytical detection levels are compared against the 105DR PQLs to ensure that laboratory detection levels meet the required criteria. All reported laboratory MDAs were at or below the analyte-specific TDL.

#### Completeness

Data Package No. H0475 (SDG No. H0475) was submitted for validation and verified for completeness. The completion rate was 100%.

#### **MAJOR DEFICIENCIES**

None found.

#### MINOR DEFICIENCIES

None found.

#### REFERENCES

BHI, MRB-SBB-A23665, *Validation Statement of Work*, Bechtel Hanford Incorporated, September 5, 1997.

DOE/RL-99-35, Sample and Analysis Plan for 105F and 105DR Phase III Below Grade Structures and Underlying Soils.

Appendix 1

Glossary of Data Reporting Qualifiers

Qualifiers which may be applied by data validators in compliance with the BHI statement of work are as follows:

- Indicates the compound or analyte was analyzed for and not detected above the minimum detectable activity (MDA) in the sample. The value reported is the sample result corrected for sample dilution and moisture content by the laboratory. The data is usable for decision making purposes.
- Indicates the compound or analyte was analyzed for and not detected at
  concentrations above the minimum detectable activity (MDA) in the
  sample. Due to a QC deficiency identified during the data validation, the
  associated quantitation limit is an estimate, but is usable for decision
  making purposes.
- Indicates the compound or analyte was analyzed for and detected. Due to a QC deficiency identified during the data validation, the associated concentration is an estimate, but the data are usable for decision-making purposes.
- R Indicates the compound or analyte was analyzed for, detected, and due to an identified QC deficiency, the data are unusable.
- UR Indicates the compound or analyte was analyzed for and not detected in the sample. Additionally, the data is unusable due to an identified QC deficiency.

Appendix 2
Summary of Data Qualification

#### **DATA QUALIFICATION SUMMARY**

SDG: H0475	REVIEWER: TLI	DATE: 1/19/00	PAGE_1_OF_1
COMMENTS: No qualifiers	assigned		
COMPOUND	QUALIFIER	SAMPLES AFFECTED	REASON

# Appendix 3

Qualified Data Summary and Annotated Laboratory Reports

ς	
(	
(	
	3
ζ	Ĉ

Project: BECHTEL-HANFORD				1																	
Laboratory: TNU				1																	
Case	SDG: H	0475		1																	
Sample Number		B0W0X9		BOWOYO				1				<u> </u>		[		Ϊ					$\neg$
Location		В		D																	$\neg \neg$
Remarks									-					<u> </u>							$\neg$
Sample Date		07/19/99		07/19/99																	ᅱ
Radiochemistry	CRDL	Result	a	Result	Q	Result	a	Result	Q	Result	Q	Result	Q	Result	Q	Result	α	Result	Ια	Result	a
Tritium		6.23		8.09									П				Г				$\Box$
Carbon-14	50	540		961									Π						1		$\sqcap$
Technetium-99	15	1.37		0.438													Г		T		$\Box$
Uranium-233/2 <b>34</b>	1	3.10		1.37															1		$\Box$
Uranium-235	1	0.321		0.059															1		П
Uranium-238	1	3.19		1.21																	П
Plutonium-238	1	5.77		6.63	L														П		П
Plutonium-239/40	1	358	<u> </u>	240	<u></u>		L					•									$\Box$
Nickel-63	30	5360		11900																	$\Box$
Americium-241	1	54.7		72.0																	П
Strontium (total)	1	4500		1980				.=													П
Potassium-40		U	U_	U	υ																
Barium-133		u	U	U	U,																
Cobalt 60	0.1	323		596																	
Cesium 137	0.1	5070		5140																	
Europium 152	0.2	806	Ĺ	2810														[			
Europium 154	0.2	105		518										,							
Europium 155	0.1	4.38		21.5					$\Box$												
Radium-226		U	U	U	1																
Radium-228		U	U	U		,															
Thorium-228		U	U		υ																
Thorium-232		U	U	U	υ																
Americium-241 (GEA)		60.0	U	119																	Ш
Uranium-238 (GEA)	l	U	Ų	U	U																Ш
Uranium-235 (GEA)		U	U_	U	U																Ш
				:					$\Box$												Ш
															$\Box$				Ш		Ш
																					Ш
									[												Ш

BOWOX9

#### DATA SHEET

7166 L.A. Johnson	Client/Case no Contract	<u>Hanford</u> <u>SDG-H0475</u> <u>TRB-SBB-207925</u>
	Client sample id Location/Matrix Collected Custody/SAF No	105-DR SOLID 07/19/99 10:15

ANALYTE	CAS NO	RESULT pCi/g	20 ERR (COUNT)	MDA pci/g	RDL pci/g	QUALI- FIERS	Test
Tritium	10028-17-8	6.23	0.17	0.087	400	3	H
Carbon 14	14762-75-5	540	8.6	4.4	50		С
Technetium 99	14133-76-7	1.37	0.51	0.88	15	J	TC
Uranium 233/234	U-233/234	3.10	0.33	0.080	1.0		U
Uranium 235	15117-96-1	0.321	0.091	0.048	1.0	J	U
Uranium 238	U-238	3.19	0.34	. 0.075	1.0		ט
Plutonium 238	13981-16-3	5.77	0.50	0.031	1.0		ÞΩ
Plutonium 239/240	PU-239/240	358	24	0.050	1.0	B	PU
Nickel 63	13981-37-8	5360	54	5.3	30		NI_L
Americium 241	14596-10-2	54.7	11	0.34	1.0		AM
Total Strontium	SR-RAD	4500	9.0	0.27	1.0		SR
Potassium 40	13966-00-2	ט		7.3		ט	GAM
Barium 133	13981-41-4	ט		2.6	•	UX	GAM
Cobalt 60	10198-40-0	323	2.5	1.1_	0.050		GAM
Cesium 137	10045-97-3	5070	7.0	2.5	0.10		MAĐ
Europium 152	14683-23-9	806	6.4	7.1	0.10		GAM
Europium 154	15585-10-1	105	3.9	3.4	0.10		GAM
Europium 155	14391-16-3	4.38	2.9	4.0	0.10		gam
Radium 226	13982-63-3	Ū		3.2	, 0.10	Ū	GAM
Radium 228	15262-20-1	ט		7.2	0.20	U	GAM
Thorium 228	14274-82-9	U		2.8		a .	GAM
Thorium 232	TH-232	ד		7.2		Ū	GAM
Americium 241	14596-10-2	60.0	1.6	2.2			GAM
Uranium 238	บ-238	U		250		U	GAM
Uranium 235	15117-96-1	Ū		5.8		σ	GAM

105-DR FSB-Concrete

1/K/00

DATA SHEETS
Page 1
SUMMARY DATA SECTION
Page 15

Protocol Hanford
Version Ver 1.0
Form DVD-DS
Version 3.06
Report date 10/07/99

BOWOY0

#### -DATA SHEET

7166 L.A. Johnson	Client/Case no Contract	Hanford TRB-SBB-207925	SDG-H0475
	Client sample id Location/Matrix Collected Custody/SAF No	105-DR 07/19/99 10:45	SOLID B99-076

ANALYTE	CAS NO	RESULT pCi/g	26 ERR (COUNT)	MDA pCi/g	RDL pci/g	QUALI- FIERS	TEST
Tritium	10028-17-8	8.09	0.19	0.085	400	<b>J</b> .	_H
Carbon 14	14762-75-5	961	12	5.0	50		C
Technetium 99	14133-76-7	0.438	0.35	0.66	15	U	TC
Uranium 233/234	U-233/234	1.37	0.22	0.054	1.0		Ū
Uranium 235	15117-96-1	0.059	0.051	0.065	1.0	U	U
Uranium 238	U-238	1.21	0.20	0.054	1.0		u
Plutonium 238	13981-16-3	6.63	0.52	0.063	1.0		PU
Plutonium 239/240	PU-239/240	240	15	0.027	1.0	В	PU
Nickel 63	13981-37-8	11900	120	8.1	30		NI_I
Americium 241	14596-10-2	72.0	14	0.30	1.0		AM
Total Strontium	SR-RAD	1980	4.7	0.17	1.0	В	SR
Potassium 40	13966-00-2	U		11		σ.	GAM
Barium 133	13981-41-4	U		3.0		UX	GAM
Cobalt 60	10198-40-0	596	3.3	_ 1.8	0.050		GAM
Cesium 137	10045-97-3	5140	7 0	2.6	0.10		GAM
Europium 152	14683-23-9	2810	10	9.7	0.10		GAM
Europium 154	15585-10-1	518	7.1	6.2	0.10		GAM
Europium 155	14391-16-3	21.5	4.3	6.3	. 0.10		GAM
Radium 226	13982-63-3	ט		4.7_	. 0.10	U	GAM
Radium 228	15262-20-1	Ū		9.9	0.20	IJ	GAM
Thorium 228	14274-82-9	ט		3.3		σ	GAM
Thorium 232	TH-232	ช		9.9		Ø	GAM
Americium 241	14596-10-2	119	5.5	7.5			GAM
Uranium 238	<b>U-238</b>	ט		340		U	GAM
Uranium 235	15117-96-1	Ū		7.0	•	U	GAN

105-DR FSB-Concrete

pr/19/00

DATA SHEETS
Page 2
SUMMARY DATA SECTION
Page 16

Lab id TMANC
Protocol Hanford
Version Ver 1.0
Form DVD-DS
Version 3.06
Report date 10/07/99

# Appendix 4

Laboratory Narrative and Chain-of-Custody Documentation

#### Case Narrative

10 j

#### 1.0 GENERAL

Bechtel Hanford Inc. Sample Delivery Group H0475 is composed of two solid samples designated under SAF No. B99-076 with a Project Designation of: 105-DR FSB-Concrete.

The sample was received as stated on the Chain-of-Custody document. Any discrepancies are noted on the TNU Sample Receipt Checklist. The results were transmitted to BHI via facsimile on August 19, 1999.

#### 2.0 ANALYSIS NOTES

#### 2.1 Gamma Scan Analyses

No problems were encountered during the course of the analyses.

#### 2.2 Total Strontium Analyses

The RPD in the duplicate result and the original was 28%, greater than the 3 sigma total limit of 22%. The blank sample indicated slight cross contamination from the high activity of the samples.

#### 2.3 Americium-241 Analyses

No problems were encountered during the course of the analyses although all client samples, the duplicate and the LCS sample were recounted.

#### 2.4 Isotopic Plutonium Analyses

No problems were encountered during the course of the analyses although all client samples and the duplicate were recounted.

#### 2.5 Nickel-63 Analyses

No problems were encountered during the course of the analyses.

#### 2.6 Isotopic Uranium Analyses

No problems were encountered during the course of the analyses, although sample BOWOX9 was recounted.

#### 2.7 Carbon-14 Analyses

The RPD in the duplicate result and the original was 23%, slightly greater than the 3 sigma total limit of 22%.

#### 2.8 Tritium Analyses

No problems were encountered during the course of the analyses.

#### 2.9 Technetium-99 Analyses

The RPD in the duplicate result and the original was 59%, slightly greater than the 3sigma total limit of 58%.

Decuter transfold In	e,	C	CHAIN OF CUSTODY/SAMPLE ANALYSIS REQUEST					T .	B99-076-01		Page 1	of <u>2</u> ·	
Collector F ahlberg/Porter	······································	Comp J A	dler	Telepho 373-				Project Coord TRENT, SJ	inator	Price Code	9K	_	rnaround
Project Designation 105-DR FSB - Concrete		Samp 105	ling Location -DR					SAF No. B99-076		•		15	Days
Ice Chest No.		Field EL	Logbook No. 1281			- · · · · · · · · · · · · · · · · · · ·		Method of Ship	pment Ex	<u> </u>			-
Shipped To TMA/RECKA TO 7-19.99		Offsit	e Property No.	·				Bill of Lading		io.			<del></del>
							_	COA T	710	5D4	287	<u> </u>	
POSSIBLE SAMPLE HAZARD	S/REMARKS		Preservation	Cool 4C	None	None ·							
			Type of Container	aG	aG	#G							
Special Handling and/or Storage	. •		No. of Container(s)  Volume	60mL	i 60mL	1 120mL	 				, .	I	
	SAMPLE ANAL	.Ysis	:	PCBs - 9000	ICP Metah - 6010A (Add- 9n) {Lead}; Mercury - 7471 - (CV)	See item (1) in Special Instructions.							
Sample No.	Matrix *	Sample Date	Sample Time										Concession of the second
B0W0X9	Other Solid	7.19-99	1015			X.	· ·			tieto	BC	MOA	4
BOWOYO	Other Solid	7.19.99	1045			x'			, ]	!	اص[	<u>لاه ل</u>	5
BOMOVI TEE 719 %	Other Solid,								1	!	,		
BOWNEYS 12 7 7 75	Other Solid	· · · · · · · · · · · · · · · · · · ·						ļ <u> </u>	:				
	Other Solid											Matrix	<u></u>
CHAIN OF POSSESSION  Relinquished By Relinquished By	Date/Time 1700	Sign/Print	Z-C D	te/Time 176	(1) Ga Europi 2 9 89,90	AL INSTRU mma Spectrosc um-155)   Isoto - Total Si   Teck		um-137, Cobalt-6 urly (sotopic Urn Nickel-63 Carl	0, Europiu nium Ame bon-14 Td	m-152, Europium ricium-241 Stron ĝum - H3	-154, <del>dian-</del>	Soil Water Vapor Other Solid Other Liquid	
Relinquished By  R. F. G. Lea   R. f. h.	Date/Time   374	Received By	2/Rfablbe	10-7-22 10-71me 9-9		•							
LABORATORY Received By	7-23-99	مد النصا	Coldenberg	7-23	-9 <i>9</i>	<u>.</u> .					D <sub>i</sub>	ne/Time	·
FINAL SAMPLE Disposal Method DISPOSITION		<u> </u>	<del></del>	<u>.                                    </u>		Dispose	d By				Da	te/Time	

# Appendix 5

**Data Validation Supporting Documentation** 

# WHC-SD-EN-SPP-001, Rev. 1

# RADIOCHEMICAL DATA VALIDATION CHECKLIST

VALIDATION LEVEL:	. A	B	(	)	1	)	Ε	
PROJECT: 10	SDR FSB	Concrete.	DATA F	PACKAGE	: H	047	5	
VALIDATOR:		LAB: TA	<i>/ / / / / / / / / /</i>		DATE:	10/	7/99	
CASE:			SDG:		H 04			
		ANALYSES	PERFORM					
☐ Gross Alphe/Bets	Strontium-90	X connetium-99	□ Alphe Spectrosc	ору	Spectros			.'
☐ Total Uranium	☐ Redium-22	Mitricium	X C14		X	J		
SAMPLES/MATE		οω σχη	<u></u>	~0Y6	<b>D</b>			
							sald	
1. Completen	ess		• • •				Д	EN/A
Technical ver	ification for	ms present? .				Ye:	) on z	N/A
Comments:	·	•			9			•
							· · ·	
2. Initial C	alibration .	• • • • • •		•, • •	• • •		· · · ¿	<b>Z</b> M\v
Instruments/d one yea	etectors cali r of sample a	brated within nalysis?	1			Ye	s No	N/A
Initial calib	ration accept	able?				Ye	s No	N/A
Standards NIS	T traceable?	• • • • • •				Ye	s No	N/A
Standards Exp	ired?	• • • • • •				Ye	s Nọ	N/A
Comments:								
							<del></del>	<del></del> -
			<del></del>	<del></del>	<del></del>		<del></del>	

3. Continuing Calibration		• • •		• •		TE	N/A
Calibration checked within one week of sample	e ana	lysis	? .	•	. Yes	No	N/A
Calibration check acceptable?						No	N/A
Calibration check standards NIST traceable?						No	N/A
Calibration check standards expired?						No	N/A
Comments:							
	·	<del>- :</del>	;				
		<del></del>	<u>.</u>				
		<u> </u>	•			·	<del></del>
4. Blanks						[	 ] N/A
Method blank analyzed?					(Yes)	No	N/A
Method blank results acceptable?					=	No	N/A
Analytes detected in method blank?						) No	N/A
Field blank(s) analyzed?							N/A
Field blank results acceptable?						No	<b>(</b> 73)
Analytes detected in field blank(s)?						No	
Transcription/Calculation Errors?						No	<b>Q</b> ZA
Comments: Du 239 SR-90 11 CO GO	c.\$	137		E	0152	1154/	155
Am 241 (sea) 1738 (sea)	027	3	-	٠,	~~ ^		<del></del>
No quel ree			·	· · ·			
						·	
5. Matrix Spikes	•, • •			•			A/N E
Matrix spike analyzed?				•	. Yes	No	N/A
Spike recoveries acceptable?						No	N/A
Spike source traceable?						No	N/A
Spike source expired?						No	. N/A
Transcription/Calculation Errors?							N/A
Comments: IR							
							<del> </del>
<u> </u>		<del></del>					<del></del>
						<del></del>	

# WHC-SD-EN-SPP-001, Rev. 1

6. Laboratory Control Samples
LCS analyzed?
LCS recoveries acceptable?
LCS traceable? Yes No NA
Transcription/Calculation Errors? Yes No
Comments: U233/34 I 822 US 8376 36C
7. Chemical Recovery
Chemical carrier added?
Chemical recovery acceptable?
Chemical carrier traceable? Yes No N/A
Chemical carrier expired?
Transcription/Calculation errors?
Comments:
8. Duplicates
and the second s
Comments: 5755
<u>C14 2392</u>

AL

9. Field QC Samples		• • •/.• •	□ N/A	
Field duplicate sample(s) analyzed?		NO (NO	A) N/A	• .
Field duplicate RPD values acceptable?		/	( N/A)	
Field split sample(s) analyzed?			N/A	
Field split RPD values acceptable?	•			
Performance audit sample(s) analyzed?			N/A	
Performance audit sample results acceptable?		and the second s	o) N/A o N/A	
Comments:	and the second s			
	<u> </u>	<u></u>		
			<u>.</u>	
10. Holding Times		·		
Are sample holding times acceptable?		Yes N	o N/A	
			·	
Comments:	<del></del>			
	··.		<del></del>	
	·			
		44		
11. Results and Detection Limits (Levels D & E)			□ N/A	
Results reported for all required sample analyses			lo N/A	
Results supported in raw data?			lo (N/A)	•
Results Acceptable?			lo N/A	
Transcription/Calculation errors?				
MDA's meet required detection limits?			N/A	
Transcription/calculation errors?			IO (NZ)	
·	-1			11/1
Comments: 6-40 CS137 all By Anza	HAY U	534 (gm)	2000	<del>~</del> ~ ₩
		<del></del>		
	<del></del>		<del></del>	
			<del></del>	



075769

Job No. 22192
Written Response Required: NC
Due Date: N/A
Actionee: N/A
Closes CCN: N/A
OU: N/A
TSD: N/A
ERA: N/A
Subject Code: 8620

TO:

J.G. Adler X5-53

R.S. Day X5-53 M.R. Morton X9-08

COPIES:

J.M. Duncan H9-03

Document and Info Services H0-09

FROM:

DATE:

R.L. Weiss 124

January 24, 2000

Sample Management H9-03/372-9592

SUBJECT:

VALIDATION OF POLYCHLORINATED BIPHENYLS (PCB) ANALYSIS FOR

SAMPLE DELIVERY GROUPS (SDG) H0475 & H0483

Analysis for PCBs was performed on samples in SDGs H0475 & H0483. During analysis, levels of one PCB mixture (Aroclor-1254) were determined initially above the upper calibration range for three samples (SDG H0475 – B0W0Y2 & B0W0Y3, SDG H0483 – B0W3Y6). In order to bring the analytical solution within the instrument calibration range for this Aroclor, a 10-fold dilution of the primary solutions were performed. This dilution has resulted in inappropriate validation parameters being applied to the non—detect results reported for these samples.

One component of quality control (QC) associated with analysis of PCBs includes addition of "surrogate" compounds to the sample prior to any sample preparation for analysis. Surrogate materials are expected to follow through sample preparation and analysis very similarly to the target compounds. Poor or non-recovery of the surrogates may indicate potential failure of the methodology to determine presence and concentrations of the target compounds. Because surrogates are very similar to the materials they mimic, surrogates are added (spiked) at levels within the normal calibration range for the target compounds. Most often, spiking levels are only 5 to 10 times the method detection limits (this gives the most "robust" data when attempting to establish non-detection for compounds). When the primary sample preparation must be diluted, the resulting levels of surrogate compound may be reduced below the detection limit of the equipment. This occurred in the analysis of the samples noted above.

The current validation procedure ("Data Validation Procedures for Chemical Analysis", WHC-SD-EN-WPP-002) used by the ERC to validate PCB analysis does not correctly address validation when the primary sample preparation must be diluted before final analysis. The wording of the procedure is:

"Qualify all associated detected results as estimated (J) and non-detects as unusable (R) for surrogate recoveries <10%"

Application of this requirement on the data for sample B0W3Y6, B0W0Y2 AND B0W0Y3 resulted in applying the "J" flag to the Aroclor-1254 result and "R" flag to all others (non-detects).

Distribution Page 2

The procedure used for ERC data is based on the "USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review", EPA540/R94/012. This document provides different guidance when validating PCB data when sample dilution is required. The wording of that document is:

"If low surrogate recoveries are found to be due to sample dilution, then professional judgement should be used to determine if the resulting data should be qualified. If sample dilution is not a factor, then detected target compounds may be qualified "J" and non-detected target compound results should be qualified unusable (R)."

The error in the procedure will be corrected as part of ongoing revision activities planned for the validation procedures occurring this year.

The non-detect results for samples B0W0Y2, B0W0Y3, & B0W3Y6 should not be considered to be unusable. The methodology has demonstrated the ability to detect Aroclor-1254. The presence of this PCB mixture has raised the detection limits for the other Aroclors, but should still be adequate to detect these materials if present. The "J" qualifier (estimated result but useable) is more appropriate for all PCB results for these samples.

RLW:dmr

# REVIEW OF VALIDATION PACKAGES – R.L. WEISS - JAN. 20, 2000 105-DR FSB

SDG H0544 - Inorganic, Radiochemistry, & PCB packages: no comment, OK

SDG H0475 - Inorganic, Radiochemistry, & PCB packages: no comment, OK

	Review Comment Record (RCR)				1. Date 2. Review No. 1/2500 BHI/QA0011		
					3. Project 105-DR	4. Page Page 1 o	f 1
5. Do	cument Number(s)/Title(s)	6. Program/Project/ Building Number			8. Organization/Group	9. Location/Phone	
SDG	No. H0475	105-DR FSB - Concrete	Claude Sta	cey	BHI/QA	H0-16/372	2-9208
17. Co	mment Submittal Approval:	10. Agreement with indicated of	omment dispositi	on(s)	11. CLOSED		
12. Item		Provide technical justification for the lation of the action required to correct/	14. Hold Point	15 Dienocit	tion (Provide justification if NO	Author/Originator	16. Status
1	All: OK No Comments	inicateu.)	- Foint	13. Disposit	tion (Frovide Justineation II NO	accepted.)	Status
2					<del></del>		
3							
		· · · · · · · · · · · · · · · · · · ·					
	I		I	I			1

# **FAX**

# TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanctte Duncan

From: Bruce Christian

Pages: 1

Date: 17 January 2000

Information Request

110475 - Rad

The new rad pages you sent me list the sample matrix as liquid versus solid everywhere else in the package.

# **FAX**

# TECHLAW, INC.

451 Цills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeancite Duncan

From: Bruce Christian

Pages: 1

Date: 17 January 2000

Information Request

110475 - Rad

The new rad pages you sent me list the sample matrix as liquid versus solid everywhere else in the package.

Replacement tables attached R24 1-18-00

#### TMA/RICHMOND SAMPLE DELIVERY GROUP H0475

N907145-04

#### METHOD BLANK

Method Blank

i	7166 L.A. Johnson	Client/Case no Contract	Hanford TRB-SBB-207925	SDG-H0475
Lab sample id Dept sample id		Client sample id Material/Matrix SAF No		SOLID

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TES1
Critium	10028-17-8	0.006	0.051	0.086	400	U	н
Technetium 99	14133-76-7	0.497	0.31	0.70	15	U	TC
Jranium 233/234	U-233/234	0.010	0.019	0.073	1.0	ซ	Ū
Jranium 235	15117-96-1	0	0.023	0.088	1.0	ซ	U
Jranium 238	U-238	0.010	0.019	0.073	1.0	U	U
Plutonium 238	13981-16-3	0	0.031	0.064	1.0	Ū	PÜ
Plutonium 239/240	PU-239/240	0.089	0.053	0.058	1.0	J	PU
Nickel 63	13981-37-8	3.38	2.1	4.1	30	ซ	NI_
Americium 241	14596-10-2	0.008	0.016	0.030	1.0	U	AM
Total Strontium	SR-RAD	0.248	0.14	0.18	1.0	J	SR
Potassium 40	13966-00-2	U		0.95		บ	GAM
Barium 133	13981-41-4	. 0	•	0.057		UX	GAM
Cobalt 60	10198-40-0	ט		0.061	0.050	U	GAM
Cesium 137	10045-97-3	บ		0.059	0.10	U	GAM
Europium 152	14683-23-9	U		0.16	0.10	U	GAM
Europium 154	15585-10-1	ט י		0.17	0.10	บ	GAM
Europium 155	14391-16-3	U		0.14	0.10	<b>ט</b>	GAM
Radium 226	13982-63-3	U		0.11	0.10	ซ	GAM
Radium 228	15262-20-1	U		0.38	0.20	U	GAM
Thorium 228	14274-82-9	σ		0.081		U	GAM
Thorium 232	TH-232	ט		0.38		U	GAM
Americium 241	14596-10-2	ט		0.17		U .	GAM
Uranium 238	U-238	Ū		6.6		U	GAM
Uranium 235	15117-96-1	<b>ט</b> י		0.18		υ	GAM

105-DR FSB-Concrete

QC-BLANK 31424

METHOD BLANKS
Page 1
SUMMARY DATA SECTION
Page 9

#### TMA/RICHMOND SAMPLE DELIVERY GROUP H0475

N907145-07

#### METHOD BLANK

Method Blank

	7166 L.A. Johnson	Client/Case no Contract	Hanford TRB-SBB-207925	SDG-H0475
Lab sample id		Client sample id Material/Matrix SAF No		SOLID

ANALYTE	CAS NO	RESUL <b>T</b> pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	Te <b>st</b>
Carbon 14	14762-75-5	1.95	2.7	4.5	50	Ū	С

105-DR FSB-Concrete

QC-BLANK 31578	
----------------	--

METHOD BLANKS
Page 2
SUMMARY DATA SECTION
Page 10

 Lab id
 TMANC

 Protocol
 Hanford

 Version
 Ver 1.0

 Form
 DVD-DS

 Version
 3.06

 Report date
 10/07/99

#### TMA/RICHMOND

SAMPLE DELIVERY GROUP H0475

N907145-03

#### LAB CONTROL SAMPLE

Lab Control Sample

SDG 7166 Contact L.A. Johnson	Client/Case no Hanford SDG-H0475  Case no TRE-SBB-207925
Lab sample id N907145-03 Dept sample id 7166-003	Client sample id <u>Lab Control Sample</u>

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	2σ ERR pCi/g	RBC	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	4.58	0.15	0.086	400	J	н	4.93	0.20	93	84-116	80-120
Technetium 99	67.0	2.1	0.66	15		TC	68.4	2.7	98	84-116	80-120
Uranium 233/234	3.76	0.45	0.23	1.0		יט	4.64	0.19	81	83-117	80-120
Uranium 235	3.12	0.40	0.065	1.0	•	ט	3.77	0.15	83	82-118	80-120
Uranium 238	4.17	0.48	0.22	1.0		ט	5.04	0.20	83	83-117	80-120
Plutonium 238	9.73	0.89	0.054	1.0		PU .	10.0	0.40	97	84-116	80-120
Plutonium 239/240	10.2	0.92	0.054	1.0	В	PU	10.6	0.42	96	84-116	80-120
Nickel 63	128	4.3	2.8	30		NI_L	134	5.4	96	84-116	
Americium 241	18.8	1.3	0.034	1.0		AM	19.2	0.77	98	86-114	80-120
Total Strontium	13.2	1.1	0.89	1.0		SR	11.4	0.46	116	77-123	
Cobalt 60	3.95	0.21	0.099	0.050		GAM	4.10	0.16	96	76-124	80-120
Cesium 137	3.70	0.17	0.12	0.10		GAM	3.72	0.15	99	76-124	80-120

105-DR FSB-Concrete

QC-LCS 31423	,

LAB CONTROL SAMPLES

Page 1

SUMMARY DATA SECTION

Page 11

#### TMA/RICHMOND

SAMPLE DELIVERY GROUP H0475

N907145-06

#### LAB CONTROL SAMPLE

Lab Control Sample

SDG 7166 Contact <u>L.A. Johnson</u>	Client/Case no Hanford SDG-H0475  Case no TRB-SBB-207925
Lab sample id <u>N907145-06</u>	Client sample id Lab Control Sample
Dept sample id <u>7166-006</u>	Material/Matrix SOLID
	SAF No <u>B99-076</u>

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ADDED pCi/g	20 ERR pC1/g	REC	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Carbon 14	10400	100	13	50		C	10800	430	96	84-116	

105-DR FSB-Concrete

QC-LCS 31577	

LAB CONTROL SAMPLES
Page 2
SUMMARY DATA SECTION
Page 12

N907145-05

DUPLICATE

BOWOX9

SOLID

SDG 7166

Contact L.A. Johnson

DUPLICATE

Lab sample id N907145-05

Dept sample id 7166-005

ORIGINAL

Lab sample id N907145-01

Dept sample id 7166-001

Received 07/23/99

% solids 100.0

Client/Case no Hanford

SDG-H0475

Case no TRB-SBB-207925

Client sample id BOWOX9

Location/Matrix 105-DR

Collected 07/19/99 10:15

Custody/SAF No <u>B99-076-01 B99-076</u>

ANALYTE	DUPLIC <b>ATE</b> pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TE <b>ST</b>	ORIGI <b>NAL</b> pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD	3σ PR	ROT MIT
Tritium	7.52	0.19	0.085	400	J	н	6.23	0.17	0.087	J	19	22	
Technetium 99	2.51	0.48	0.84	15	J ·	TC	1.37	0.51	0.88	J	<u>59</u>	58	
Uranium 233/234	3.33	0.41	0.093	1.0		<b>ט</b>	3.10	0.33	0.000		7	27	
Uranium 235	0.282	0.11	0.070	1.0	J	ט	0,321	0.091	0.048	J	13	72	
Uranium 238	2.90	0.38	0.083	1.0		ט	3.19	0.34	0.075		10	27	
Plutonium 238	5.32	0.44	0.029	1.0		PU	5.77	0.50	0.031		8	21	,
Plutonium 239/240	358	23	0.029	1.0	В	PU	358	24	0.050	В	0	18	
Nickel 63	5330	53	5.4	30		NI_L	5360	54	5.3		1	21	
Americium 241	49.8	4.0	0.050	1.0		MA	54.7	11	0.34		9	35	į
Total Strontium	5970	150	B.8	1.0		SR	4500	9.0	0.27		28	22	
Potassium 40	ט		7.2		U	GAM	U		7.3	ช	-		
Barium 133	ט		2.6		UX	GAM	ט		2.6	UX	-		
Cobalt 60	323	2.5	1.0	0.050		GAM	323	2.5	1.1		0	32	
Cesium 137	5070	7.0	2.5	0.10		GAM	5070	7.0	2.5		0	32	
Europium 152	801	7.0	7.7	0.10		GAM	806	6.4	7.1		1	32	
Europium 154	108	4.2	3.7	0.10		GAM	105	3.9	3.4		3	33 .	
Europium 155	5.03	2,2	3.5	0.10		GAM	4.38	2.9	4.0		14	120	
Radium 226	ซ		3.2	0.10	σ	GAM	ט		3.2	ט	-	•	
Radium 228	U		7.3	0.20	υ	GAM	ט		7,2	ט	· -		
Thorium 228	ซ		2.4	٠	ט	GAM	ט		2.8	U	-		
Thorium 232	υ		7.3		ט	GAM	ט		7.2	ט	-		
Americium 241	60.2	1.8	2.4			GAM	60.0	1.6	2.2		0	32	
Uranium 238	σ		260		ט	GAM	ט		250	U	-		
Uranium 235	ซ		5.9		U	GAM	σ	÷	5.8	ប	_		

105-DR FSB-Concrete

QC-DUP#1 31425

DUPLICATES Page 1 SUMMARY DATA SECTION

Page 13

Lab id TMANC

Protocol Hanford

Version Ver 1.0

Form DVD-DUP

Version 3.06 Report date 10/07/99

### TMA/RICHMOND

SAMPLE DELIVERY GROUP H0475

N907145-08

### DUPLICATE

BOWOX9

SDG	7166			Client/Case no	Hanford	SDG-H0475
Contact	L.A. Johnson			Case no	TRB-SBB-207925	
	DUPLICATE		ORIGINAL			
Lab sample id	N907145-08	Lab sample i	d <u>N907145-01</u>	Client sample id	BOWOX9	
Dept sample id	7166-008	Dept sample i	d 7166-001	Location/Matrix	105-DR	SOLID
	•	Receive	d <u>07/23/99</u>	Collected	07/19/99 10:15	
1		* solid	s <u>100.0</u>	Custody/SAF No	B99-076-01	B99-076

ANALYTE	DUPLICATE pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST	ORIGINAL pCi/g	2σ ERR (COUNT)	MDA pCi/g	QUALI- FIERS	RPD	3ø PRO
Carbon 14	678	9.8	4.5	50		с	540	8.6	4.4		23	22

105-DR FSB-Concrete

QC-DUP#1	31579		

DUPLICATES
Page 2
SUMMARY DATA SECTION
Page 14

Lab id TMANC
Protocol Hanford
Version Ver 1.0
Form DVD-DUP
Version 3.06
Report date 10/07/99

### TMA/RICHMOND SAMPLE DELIVERY GROUP H0475

### N907145-01

### DATA SHEET

BOWOX9

1	7166 L.A. Johnson	Client/Case no Contract	Hanford TRB-SBB-207925	SDG-H0475
Lab sample id Dept sample id Received % solids	7166-001 07/23/99	Client sample id Location/Matrix Collected Custody/SAF No	105-DR 07/19/99 10:15	SOLID 076

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TES <b>T</b>
Tritium	10028-17-8	6.23	0.17	0.087	400	J	н
Carbon 14	14762-75-5	540	8.6	4.4	50		C
Technetium 99	14133-76-7	1.37	0.51	0.88	15	J	TC
Uranium 233/234	U-233/234	3.10	0.33	0.080	1.0		Ü
Uranium 235	15117-96-1	0.321	0.091	0.048	1.0	J	บ
Uranium 238	U-238	3.19	0.34	0.075	1.0		U
Plutonium 238	13981-16-3	5.77	0.50	0.031	1.0		ΡŪ
Plutonium 239/240	PU-239/240	358	24	0.050	1.0	В	PU
Nickel 63	13981-37-8	5360	54	5.3	30		NI_L
Americium 241	14596-10-2	54.7	11	0.34	1.0		AM .
Total Strontium	SR-RAD	4500	9.0	0.27	1.0		SR
Potassium 40	13966-00-2	ט		7.3		U	GAM
Barium 133	13981-41-4	U		2.6		UX	GAM
Cobalt 60	10198-40-0	323	2.5	1.1	0.050		GAM
Cesium 137	10045-97-3	5070	7.0	2.5	0.10		GAM
Europium 152	14683-23-9	806	6.4	7.1	0.10		GAM
Europium 154	15585-10-1	105	3.9	3.4	0.10		GAM
Europium 155	14391-16-3	4.38	2.9	4.0	0.10		GAM
Radium 226	13982-63-3	ซ		3.2	0.10	บ	GAM
Radium 228	15262-20-1	U		7.2	0.20	ט	GAM
Thorium 228	14274-82-9	U		2.8		U	GAM
Thorium 232	TH-232	Ū		7.2		U	GAM
Americium 241	14596-10-2	60.0	1.6	2.2			GAM
Uranium 238	U-238	U		250	•	U	GAM
Uranium 235	15117-96-1	ប		5.8		U	GAM

105-DR FSB-Concrete

DATA SHERTS
Page 1
SUMMARY DATA SECTION
Page 15

Lab id TMANC

Protocol Hanford

Version Ver 1.0

Form DVD-DS

Version 3.06

Report date 10/07/99

BOWOYO

### DATA SHEET

SDG	7166	Client/Case no	<u>Hanford</u>	SDG.	-H0475
Contact	L.A. Johnson	Contract	TRB-SBB-207925		
Lab sample id	N907145-02	Client sample id	BOWOYO		
Dept sample id	7166-002	Location/Matrix	105-DR		SOLID
Received	07/23/99	Collected	07/19/99 10:45		
* solids	100.0	Custody/SAF No	B99-076-01	B99-076	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TES <b>T</b>
Tritium	10028-17-8	8.09	0.19	0.085	400	J	. н
Carbon 14	14762-75-5	961	12	5.0	50		C
Technetium 99	14133-76-7	0.438	0.35	0.66	15	U	TC
Uranium 233/234	U-233/234	1.37	0.22	0.054	1.0		U
Uranium 235	15117-96-1	0.059	0.051	0.065	1.0	U.	ט
Uranium 238	U-238	1.21	0.20	0.054	1.0		ט
Plutonium 238	13981-16-3	6.63	0.52	0.063	1.0		PU
Plutonium 239/240	PU-239/240	240	15	0.027	1.0	В	PU
Nickel 63	13981-37-8	11900	120	8.1	30		NI L
Americium 241	14596-10-2	72.0	14	0.30	1.0		MA
Total Strontium	SR-RAD	1980	4.7	0.17	1.0	В	SR
Potassium 40	13966-00-2	σ		11		U.	GAM
Barium 133	13981-41-4	ט		3.0		UX	GAM
Cobalt 60	10198-40-0	596	3.3	1.8	0.050		GAM
Cesium 137	10045-97-3	5140	7.0	2.6	0.10		GAM
Europium 152	14683-23-9	2810	10	9.7_	0.10		GAM
Europium 154	15585-10-1	518	7.1	6.2	0.10		GAM
Europium 155	14391-16-3	21.5	4.3	6.3	0.10		GAM
Radium 226	13982-63-3	Ū		4.7	0.10	บ	GAM
Radium 228	15262-20-1	ŭ		9.9	0.20	U	GAM
Thorium 228	14274-82-9	σ		3.3		บ	GAM
Thorium 232	TH-232	ប		9.9		ซ	GAM
Americium 241	14596-10-2	119	5.5	7.5		•	GAM
Uranium 238	U-238	ប		340		U	GAM
Uranium 235	15117-96-1	Ü		7.0		บ่	GAM

105-DR FSB-Concrete

DATA SHERTS
Page 2
SUMMARY DATA SECTION
Page 16

Lab id TMANC
Protocol Hanford

Version Ver 1.0
Form DVD-DS
Version 3.06

Report date 10/07/99

Data Package	IR	
H0472	Rad MS ★	
H0475	Rad MS 💥	一
H0473	Rad MS 🗶	
H0538	Rad MS 🔏	
	Rad - New Form 1s list liquid versus solid matrix	
H0542	Rad MS *	
H0544	Rad MS %	
	Metals - Case narrative states that only 1 sample was analyzed (two were analyzed)	
H0551	Rad MS *	
H0514	CR VI - Method of analysis not identified	-
H050 <b>6</b>	Samples not listed in VSR	
	Rad MS A Alcohols - Surrogate not run?	
H0534	Samples not listed in VSR	
	Was nickel, 3H and TC-99 analysis to be conducted	
	on samples BR0, BR1, BR2, BR4?	
	Rad MS *	
	PCBs - What do you want for CRDLs	
	alcohols - No surrogate?	
l	MS/MSD for UOA	

L BROIBRI, BRZ 1BR4 - Cast necretion gine States
that the assembled MS/MSD is the one for the
other samples in the SDG- But they were not
run together.

Brace

Brocede with validation for all "Real M 5" justed

Procede with validation for all "Real M 5" justed

intendified above (\*) and with missing alcohol surregulars

(D) idend first above

Richard Wiso

## TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: I

Date: 7 October 1999

Information Request

H0475 - Rad

The new rad pages you sent me list the sample matrix as liquid versus solid everywhere else in the package.

in with the present part as a security

# ikesionie iransanija

To: Bruce christian	Fax: 375-515)	
From: Rich Weiss	Date: 10-20-79	
Re: Count deter	Pages: 3	
cc:		

□ Quick Turn / Priority Data

☐ Final Data Package

Bruce

Look this over for places in the procedure that I've missed and for areas that meke uslidation sither "blow up" or weeld toply more restrictive qualifiers than corrently

Rich

Inconsistencies and inadequately defined criteria have been identified in "Data Validation Procedures for Radiochemical Analysis", WHC-SD-EN-SPP-001, Rev.1. The following identifies the affected sections, provides a consistent replacement, and clarifies interpretation for these issues.

### Laboratory Blanks

Current Wording (by section):

- 4.3.1 Prepared at the same time and analyzed with the samples using the same procedure.
- 5.3.1 Prepared at the same time and analyzed with the samples using the same procedure.
- 6.3.1 Prepared at the same time and analyzed with the samples using the same procedure, aliquot size, and counting time.
- 5.3.1 Analyzed using a similar aliquot size, counted in the same geometry and count time as the samples.
- 7.3.1 Prepared at the same time and analyzed with the samples using the same procedure.
- 8.3.1 Laboratory blanks have been prepared, distilled and analyzed using the same procedure and aliquot size as the samples.
- 9.3.1 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.

### Laboratory Control or Blank Spike Samples

Current Wording (by section):

- 4.4.1 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.
- 5.4.1 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.
- 6.4.1 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.
- 7.4.1 LCS of BSS was analyzed in the same geometry, count duration, and aliquot size as the samples.
- 8.4.1 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.
- 9.4.1 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.

### Matrix Spike Samples

Current Wording (by section):

Section 4 - no matrix spike requirements

- 5.4.3 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.
- 6.4.3 Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.

Section 7 – no matrix spike requirements.

8.4.3 - Prepared at the same time and analyzed in the same batch, using the same procedure, as the associated samples.

Section 9 – no matrix spike requirements.

### Laboratory Duplicates

Current Wording (by section):

- 4.5.1 The duplicate analysis was prepared and analyzed in the same batch, using the same procedure as the associated samples.
- 5.5.1 The duplicate analysis was prepared and analyzed in the same batch, using the same procedure as the associated samples.
- 6.5.1 The duplicate analysis was prepared and analyzed in the same batch, using the same procedure as the associated samples.
- 7.5.1 The duplicate analysis was prepared and analyzed at the same time, using the same geometry, aliquot size and count duration as the samples.
- 8.5.1 Prepared and analyzed using the same aliquot size as the samples.
- 9.5.1 The duplicate analysis was prepared and analyzed in the same batch, using the same procedure as the associated samples.

#### Replacement Wording (all sections above):

Preparation performed as part of an analytical batch, at the same time, using the same procedures and aliquot sizes as the associated samples. All components of the analytical batch (QC and sample) counted using the same or comparable geometry and count duration within a two week time period.

Laboratory failure to meet the criteria (in any section) – qualify all associated sample results as estimated (J for detects, UJ for non-detects).

ERRORS  1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSLER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phose: (509) 372-9467						T REPOR	RESUL	KSMISSION	·········· TRAN	************	*************	**********	٠
THE FOLLOWING FILE (S) ERASED  FILE FILE TYPE OPTION TEL. NO. PAGE RESULT  057 MEMORY TX 3755151 03-203 OK  ERRORS  1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSLER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9446  FAX: (509) 372-9487									*******				•••••
ERRORS  1) HANG UP OR LINE FAIL  2) BUSY  3) NO ANSHER  4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487	<b>0</b> ,	····· (HO)										THE FOL	
ERRORS  1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487	<b>L</b> T	RESL	PAGE			TEL NO.							
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487		13 OK	03/03								MORY TX	057 M	
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487								•					
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487		٠	·										
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487													
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487								•					
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487				,									•
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487						•					•		
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487		·	•										
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487					٠								
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487			-										
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487													
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487	•												
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487	4.*						٠.						
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487			•			•					•		
1) HANG UP OR LINE FAIL 2) BUSY 3) NO ANSWER 4) NO FACSIMILE CONNECTION  BHI Sample Management Phone: (509) 372-9346  FAX: (509) 372-9487	•	•									•		
fatesinalle in ansanite se	ITON	CONNECT	nagement 2-9346	ample Ma : (509) 37:	BHI Sa	I ANSWER	S) N(	BUSY	IL 2)	LINE FH		1) F	
l.	The second		lange of the			i ta	illa	inster		esina	fa	4.30	Mag
	•			ŀ	. •								
To: Bruce christian Fax: 375-515)			! 	515	75-	ax:	-1	7, sn	chas	Bruce	To:		
From: Rich Woiss Date: 10-20-79				· 5	/ <del>/ 7 _</del> · 3	ate:	·		- / *	12.	From:		
Re: Count offer Pages: 3		· .	9	<u>G-7</u>	0-2				Ch/6127	5:2h			
cc:			9	,			. 1		deter	tich	Re:		

Bruce

Look this over for places is the

HO473

BHI Sample Management Phone: (509) 372-9346 FAX: (509) 372-9487

# lajimenajo limbosi

To: Brace Christian	Fax: 375-5151	
From: Rich Weiss	Date: 10-21-99	
RE: FEB Sciragetra	Pages: 3	
cc:		
Quick Turn / Priority Data	☐ Final Data Package	

Bruce

The last sheet is an email from the labs with surrest into from the two 'dilates' out' samples for SDB HO475. I've asked for replacement pages and similar deta for HO483. IF I haven't talked to you when you get this, give mag

Rich

## TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages; 1

Date: 20 October 1999

110475 - PCB analysis

Due to surrogates being diluted out, the following samples have been rejected.

All except arochlor-1254	UR	BOWOY2, BOWOY3	Surrogate diluted
			out

110483 - PCB analysis

Due to surrogates being diluted out, the following samples have been rejected.

All except Aroclor-1254	UR	B0W3Y6	Surrogate diluted
			out

## Weiss, Richard L

From: Sent:

Johnson, Orlette [johnsono@recralab.com] Thursday, October 21, 1999 8:18 AM Rich Weiss H0475

To:

Subject:

Surrogate recoveries are calculated as follows:

B0WY2 = TCMX 30%; DCB 10% B0WY3 = TCMX 30%; DCB 11%

Do we need to reissue this report?

## TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: 1

Date: 20 October 1999

110475 - PCB analysis

Due to surrogates being diluted out, the following samples have been rejected.

All except arochlor-1254	UR	B0W0Y2, B0W0Y3	Surrogate diluted
· · · · · · · · · · · · · · · · · · ·			out

H0483 - PCB analysis

Due to surrogates being diluted out, the following samples have been rejected.

All except Aroclor-1254	UR	B0W3Y6	Surrogate diluted
			out

TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: I

Date: 7 October 1999

Information Request

110475 - Rad

There is no indication of a matrix spike for 3H, C-14

Lob is regnalyzing Hot C-14.
Will provide replacement results

R29W 10111/85

TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: 1

Date: 7 October 1999

Information Request

W02840 - inorganics

The sample sumary for W02840 states that sample B0W100 is an equipment blank for sample B0W107 - however, the sample summary for W02834 states that sample B0W107 is the equipment blank. Which one is it.

See revised Summirs
-RLW 107-95

TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: 1

Date: 7 October 1999

Information Request

110475 - Rad

The sample summary states that sample B0W0Y0 is an equipment blank. Can you double check because it doesn't look like one.

See revocal sammaries

SAMPLE SUMMARY							
Project ID:	105-DR FSB - Concrete	Sampling Team:	ERC Field Sampling				
Task ID:	3	Sampling Mgr/Coordinator:	St. John				
Opperable Unit:	100-DR	Samplers:	FAHLBERG, RT				
SAF Number:	B99-076	Field Logbook ID:	EL 1281				
	· ·	Sampling Media:	Other Solid				

Sample Number	SDG Number	Location	Analyte Code	Laboratory	Date Collected	Date Shipped	Comments
B0W0X9	H0475	105-DR	2,3,4,5,7,8,9,10,11, 12,13,14	TMA/RECRA	7/19/99 10:15 AM	7/22/99 1:36 PM	Location B/Samples NOT received at RECRA due to bottle mix-up - chemical analyses canceled.
B0W0Y0	H0475	105-DR	2,3,4,5,7,8,9,10,11, 12,13,14	TMA/RECRA	7/19/99 10:45 AM	7/22/99 1:36 PM	Location D/Samples NOT received at RECRA due to bottle mix-up - chemical analyses canceled.
B0W0Y1	H0475	105-DR	2,3,4,5,7,8,9,10,11, 12,13,14	TMA/RECRA	7/20/99 8:55 AM	7/22/99 1:30 PM	Location A/Samples NOT received at TMA due to bottle mix-up - radiochemistry analyses canceled.
B0W0Y2	H0475	105-DR	2,3,4,5,7,8,9,10,11, 12,13,14	TMA/RECRA	7/20/99 9:05 AM	7/22/99 1:30 PM	Location C-1/Samples NOT received at TMA due to bottle mix-up - radiochemistry analyses canceled.
B0W0Y3	H0475	105-DR	2,3,4,5,7,8,9,10,11, 12,13,14	TMA/RECRA	7/20/99 9:20 AM	7/22/99 1:30 PM	Location C-1/Samples NOT received at TMA due to bottle mix-up - radiochemistry analyses canceled.
B0W0Y4	RCF99076	105DR	15	Radiological Counting Facility	7/19/99 10:15 AM	7/20/99 7:25 AM	Location B Rad. Screen for {B0W0X9}
B0W0Y5	RCF99076	105DR	15	Radiological Counting Facility	7/19/99 10:45 AM	7/20/99 7:25 AM	Location D Rad. Screen for {B0W0Y0}
B0W0Y6	RCF99076	105DR	15	Radiological Counting Facility	7/20/99 8:55 AM	7/20/99 1:50 PM	Location A Rad. Screen for {B0W0Y1}
B0W0Y7	RCF99076		15	Radiological Counting Facility	7/20/99 9:05 AM	7/20/99 1:50 PM	Location C-1 Rad. Screen for {B0W0Y2}
B0W0Y8	RCF99076	105DR	15	Radiological Counting Facility	7/20/99 9:20 AM	7/20/99 1:50 PM	Location C-1 Rad. Screen for {B0W0Y3}
B0W0Y9	W02840	105DR	1	Quanterra Incorporated	7/19/99 10:15 AM	7/19/99 4:30 PM	Location B

Project ID: 105-DR FSB - Concrete

SAF Number: B99-076

Page 1 of 3

Date: 10/7/99 10:11:00 AM

Update

SAMPLE SUMMARY								
Project ID:	105-DR FSB - Concrete	Sampling Team:	ERC Field Sampling					
Task ID:	3	Sampling Mgr/Coordinator:	St. John					
Opperable Unit:	100-DR	Samplers:	FAHLBERG, RT					
SAF Number:	B99-076	Field Logbook ID:	EL 1281					
		Sampling Media:	Other Solid					

Sample Number	SDG Number	Location	Analyte Code	Laboratory	Date Collected	Date Shipped	Comments
B0W100	W02840	105DR	1	Quanterra Incorporated	7/19/99 10:45 AM	7/19/99 4:30 PM	Location D
B0W101	W02841	105DR	1	Quanterra Incorporated	7/20/99 8:55 AM	7/20/99 2:45 PM	Location A
B0W102	W02841	105DR	1	Quanterra Incorporated	7/20/99 9:05 AM	7/20/99 2:45 PM	Location C-1
B0W103	W02841	105DR	1	Quanterra Incorporated	7/20/99 9:20 AM	7/20/99 2:45 PM	Location C-1
B0W3Y6	H0483	105 DR	2,3,4	TMA/RECRA	8/4/99 9:45 AM	8/5/99 2:00 PM	Location B - original location extended +/- 4 inches south
B0W3Y7	H0483	105 DR	2,3,4	TMA/RECRA	8/4/99 9:55 AM	8/5/99 2:00 PM	Location D
B0W3Y9	H0483	105 DR	5,7,8,9,10,11,12,13, 14	TMA/RECRA	8/4/99 9:35 AM	8/5/99 2:00 PM	Location A - original location extended +/- 4 inches east
B0W400	H0483	105 DR	5,7,8,9,10,11,12,13, 14	TMA/RECRA	8/4/99 9:25 AM	8/5/99 2:00 PM	Location C-1 - original location extended +/- 4 inches west
B0W401	H0483	105 DR	5,7,8,9,10,11,12,13, 14	TMA/RECRA	8/4/99 9:09 AM	8/5/99 2:00 PM	Location C-2 - original location extended +/- 4 inches east

### **Analyte Codes:**

- 1) Chromium Hex 7196
- 2) PCBs 8080
- 3) ICP Metals 6010A (Add-on) {Lead}

Project ID: 105-DR FSB - Concrete

SAF Number: B99-076

Page 2 of 3

Date: 10/7/99 10:11:00 AM

Update

SAMPLE SUMMARY							
Project ID:	105-DR FSB - Concrete	Sampling Team:	ERC Field Sampling				
Task ID:	3	Sampling Mgr/Coordinator:	St. John				
Opperable Unit:	100-DR	Samplers:	FAHLBERG, RT				
SAF Number:	B99-076	Field Logbook ID:	EL 1281				
		Sampling Media:	Other Solid				

	SDG Number	Location	Analyte	Laboratory	Date	Date	Comments
Number	1		Code		Collected	Shipped	

- 4) Mercury 7471 (CV)
- 5) Gamma Spectroscopy (Cesium-137, Cobalt-60, Europium-152, Europium-154, Europium-155)
- 6) Gamma Spec Add-on (Barium-133)
- 7) Isotopic Plutonium
- 8) Isotopic Uranium
- 9) Americium-241
- 10) Strontium-89,90 -- Total Sr
- 11) Technetium-99
- 12) Nickel-63
- 13) Carbon-14
- 14) Tritium H3
- 15) Rad Screen

Project ID: 105-DR FSB - Concrete

SAF Number: B99-076 Page 3 of 3 Date: 10/7/99 10:11:00 AM

TRANSMISSION RESULT REPORT .....(OCT 07 '99 11:55AM).......

BHI 5%D MANAGEMENT 509 372 9487

THE FOLLOWING FILE(S) ERASED

FILE FILE TYPE

OPTION

TEL NO.

PAGE RESULT

071 MEMORY TX

3755151

05/05 OK

**ERRORS** 

1) HANG UP OR LINE FAIL

2) BUSY

3) NO ANSWER

4) NO FACSIMILE CONNECTION

Oct-07-99 08:28A

OCT 07 '99 08:43A91

## **FAX**

## TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: 1

Date: 7 October 1999

Information Request

\*\*\*\*\*\*\*

# TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: 1

Date: 7 October 1999

Information Request

110475 - Rad

The sample summary states that sample B0W0Y0 is an equipment blank. Can you double check because it doesn't look like one.

# TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: 1

Date: 7 October 1999

Information Request

H0475 - Rad

The new rad pages you sent me list the sample matrix as liquid versus solid everywhere else in the package.

## TECHLAW, INC.

451 Hills, Suite 23 Richland, WA 99352 509-375-5667 509-375-5151 (fax)

To: Jeanette Duncan

From: Bruce Christian

Pages: I

Date: 7 October 1999

Information Request

110475 - Rad

There is no indication of a matrix spike for 3H, C-14