



0081575 REV. 1

EBERLINE ANALYTICAL CORPORATION
2030 Wright Avenue
Richmond, California 94804-3849
Phone (510) 235-2633 Fax (510) 235-0438
Toll Free (800) 841-5487
www.eberlineservices.com

July 17, 2008

Mr. Steve Trent
Fluor Hanford Inc.
1200 Jadwin Avenue
Richland, WA 99352

Reference: **P.O. #33677**
Eberline Services R8-04-057-7075, SDG H3681
R8-06-180-7075



Dear Mr. Trent:

Enclosed is an updated data report for one solid (soil) sample designated under SAF No. F08-043 received at Eberline Services on April 9, 2008. Results were originally reported on May 22, this report includes results for Se-79.

Please call if you have any questions concerning this report.

Sincerely,

Melissa C. Mannion
Senior Program Manager

MCM/njv

Enclosure: Data Package

RECEIVED
JAN 22 2009
EDMC

REVISED
7-21-08

00000001

1.0 GENERAL

Fluor Hanford Inc. (FH) Sample Delivery Group H3681 was composed of one solid (soil) sample designated under SAF No. F08-043 with a Project Designation of: 216-A-30 Crib Sampling.

The sample was received as stated on the Chain-of-Custody document. Any discrepancies are noted on the Eberline Services Sample Receipt Checklist. Selenium-79 analysis was order after results for the originally requested analyses were reported.

2.0 ANALYSIS NOTES

2.1 Tritium Analysis

No problems were encountered during the course of the analyses.

2.2 Nickel-63 Analysis

No problems were encountered during the course of the analyses.

2.3 Selenium-79 Analysis

Eberline Services does not maintain a stock of Se-79 activity with which to prepare laboratory control samples, as a consequence an LCS was not performed. No problems were encountered during the course of the analyses.

2.4 Technetium-99 Analysis

No problems were encountered during the course of the analyses.

2.5 Isotopic Thorium Analysis

No problems were encountered during the course of the analyses.

3.0 Case Narrative Certification Statement

"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."



Melissa C. Mannion
Senior Program Manager



Date

EBRLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

Client Hanford
Contract No. 33677
Case no SDG_H3681

S U M M A R Y D A T A S E C T I O N

T A B L E O F C O N T E N T S

About this section	1
Sample Summaries	3
Prep Batch Summary	5
Work Summary	6
Method Blanks	8
Lab Control Samples	10
Duplicates	11
Data Sheets	13
Method Summaries	14
Report Guides	19
End of Section	33

Prepared by

M. Mannion

Reviewed by

Melissa Mannion

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-TOC
Version 3.06
Report date 07/16/08

00000003

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000004

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 33677

Case no SDG H3681

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 2

Lab id EBRLNE

Protocol Hanford1

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 07/16/08

0000005

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 33677
 Case no SDG H3681

LAB SAMPLE SUMMARY

LAB SAMPLE ID	CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	SAF NO	CHAIN OF CUSTODY	COLLECTED
R803100-08	Method Blank		SOLID		F08-043		
R804057-01	B1TH05	C5941, I-033	SOLID		F08-043	F08-043-150	03/19/08 08:50
R804057-02	Lab Control Sample		SOLID		F08-043		
R804057-03	Method Blank		SOLID		F08-043		
R804057-04	Duplicate (R804057-01)	C5941, I-033	SOLID		F08-043		03/19/08 08:50
R804057-05	Duplicate (R804057-01)	C5941, I-033	SOLID		F08-043		03/19/08 08:50

LAB SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-LS
 Version 3.06
 Report date 07/16/08

00000006

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 33677
 Case no SDG H3681

QC SUMMARY

QC BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL SAMPLE ID	DEPARTMENT SAMPLE ID
7063		Method Blank	SOLID					R803100-08	7063-008
7075	F08-043-150	B1TH05	SOLID	93.4	129 g		04/09/08 21	R804057-01	7075-001
		Method Blank	SOLID					R804057-03	7075-003
		Lab Control Sample	SOLID					R804057-02	7075-002
		Duplicate (R804057-01)	SOLID	93.4	129 g		04/09/08 21	R804057-04	7075-004
		Duplicate (R804057-01)	SOLID	93.4	129 g		04/09/08 21	R804057-05	7075-005

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-QS
 Version 3.06
 Report date 07/16/08

00000007

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

PREP BATCH SUMMARY

Client Hanford
 Contract No. 33677
 Case no SDG H3681

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED				QUALI- FIERS	
			BATCH	2σ %	CLIENT	MORE	RE	BLANK		LCS
Alpha Spectroscopy										
TH	SOLID	Thorium, Isotopic in Solids	6152-064	8.0	1			1	1	1/1
Beta Counting										
TC	SOLID	Technetium 99 in Solids	6152-064	13.2	1			1	1	1/1
Liquid Scintillation Counting										
H	SOLID	Tritium in Solids	6152-064	10.0	1			1	1	1/1
NI_L	SOLID	Nickel 63 in Solids	6152-064	11.2	1			1	1	1/1
SE_L	SOLID	Selenium 79 in Solids	6145-169	11.2	1			1		1/1

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.
 Blank and LCS planchets are those in the same preparation batch as some Client, Duplicate or Spike sample.

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-PBS
 Version 3.06
 Report date 07/16/08

00000008

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 33677
 Case no SDG H3681

LAB WORK SUMMARY

LAB SAMPLE	CLIENT SAMPLE ID		MATRIX		SUF-					
COLLECTED	LOCATION			PLANCHET	TEST	FIX	ANALYZED	REVIEWED	BY	METHOD
RECEIVED	CUSTODY	SAF No								
R803100-08	Method Blank		SOLID	7063-008	SE_L		07/09/08	07/15/08	BW	Selenium 79 in Solids
			F08-043							
R804057-01	B1TH05		SOLID	7075-001	H		04/26/08	04/29/08	BW	Tritium in Solids
03/19/08	C5941, I-033			7075-001	NI_L		05/16/08	05/20/08	BW	Nickel 63 in Solids
04/09/08	F08-043-150	F08-043		7075-001	SE_L		07/09/08	07/15/08	BW	Selenium 79 in Solids
				7075-001	TC		05/06/08	05/06/08	BW	Technetium 99 in Solids
				7075-001	TH		05/13/08	05/14/08	BW	Thorium, Isotopic in Solids
R804057-02	Lab Control Sample		SOLID	7075-002	H		04/26/08	04/29/08	BW	Tritium in Solids
				7075-002	NI_L		05/16/08	05/20/08	BW	Nickel 63 in Solids
		F08-043		7075-002	TC		05/03/08	05/06/08	BW	Technetium 99 in Solids
				7075-002	TH		05/13/08	05/14/08	BW	Thorium, Isotopic in Solids
R804057-03	Method Blank		SOLID	7075-003	H		04/26/08	04/29/08	BW	Tritium in Solids
				7075-003	NI_L		05/16/08	05/20/08	BW	Nickel 63 in Solids
		F08-043		7075-003	TC		05/03/08	05/06/08	BW	Technetium 99 in Solids
				7075-003	TH		05/13/08	05/14/08	BW	Thorium, Isotopic in Solids
R804057-04	Duplicate (R804057-01)		SOLID	7075-004	H		04/26/08	04/29/08	BW	Tritium in Solids
03/19/08	C5941, I-033			7075-004	NI_L		05/16/08	05/20/08	BW	Nickel 63 in Solids
04/09/08		F08-043		7075-004	TC		05/03/08	05/06/08	BW	Technetium 99 in Solids
				7075-004	TH		05/13/08	05/14/08	BW	Thorium, Isotopic in Solids
R804057-05	Duplicate (R804057-01)		SOLID	7075-005	SE_L		07/09/08	07/15/08	BW	Selenium 79 in Solids
03/19/08	C5941, I-033									
04/09/08		F08-043								

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-LWS
 Version 3.06
 Report date 07/16/08

00000009

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

WORK SUMMARY, cont.

Client Hanford
 Contract No. 33677
 Case no SDG H3681

COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP SPIKE	TOTAL
H	F08-043	Tritium in Solids	TRITIUM_COX_LSC	1			1	1	1	4
NI_L	F08-043	Nickel 63 in Solids	NI63_LSC	1			1	1	1	4
SE_L	F08-043	Selenium 79 in Solids	SE79_SEP_IE_LSC	1			1		1	3
TC	F08-043	Technetium 99 in Solids	TC99_TR_SEP_GPC	1			1	1	1	4
TH	F08-043	Thorium, Isotopic in Solids	THISO_IE_PLATE_AEA	1			1	1	1	4
TOTALS				5			5	4	5	19

WORK SUMMARY

Page 2

SUMMARY DATA SECTION

Page 7

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-LWS
 Version 3.06
 Report date 07/16/08

00000010

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

7063-008

Method Blank

METHOD BLANK

SDG <u>7075</u>	Client/Case no <u>Hanford</u>	SDG <u>H3681</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R803100-08</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7063-008</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F08-043</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Selenium-79	15758-45-9	-0.151	2.0	3.36	10.0	U	SE_L

216-A-30 Crib Sampling

QC-BLANK #66278

Lab id <u>EBRLNE</u>
Protocol <u>Hanford1</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>07/16/08</u>

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

7075-003

Method Blank

METHOD BLANK

SDG <u>7075</u>	Client/Case no <u>Hanford</u>	SDG <u>H3681</u>
Contact <u>Melissa C. Mannion</u>	Contract <u>No. 33677</u>	
Lab sample id <u>R804057-03</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7075-003</u>	Material/Matrix <u>SOLID</u>	
	SAF No <u>F08-043</u>	

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	0	3.6	6.18	400	U	H
Nickel 63	13981-37-8	0.373	1.7	2.88	30.0	U	NI_L
Technetium 99	14133-76-7	-0.007	0.16	0.549	15.0	U	TC
Thorium 228	14274-82-9	0.006	0.098	0.176	1.00	U	TH
Thorium 230	14269-63-7	-0.006	0.11	0.220	1.00	U	TH
Thorium 232	TH-232	-0.018	0.024	0.058	1.00	U	TH

216-A-30 Crib Sampling

QC-BLANK #65344

Lab id <u>EBRLNE</u>
Protocol <u>Hanford1</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>07/16/08</u>

00000012

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

7075-002

Lab Control Sample

LAB CONTROL SAMPLE

SDG <u>7075</u>	Client/Case no <u>Hanford</u> <u>SDG H3681</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>
Lab sample id <u>R804057-02</u>	Client sample id <u>Lab Control Sample</u>
Dept sample id <u>7075-002</u>	Material/Matrix <u>SOLID</u>
	SAF No <u>F08-043</u>

ANALYTE	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS TEST	ADDED pCi/g	2σ ERR pCi/g	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Tritium	843	17	6.86	400	H	823	33	102	83-117	80-120
Nickel 63	243	6.1	2.94	30.0	NI_L	266	11	91	83-117	80-120
Technetium 99	114	2.6	0.570	15.0	TC	120	4.8	95	80-120	80-120
Thorium 230	17.8	1.0	0.211	1.00	TH	21.9	0.88	<u>81</u>	87-113	80-120

216-A-30 Crib Sampling

QC-LCS #65343

Lab id <u>EBRLNE</u>
Protocol <u>Hanford1</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>07/16/08</u>

00000013

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

7075-004

B1TH05

DUPLICATE

SDG <u>7075</u> Contact <u>Melissa C. Mannion</u> DUPLICATE Lab sample id <u>R804057-04</u> Dept sample id <u>7075-004</u> % solids <u>93.4</u>	ORIGINAL Lab sample id <u>R804057-01</u> Dept sample id <u>7075-001</u> Received <u>04/09/08</u> % solids <u>93.4</u>	Client/Case no <u>Hanford</u> <u>SDG H3681</u> Contract <u>No. 33677</u> Client sample id <u>B1TH05</u> Location/Matrix <u>C5941, I-033</u> <u>SOLID</u> Collected/Weight <u>03/19/08 08:50</u> <u>129 g</u> Custody/SAF No <u>F08-043-150</u> <u>F08-043</u>
--	---	--

ANALYTE	DUPLICATE	2σ ERR	MDA	RDL	QUALI-	ORIGINAL	2σ ERR	MDA	QUALI-	RPD	3σ	DER
	pCi/g	(COUNT)	pCi/g	pCi/g	FIERS TEST		pCi/g	(COUNT)	pCi/g	FIERS	%	TOT
Tritium	1.21	2.9	4.88	400	U	H	-0.477	2.9	4.94	U	-	0.8
Nickel 63	0.761	2.1	3.59	30.0	U	NI_L	0.245	2.0	3.46	U	-	0.4
Technetium 99	0.046	0.20	0.638	15.0	U	TC	0.194	0.36	0.627	U	-	0.7
Thorium 228	0.439	0.14	0.176	1.00		TH	0.459	0.13	0.119		4	66 0.2
Thorium 230	0.402	0.14	0.211	1.00		TH	0.435	0.15	0.203		8	75 0.3
Thorium 232	0.618	0.13	0.084	1.00		TH	0.474	0.11	0.081		26	50 1.6

216-A-30 Crib Sampling

QC-DUP#1 65345

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-DUP
 Version 3.06
 Report date 07/16/08

00000014

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

7075-005

B1TH05

DUPLICATE

SDG <u>7075</u>		Client/Case no <u>Hanford</u> <u>SDG H3681</u>
Contact <u>Melissa C. Mannion</u>		Contract <u>No. 33677</u>
DUPLICATE	ORIGINAL	
Lab sample id <u>R804057-05</u>	Lab sample id <u>R804057-01</u>	Client sample id <u>B1TH05</u>
Dept sample id <u>7075-005</u>	Dept sample id <u>7075-001</u>	Location/Matrix <u>C5941, I-033</u> <u>SOLID</u>
	Received <u>04/09/08</u>	Collected/Weight <u>03/19/08 08:50</u> <u>129 g</u>
% solids <u>93.4</u>	% solids <u>93.4</u>	Custody/SAF No <u>F08-043-150</u> <u>F08-043</u>

ANALYTE	DUPLICATE	2σ ERR	MDA	RDL	QUALI-	ORIGINAL	2σ ERR	MDA	QUALI-	RPD	3σ	DER
	pCi/g	(COUNT)	pCi/g	pCi/g	FIERS		TEST	pCi/g	(COUNT)	pCi/g	FIERS	%
Selenium-79	1.42	2.2	3.61	10.0	U	SE_L	1.02	2.0	3.31	U	-	0.3

216-A-30 Crib Sampling

QC-DUP#1 66252

DUPLICATES

Page 2

SUMMARY DATA SECTION

Page 12

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-DUP
 Version 3.06
 Report date 07/16/08

00000015

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3681

7075-001

B1TH05

DATA SHEET

SDG <u>7075</u>	Client/Case no <u>Hanford</u>	SDG <u>H3681</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>33677</u>	
Lab sample id <u>R804057-01</u>	Client sample id <u>B1TH05</u>	
Dept sample id <u>7075-001</u>	Location/Matrix <u>C5941, I-033</u>	<u>SOLID</u>
Received <u>04/09/08</u>	Collected/Weight <u>03/19/08 08:50</u>	<u>129 g</u>
% solids <u>93.4</u>	Custody/SAF No <u>F08-043-150</u>	<u>F08-043</u>

ANALYTE	CAS NO	RESULT pCi/g	2σ ERR (COUNT)	MDA pCi/g	RDL pCi/g	QUALI- FIERS	TEST
Tritium	10028-17-8	-0.477	2.9	4.94	400	U	H
Nickel 63	13981-37-8	0.245	2.0	3.46	30.0	U	NI_L
Technetium 99	14133-76-7	0.194	0.36	0.627	15.0	U	TC
Thorium 228	14274-82-9	0.459	0.13	0.119	1.00		TH
Thorium 230	14269-63-7	0.435	0.15	0.203	1.00		TH
Thorium 232	TH-232	0.474	0.11	0.081	1.00		TH
Selenium-79	15758-45-9	1.02	2.0	3.31	10.0	U	SE_L

216-A-30 Crib Sampling

Lab id <u>EBRLNE</u>
Protocol <u>Hanford1</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>07/16/08</u>

00000016

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

LAB METHOD SUMMARY

THORIUM, ISOTOPIC IN SOLIDS
ALPHA SPECTROSCOPY

Test TH Matrix SOLID
SDG 7075
Contact Melissa C. Mannion

Client Hanford
Contract No. 33677
Contract SDG H3681

RESULTS

LAB RAW SUF-
SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Thorium 230

Preparation batch 6152-064				
R804057-01		7075-001	B1TH05	0.435
R804057-02		7075-002	Lab Control Sample	<u>LOW</u>
R804057-03		7075-003	Method Blank	U
R804057-04		7075-004	Duplicate (R804057-01)	ok

Nominal values and limits from method RDLs (pCi/g) 1.00
216-A-30 Crib Sampling

METHOD PERFORMANCE

LAB	RAW	SUF-	MAX MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/g	g	FAC	TION	%	%	min	keV	KeV	HELD PREPARED	YZED DETECTOR
Preparation batch 6152-064 2σ prep error 8.0 % Reference Lab Notebook #6152 pg. 64													
R804057-01		B1TH05	0.203	0.250			95		849			55 05/13/08	05/13 SS-033
R804057-02		Lab Control Sample	0.211	0.250			87		849			05/13/08	05/13 SS-034
R804057-03		Method Blank	0.220	0.250			90		846			05/13/08	05/13 SS-035
R804057-04		Duplicate (R804057-01)	0.211	0.250			92		846			55 05/13/08	05/13 SS-036

Nominal values and limits from method 1.00 0.250 20-105 150 180

PROCEDURES	REFERENCE	THISO_IE_PLATE_AEA
	SPP-070	Soil Dissolution, < 1.0g Aliquot, rev 7
	CP-900	Thorium in Water and Dissolved Solid Samples by Extraction Chromatography, rev 1
	CP-008	Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD	MDA <u>0.211</u> ± <u>0.014</u>
FOR 4 SAMPLES	YIELD <u>91</u> ± <u>7</u>

Lab id <u>EBRLNE</u>
Protocol <u>Hanford1</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LMS</u>
Version <u>3.06</u>
Report date <u>07/16/08</u>

00000017

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

Test TC Matrix SOLID

SDG 7075

Contact Melissa C. Mannion

LAB METHOD SUMMARY

TECHNETIUM 99 IN SOLIDS

BETA COUNTING

Client Hanford

Contract No. 33677

Contract SDG H3681

RESULTS

LAB	RAW	SUF-	Technetium	
SAMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	99
Preparation batch 6152-064				
R804057-01		7075-001	B1TH05	U
R804057-02		7075-002	Lab Control Sample	ok
R804057-03		7075-003	Method Blank	U
R804057-04		7075-004	Duplicate (R804057-01)	- U

Nominal values and limits from method RDLs (pCi/g) 15.0

216-A-30 Crib Sampling

METHOD PERFORMANCE

LAB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-		
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/g	g	FAC	TION	%	%	min	keV	KeV	HELD	PREPARED	YZED	DETECTOR
Preparation batch 6152-064			2σ prep error 13.2 %		Reference Lab Notebook #6152		pg. 64								
R804057-01		B1TH05	0.627	1.00			82	50			48	04/30/08	05/06	GRB-203	
R804057-02		Lab Control Sample	0.570	1.00			90	50				04/30/08	05/03	GRB-222	
R804057-03		Method Blank	0.549	1.00			94	50				04/30/08	05/03	GRB-223	
R804057-04		Duplicate (R804057-01)	0.638	1.00			80	50			45	04/30/08	05/03	GRB-224	

Nominal values and limits from method 15.0 1.00 20-105 50 180

PROCEDURES	REFERENCE	TC99_TR_SEP_GPC
	SPP-062	Sample Aliquoting, rev 0
	CP-431	Technetium-99 Purification of Soil or Resin by Extraction Chromatography, rev 2
	CP-008	Heavy Element Electroplating, rev 9

AVERAGES ± 2 SD	MDA	<u>0.596</u> ± <u>0.086</u>
FOR 4 SAMPLES	YIELD	<u>86</u> ± <u>13</u>

METHOD SUMMARIES

Page 2

SUMMARY DATA SECTION

Page 15

Lab id EBRLNE

Protocol Hanford1

Version Ver 1.0

Form DVD-LMS

Version 3.06

Report date 07/16/08

00000018

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

LAB METHOD SUMMARY

TRITIUM IN SOLIDS

LIQUID SCINTILLATION COUNTING

Test H Matrix SOLID
 SDG 7075
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 33677
 Contract SDG H3681

RESULTS

LAB	RAW	SUF-			
SAMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID		Tritium
Preparation batch 6152-064					
R804057-01		7075-001	B1TH05		U
R804057-02		7075-002	Lab Control Sample		ok
R804057-03		7075-003	Method Blank		U
R804057-04		7075-004	Duplicate (R804057-01)		- U

Nominal values and limits from method RDLs (pCi/g) 400
 216-A-30 Crib Sampling

METHOD PERFORMANCE

LAB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/g	g	FAC	TION	%	%	min	keV	KeV	HELD PREPARED	YZED DETECTOR
Preparation batch 6152-064 2σ prep error 10.0 % Reference Lab Notebook #6152 pg. 64													
R804057-01		B1TH05	4.94	0.384			100		50		38	04/25/08 04/26	LSC-007
R804057-02		Lab Control Sample	6.86	0.300			100		50			04/25/08 04/26	LSC-007
R804057-03		Method Blank	6.18	0.300			100		50			04/25/08 04/26	LSC-007
R804057-04		Duplicate (R804057-01)	4.88	0.385			100		50		38	04/25/08 04/26	LSC-007

Nominal values and limits from method 400 0.300 25 180

PROCEDURES REFERENCE TRITIUM_COX_LSC
 CP-251 Tritium/Carbon-14 Oxidation, rev 8

AVERAGES ± 2 SD MDA 5.72 ± 1.94
 FOR 4 SAMPLES YIELD 100 ± 0

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 07/16/08

00000019

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

Test NI L Matrix SOLID
 SDG 7075
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

NICKEL 63 IN SOLIDS

LIQUID SCINTILLATION COUNTING

Client Hanford
 Contract No. 33677
 Contract SDG H3681

RESULTS

LAB RAW SUF-
 SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Nickel 63

Preparation batch 6152-064

R804057-01	7075-001	B1TH05	U
R804057-02	7075-002	Lab Control Sample	ok
R804057-03	7075-003	Method Blank	U
R804057-04	7075-004	Duplicate (R804057-01)	- U

Nominal values and limits from method RDLs (pCi/g) 30.0

216-A-30 Crib Sampling

METHOD PERFORMANCE

LAB RAW SUF- MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-
 SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/g g FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6152-064 2σ prep error 11.2 % Reference Lab Notebook #6152 pg. 64

R804057-01	B1TH05	3.46	0.500	81	50	58	05/14/08	05/16	LSC-004
R804057-02	Lab Control Sample	2.94	0.500	96	50		05/14/08	05/16	LSC-004
R804057-03	Method Blank	2.88	0.500	97	50		05/14/08	05/16	LSC-004
R804057-04	Duplicate (R804057-01)	3.59	0.500	79	50	58	05/14/08	05/16	LSC-004

Nominal values and limits from method 30.0 0.500 30-105 25 180

PROCEDURES REFERENCE NI63_LSC
 SPP-070 Soil Dissolution, < 1.0g Aliquot, rev 7
 CP-280 Nickel-63 Purification, rev 3

AVERAGES ± 2 SD MDA 3.22 ± 0.720
 FOR 4 SAMPLES YIELD 88 ± 19

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 07/16/08

00000020

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

LAB METHOD SUMMARY

SELENIUM 79 IN SOLIDS

LIQUID SCINTILLATION COUNTING

Test SE L Matrix SOLID

SDG 7075

Contact Melissa C. Mannion

Client Hanford

Contract No. 33677

Contract SDG H3681

RESULTS

LAB RAW SUF-
SAMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Selenium-79

Preparation batch 6145-169

R803100-08	7063-008	Method Blank	U
R804057-01	7075-001	B1TH05	U
R804057-05	7075-005	Duplicate (R804057-01)	- U

Nominal values and limits from method RDLs (pCi/g) 10.0
216-A-30 Crib Sampling

METHOD PERFORMANCE

LAB RAW SUF- MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-
SAMPLE ID TEST FIX CLIENT SAMPLE ID pCi/g g FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

Preparation batch 6145-169 2σ prep error 11.2 % Reference Lab Notebook #6145, pg. 169

R803100-08	Method Blank	3.36	0.500	78	<u>50</u>				07/09/08	07/09	LSC-004
R804057-01	B1TH05	3.31	0.500	78	<u>50</u>			112	07/09/08	07/09	LSC-004
R804057-05	Duplicate (R804057-01)	3.61	0.500	70	<u>50</u>			112	07/09/08	07/09	LSC-004

Nominal values and limits from method 10.0 0.500 20-105 100 180

PROCEDURES REFERENCE SE79_SEP_IE_LSC
SPP-070 Soil Dissolution, < 1.0g Aliquot, rev 7
RP-340 Selenium-79 in Solids and Water, rev 0

AVERAGES ± 2 SD MDA 3.43 ± 0.321
FOR 3 SAMPLES YIELD 75 ± 9

METHOD SUMMARIES

Page 5

SUMMARY DATA SECTION

Page 18

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-LMS
Version 3.06
Report date 07/16/08

00000021

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- * LAB SAMPLE ID is the lab's primary identification for a sample.
- * DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- * CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- * QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- * All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- * The preparation batches are shown in the same order as the Method Summary Reports are printed.
- * Only analyses of planchets relevant to the SDG are included.
- * Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- * The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000023

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- * TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- * SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- * The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- * PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- * For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- * The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

REPORT GUIDES

Page 3

SUMMARY DATA SECTION

Page 21

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

0000024

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

Client Hanford
Contract No. 33677
Case no SDG H3681

REPORT GUIDE

DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- * TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- * The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- * ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- * A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- * When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

- U The RESULT is less than the MDA (Minimum Detectable Activity).

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
 Contract No. 33677
 Case no SDG H3681

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
 - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
 - H Similar to 'L' except the recovery was high.
 - P The RESULT is 'preliminary'.
 - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
 - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- * An MDA is underlined if it is bigger than its RDL.

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 07/16/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 33677
Case no SDG H3681

DATA SHEET

- * An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- * A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- * When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000027

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- * An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- * The first, computed limits for the recovery reflect:
 1. The error of RESULT, including that introduced by rounding the result prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
 2. The error of ADDED.
 3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- * The second limits are protocol defined upper and lower QC limits for the recovery.
- * The recovery is underlined if it is outside either of these ranges.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- * The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- * The second limit for the RPD is the larger of:
 1. A fixed percentage specified in the protocol.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000029

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 33677
Case no SDG H3681

DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- * The RPD is underlined if it is greater than either limit.
- * If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- * The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000030

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 33677
Case no SDG H3681

MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- * The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- * The second limits are protocol defined upper and lower QC limits

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000031

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 33677

Case no SDG H3681

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- * The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 29

Lab id EBRLNE

Protocol Hanford1

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 07/16/08

00000032

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

Client Hanford
Contract No. 33677
Case no SDG H3681

REPORT GUIDE

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- * Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- * The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- * If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- * Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- * Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
 Contract No. 33677
 Case no SDG H3681

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- * Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- * If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- * Aliquots are underlined if less than the nominal value specified for the method.
- * Preparation factors are underlined if greater than the nominal value specified for the method.
- * Dilution factors are underlined if greater than the nominal value specified for the method.
- * Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- * Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- * Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

Lab id EBRLNE
 Protocol Hanford1
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 07/16/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 33677
Case no SDG H3681

METHOD SUMMARY

- * Count times are underlined if less than the nominal value specified for the method.
- * Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- * Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- * Days Held are underlined if greater than the holding time specified in the protocol.
- * Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3681

SDG 7075
Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
Contract No. 33677
Case no SDG H3681

METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

Lab id EBRLNE
Protocol Hanford1
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 07/16/08

00000036

COLLECTOR
NCO Sampler *WDB, Kauer, Herrick*

SAMPLING LOCATION
C5941, I-033

ICE CHEST NO.
GRP-04-014

COMPANY CONTACT
TRENT, SJ

PROJECT DESIGNATION
216-A-30 Crib Sampling

FIELD LOGBOOK NO.

TELEPHONE NO.
373-5869

ACTUAL SAMPLE DEPTH
H3681 (7075)
85' - 87.5'

PROJECT COORDINATOR
WIDRIG, DL

PRICE CODE
8N

SAF NO.
F08-043

AIR QUALITY

DATA TURNAROUND
45 Days / 45 Days

COA
123215ES20

METHOD OF SHIPMENT
FEDERAL EXPRESS

SHIPPED TO
Eberline Services

OFFSITE PROPERTY NO.
SEE PTR

BILL OF LADING/AIR BILL NO.
SEE PTR

MATRIX*
A=Air
DL=Drum
L=Liquid
DS=Drum
S=Solids
L=Liquid
O=Oil
S=Soil
SE=Sediment
T=Tissue
V=Vegetation
W=Water
WI=Wipe
X=Other

POSSIBLE SAMPLE HAZARDS/ REMARKS
Contains Radioactive Material at concentrations that are not regulated for transportation per 49 CFR but are not releasable per DOE Order 5400.5 (1990/1993)

SPECIAL HANDLING AND/OR STORAGE
Radioactive tie to B1TDB7

PRESERVATION	None
TYPE OF CONTAINER	G/P
NO. OF CONTAINER(S)	1
VOLUME	120mL
SAMPLE ANALYSIS	SEE ITEM (1) IN SPECIAL INSTRUCTIONS

2500000037

SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME						
B1TH05	SOIL	3-19-08	0850	X					

Lot# 024875

CHAIN OF POSSESSION		SIGN/ PRINT NAMES	
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME
<i>Dr. WDB/Al Wda</i>	<i>3-19-08/1052</i>	<i>MOSCO FRIDGE</i>	<i>3-19-08/1052</i>
<i>FED EX</i>		<i>FFW</i>	<i>04/09/08 09:30</i>
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME
RELINQUISHED BY/REMOVED FROM	DATE/TIME	RECEIVED BY/STORED IN	DATE/TIME

SPECIAL INSTRUCTIONS

** The 200 Area S&GRP Characterization and Monitoring Sampling and Analysis GKI applies to this SAF.
(1) Tritium - H3; Technetium-99 (Technetium-99); Nickel-63; Isotopic Thorium (Thorium-232)

LABORATORY SECTION	RECEIVED BY	TITLE	DATE/TIME
FINAL SAMPLE DISPOSITION	DISPOSAL METHOD	DISPOSED BY	DATE/TIME