



EBERLINE
SERVICES

0077790
Part 1 of 2

November 21, 2007

Mr. Steve Trent
Fluor Hanford Inc.
1200 Jadwin Avenue
Richland, WA 99352

Reference: **P.O. #630**
Eberline Services R7-09-125-7692, SDG H3579

Dear Mr. Trent:

Enclosed is the data report for one water sample designated under SAF No. F07-058 received at Eberline Services on September 20, 2007. The sample was analyzed according to the accompanying chain-of-custody document.

Please call if you have any questions concerning this report.

Sincerely,

Melissa Mannion

Melissa C. Mannion
Senior Program Manager

MCM/njv

Enclosure: Data Package



RECEIVED
JUN 11 2008

EDMC

Analytical Services
2030 Wright Avenue
P.O. Box 4040
Richmond, California 94804-0040
(510) 235-2633 Fax (510) 235-0438
Toll Free (800) 841-5487
www.eberlineservices.com

1.0 GENERAL

Fluor Hanford Inc. (FH) Sample Delivery Group H3579 was composed of one water sample designated under SAF No. F07-058 with a Project Designation of: 216-A-2 and 216-A-21 Characterization Sampling and Analysis-Groundwater.

The sample was received as stated on the Chain-of-Custody document. Any discrepancies are noted on the Eberline Services Sample Receipt Checklist.

2.0 ANALYSIS NOTES

2.1 Tritium Analysis

No problems were encountered during the course of the analyses.

2.2 Carbon-14 Analysis

No problems were encountered during the course of the analyses.

2.3 Nickel-63 Analysis

No problems were encountered during the course of the analyses.

2.4 Selenium-79 Analysis

Eberline Services does not maintain a stock of Se-79 activity with which to prepare laboratory control samples, as a consequence an LCS was not performed.

2.5 Iodine-129 Analysis

No problems were encountered during the course of the analyses.

2.6 Protactinium-231 Analysis

No problems were encountered during the course of the analyses.

3.0 Case Narrative Certification Statement

"I certify that this data package is in compliance with the SOW, both technically and for completeness, for other than the conditions detailed above. Release of the data obtained in this hard copy data package has been authorized by the Laboratory Manager or a designee, as verified by the following signature."

Melissa C. Mannion
Melissa C. Mannion
Senior Program Manager

11/21/07
Date

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3579

SDG 7692
Contact Melissa C. Mannion

Client Hanford
Contract No. 630
Case no SDG_H3579

S U M M A R Y D A T A S E C T I O N

T A B L E O F C O N T E N T S				
About this section	.	.	.	1
Sample Summaries	.	.	.	3
Prep Batch Summary	.	.	.	5
Work Summary	.	.	.	6
Method Blanks	.	.	.	8
Lab Control Samples	.	.	.	10
Duplicates	.	.	.	12
Matrix Spikes	.	.	.	14
Data Sheets	.	.	.	16
Method Summaries	.	.	.	17
Report Guides	.	.	.	23
End of Section	.	.	.	37

Melissa Mannion
Prepared by

Melissa Mannion
Reviewed by

Lab id EBRINE
Protocol Hanford
Version Ver 1.0
Form DVD-TOC
Version 3.06
Report date 11/21/07

00000002

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 630

Case no SDG_H3579

ABOUT THE DATA SUMMARY SECTION

The Data Summary Section of a Data Package has all data, in several useful orders, necessary for first level, routine review of the data package for a Sample Delivery Group (SDG). This section follows the Data Package Narrative, which has an overview of the data package and a discussion of special problems. It is followed by the Raw Data Section, which has full details.

The Data Summary Section has several groups of reports:

SAMPLE SUMMARIES

The Sample and QC Summary Reports show all samples, including QC samples, reported in one SDG. These reports cross-reference client and lab sample identifiers.

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches (lab groupings reflecting how work was organized) relevant to the reported SDG with information necessary to check the completeness and consistency of the SDG.

WORK SUMMARY

The Work Summary Report shows all samples and work done on them relevant to the reported SDG.

METHOD BLANKS

The Method Blank Reports, one for each Method Blank relevant to the SDG, show all results and primary supporting information for the blanks.

LAB CONTROL SAMPLES

The Lab Control Sample Reports, one for each Lab Control Sample relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 1

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000003

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 630

Case no SDG H3579

ABOUT THE DATA SUMMARY SECTION

DUPLICATES

The Duplicate Reports, one for each Duplicate and Original sample pair relevant to the SDG, show all results, differences and primary supporting information for these QC samples.

MATRIX SPIKES

The Matrix Spike Reports, one for each Spiked and Original sample pair relevant to the SDG, show all results, recoveries and primary supporting information for these QC samples.

DATA SHEETS

The Data Sheet Reports, one for each client sample in the SDG, show all results and primary supporting information for these samples.

METHOD SUMMARIES

The Method Summary Reports, one for each test used in the SDG, show all results, QC and method performance data for one analyte on one or two pages. (A test is a short code for the method used to do certain work to the client's specification.)

REPORT GUIDES

The Report Guides, one for each of the above groups of reports, have documentation on how to read the associated reports.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 2

Lab id EBRINE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 11/21/07

00000004

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

LAB SAMPLE SUMMARY

Client Hanford
 Contract No. 630
 Case no SDG H3579

LAB	CLIENT SAMPLE ID	LOCATION	MATRIX	LEVEL	SAF NO	CHAIN OF CUSTODY	COLLECTED
R709125-01	B1PLH0	C5515, I-Water	WATER		F07-058	F07-058-012	09/06/07 08:25
R709125-02	Lab Control Sample		WATER		F07-058		
R709125-03	Method Blank		WATER		F07-058		
R709125-04	Duplicate (R709125-01)	C5515, I-Water	WATER		F07-058		09/06/07 08:25
R709125-05	Spike (R709125-01)	C5515, I-Water	WATER		F07-058		09/06/07 08:25
R709125-07	Lab Control Sample		WATER		F07-058		
R709125-08	Method Blank		WATER		F07-058		
R709125-09	Duplicate (R709125-01)	C5515, I-Water	WATER		F07-058		09/06/07 08:25
R709125-10	Spike (R709125-01)	C5515, I-Water	WATER		F07-058		09/06/07 08:25

LAB SUMMARY

Page 1

SUMMARY DATA SECTION

Page 3

Lab id EBRLINE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-LS
 Version 3.06
 Report date 11/21/07

00000005

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 630
 Case no SDG H3579

QC SUMMARY

C BATCH	CHAIN OF CUSTODY	CLIENT SAMPLE ID	MATRIX	% SOLIDS	SAMPLE AMOUNT	BASIS AMOUNT	DAYS SINCE RECEIVED	LAB COLL SAMPLE ID	DEPARTMENT SAMPLE ID
692	F07-058-012	B1PLH0	WATER		7.0 L		09/20/07 14	R709125-01	7692-001
		Method Blank	WATER					R709125-03	7692-003
		Method Blank	WATER					R709125-08	7692-008
		Lab Control Sample	WATER					R709125-02	7692-002
		Lab Control Sample	WATER					R709125-07	7692-007
		Duplicate (R709125-01)	WATER		7.0 L		09/20/07 14	R709125-04	7692-004
		Duplicate (R709125-01)	WATER		7.0 L		09/20/07 14	R709125-09	7692-009
		Spike (R709125-01)	WATER		7.0 L		09/20/07 14	R709125-05	7692-005
		Spike (R709125-01)	WATER		7.0 L		09/20/07 14	R709125-10	7692-010

QC SUMMARY

Page 1

SUMMARY DATA SECTION

Page 4

Lab id EBERLINE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-QS
 Version 3.06
 Report date 11/21/07

00000006

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

PREP BATCH SUMMARY

Client Hanford
 Contract No. 630
 Case no SDG H3579

TEST	MATRIX	METHOD	PREPARATION ERROR		PLANCHETS ANALYZED				QUALI-	
			BATCH	2σ %	CLIENT	MORE	RE	BLANK		LCS
Alpha Spectroscopy										
PA	WATER	Pa-231 in Water	6121-102	5.0	1		1	1	1/1	
Gamma Spectroscopy										
I	WATER	Iodine 129 in Water	6121-102	5.0	1		1	1	1/1	
Liquid Scintillation Counting										
C	WATER	Carbon 14 in Water	6121-102	10.0	1		1	1	1/1	1/1 X
H	WATER	Tritium in Water	6121-102	10.0	1		1	1	1/1	1/1 X
NI_L	WATER	Nickel-63 in Liquid	6121-102	10.0	1		1	1	1/1	
SE_L	WATER	Selenium 79 in Water	6121-102	10.0	1		1		1/1	

Duplicates and Matrix Spikes are those with original (Client) sample in this Sample Delivery Group.
 Blank and LCS plachets are those in the same preparation batch as some Client, Duplicate or Spike sample.

Lab id EBRLNE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-PBS
 Version 3.06
 Report date 11/21/07

00000007

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

LAB WORK SUMMARY

Client Hanford

Contract No. 630

Case no SDG H3579

AB SAMPLE	CLIENT SAMPLE ID									
COLLECTED	LOCATION	MATRIX	SUP-							
RECEIVED	CUSTODY	SAF No	PLANCHET	TEST	FIX	ANALYZED	REVIEWED	BY	METHOD	
709125-01	B1PLH0		7692-001	C	Al	11/07/07	11/09/07	BW	Carbon 14 in Water	
09/06/07	C5515, I-Water		7692-001	H		10/21/07	10/26/07	BW	Tritium in Water	
09/20/07	F07-058-012	F07-058	7692-001	I		10/30/07	10/31/07	BW	Iodine 129 in Water	
			7692-001	NI_L		10/24/07	10/25/07	BW	Nickel-63 in Liquid	
			7692-001	PA		11/09/07	11/13/07	BW	Pa-231 in Water	
			7692-001	SE_L		10/19/07	11/14/07	BW	Selenium 79 in Water	
709125-02	Lab Control Sample		7692-002	H		10/21/07	10/26/07	BW	Tritium in Water	
			7692-002	I		10/31/07	11/01/07	BW	Iodine 129 in Water	
		F07-058	7692-002	NI_L		10/24/07	10/25/07	BW	Nickel-63 in Liquid	
			7692-002	PA		11/09/07	11/13/07	BW	Pa-231 in Water	
709125-03	Method Blank		7692-003	H		10/21/07	10/26/07	BW	Tritium in Water	
			7692-003	I		10/31/07	11/13/07	BW	Iodine 129 in Water	
		F07-058	7692-003	NI_L		10/24/07	10/25/07	BW	Nickel-63 in Liquid	
			7692-003	PA		11/09/07	11/13/07	BW	Pa-231 in Water	
			7692-003	SE_L		10/19/07	11/14/07	BW	Selenium 79 in Water	
709125-04	Duplicate (R709125-01)		7692-004	H		10/21/07	10/26/07	BW	Tritium in Water	
09/06/07	C5515, I-Water		7692-004	I		10/31/07	11/01/07	BW	Iodine 129 in Water	
09/20/07		F07-058	7692-004	NI_L		10/24/07	10/25/07	BW	Nickel-63 in Liquid	
			7692-004	PA		11/09/07	11/13/07	BW	Pa-231 in Water	
			7692-004	SE_L		10/19/07	11/14/07	BW	Selenium 79 in Water	
709125-05	Spike (R709125-01)		7692-005	H		10/20/07	10/26/07	BW	Tritium in Water	
09/06/07	C5515, I-Water									
09/20/07		F07-058								
709125-07	Lab Control Sample		7692-007	C		11/07/07	11/09/07	BW	Carbon 14 in Water	
		F07-058								
709125-08	Method Blank		7692-008	C		11/07/07	11/09/07	BW	Carbon 14 in Water	
		F07-058								
709125-09	Duplicate (R709125-01)		7692-009	C		11/07/07	11/09/07	BW	Carbon 14 in Water	
09/06/07	C5515, I-Water									
09/20/07		F07-058								

WORK SUMMARY

Page 1

SUMMARY DATA SECTION

Page 6

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-LWS

Version 3.06

Report date 11/21/07

00000008

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

WORK SUMMARY, cont.

Client Hanford
 Contract No. 630
 Case no SDG H3579

AB SAMPLE	CLIENT SAMPLE ID	COLLECTED	LOCATION	MATRIX	PLANCHET	TEST	SUP-	FIX	ANALYZED	REVIEWED	BY	METHOD
RECEIVED	CUSTODY	SAF No										
709125-10	Spike (R709125-01)				7692-010	C		11/07/07	11/09/07	BW		Carbon 14 in Water
09/06/07	C5515, I-Water			WATER								
09/20/07		F07-058										

COUNTS OF TESTS BY SAMPLE TYPE

TEST	SAF No	METHOD	REFERENCE	CLIENT	MORE	RE	BLANK	LCS	DUP	SPIKE	TOTAL
C	F07-058	Carbon 14 in Water	C14_CHEM_LSC	1			1	1	1	1	5
H	F07-058	Tritium in Water	906.0_H3_LSC	1			1	1	1	1	5
I	F07-058	Iodine 129 in Water	I129_SEP_LEPS_GS	1			1	1	1		4
NI_L	F07-058	Nickel-63 in Liquid	NI63_LSC	1			1	1	1		4
PA	F07-058	Pa-231 in Water	PA231_IE_PLATE_AEA	1			1	1	1		4
SE_L	F07-058	Selenium 79 in Water	SE79_SEP_DIS_LSC	1			1		1		3
TOTALS				6			6	5	6	2	25

WORK SUMMARY

Page 2

SUMMARY DATA SECTION

Page 7

Lab id EBRLNE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-LWS
 Version 3.06
 Report date 11/21/07

00000009

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3579

7692-008

Method Blank

METHOD BLANK

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	SDG <u>H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R709125-08</u>	Client sample id <u>Method Blank</u>	
Dept sample id <u>7692-008</u>	Material/Matrix <u>WATER</u>	
	SAF No <u>F07-058</u>	

ANALYTE	CAS NO	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST
Carbon 14	14762-75-5	0.473	20	34	200	U	C

216-A-2 & 216-A-1 - Groundwater

QC-BLANK #63449

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000011

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

7692-002

Lab Control Sample

LAB CONTROL SAMPLE

SDG <u>7692</u> Contact <u>Melissa C. Mannion</u>	Client/Case no <u>Hanford</u> SDG <u>H3579</u> Contract No. <u>630</u>
Lab sample id <u>R709125-02</u> Dept sample id <u>7692-002</u>	Client sample id <u>Lab Control Sample</u> Material/Matrix <u>WATER</u> SAF No <u>F07-059</u>

ANALYTE	RESULT	2σ ERR	MDA	RDL	QUALI-	ADDED	2σ ERR	REC	3σ LMTS	PROTOCOL
	pCi/L	(COUNT)	pCi/L	pCi/L	FIERS TEST	pCi/L	pCi/L	%	(TOTAL)	LIMITS
Tritium	22200	1500	<u>1600</u>	400	H	22400	900	99	81-119	80-120
Nickel 63	259	6.2	3.1	15	NI_L	266	11	97	84-116	80-120
Protactinium 231	6.22	0.81	0.20	1.0	PA	6.65	0.27	94	80-120	80-120
Iodine 129	277	3.6	4.2	5.0	I	254	10	109	90-110	80-120

216-A-2 & 216-A-1 - Groundwater

QC-LCS #63142

LAB CONTROL SAMPLES

Page 1

SUMMARY DATA SECTION

Page 10

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-LCS</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000012

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

7692-007

Lab Control Sample

LAB CONTROL SAMPLE

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	SDG <u>H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R709125-07</u>	Client sample id <u>Lab Control Sample</u>	
Dept sample id <u>7692-007</u>	Material/Matrix <u>WATER</u>	
	SAF No <u>F07-058</u>	

ANALYTE	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST	ADDED pCi/L	2σ ERR pCi/L	REC %	3σ LMTS (TOTAL)	PROTOCOL LIMITS
Carbon 14	7830	83	39	200		C	7970	320	98	84-116	80-120

216-A-2 & 216-A-1 - Groundwater

QC-LCS #63448

LAB CONTROL SAMPLES

Page 2

SUMMARY DATA SECTION

Page 11

Lab id <u>EBERLINE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVI-LCS</u>
Version <u>3.05</u>
Report date <u>11/21/07</u>

00000013

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

7692-004

B1PLH0

DUPLICATE

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	SDG <u>H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
DUPLICATE	ORIGINAL	
Lab sample id <u>R709125-04</u>	Lab sample id <u>R709125-01</u>	Client sample id <u>B1PLH0</u>
Dept sample id <u>7692-004</u>	Dept sample id <u>7692-001</u>	Location/Matrix <u>C5515, I-Water</u> <u>WATER</u>
	Received <u>09/20/07</u>	Collected/Volume <u>09/06/07 08:25</u> <u>7.0 L</u>
		Custody/SAF No <u>F07-058-012</u> <u>F07-058</u>

ANALYTE	DUPLICATE pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST	ORIGINAL pCi/L	2σ ERR (COUNT)	MDA pCi/L	QUALI- FIERS	RPD %	3σ TOT	DER σ
Tritium	621000	1900	160	400		H	601000	1800	160		3	21	0.5
Nickel 63	0.644	2.0	3.4	15	U	NI_L	0.588	2.0	3.3	U	-		0
Protactinium 231	0.057	0.076	0.15	1.0	U	PA	0.017	0.067	0.13	U	-		0.8
Iodine 129	4.66	1.1	2.4	5.0		I	6.23	1.0	2.2		29	42	2.0
Selenium 79	2.09	23	38	50	U	SE_L	1.20	26	44	U	-		0.1

216-A-2 & 216-A-1 - Groundwater

QC-DUP#1 63144

DUPLICATES

Page 1

SUMMARY DATA SECTION

Page 12

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000014

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

7692-009

B1PLH0

DUPLICATE

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	SDG <u>H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
DUPLICATE	ORIGINAL	
Lab sample id <u>R709125-09</u>	Lab sample id <u>R709125-01</u>	Client sample id <u>B1PLH0</u>
Dept sample id <u>7692-009</u>	Dept sample id <u>7692-001</u>	Location/Matrix <u>C5515, I-Water</u> <u>WATER</u>
	Received <u>09/20/07</u>	Collected/Volume <u>09/06/07 08:25</u> <u>7.0 L</u>
		Custody/SAF No <u>F07-058-012</u> <u>F07-058</u>

ANALYTE	DUPLICATE	2σ ERR	MDA	RDL	QUALI-	ORIGINAL	2σ ERR	MDA	QUALI-	RPD	3σ	DER
	pCi/L	(COUNT)	pCi/L	pCi/L	FIERS		TEST	pCi/L	(COUNT)	pCi/L	%	TOT
Carbon 14	28.9	20	33	200	U	C	18.2	20	33	U	-	0.8

216-A-2 & 216-A-1 - Groundwater

QC-DUP#1A1 63450

DUPLICATES

Page 2

SUMMARY DATA SECTION

Page 13

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DUP</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000015

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

7692-005

B1PLH0

MATRIX SPIKE

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	<u>SDG H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
MATRIX SPIKE	ORIGINAL	
Lab sample id <u>R709125-05</u>	Lab sample id <u>R709125-01</u>	Client sample id <u>B1PLH0</u>
Dept sample id <u>7692-005</u>	Dept sample id <u>7692-001</u>	Location/Matrix <u>C5515, I-Water</u> <u>WATER</u>
	Received <u>09/20/07</u>	Collected/Volume <u>09/06/07 08:25</u> <u>7.0 L</u>
		Custody/SAP No <u>F07-058-012</u> <u>F07-058</u>

ANALYTE	SPIKE pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST	ADDED pCi/L	2σ ERR pCi/L	ORIGINAL pCi/L	2σ ERR (COUNT)	REC 3σ % (TOTAL)	LMTS LIMITS	PROTOCOL
Tritium	629000	1900	160	400	X	H	27300	1100	601000	1800	103	60-140	

216-A-2 & 216-A-1 - Groundwater

QC-MS#1 63145

MATRIX SPIKES

Page 1

SUMMARY DATA SECTION

Page 14

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-MS</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000016

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

7692-010

B1PLH0

MATRIX SPIKE

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	<u>SDG H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
MATRIX SPIKE	ORIGINAL	
Lab sample id <u>R709125-10</u>	Lab sample id <u>R709125-01</u>	Client sample id <u>B1PLH0</u>
Dept sample id <u>7692-010</u>	Dept sample id <u>7692-001</u>	Location/Matrix <u>C5515, I-Water</u> <u>WATER</u>
	Received <u>09/20/07</u>	Collected/Volume <u>09/06/07 08:25</u> <u>7.0 L</u>
		Custody/SAF No <u>F07-058-012</u> <u>F07-058</u>

ANALYTE	SPIKE pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TRST	ADDED pCi/L	2σ ERR pCi/L	ORIGINAL pCi/L	2σ ERR (COUNT)	REC 3σ % (TOTAL)	LMTS LIMITS	PROTOCOL
Carbon 14	24400	250	81	200	X	C	23900	960	18.2	20	102	83-117	60-140

216-A-2 & 216-A-1 - Groundwater

QC-MS#1A1 63451

MATRIX SPIKES

Page 2

SUMMARY DATA SECTION

Page 15

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version Ver <u>1.0</u>
Form <u>DVD-MS</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000017

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3579

7692-001

B1PLH0

D A T A S H E E T

SDG <u>7692</u>	Client/Case no <u>Hanford</u>	SDG <u>H3579</u>
Contact <u>Melissa C. Mannion</u>	Contract No. <u>630</u>	
Lab sample id <u>R709125-01</u>	Client sample id <u>B1PLH0</u>	
Dept sample id <u>7692-001</u>	Location/Matrix <u>C5515, I-Water</u>	<u>WATER</u>
Received <u>09/20/07</u>	Collected/Volume <u>09/06/07 08:25</u>	<u>7.0 L</u>
	Custody/SAF No <u>F07-058-012</u>	<u>F07-058</u>

ANALYTE	CAS NO	RESULT pCi/L	2σ ERR (COUNT)	MDA pCi/L	RDL pCi/L	QUALI- FIERS	TEST
Tritium	10028-17-8	601000	1800	160	400		H
Carbon 14	14762-75-5	18.2	20	33	200	U	C
Nickel 63	13981-37-8	0.588	2.0	3.3	15	U	NI_L
Protactinium 231	14331-85-2	0.017	0.067	0.13	1.0	U	PA
Iodine 129	15046-84-1	6.23	1.0	2.2	5.0		I
Selenium 79	15758-45-9	1.20	26	44	50	U	SE_L

216-A-2 & 216-A-1 - Groundwater

DATA SHEETS

Page 1

SUMMARY DATA SECTION

Page 16

Lab id <u>EBRLNE</u>
Protocol <u>Hanford</u>
Version <u>Ver 1.0</u>
Form <u>DVD-DS</u>
Version <u>3.06</u>
Report date <u>11/21/07</u>

00000018

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

Test PA Matrix WATER
 SDG 7692
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

PA-231 IN WATER
 ALPHA SPECTROSCOPY

Client Hanford
 Contract No. 630
 Contract SDG H3579

RESULTS

AB	RAW	SUF-	Protactinium	
SAMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	231
Preparation batch 6121-102				
.709125-01		7692-001	B1PLH0	U
.709125-02		7692-002	LCS (QC ID=63142)	ok
.709125-03		7692-003	BLK (QC ID=63143)	U
.709125-04		7692-004	Duplicate (R709125-01)	- U

nominal values and limits from method RDLs (pCi/L) 1.0
 16-A-2 & 216-A-1 - Groundwater

METHOD PERFORMANCE

AB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-		
SAMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/L	L	PAC	TION	%	%	min	keV	KeV	HELD	PREPARED	YZED	DETECTOR
Preparation batch 6121-102			2σ prep error 5.0 %		Reference Lab Notebook #6121, pg. 102										
.709125-01		B1PLH0	0.13	0.150			52		939			64	11/06/07	11/09	SS-055
.709125-02		LCS (QC ID=63142)	0.20	0.150			35		939				11/06/07	11/09	SS-056
.709125-03		BLK (QC ID=63143)	0.13	0.150			64		939				11/06/07	11/09	SS-057
.709125-04		Duplicate (R709125-01) (QC ID=63144)	0.15	0.150			46		940			64	11/06/07	11/09	SS-058

nominal values and limits from method 1.0 0.150 20-105 200 180

PROCEDURES	REFERENCE	PA231_IE_PLATE_AEA
CP-062	Sample Aliquoting, rev 2	
CP-910	Protactinium-231 in Soil, (0 to 0.25 g) Aliquot, rev 2	
CP-008	Heavy Element Electroplating, rev 9	

AVERAGES ± 2 SD	MDA	0.15 ± 0.066
FOR 4 SAMPLES	YIELD	49 ± 24

METHOD SUMMARIES

Page 1

SUMMARY DATA SECTION

Page 17

Lab id EBRLNE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 11/21/07

00000019

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

Test I Matrix WATER
 SDG 7692
 Contact Melissa C. Mannion

LAB METHOD SUMMARY

IODINE 129 IN WATER
 GAMMA SPECTROSCOPY

Client Hanford
 Contract No. 630
 Contract SDG H3579

RESULTS

AB RAW SUP-
 AMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Iodine 129

reparation batch 6121-102

709125-01	7692-001	B1PLH0	6.23
709125-02	7692-002	LCS (QC ID=63142)	ok
709125-03	7692-003	BLK (QC ID=63143)	U
709125-04	7692-004	Duplicate (R709125-01)	ok

nominal values and limits from method RDLs (pCi/L) 5.0
 16-A-2 & 216-A-1 - Groundwater

METHOD PERFORMANCE

AB RAW SUP- MDA ALIQ PREP DILU- YIELD EFF COUNT FWHM DRIFT DAYS ANAL-
 AMPLE ID TEST FIX CLIENT SAMPLE ID pCi/L L FAC TION % % min keV KeV HELD PREPARED YZED DETECTOR

reparation batch 6121-102 2σ prep error 5.0 % Reference Lab Notebook #6121, pg. 102

709125-01	B1PLH0	2.2	0.500	79	780	54	10/25/07	10/30	XSPEC-002
709125-02	LCS (QC ID=63142)	4.2	0.500	66	606		10/25/07	10/31	XSPEC-004
709125-03	BLK (QC ID=63143)	2.5	0.500	83	606		10/25/07	10/31	XSPEC-002
709125-04	Duplicate (R709125-01) (QC ID=63144)	2.4	0.500	71	791	55	10/25/07	10/31	XSPEC-004

nominal values and limits from method 5.0 0.500 20-105 300 100 180

PROCEDURES REFERENCE I129_SEP_LEPS_GS
 SPP-062 Sample Aliquoting, rev 0
 CP-531 Iodine-129, 131 in Water, Large Aliquots, rev 1

AVERAGES ± 2 SD MDA 2.8 ± 1.9
 FOR 4 SAMPLES YIELD 75 ± 15

Lab id EBRLNE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-LMS
 Version 3.06
 Report date 11/21/07

00000020

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

Test C Matrix WATER
SDG 7692
Contact Melissa C. Mannion

LAB METHOD SUMMARY

CARBON 14 IN WATER

LIQUID SCINTILLATION COUNTING

Client Hanford
Contract No. 630
Contract SDG H3579

RESULTS

AB	RAW	SUF-	AMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	Carbon 14
reparation batch 6121-102							
			709125-01	A1	7692-001	B1PLH0	U
			709125-07		7692-007	LCS (QC ID=63448)	ok
			709125-08		7692-008	BLK (QC ID=63449)	U
			709125-09		7692-009	Duplicate (R709125-01)	- U
			709125-10		7692-010	Spike (R709125-01)	ok X

nominal values and limits from method RDLs (pCi/L) 200
16-A-2 & 216-A-1 - Groundwater

METHOD PERFORMANCE

AB	RAW	SUF-	AMPLE ID	TEST FIX	CLIENT SAMPLE ID	MDA pCi/L	ALIQ L	PREP FAC	DILU TION	YIELD %	EFF %	COUNT min	FWHM keV	DRIFT KeV	DAYS HELD	ANAL- PREPARED	YZED	DETECTOR
reparation batch 6121-102 2σ prep error 10.0 % Reference Lab Notebook #6121, pg. 102																		
			709125-01	A1	B1PLH0	33	0.0300			100	150	62	11/07/07	11/07	LSC-006			
			709125-07		LCS (QC ID=63448)	39	0.0300			100	116	62	11/07/07	11/07	LSC-006			
			709125-08		BLK (QC ID=63449)	34	0.0300			100	150	62	11/07/07	11/07	LSC-006			
			709125-09		Duplicate (R709125-01)	33	0.0300			100	150	62	11/07/07	11/07	LSC-006			
			709125-10		Spike (R709125-01)	81	0.0200			100	54	62	11/07/07	11/07	LSC-006			
					(QC ID=63450)													
					(QC ID=63451)													

nominal values and limits from method 200 0.0300 50 180

PROCEDURES REFERENCE C14_CHEM_LSC
CP-241 Carbon-14 in Aqueous Samples, rev 6

AVERAGES ± 2 SD MDA 44 ± 42
FOR 5 SAMPLES YIELD 100 ± 0

METHOD SUMMARIES

Page 3

SUMMARY DATA SECTION

Page 19

Lab id EBRLINE
Protocol Hanford
Version Ver 1.0
Form DVD-LMS
Version 3.06
Report date 11/21/07

00000021

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP H3579

LAB METHOD SUMMARY

TRITIUM IN WATER

LIQUID SCINTILLATION COUNTING

Test H Matrix WATER

SDG 7692

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Contract SDG H3579

RESULTS

LAB	RAW	SUF-		
AMPLE ID	TEST FIX	PLANCHET	CLIENT SAMPLE ID	Tritium
reparation batch 6121-102				
709125-01			B1PLHO	601000
709125-02			LCS (QC ID=63142)	ok
709125-03			BLK (QC ID=63143)	U
709125-04			Duplicate (R709125-01)	ok
709125-05			Spike (R709125-01)	ok X

ominal values and limits from method RDLs (pCi/L) 400
16-A-2 & 216-A-1 - Groundwater

METHOD PERFORMANCE

LAB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	PWHM	DRIFT	DAYS	ANAL-		
AMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/L	L	FAC	TION	%	%	min	keV	KeV	HELD	PREPARED	YZED	DETECTOR
reparation batch 6121-102 2σ prep error 10.0 % Reference Lab Notebook #6121, pg. 102															
709125-01		B1PLHO	160	0.0100			100	150				45	10/19/07	10/21	LSC-004
709125-02		LCS (QC ID=63142)	1600	0.0100			10	150					10/19/07	10/21	LSC-004
709125-03		BLK (QC ID=63143)	1700	0.0100			10	150					10/19/07	10/21	LSC-004
709125-04		Duplicate (R709125-01) (QC ID=63144)	160	0.0100			100	150				45	10/19/07	10/21	LSC-004
709125-05		Spike (R709125-01) (QC ID=63145)	160	0.0300			33	150				44	10/19/07	10/20	LSC-004

ominal values and limits from method 400 0.0100 25 180

PROCEDURES REFERENCE 906.0_H3_LSC
CP-210 Tritium in Water Samples by Distillation, rev 8

AVERAGES ± 2 SD MDA 760 ± 1600
FOR 5 SAMPLES YIELD 51 ± 92

METHOD SUMMARIES

Page 4

SUMMARY DATA SECTION

Page 20

Lab id EBRLINE
Protocol Hanford
Version Ver 1.0
Form DVD-LMS
Version 3.06
Report date 11/21/07

00000022

EBERLINE SERVICES/RICHMOND

SAMPLE DELIVERY GROUP 'H3579

Test NI L Matrix WATER
 SDG 7692
 Contact Melissa C. Mannion

Client Hanford
 Contract No. 630
 Contract SDG H3579

LAB METHOD SUMMARY

NICKEL-63 IN LIQUID

LIQUID SCINTILLATION COUNTING

RESULTS

AB RAW SUF-
 AMPLE ID TEST FIX PLANCHET CLIENT SAMPLE ID Nickel 63

reparation batch 6121-102

709125-01	7692-001	B1PLH0	U
709125-02	7692-002	LCS (QC ID=63142)	ok
709125-03	7692-003	BLK (QC ID=63143)	U
709125-04	7692-004	Duplicate (R709125-01)	- U

ominal values and limits from method RDLs (pCi/L) 15
 16-A-2 & 216-A-1 - Groundwater

METHOD PERFORMANCE

AB	RAW	SUF-	MDA	ALIQ	PREP	DILU-	YIELD	EFF	COUNT	FWHM	DRIFT	DAYS	ANAL-		
AMPLE ID	TEST FIX	CLIENT SAMPLE ID	pCi/L	L	FAC	TION	%	%	min	keV	KeV	HRLD	PREPARED	YZED	DETECTOR

reparation batch 6121-102 2σ prep error 10.0 % Reference Lab Notebook #6121, pg. 102

709125-01	B1PLH0	3.3	0.500	91	50	48	10/23/07	10/24	LSC-004
709125-02	LCS (QC ID=63142)	3.1	0.500	96	50	10/23/07	10/24	LSC-004	
709125-03	BLK (QC ID=63143)	3.2	0.500	94	50	10/23/07	10/24	LSC-004	
709125-04	Duplicate (R709125-01) (QC ID=63144)	3.4	0.500	89	50	48	10/23/07	10/24	LSC-004

ominal values and limits from method 15 0.500 50 180

PROCEDURES	REFERENCE	NI63_LSC
	SPP-040	Environmetnal Water Dissolution, rev 0
	CP-280	Nickel-63 Purification, rev 3

AVERAGES ± 2 SD	MDA	<u>3.2</u> ± <u>0.26</u>
FOR 4 SAMPLES	YIELD	<u>92</u> ± <u>6</u>

Lab id	<u>EBRLNE</u>
Protocol	<u>Hanford</u>
Version	<u>Ver 1.0</u>
Form	<u>DVD-LMS</u>
Version	<u>3.06</u>
Report date	<u>11/21/07</u>

00000023

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H3579

SAMPLE SUMMARY

The Sample and QC Summary Reports show all samples, including QC samples, reported in one Sample Delivery Group (SDG).

The Sample Summary Report fully identifies client samples and gives the corresponding lab sample identification. The QC Summary Report shows at the sample level how the lab organized the samples into batches and generated QC samples. The Preparation Batch and Method Summary Reports show this at the analysis level.

The following notes apply to these reports:

- * LAB SAMPLE ID is the lab's primary identification for a sample.
- * DEPARTMENT SAMPLE ID is an alternate lab id, for example one assigned by a radiochemistry department in a lab.
- * CLIENT SAMPLE ID is the client's primary identification for a sample. It includes any sample preparation done by the client that is necessary to identify the sample.
- * QC BATCH is a lab assigned code that groups samples to be processed and QCed together. These samples should have similar matrices.

QC BATCH is not necessarily the same as SDG, which reflects samples received and reported together.

- * All Lab Control Samples, Method Blanks, Duplicates and Matrix Spikes are shown that QC any of the samples. Due to possible reanalyses, not all results for all these QC samples may be relevant to the SDG. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.

REPORT GUIDES

Page 1

SUMMARY DATA SECTION

Page 23

Lab id EBRLNE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 11/21/07

00000025

EBERLINE SERVICES / RICHMOND
SAMPLE DELIVERY GROUP H3579

SDG 7692
Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
Contract No. 630
Case no SDG H3579

PREPARATION BATCH SUMMARY

The Preparation Batch Summary Report shows all preparation batches in one Sample Delivery Group (SDG) with information necessary to check the completeness and consistency of the SDG.

The following notes apply to this report:

- * The preparation batches are shown in the same order as the Method Summary Reports are printed.
- * Only analyses of planchets relevant to the SDG are included.
- * Each preparation batch should have at least one Method Blank and LCS in it to validate client sample results.
- * The QUALIFIERS shown are all qualifiers other than U, J, B, L and H that occur on any analysis in the preparation batch. The Method Summary Report has these qualifiers on a per sample basis.

These qualifiers should be reviewed as follows:

- X Some data has been manually entered or modified. Transcription errors are possible.
- P One or more results are 'preliminary'. The data is not ready for final reporting.
- 2 There were two or more results for one analyte on one planchet imported at one time. The results in DVD may not be the same as on the raw data sheets.

Other lab defined qualifiers may occur. In general, these should be addressed in the SDG narrative.

REPORT GUIDES

Page 2

SUMMARY DATA SECTION

Page 24

Lab id EBRLINE
Protocol Hanford
Version Ver 1.0
Form DVD-RG
Version 3.06
Report date 11/21/07

00000026

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 630

Case no SDG H3579

WORK SUMMARY

The Work Summary Report shows all samples, including QC samples, and all relevant analyses in one Sample Delivery Group (SDG). This report is often useful as supporting documentation for an invoice.

The following notes apply to this report:

- * TEST is a code for the method used to measure associated analytes. Results and related information for each analyte are on the Data Sheet Report. In special cases, a test code used in the summary data section is not the same as in associated raw data. In this case, both codes are shown on the Work Summary.
- * SUFFIX is the lab's code to distinguish multiple analyses (recounts, reworks, reanalyses) of a fraction of the sample. The suffix indicates which result is being reported. An empty suffix normally identifies the first attempt to analyze the sample.
- * The LAB SAMPLE ID, TEST and SUFFIX uniquely identify all supporting data for a result. The Method Summary Report for each TEST has method performance data, such as yield, for each lab sample id and suffix and procedures used in the method.
- * PLANCHET is an alternate lab identifier for work done for one test. It, combined with the TEST and SUFFIX, may be the best link to raw data.
- * For QC samples, only analyses that directly QC some regular sample are shown. The Lab Control Sample, Method Blank, Duplicate, Matrix Spike and Method Summary Reports detail these relationships.
- * The SAS (Special Analytical Services) Number is a client or lab assigned code that reflects special processing for samples, such as rapid turn around. Counts of tests done are lists by SAS number since it is likely to affect prices.

REPORT GUIDES

Page 3

SUMMARY DATA SECTION

Page 25

Lab id EBRLINE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000027

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 630

Case no SDG H3579

DATA SHEET

The Data Sheet Report shows all results and primary supporting information for one client sample or Method Blank. This report corresponds to both the CLP Inorganics and Organics Data Sheet.

The following notes apply to this report:

- * TEST is a code for the method used to measure an analyte. If the TEST is empty, no data is available; the analyte was not analyzed for.
- * The LAB SAMPLE ID and TEST uniquely identify work within the Summary Data Section of a Data Package. The Work Summary and Method Summary Reports further identify raw data that underlies this work.

The Method Summary Report for each TEST has method performance data, such as yield, for each Lab Sample ID and a list of procedures used in the method.

- * ERRORS can be labeled TOTAL or COUNT. TOTAL implies a preparation (non-counting method) error has been added, as square root of sum of squares, to the counting error denoted by COUNT. The preparation errors, which may vary by preparation batch, are shown on the Method Summary Report.
- * A RESULT can be 'N.R.' (Not Reported). This means the lab did this work but chooses not to report it now, possibly because it was reported at another time.
- * When reporting a Method Blank, a RESULT can be 'N.A.' (Not Applicable). This means there is no reported client sample work in the same preparation batch as the Blank's result. This is likely to occur when the Method Blank is associated with reanalyses of selected work for a few samples in the SDG.

The following qualifiers are defined by the DVD system:

U The RESULT is less than the MDA (Minimum Detectable Activity).

REPORT GUIDES

Page 4

SUMMARY DATA SECTION

Page 26

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000028

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

GUIDE , cont .

Client Hanford

Contract No. 630

Case no SDG H3579

DATA SHEET

If the MDA is blank, the ERROR is used as the limit.

- J The RESULT is less than the RDL (Required Detection Limit) and no U qualifier is assigned.
 - B A Method Blank associated with this sample had a result without a U flag and, after correcting for possibly different aliquots, that result is greater than or equal to the MDA for this sample.
- Normally, B is not assigned if U is. When method blank subtraction is shown on this report, B flags are assigned based on the unsubtracted values while U's are assigned based on the subtracted ones. Both flags can be assigned in this case.
- For each sample result, all Method Blank results in the same preparation batch are compared. The Method Summary Report documents this and other QC relationships.
- L Some Lab Control Sample that QC's this sample had a low recovery. The lab can disable assignment of this qualifier.
 - H Similar to 'L' except the recovery was high.
 - P The RESULT is 'preliminary'.
 - X Some data necessary to compute the RESULT, ERROR or MDA was manually entered or modified.
 - 2 There were two or more results available for this analyte. The reported result may not be the same as in the raw data.

Other qualifiers are lab defined. Definitions should be in the SDG narrative.

The following values are underlined to indicate possible problems:

- * An MDA is underlined if it is bigger than its RDL.

REPORT GUIDES

Page 5

SUMMARY DATA SECTION

Page 27

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000029

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

Client Hanford

Contract No. 630

Case no SDG H3579

GUIDE, cont.

DATA SHEET

- * An ERROR is underlined if the 1.645 sigma counting error is bigger than both the MDA and the RESULT, implying that the MDA may not be a good estimate of the 'real' minimum detectable activity.
- * A negative RESULT is underlined if it is less than the negative of its 2 sigma counting ERROR.
- * When reporting a Method Blank, a RESULT is underlined if greater than its MDA. If the MDA is blank, the 2 sigma counting error is used in the comparison.

REPORT GUIDES

Page 6

SUMMARY DATA SECTION

Page 28

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000030

RLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford
 Contract No. 630
 Case no SDG H3579

LAB CONTROL SAMPLE

The Lab Control Sample Report shows all results, recoveries and primary supporting information for one Lab Control Sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. Refer to its Report Guide for details.
- * An amount ADDED is the lab's value for the actual amount spiked into this sample with its ERROR an estimate of the error of this amount.

An amount added is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is RESULT divided by ADDED expressed as a percent.
- * The first, computed limits for the recovery reflect:
 1. The error of RESULT, including that introduced by rounding the result prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.
 2. The error of ADDED.
 3. A lab specified, per analyte bias. The bias changes the center of the computed limits.
- * The second limits are protocol defined upper and lower QC limits for the recovery.
- * The recovery is underlined if it is outside either of these ranges.

Lab id EBRLNE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 11/21/07

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 630

Case no SDG H3579

DUPLICATE

The Duplicate Report shows all results, differences and primary supporting information for one Duplicate and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Duplicate and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Duplicate has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * The RPD (Relative Percent Difference) is the absolute value of the difference of the RESULTS divided by their average expressed as a percent.

If both RESULTS are less than their MDAs, no RPD is computed and a '-' is printed.

For an analyte, if the lab did work for both samples but has data for only one, the MDA from the sample with data is used as the other's result in the RPD.

- * The first, computed limit is the sum, as square root of sum of squares, of the errors of the results divided by the average result as a percent, hence the relative error of the difference rather than the error of the relative difference. The errors include those introduced by rounding the RESULTS prior to printing.

If this limit is labeled TOT, it includes the preparation error in the RESULTS. If labeled CNT, it does not.

This value reported for this limit is at most 999.

- * The second limit for the RPD is the larger of:

1. A fixed percentage specified in the protocol.

REPORT GUIDES

Page 8

SUMMARY DATA SECTION

Page 30

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000032

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

GUIDE , cont .

Client Hanford

Contract No. 630

Case no SDG H3579

DUPLICATE

2. A protocol factor (typically 2) times the average MDA as a percent of the average result. This limit applies when the results are close to the MDAs.

- * The RPD is underlined if it is greater than either limit.
- * If specified by the lab, the second limit column is replaced by the Difference Error Ratio (DER), which is the absolute value of the difference of the results divided by the quadratic sum of their one sigma errors, the same errors as used in the first limit.

Except for differences due to rounding, the DER is the same as the RPD divided by the first RPD limit with the limit scaled to 1 sigma.

- * The DER is underlined if it is greater than the sigma factor, typically 2 or 3, shown in the header for the first RPD limit.

REPORT GUIDES

Page 9

SUMMARY DATA SECTION

Page 31

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000033

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 630

Case no SDG H3579

MATRIX SPIKE

The Matrix Spike Report shows all results, recoveries and primary supporting information for one Matrix Spike and associated Original sample.

The following notes apply to this report:

- * All fields in common with the Data Sheet Report have similar usage. This applies both to the Spiked and Original sample data. Refer to the Data Sheet Report Guide for details.

If the Spike has data for a TEST and the lab did not do this test to the Original, the Original's RESULTS are underlined.

- * An amount ADDED is the lab's value for the actual amount spiked into the Spike sample with its ERROR an estimate of the error of this amount.

An amount is underlined if its ratio to the corresponding RDL is outside protocol specified limits.

- * REC (Recovery) is the Spike RESULT minus the Original RESULT divided by ADDED expressed as a percent.

- * The first, computed limits for the recovery reflect:

1. The errors of the two RESULTS, including those introduced by rounding them prior to printing.

If the limits are labeled (TOTAL), they include preparation error in the result. If labeled (COUNT), they do not.

2. The error of ADDED.

3. A lab specified, per analyte bias. The bias changes the center of the computed limits.

- * The second limits are protocol defined upper and lower QC limits

REPORT GUIDES

Page 10

SUMMARY DATA SECTION

Page 32

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000034

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford

Contract No. 630

Case no SDG H3579

MATRIX SPIKE

for the recovery.

These limits are left blank if the Original RESULT is more than a protocol defined factor (typically 4) times ADDED. This is a way of accounting for that when the spike is small compared to the amount in the original sample, the recovery is unreliable.

- * The recovery is underlined (out of spec) if it is outside either of these ranges.

REPORT GUIDES

Page 11

SUMMARY DATA SECTION

Page 33

Lab id EBRINE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000035

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692

Contact Melissa C. Mannion

REPORT GUIDE

Client Hanford

Contract No. 630

Case no SDG H3579

METHOD SUMMARY

The Method Summary Report has two tables. One shows up to five results measured using one method. The other has performance data for the method. There is one report for each TEST, as used on the Data Sheet Report.

The following notes apply to this report:

- * Each table is subdivided into sections, one for each preparation batch. A preparation batch is a group of aliquots prepared at roughly the same time in one work area of the lab using the same method.

There should be Lab Control Sample and Method Blank results in each preparation batch since this close correspondence makes the QC meaningful. Depending on lab policy, Duplicates need not occur in each batch since they QC sample dependencies such as matrix effects.

- * The RAW TEST column shows the test code used in the raw data to identify a particular analysis if it is different than the test code in the header of the report. This occurs in special cases due to method specific details about how the lab labels work.

The Lab Sample or Planchet ID combined with the (Raw) Test Code and Suffix uniquely identify the raw data for each analysis.

- * If a result is less than both its MDA and RDL, it is replaced by just 'U' on this report. If it is greater than or equal to the RDL but less than the MDA, the result is shown with a 'U' flag.

The J and X flags are as on the data sheet.

- * Non-U results for Method Blanks are underlined to indicate possible contamination of other samples in the preparation batch. The Method Blank Report has supporting data.
- * Lab Control Sample and Matrix Spike results are shown as: ok, No data, LOW or HIGH, with the last two underlined. 'No data'

REPORT GUIDES

Page 12

SUMMARY DATA SECTION

Page 34

Lab id EBRLNE

Protocol Hanford

Version Ver 1.0

Form DVD-RG

Version 3.06

Report date 11/21/07

00000036

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
 Contract No. 630
 Case no SDG H3579

METHOD SUMMARY

means no amount ADDED was specified. 'LOW' and 'HIGH' correspond to when the recovery is underlined on the Lab Control Sample or Matrix Spike Report. See these reports for supporting data.

- * Duplicate sample results are shown as: ok, No data, or OUT, with the last two underlined. 'No data' means there was no original sample data found for this duplicate. 'OUT' corresponds to when the RPD is underlined on the Duplicate Report. See this report for supporting data.
- * If the MDA column is labeled 'MAX MDA', there was more than one result measured by the reported method and the MDA shown is the largest MDA. If not all these results have the same RDL, the MAX MDA reflects only those results with RDL equal to the smallest one.

MDAs are underlined if greater than the printed RDL.

- * Aliquots are underlined if less than the nominal value specified for the method.
- * Preparation factors are underlined if greater than the nominal value specified for the method.
- * Dilution factors are underlined if greater than the nominal value specified for the method.
- * Residues are underlined if outside the range specified for the method. Residues are not printed if yields are.
- * Yields, which may be gravimetric, radiometric or some type of recovery depending on the method, are underlined if outside the range specified for the method.
- * Efficiencies are underlined if outside the range specified for the method. Efficiencies are detector and geometry dependent so this test is only approximate.

Lab id EBRINE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 11/21/07

00000037

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
 Contract No. 630
 Case no SDG H3579

METHOD SUMMARY

- * Count times are underlined if less than the nominal value specified for the method.
- * Resolutions (as FWHM; Full Width at Half Max) are underlined if greater than the method specified limit.
- * Tracer drifts are underlined if their absolute values are greater than the method specified limit. Tracer drifts are not printed if percent moistures are.
- * Days Held are underlined if greater than the holding time specified in the protocol.
- * Analysis dates are underlined if before their planchet's preparation date or, if a limit is specified, too far after it.

For some methods, ratios as percentages and error estimates for them are computed for pairs of results. A ratio column header like '1+3' means the ratio of the first result column and the third result column.

Ratios are not computed for Lab Control Sample, Method Blank or Matrix Spike results since their matrices are not necessarily similar to client samples'.

The error estimate for a ratio of results from one planchet reflects only counting errors since other errors should be correlated. For a ratio involving different planchets, if QC limits are computed based on total errors, the error for the ratio allows for the preparation errors for the planchets.

The ratio is underlined (out of spec) if the absolute value of its difference from the nominal value is greater than its error estimate. If no nominal value is specified, this test is not done.

For Gross Alpha or Gross Beta results, there may be a column showing the sum of other Alpha or Beta emitters. This sum includes all relevant

REPORT GUIDES

Page 14

SUMMARY DATA SECTION

Page 36

Lab id EBRINE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 11/21/07

00000038

EBERLINE SERVICES / RICHMOND

SAMPLE DELIVERY GROUP H3579

SDG 7692
 Contact Melissa C. Mannion

GUIDE, cont.

Client Hanford
 Contract No. 630
 Case no SDG H3579

METHOD SUMMARY

results in the DVD database, whether reported or not. Results in the sum are weighted by a particles/decay value specified by the lab for each relevant analyte. Results less than their MDA are not included. No sums are computed for Lab Control, Method Blank or Matrix Spike samples since their various planchets may not be physically related.

If a ratio of total isotopic to Gross Alpha or Beta is shown, the error for the ratio reflects both the error in the Gross result and the sum, as square root of sum of squares, of the errors in the isotopic results.

For total elemental uranium or thorium results, there may be a column showing the total weight computed from associated isotopic results. Ignoring results less than their MDAs, this is a weighted sum of the isotopic results. The weights depend on the molecular weight and half-life of each isotope so as to convert activities (decays) to weight (atoms).

If a ratio of total computed to measured elemental uranium or thorium is shown, the error for the ratio reflects the errors in all the measurements.

Lab id EBRINE
 Protocol Hanford
 Version Ver 1.0
 Form DVD-RG
 Version 3.06
 Report date 11/21/07

00000039



RICHMOND, CA LABORATORY
SAMPLE RECEIPT CHECKLIST

Handwritten: 9/20/07

Client: F. HANFORD City RICHMOND State WA
Date/Time received 09/20/07 09:30 CoC No. F07-058-012
Container I.D. No. GRP-03-024 Requested TAT (Days) 50 45 P.O. Received Yes [] No []

INSPECTION

- 1. Custody seals on shipping container intact? Yes No [] N/A []
- 2. Custody seals on shipping container dated & signed? Yes No [] N/A []
- 3. Custody seals on sample containers intact? Yes No [] N/A []
- 4. Custody seals on sample containers dated & signed? Yes No [] N/A []
- 5. Packing material is: Wet [] Dry
- 6. Number of samples in shipping container: 1 Sample Matrix W
- 7. Number of containers per sample: 9 (Or see CoC _____)
- 8. Samples are in correct container Yes No []
- 9. Paperwork agrees with samples? Yes No []
- 10. Samples have: Tape [] Hazard labels [] Rad labels [] Appropriate sample labels
- 11. Samples are: In good condition Leaking [] Broken Container [] Missing []
- 12. Samples are: Preserved Not preserved pH 1/7 Preservative #N03
- 13. Describe any anomalies:

14. Was P.M. notified of any anomalies? Yes [] No [] Date _____
15. Inspected by M. King Date: 09/20/07 Time: 12:45

Customer Sample No.	cpm	mR/hr	Wipe	Customer Sample No.	cpm	mR/hr	wipe

Ion Chamber Ser. No. _____ Calibration date _____
Alpha Meter Ser. No. _____ Calibration date _____
Beta/Gamma Meter Ser. No. _____ Calibration date _____

COLLECTOR POPE	COMPANY CONTACT TRENT, SJ	TELEPHONE NO. 373-5869	PROJECT COORDINATOR TRENT, SJ	PRICE CODE 7N	DATA TURNAROUND 45 Days / 45 Days
SAMPLING LOCATION C5515, I-Water 2221	PROJECT DESIGNATION 216-A-2 and 216-A-21 Characterization Sampling and Analysis - Groundwat		SAF NO. F07-058	AIR QUALITY <input type="checkbox"/>	
ICE CHEST NO. GRP-03-026	FIELD LOGBOOK NO.	COA 122585ES10	METHOD OF SHIPMENT FEDERAL EXPRESS		
SHIPPED TO Eberline Services	OFFSITE PROPERTY NO. See PTR 20297	BILL OF LADING/AIR BILL NO. See PTR 20297			

MATRIX*	POSSIBLE SAMPLE HAZARDS/ REMARKS Contains Radioactive Material at concentrations that are not regulated for transportation per 49 CFR but are not releasable per DOE Order 5400.5 (1990/1993) Radiological tie to B1PLF8	PRESERVATION						NO. OF CONTAINER(S)	VOLUME	SAMPLE ANALYSIS
		None	HNO3 to pH <2	None	HNO3 to pH <2	HNO3 to pH <2	None			
A=Air DL=Drum Liquids DS=Drum Solids L=Liquid O=Oil S=Soil SE=Sediment T=Tissue V=Vegetation W=Water WI=Wipe X=Other		G/P	G/P	G/P	G/P	G/P	G	1	125mL	Carbon-14; Nickel-63; Iodine-129; Selenium-79; Isotopic Protactinium (Protactinium-231); TRITIUM - MIDLEVEL;
	SPECIAL HANDLING AND/OR STORAGE Radio BIPLF8									

SAMPLE NO.	MATRIX*	SAMPLE DATE	SAMPLE TIME						
B1PLH0	WATER	9-6-07	0825	X	X	X	X	X	X

CHAIN OF POSSESSION	SIGN/ PRINT NAMES	SPECIAL INSTRUCTIONS
RELINQUISHED BY/REMOVED FROM J. POPE / ASH 9-6-07	RECEIVED BY/STORED IN MO 745 FRIDGE D 9-6-07 / 1500	
RELINQUISHED BY/REMOVED FROM MO 745 KHP SER 19 2007 0830	RECEIVED BY/STORED IN M.A. Baechler / M/G Ductile 9-6-07 0830	
RELINQUISHED BY/REMOVED FROM M.A. Baechler / M/G Ductile 9-6-07 0830	RECEIVED BY/STORED IN Fed Ex	
RELINQUISHED BY/REMOVED FROM Fed Ex	RECEIVED BY/STORED IN MFM 09/20/07 09:30	
RELINQUISHED BY/REMOVED FROM	RECEIVED BY/STORED IN	
RELINQUISHED BY/REMOVED FROM	RECEIVED BY/STORED IN	

LABORATORY SECTION	RECEIVED BY	TITLE	DATE/TIME
FINAL SAMPLE DISPOSITION	DISPOSAL METHOD	DISPOSED BY	DATE/TIME

00000041