




a division of Recra Environmental, Inc.

Virtual Laboratories Everywhere


0049218



Recra LabNet Philadelphia Analytical Report

Client : TNU-HANFORD
RFW# : 9801L314

W.O.# : 10985-001-001-9999-00
Date Received: 01-29-98



METALS CASE NARRATIVE

1. This narrative covers the analyses of 1 water sample.
2. The sample was prepared and analyzed in accordance with methods checked on the attached glossary.
3. All analyses were performed within the required holding times.
4. The cooler temperature has been recorded on the Chain of Custody.
5. All Initial and Continuing Calibration Verifications (ICV/CCVs) were within control limits.
6. All Initial and Continuing Calibration Blanks (ICB/CCBs) were within control limits.
7. All preparation method blanks were within method criteria. Refer to the Inorganics Method Blank Data Summary.
8. All ICP Interference Check Standards were within control limits.
9. All laboratory control samples (LCS) were within the 85-115% control limits. Refer to the Inorganics Laboratory Control Standards Report.
10. Both matrix spike (MS) recoveries were within the 70-130% control limits. Refer to the Inorganics Accuracy Report. A post-digestion MS (PDS) for Iron has been included for reference purposes.

The results presented in this report relate only to the analytical testing and conditions of the samples at receipt and during storage. All pages of this report are integral parts of the analytical data. Therefore, this report should only be reproduced in its entirety of 11 pages.

001

11. A PDS was prepared at meaningful concentration levels, due to high concentrations of the following analyte:

<u>Sample ID</u>	<u>Element</u>	<u>PDS</u> <u>Concentration (ppb)</u>	<u>PDS</u> <u>% Recovery</u>
BOMR91	Iron	1,000	111.5

12. The duplicate analysis for 1 analyte was outside the 20% Relative Percent Difference (RPD) control limits. Refer to the Inorganics Precision Report.
13. For the purposes of this report, the data has been reported to the Instrument Detection Limit (IDL). Values between the IDL and the Practical Quantitation Limit (PQL) are acquired in a region of less-certain quantification.

fn Bruce C. Taylor
J. Michael Taylor

Vice President and Laboratory Manager
Lionville Analytical Laboratory

skl m01-314

3.3.98
Date

002



METALS METHODS GLOSSARY

The following methods are used as reference for the digestion and analysis of samples contained within this

RFW Lot#: 9801L314

Leaching Procedure: 1310 1311 1312 Other: _____

CLP Metals Digestion and Analysis Methods: ILM03.0 ILM04.0

Metals Digestion Methods: 3005A 3010A 3015 3020A 3050A 3051 200.7 SS17
Other: _____

Metals Analysis Methods

	SW846	EPA	STD MTD	EPA OSWR	USATHAMA
Aluminum	6010A	200.7			99
Antimony	6010A 7041 ⁵	200.7 204.2			99
Arsenic	6010A 7060A ⁵	200.7 206.2	3113B		99
Barium	6010A	200.7			99
Beryllium	6010A	200.7			99
Bismuth	6010A ¹	200.7 ¹		1620	99
Boron	6010A ¹	200.7			99
Cadmium	6010A 7131A ⁵	200.7 213.2			99
Calcium	6010A	200.7			99
Chromium	6010A 7191 ⁵	200.7 218.2			SS17
Cobalt	6010A	200.7			99
Copper	6010A 7211 ⁵	200.7 220.2			99
Iron	6010A	200.7			99
Lead	6010A 7421 ⁵	200.7 239.2	3113B		99
Lithium	6010A 7430 ⁴	200.7		1620	99
Magnesium	6010A	200.7			99
Manganese	6010A	200.7			99
Mercury	7470A ³ 7471A ³	245.1 ² 245.5 ²			99
Molybdenum	6010A	200.7			99
Nickel	6010A	200.7			99
Potassium	6010A 7610 ⁴	200.7 258.1 ⁴			99
Rare Earths	6010A ¹	200.7 ¹		1620	99
Selenium	6010A 7740 ⁵	200.7 270.2	3113B		99
Silicon	6010A ¹	200.7		1620	99
Silica	6010A ¹	200.7		1620	99
Silver	6010A 7761 ⁵	200.7 272.2			99
Sodium	6010A 7770 ⁴	200.7 273.1 ⁴			99
Strontium	6010A	200.7			99
Thallium	6010A 7841 ⁵	200.7 279.2 200.9			99
Tin	6010A ¹	200.7			99
Titanium	6010A ¹	200.7			99
Uranium	6010A ¹	200.7 ¹		1620	99
Vanadium	6010A	200.7			99
Zinc	6010A	200.7			99
Zirconium	6010A ¹	200.7 ¹		1620	99

Other: _____

Method: _____

METHOD REFERENCES AND DATA QUALIFIERS

DATA QUALIFIERS

- U = Indicates that the parameter was not detected at or above the reported limit. The associated numerical value is the sample detection limit.
- * = Indicates that the original sample result is greater than 4x the spike amount added.

ABBREVIATIONS

- MB = Method or Preparation Blank.
MS = Matrix Spike.
MSD = Matrix Spike Duplicate.
REP = Sample Replicate
LCS = Laboratory Control Sample.
NC = Not calculated.

ANALYTICAL METAL METHODS

1. Not included in the method element list.
2. Modified Hg: Hg1 and Hg2 require less total volume of digestate due to the autosampler analysis. Sample volumes and reagents for mercury determinations in water and soil have been proportionately scaled down to adapt to this semi-automated technique. The sample volume used for water analysis is 33 mL. For soils, 0.1 grams of sample is taken to a final volume of 50 mL (including all reagents).
3. Modified Hg: Hg1 and Hg2 require less total volume of digestate due to the autosampler analysis. Sample volumes and reagents for mercury determinations in water and soil have been proportionately scaled down to adapt to this semi-automated technique. The sample volume used for water analysis is 33 mL. For soils, three 0.1 gram of sample is taken to a final volume of 50 mL (including all reagents).
4. Flame AA.
5. Graphite Furnace AA.

RFW 21-21L-033/N-10/96

Recra LabNet - Lionville

INORGANICS DATA SUMMARY REPORT 02/06/98

CLIENT: TNU-MANFORD

RECRA LOT #: 9801L314

WORK ORDER: 10985-001-001-9999-00

SAMPLE	SITE ID	ANALYTE	RESULT	UNITS	REPORTING LIMIT	DILUTION FACTOR
*****	*****	*****	*****	*****	*****	*****
-001	BOMR91	Chromium, Total	3.1	u UG/L	3.1	1.0
		Iron, Total	643	UG/L	3.4	1.0

Recra LabNet - Lionville Laboratory
INORGANIC ANALYTICAL DATA PACKAGE FOR
TNU-HANFORD

DATE RECEIVED: 01/29/98

RFW LOT # :9801L314

CLIENT ID /ANALYSIS	RFW #	MTX	PREP #	COLLECTION	EXTR/PREP	ANALYSIS
---------------------	-------	-----	--------	------------	-----------	----------

BOMR91

CHROMIUM, TOTAL	001	W	98L0082	01/26/98	02/02/98	02/05/98
CHROMIUM, TOTAL	001 REP	W	98L0082	01/26/98	02/02/98	02/05/98
CHROMIUM, TOTAL	001 MS	W	98L0082	01/26/98	02/02/98	02/05/98
IRON, TOTAL	001	W	98L0082	01/26/98	02/02/98	02/05/98
IRON, TOTAL	001 REP	W	98L0082	01/26/98	02/02/98	02/05/98
IRON, TOTAL	001 MS	W	98L0082	01/26/98	02/02/98	02/05/98

LAB QC:

CHROMIUM LABORATORY	LC1 BS	W	98L0082	N/A	02/02/98	02/05/98
CHROMIUM, TOTAL	MB1	W	98L0082	N/A	02/02/98	02/05/98
IRON LABORATORY	LC1 BS	W	98L0082	N/A	02/02/98	02/05/98
IRON, TOTAL	MB1	W	98L0082	N/A	02/02/98	02/05/98

9801L314

Custody Transfer Record/Lab Work Request

**ORIGINAL
REWRITTEN**

Sample Disposition Record

Control #: B98-031
Revision#: 0
Date Initiated: 2/9/98

Section 1 - BACKGROUND

SAF#: C98-022
OU: 100-NR-2
Project ID: NR2IAM(2)
Task ID:
Sampling Event: NR2IAM(2)
Laboratory: TMA/WESTON
Project Coordinator: FORD, BH
Task Manager: STEWART, DL

Section 2 - SAMPLE INFORMATION

Number of Samples: 2
ID Numbers: B0M307, B0MR91
MATRIX: Water
Collection Date: 01/26/98

Section 3 - ISSUE

Class: Lab Direction
NCR Number: N/A
Type: Other - Incorrect Method Number
Description: Both samples requested chromium by method 218.2 and iron by method 236.2. These methods are not available at ThermoNuTech.

N/A

NCR Validation (Print/Sign)

Date

Section 4 - DISPOSITION

Type: Rework
Description: The lab is directed to analyze for both chromium and iron by method 200.7.

FORD, BH

Project Coordinator (Print/Sign)

Date

STEWART, DL

Task Manager (Print/Sign)

Date

N/A

QA (Print/Sign)

Date

Section 5 - INSPECTION (Issue Class: Nonconformance Only)

Inspection Number: N/A
Inspection Results: N/A

N/A

Inspector (Print/Sign)


Date



**RECRA
LabNet**

a division of Recra Environmental, Inc.

Virtual Laboratories Everywhere



**Recra LabNet Philadelphia
Analytical Report**

Client : TNU-HANFORD
RFW# : 9801L314
SDG# : H0132

W.O. # : 10985-001-001-9999-00
Date Received: 01-29-98

INORGANIC CASE NARRATIVE

1. This narrative covers the analyses of 1 water sample.
2. The sample was prepared and analyzed in accordance with the methods checked on the attached glossary. For NPDES samples: Ammonia distillations for method 350.3 were not performed as specified in 40 CFR part 136.
3. Sample holding times as required by the method and/or contract were met.
4. The cooler temperature was recorded on the chain-of-custody.
5. The method blanks were within method criteria.
6. The Laboratory Control Samples (LCS) for Ammonia and LCS duplicate for Oil and Grease were within the laboratory control limits (LCL), however the LCS 98LOG003-MB1 for Oil and Grease was below the LCL of 73.4-115.7%. The duplicate LCS for Ammonia was within the 20% Relative Percent Difference (RPD) control limit, however LCS duplicate for Oil and Grease was outside the control limit. The LCS for Oil and Grease lost freon volume during the heating for distillation and therefore resulted in low spike recovery.
7. The matrix spike recoveries for Ammonia were within the 75-125% control limits. The matrix spike duplicate was within the 20% RPD control limit.
8. The replicate analyses were within the 20% RPD control limit.

J. Michael Taylor
J. Michael Taylor
Vice President and Laboratory Manager
Lionville Analytical Laboratory

2-23-98
Date

njpl01-314

The results presented in this report relate only to the analytical testing and conditions of the samples at receipt and during storage. All pages of this report are integral parts of the analytical data. Therefore, this report should only be reproduced in its entirety of 11 pages.

WET CHEMISTRY METHODS GLOSSARY FOR ANALYSIS OF WATER SAMPLES

	<u>EPA 600</u>	<u>SW846</u>	<u>OTHER</u>
Acidity	__305.1		
__Alkalinity __Bicarbonate __Carbonate	__310.1		
BOD	__405.1		__5210B (b)
Ion Chromatography:			
__Bromide __Chloride __Fluoride	__300.0	__9056	
__Nitrite __Nitrate __Phosphate	__300.0	__9056	
__Sulfate __Formate __Acetate __Oxalate	__300.0	__9056	
Chloride	__325.2	__9251	
Chlorine Residual	__330.5 (mod)		
Cyanide Amenable to Chlorination	__335.2	__9010A	
Cyanide (Total)	__335.2	__9010A __9012	__ILM04.0 (e)
Cyanide, Weak Acid Dissociable			__412 (a) __4500CN-I (b)
COD	__410.4 (mod)		__5220 C (b)
Color	__110.2		
Corrosivity (by Coupon)		__1110 (mod)	
Chromium VI		__7196A	__3500Cr-D (b)
Fluoride	__340.2		
Hardness, Calcium	__215.2		
Hardness, Total	__130.2		
Iodide			__ASTM D19P202 (1)
Surfactant	__425.1		
__Nitrate-Nitrite __Nitrate __Nitrite	__353.2		
Ammonia	✓350.3		
Total __Kjeldahl Nitrogen __Organic Nitrogen	__351.4		
Total __Organic __Inorganic Carbon	__415.1	__9060	
Oil and Grease	✓413.1	__9070	
__pH __pH, Paper	__150.1	__9040A __9041A	
Petroleum Hydrocarbons, Total Recoverable	__418.1		
Phenol	__420.1 __420.2	__9065 __9066	
__Ortho Phosphate __Total Phosphate	__365.2		__4500-P B __C
Salinity			__210A (a) __2520B (b)
Settleable Solids	__160.5		
Sulfide	__376.2 __376.1	__9030A	
Reactive __Cyanide __Sulfide		__Sec 7.3	
Silica	__370.1		
Sulfite	__377.1		
Sulfate	__375.4	__9038	
Specific Conductance	__120.1	__9050	
Specific Gravity			__213E (a)
__TCLP __TCLV		__1311	
Synthetic Precipitation Leach		__1312	
Total __Dissolved __Suspended __Solids	160 __.1 __.2 __.3		
Total Organic Halides	__450.1	__9020B	
Turbidity	__180.1		
Volatile Solids __Total __Dissolved __Suspended	__160.4		
Other: _____		Method: _____	

METHOD REFERENCES AND DATA QUALIFIERS

DATA QUALIFIERS

- U = Indicates that the parameter was not detected at or above the reported limit. The associated numerical value is the sample detection limit.
- * = Indicates that the original sample result is greater than 4x the spike amount added.

ABBREVIATIONS

- MB = Method or Preparation Blank.
MS = Matrix Spike.
MSD = Matrix Spike Duplicate.
REP = Sample Replicate
LC = Laboratory Control Sample.
NC = Not calculated.

A suffix of -R, -S, or -T following these codes indicate a replicate, spike or sample duplicate analysis respectively.

ANALYTICAL WET CHEMISTRY METHODS

1. ASTM Standard Methods.
2. USEPA Methods for Chemical Analysis of Water and Wastes (USEPA 600/4-79-020).
3. Test Methods for Evaluating Solid Waste (USEPA SW-846).
 - a. Standard Methods for the Examination of Water and Waste, 16 ed., (1989).
 - b. Standard Methods for the Examination of Water and Waste, 17 ed., (1983)
 - c. Method of Soil Analysis, Part 1, Physical and Mineralogical Methods, 2nd. Ed. (1986)
 - d. Method of Soil Analysis, Part 2, Chemical and Microbiological Properties, Am. Soc. Agron., Madison, WI (1965)
 - e. USEPA Contract Laboratory Program, Statement of Work for Inorganic Analysis.
 - f. Code of Federal Regulations.

RFW 21-21L-034/D-06/96

Recra LabNet - Lionville

INORGANICS DATA SUMMARY REPORT 02/10/98

CLIENT: TNU-HANFORD

RECRA LOT #: 9801L314

WORK ORDER: 10985-001-001-9999-00

SAMPLE	SITE ID	ANALYTE	RESULT	UNITS	REPORTING LIMIT	DILUTION FACTOR
-----	-----	-----	-----	-----	-----	-----
-001	BOMR91	Ammonia, as N	0.10 u	MG/L	0.10	1.0
		Oil & Grease Gravimetri	0.90 u	MG/L	0.90	1.0

Recra LabNet - Lionville Laboratory
INORGANIC ANALYTICAL DATA PACKAGE FOR
TNU-HANFORD

DATE RECEIVED: 01/29/98

RFW LOT # :9801L314

CLIENT ID /ANALYSIS	RFW #	MTX	PREP #	COLLECTION	EXTR/PREP	ANALYSIS
BOMR91						
AMMONIA	001	W	98LAM006	01/26/98	02/03/98	02/03/98
AMMONIA	001 REP	W	98LAM006	01/26/98	02/03/98	02/03/98
AMMONIA	001 MS	W	98LAM006	01/26/98	02/03/98	02/03/98
AMMONIA	001 MSD	W	98LAM006	01/26/98	02/03/98	02/03/98
OIL & GREASE BY GRAV	001	W	98LOG003	01/26/98	02/05/98	02/05/98
OIL AND GREASE BY GR	001 REP	W	98LOG003	01/26/98	02/05/98	02/05/98

LAB QC:

AMMONIA	MB1	W	98LAM006	N/A	02/03/98	02/03/98
AMMONIA	MB1 BS	W	98LAM006	N/A	02/03/98	02/03/98
AMMONIA	MB1 BSD	W	98LAM006	N/A	02/03/98	02/03/98
OIL & GREASE BY GRAV	MB1	W	98LOG003	N/A	02/05/98	02/05/98
OIL AND GREASE BY GR	MB1 BS	W	98LOG003	N/A	02/05/98	02/05/98
OIL AND GREASE BY GR	MB1 BSD	W	98LOG003	N/A	02/05/98	02/05/98

98012314

[illegible][illegible]Cooler Temp 4.1°

1. _____
2. _____
3. _____
4. _____
5. _____
6. _____

Samples were: ☒ or
 1) Shipped ☒ or
 Hand Delivered ☒
 Airbill # 8287741268
 2) Ambient or Chilled ☒
 3) Received in Good ☒
 Condition ☒ Y or N
 4) Labels Indicate ☒
 Properly Preserved ☒ Y or N
 5) Received Within ☒
 Holding Times ☒ Y or N

COC Tape was:
 1) Present on Outer ☒
 Package Y or N
 2) Unbroken on Outer ☒
 Package Y or N
 3) Present on Sample ☒
☒ Y or N
 4) Unbroken on ☒
 Sample ☒ Y or N
 COC Record Present ☒
 Upon Sample Rec't ☒ Y or N

Relinquished by	Received by	Date	Time	Relinquished by	Received by	Date	Time
Fed Ex	Valm	1299	0945	ORIGINAL			

Discrepancies Between
Samples Labels and
COC Record? Y or N

NOTES:

ORIGINAL REWRITTEN